

Configure Log Settings on RV110W

Objective

Log settings define the logging rules and output destinations for error messages, authorization violation messages, and trace data as various events are recorded on the network. Log settings can also specify which system messages are logged based on the facility that generated the message and its severity level.

The objective of this document is to explain how to configure log settings on the RV110W.

Applicable Devices

- RV110W

Software Version

- v1.2.0.10

Configuring Log Settings on the RV110W

Step 1. In the firewall configuration utility, choose **Administration > Logging > Log Settings**. The *Log Settings* window opens.

Step 2. In the *Log Mode* field, check the **Enable** check box in order to begin making further changes.

Log Settings

Log Configuration

Log Mode: Enable

Log Severity for Local Log and Email: Emergency Alert Critical Error Warning Notification Information Debugging

Remote Log Server Table			
<input type="checkbox"/>	Remote Log Server	Log Severity	Enable
<input type="checkbox"/>	No data to display		

Add Row Edit Delete

Save Cancel

Step 3. Check the appropriate check boxes in the *Log Severity for Local Log and Email* field below. The options are defined as follows and listed in order of highest to lowest priority.

- Emergency — An emergency log message is logged if a device is down or unusable. The message is normally broadcasted to all processes.
- Alert — An alert log message is logged if there is a serious device malfunction, such as a case in which all device features stop working.
- Critical — A critical log message is logged if there is critical device malfunction, such as two ports not functioning properly while the remaining ports work fine.
- Error — A device error log message is logged if there is an error within a device, such as a single port being offline.

- Warning — A warning log message is logged if a device is functioning properly, but an operational problem occurs.
- Notification — A notification log message is logged if a device is functioning properly, but a system notice occurs.
- Information — An informational message on a device is logged if a condition that is not an error condition exists, but may require attention or special handling.
- Debugging — Provides all detailed debugging messages.

Note: Selecting log severity options placed at lower priority levels will automatically include and check any log severity options with higher priority levels. For example, choosing “Error” logs automatically includes Emergency, Alert, and Critical logs in addition to Error logs.

Step 4. In the *Remote Log Server* table, click **Add Row**.

Remote Log Server Table			
<input type="checkbox"/>	Remote Log Server	Log Severity	Enable
No data to display			
Add Row	Edit	Delete	

A new row appears with new fields and options available.

Remote Log Server Table			
<input type="checkbox"/>	Remote Log Server	Log Severity	Enable
<input type="checkbox"/>	1.1.1.1	<input checked="" type="checkbox"/> Emergency <input checked="" type="checkbox"/> Alert <input checked="" type="checkbox"/> Critical <input checked="" type="checkbox"/> Error <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Notification <input checked="" type="checkbox"/> Information <input type="checkbox"/> Debugging	<input checked="" type="checkbox"/>
Add Row	Edit	Delete	

Step 5. Under the *Remote Log Server* column, enter the IP address of the log server that will collect the logs in the field of the row.

Step 6. Under the *Log Severity* column, check the desired severity of the logs for the corresponding remote log server.

Step 7. Under the *Enable* column, check the check box to enable the logging settings for the corresponding remote log server.

Step 8. To edit the information for particular remote log server, select the entry by checking its corresponding check box and click the **Edit** button.

Step 9. Click **Save** in order to save your settings.

Log Settings

Configuration settings have been saved successfully

Log Configuration

Log Mode: Enable

Log Severity for Local Log and Email: Emergency Alert Critical Error Warning Notification Information Debugging

Remote Log Server Table			
<input type="checkbox"/>	Remote Log Server	Log Severity	Enable
<input type="checkbox"/>	1.1.1.1	Emergency,Alert,Critical,Error,Warning,Notification,Information	Enabled
Add Row	Edit	Delete	

Save Cancel