

Configure Simple Network Management Protocol (SNMP) Communities on a Cisco Business Switch

Objective

Simple Network Management Protocol (SNMP) is a network management protocol which helps to record, store, and share information about the devices in the network. This helps the administrator address network issues. Access rights in SNMPv1 and SNMPv2 are managed by the definition of communities. Community names are shared keys between the SNMP management stations and the devices.

This document aims to show you how to configure an SNMP community on a Cisco Business Switch. It assumes that SNMP Views has already been configured for the device. For more information, click [here](#). To learn more about SNMP Groups, click [here](#).

Applicable Devices | Software Version

- CBS250 ([Data Sheet](#)) | 3.0.0
- CBS350 ([Data Sheet](#)) | 3.0.0
- CBS350-2X ([Data Sheet](#)) | 3.0.0
- CBS350-4X ([Data Sheet](#)) | 3.0.0


Configure SNMP Community on a Cisco Business Switch

Step 1. Log in to the web-based utility of the switch.

Step 2. Change the Display Mode to **Advanced**.



[Step 3.](#) Choose **SNMP > Communities**.






Step 4. Click **Add** to create a new SNMP community.

Communities

The SNMP service is currently disabled.
For a community configuration to be effective, the [SNMP service](#) must be enabled.

Community Table

<input type="checkbox"/>	SNMP Management Station	Community Type	Community String	A
--------------------------	-------------------------	----------------	------------------	---

0 results found.

Step 5. Click the radio button for the SNMP Management Station. The options are:

- All - This option gives any IP device the ability to access the SNMP community.
- User Defined - This option lets you enter the management station IP address manually.

Add SNMP Community

SNMP Management Station: All User Defined

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface:

Note: In this example, User Defined is chosen. If All is chosen, skip to [Step 8](#).

Step 6. Click the radio button of the desired IP Version. The options are:

- Version 6 - Choose this option if the Management Station IP address is an IPv6 address.
- Version 4 - Choose this option if the Management Station IP address is an IPv4 address.

Add SNMP Community

SNMP Management Station: All User Defined

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface:

Note: In this example, Version 6 is chosen. If version 4 is chosen, proceed to [Step 8](#).

Step 7. Choose the IPv6 Address Type. The options are:

- Link Local - This option is chosen when the Address starts with FE80, uniquely identified on a single network link, and used for local network communication.
- Global - This option is chosen when the Address used is reachable from other networks.

Add SNMP Community

SNMP Management Station: All User Defined

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface:

VLAN 1 ▾

Note: In this example, Link Local is chosen. If Global is chosen, skip to [Step 10](#).

[Step 8](#). Choose the Interface through which the address is received from the Link Local Interface drop-down list. The options are:

- VLAN - This option uses a Virtual Local Area Network (VLAN) as the interface through which the address is received. VLANs help create logical broadcast domains that can span a single switch or multiple switches across the network.
- ISATAP - This option uses the Intra-Site Automatic Tunnel Addressing Protocol (ISATAP) to provide tunneling in three ways, the host-to-router, the router-to-host, and the host-to-host configuration. It helps provide automatic tunnels of IPv6 over IPv4. ISATAP is a point to multipoint tunneling mechanism which connects dual stack nodes in an IPv4 network, and is used in linking IPv4 and IPv6 networks.

Add SNMP Community

SNMP Management Station: All User Defined

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface: VLAN 1 ▾

✿ IP Address:

Note: In this example, VLAN 1 is chosen.

Step 9. Enter the IP address of the SNMP management station in the *IP Address* field.

Add SNMP Community

SNMP Management Station: All User Defined

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface: VLAN 1 ▾

✿ IP Address: fe80::200:f8ff:fe21:67cf

✿ Community String: (0/20 char)

Note: In this example, the IP Address is fe80::200:f8ff:fe21:67cf.

[Step 10.](#) Enter the community name that is used to authenticate the management station to the device in the *Community String* field.


Add SNMP Community


SNMP Management Station: All User Defined

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface:

 IP Address:

 Community String: (14/20 characters used)

Note: In this example, the community string is Test_Community.

Step 11. Choose one of the radio buttons for the given community.

- Basic - Basic mode helps choose the community access level. The options are:
- Read Only - Users are only allowed to read.
- Read Write - Users can read, write and can change the device configuration. However they will not be able to modify the community.
- SNMP Admin - All users can access all device configuration and can modify the community.
- Advanced - This option is available only if IPv6 Link Local is chosen in Step 7. It gives access rights to group members associated with the group name. Choose the group name from the Group Name drop-down list.


Add SNMP Community


SNMP Management Station: All User Defined

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface:

 IP Address:

 Community String: (14/20 characters used)

Basic Access Mode Read Only Read Write SNMP Admin

View Name

Note: In this example, Basic is chosen.

Step 12. (Optional) Check the View Name check box and choose the name of the SNMP view from the View Name drop-down list that specifies the collection of MIB subtrees to which access is granted. This allows you to give appropriate permissions based on the option chosen from the Basic mode.


Add SNMP Community


SNMP Management Station: All User Defined

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface:

 IP Address:

 Community String: (14/20 characters used)

Basic Access Mode Read Only Read Write SNMP Admin

View Name

Note: The View Name option is not available when in SNMP Admin or in Advanced mode. In this example, Default is chosen.

Step 13. Click **Apply**.

SNMP Management Station: All User Defined

IP Version: Version 6 Version 4

IPv6 Address Type: Link Local Global

Link Local Interface:

IP Address:

Community String: (14/20 characters used)

Basic Advanced

Access Mode: Read Only Read Write SNMP Admin

View Name:

Group Name:

Apply

Close

Step 14. (Optional) Click **Save** to save the settings to the startup configuration file.



You should now have successfully added a community on the switch.


Manage SNMP Community

Step 1. Log in to the web-based utility of the switch.


Step 2. Change the Display Mode to **Advanced**.



[Step 3.](#) Choose **SNMP > Communities**.



Step 4. Check the check box for the community that you need to edit and then click the **Edit** button.



Step 5. Edit the desired fields and click **Apply**.

SNMP Management Station:

Community String:

Basic Access Mode: Read Only View Name




Read Write

SNMP Admin


Advanced Group Name:

Step 6. (Optional) In order to delete the communities from the Community Table, check the corresponding check box and click **Delete**.


Community Table







<input checked="" type="checkbox"/>	SNMP Management Station	Community Type	Community String
<input checked="" type="checkbox"/>	fe80::200:f8ff:fe21:67cf%vlan1	Basic	Test_Community



Step 7. (Optional) Click **Save** to save the settings to the startup configuration file.


CBS350-8P-E-2G - switc...

You should now have successfully deleted an SNMP community from your switch.