

Configure IPv4 Static Routes Settings on a Switch through the CLI

Objective

This article provides instructions on how to configure IPv4 static routes on the switch through the Command Line Interface (CLI).

Introduction

Static routing refers to the configuration of the path selection of routers. This type of mechanism takes place in the absence of communication between routers regarding the current topology of the network and thus, manually configuring routes to the routes table on the switch is recommended. Static routes help reduce the overhead on the switch CPU. This feature also allows you to deny access to certain networks.

When routing traffic, the next hop is decided on according to the longest prefix match (LPM) algorithm. A destination IPv4 address may match multiple routes in the IPv4 Static Route Table. The device uses the matched route with the highest subnet mask, that is, the longest prefix match. If more than one default gateway is defined with the same metric value, the lowest IPv4 address from among all the configured default gateways is used.

Note: For instructions on how to configure IPv4 static routes settings on the switch through the web-based utility, click [here](#).

Applicable Devices

- Sx300 Series
- Sx350 Series
- SG350X Series
- Sx500 Series

Software Version

- 1.4.8.06 - Sx300, Sx500
- 2.3.0.130 - Sx350, SG350X

Configure IPv4 Static Routes

You cannot configure a static route through a directly connected IP subnet where the device gets its IP address from a DHCP server. To configure a static IPv4 interface on the switch, click [here](#) for instructions.

Step 1. Log in to the switch console. The default username and password is cisco/cisco. If you have configured a new username or password, enter the credentials instead.

To learn how to access an SMB switch CLI through SSH or Telnet, click [here](#).

```
User Name:cisco
Password:*****
```

Note: The commands may vary depending on the exact model of your switch. In this example, the SG350X switch is accessed through Telnet.

Step 2. To display the current routes on the switch, enter the following:

```
[SG350X]#show ip route
Maximum parallel paths: 1 (1 after reset)
IP Forwarding: enabled
Codes: > - best, C - connected, S - static

C 192.168.100.0/24 is directly connected, vlan 1

SG350X#
```

Note: In this example, a directly connected route to 192.168.100.0 network is displayed.

Step 3. From the Privileged EXEC mode of the switch, enter the Global Configuration mode by entering the following:

Step 4. In the Global Configuration mode, enter the **ip route** command to establish static routes:

The options are:

- prefix - IP route prefix for the destination.
- mask - Prefix mask for the destination.
- prefix-length - Prefix mask for the destination. It specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). The range can be from 0 to 32.
- ip-address - IP address of the next hop that can be used to reach that network.
- metric value - Metric of the route. The default metric is 6 for the Next Hop on an In-Band interface and 2 for the Next Hop on Out-of-Band (OOB). The range can be from one to 255.

```
SG350X#configure
SG350X(config)#ip route 192.168.1.0 /24 192.168.100.1 metric 2
SG350X(config)#
```

Note: In this example, a static route to 192.168.1.0 network is established through 192.168.100.0. The defined administrative distance is 2. The route goes to a router with IP address 192.168.100.1.

Step 5. (Optional) To remove all static routes to the given subnet, enter the following:

Step 6. (Optional) To remove only one static route to the given subnet via the given next

hop, enter the following:

Step 7. Enter the **exit** command to go back to the Privileged EXEC mode:

```
SG350X#configure
SG350X(config)#ip route 192.168.1.0 /24 192.168.100.1 metric 2
SG350X(config)#exit
SG350X#
```

Step 8. (Optional) To display the configured route, enter the following:

```
SG350X(config)#exit
SG350X#show ip route
Maximum Parallel Paths: 1 (1 after reset)
IP Forwarding: enabled
Codes: > - best, C - connected, S - static

S   192.168.1.0/24 [1/2] via 192.168.100.1, 00:00:28, vlan 1
C   192.168.100.0/24 is directly connected, vlan 1

SG350X#
```

Step 9. (Optional) In the Privileged EXEC mode of the switch, save the configured settings to the startup configuration file, by entering the following:

```
SG350X#copy running-config startup-config
Overwrite file [startup-config]... (Y/N)[M] ?
```

Step 10. (Optional) Press **Y** for Yes or **N** for No on your keyboard once the Overwrite file [startup-config]... prompt appears.

```
SG350X#copy running-config startup-config
Overwrite file [startup-config]... (Y/N)[N] ?Y
11-Aug-2017 05:21:59 %COPY-I-FILECPY: Files Copy - source URL running-config
destination URL flash://system/configuration/startup-config
11-Aug-2017 05:22:02 %COPY-N-TRAP: The copy operation was completed successfully
SG350X#
```

You have now configured IPv4 static routes on your switch through the CLI.