



Alarm Descriptions

- [Alarm Descriptions](#), on page 1

Alarm Descriptions

This section contains a list of alarms and linked descriptions. Alarms are triggered when a rule is violated in a policy.

Table 1: Crosswork Cloud Network Insights Alarms

Unexpected AS Prefix	Prefix Withdrawal	Upstream AS Change
AS Origin Violation	ROA Expiry	Valid AS Path Violation
New AS Path Edge	ROA Failure	Peer Down
AS Path Length Violation	ROA Not Found	Advertised Prefix Count
Parent Aggregate Change	DNS Root Prefix Withdrawal	Prohibited IP Prefix
Prefix Advertisement	Subprefix Advertisement	

Table 2: Crosswork Cloud Traffic Analysis Alarms

Gateway Connectivity	Device Connectivity	Interface TX Utilization
Interface RX Utilization	Prefix Utilization	

Table 3: Crosswork Cloud Trust Insights Alarms

Gateway Connectivity	Device Running Configuration Change	Hardware Integrity Validation
Device Connectivity	Device SSH Host Key Violation	Mismatched Files
Device Certificate Expiring	Dossier Collection Failure	Package Validation
Device Certificate Violation	Expired Device Certificate	Unknown Files

