



# Appendix

---

Certain troubleshooting aids of the Cisco NCS 540 enable you to perform these tasks that assist the troubleshooting process:

- [LEDs, on page 1](#)
- [System Specifications, on page 4](#)

## LEDs



---

**Note** This section lists the LEDs of the router.

---

## Router LEDs

All the data port LEDs in the Cisco N540-6Z14S-SYS-D router are at the front panel. There are five LEDs that reflect the different statuses of the system.

*Table 1: Router LED Descriptions*

LED Label	Color	Status
'PS0 and PS1'	Off	This indicates there is no DC input.
	Red	This indicates 12V output failure. If one of the input feeds is switched off when both the feeds are connected, then that particular feed shows as red.
	Green	This indicates 12V output is active.

LED Label	Color	Status
STS	Off	the system is placed in shutdown mode; only standby power mode is available.
	Flashing Amber (Slow)	The module is booting up.
	Flashing Amber (Fast)	The module is booting up, shutting down, or is being reloaded.
	Amber	Host kernel is booted and is ready to start SysAdmin VM.
	Green	The module is operational and has no active major or critical alarms.
	Flashing Red	The router has active major or critical alarms.
ALM	Off	No alarm
	Red	Critical alarm - system scope, critical temperature
	Flashing Red	Critical alarm - Relating to voltage rail failures
	Amber	Major alarm - system-scope
	Flashing Amber	Minor alarm - system-scope
SYNC	Off	Time core clock synchronization is disabled or in free-running state.
	Green	Time core is synchronized to an external source including IEEE1588.
	Flashing Green	System is in Synchronous Ethernet mode.
	Amber	Acquiring state or Holdover: Time core is in acquiring state or holdover mode.

## Power Status LEDs

*Table 2: Power Status LEDs*

LED Label	Color	Status
PWR	Off	System is powered off
	Green	All the power supplies are on and operating normally.
	Amber	Standby FPGA upgrade is in progress (this is expected to take about three to five minutes).
	Red	Power redundancy is lost due to a power feed failure or an internal power supply failure.

## Combination of LEDs

*Table 3: Fan and Power Status LED Combination*

FAN	PWR	Status
For all the conditions below, the system will not boot.		
Flashing Red	Flashing Red	Thermal shutdown at Power Up
Flashing Red	Flashing Amber	MSS Ready Failure
Flashing Amber	Flashing Green	TAM Init Failure
Flashing Amber	Flashing Red	TAM Ready Failure
Flashing Amber	Flashing Amber	Secure JTAG Failure

## SFP and SFP+ Port LED

*Table 4: SFP and SFP+ Port LEDs*

LED Label	Color	Status
STATUS	Off	Admin is down
	Green	Link is up in 1G/10G ports.
	Yellow	Fault or Error or Link Down

## Management Port LEDs

Table 5: Management Port LEDs

LED Label	Color	Status
Left LED	Green	Link is up in 1000 Mbps
	Blinking Green	Activity in 1000 Mbps
	Amber or Orange	Link is up in 100/10Mbps
	Blinking Amber or Orange	Activity in 100/10Mbps
	Off	Link is down
Right LED	Green	Link is up in full duplex
	Off	Link is up in half duplex

## System Specifications

Certain troubleshooting aids of the Cisco NCS 540 enable you to perform these tasks that assist the troubleshooting process:

## Weight and Power Consumption

For information on physical specifications and power consumption, see table *Cisco NCS 540 chassis specification* on the [Cisco Network Convergence System 540 Small Density Router Data Sheet](#).

## Environmental Specifications

For information on environmental specifications, see table *Environmental properties for NCS 540 fixed systems* on the [Cisco Network Convergence System 540 Small Density Router Data Sheet](#).

## RJ-45 Connectors

The RJ-45 connector connects Category 3, Category 5, Category 5e, Category 6, or Category 6A foil twisted-pair or unshielded twisted-pair cable from the external network to the following module interface connectors:


- Router chassis
  - CONSOLE port
  - MGMT ETH port



**Caution** To comply with GR-1089 intrabuilding, lightning immunity requirements, you must use a foil twisted-pair (FTP) cable that is properly grounded at both ends.

The following figure shows the RJ-45 connector.

**Figure 1: RJ-45 Connector**



1	Transmit data (bidirectional)
2	NC (Not Connected)

## Transceiver and Cable Specifications

To determine which transceivers and cables are supported by this router, see [Cisco Transceiver Modules Compatibility Information](#).

To see the transceiver specifications and installation information, see [Cisco Transceiver Modules Install and Upgrade Guides](#).

## RJ-45 ToD or 1-PPS Port Pinouts



**Note** This section is not applicable to Cisco N540-6Z18G-SYS-A/D router.

This summarizes the RJ-45 ToD or 1-PPS port pinouts:

**Table 6: RJ-45 ToD or 1-PPS Port Pinouts**

Pin	Signal Name	Direction	Description
1	NA	NA	NA
2	NA	NA	NA
3	1PPS_N	Output or Input	1PPS RS422 signal

Pin	Signal Name	Direction	Description
4	GND	NA	NA
5	GND	NA	NA
6	1PPS_P	Output or Input	1PPS RS422 signal
7	TOD_N	Output or Input	Time-of-Day character
8	TOD_P	Output or Input	Time-of-Day character

## Console Port Pinouts

This summarizes the Console port pinouts:

**Table 7: Console Port Pinouts**

Pin	Signal Name	Direction	Description
1	ACONS-TX	Output	Aux Consoles transmit output, RS232
2	NC	NA	NA
3	CONS-TX	Output	Console RS232 transmit
4	GND	NA	Ground
5	GND	NA	Ground
6	CONS-RX	Input	Console RS232 receive
7	ACONS-RX	Input	Aux Consoles receive input, RS232
8	NC	NA	NA

## Alarm Port Pinouts

This summarizes the alarm port pinouts:

**Table 8: Alarm Port Pinouts**

Pin	Signal Name	Description
1	ALARM1_IN	Alarm input 1
2	ALARM2_IN	Alarm input 2
3	NC	NA
4	ALARM3_IN	Alarm input 3

Pin	Signal Name	Description
5	ALARM4_IN	Alarm input 4
6	NC	NA
7	NC	NA
8	ALARM_I_COMMON	Alarm input COM

To set the description of the alarm:

```
RP/0/RP0/CPU0:ios(config)# environment alarm-contact contact-number description
description
```

To set the severity of the alarm:

```
RP/0/RP0/CPU0:ios(config)# environment alarm-contact contact-number severity
[critical | major | minor] [
```

To set the trigger for the alarm:

```
RP/0/RP0/CPU0:ios(config)# environment alarm-contact contact-number trigger [open
| closed]
```



**Note** You can configure up to four external alarms.

The *contact-number* is the pin number of the connected alarm port, that is Alarm input 1 to Alarm input 4.

The **description** string can be up to 80 alphanumeric characters in length and is included in any generated system messages.

For **severity**, enter any one of: **critical**, **major**, or **minor**.

Description and severity are both mandatory values.

Use the **show alarms** command in admin mode to view the alarm details. Use the **show logging** command to view the displays the state of syslog error and event logging.

An SNMP trap is sent for every external alarm that is raised or cleared on the system.

## USB Port Console Pinouts

This table summarizes the USB port console pinouts:

*Table 9: USB Port Console Pinouts*

Pin	Signal Name	Description
A1	VCC	+5 VDC
A2	D-	Data-
A3	D+	Data+

Pin	Signal Name	Description
A4	GND	Ground

## USB Port Memory Pinouts

This table summarizes the USB port memory pinouts:

*Table 10: USB Port Memory Pinouts*

Pin	Signal Name	Description
A1	VCC	+5 VDC
A2	D-	Data-
A3	D+	Data+
A4	GND	Ground

## Management Ethernet Port Pinouts

This table summarizes the management ethernet port pinouts:

*Table 11: Management Ethernet Port Pinouts*

Pin	Signal Name
1	TRP0+
2	TRP0-
3	TRP1+
4	TRP2+
5	TRP2-
6	TRP1-
7	TRP3+
8	TRP3-

## GPS Port Pinouts

The table below summarizes the GPS port pinouts.



**Note** This section does not apply to Cisco N540-6Z18G-SYS-A/D router.



Table 12: GPS Port Pinouts

Category	10 MHz (Input and Output)	1PPS (Input and Output)
Waveform	Input—Sine wave Output—Sine wave	Input—Rectangular pulse Output—Rectangular pulse
Amplitude	Input— > 1.7 volts p-p Output— > 2.2 volts p-p	Input— > 1.2V Output— > 2.5V
Impedance	50 ohms	50 ohms
Pulse Width	50% duty cycle	50% duty cycle
Rise Time	Input—AC coupled	Output—5 nanoseconds

