



Command Reference Guide for Cisco Prime Infrastructure 3.8

First Published: 2020-03-19

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com go trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2020 Cisco Systems, Inc. All rights reserved.



CONTENTS

Full Cisco Trademarks with Software License ?

PREFACE

Preface ix

Who Should Read This Guide ix

How to Use This Guide ix

How This Guide Is Organized x

Document Conventions x

Related Documentation xi

Obtaining Documentation and Submitting a Service Request xi

CHAPTER 1

Overview of the Cisco Prime Infrastructure Command-Line Interface 1

Accessing the Prime Infrastructure Command Environment 2

User Accounts and Modes in Cisco Prime Infrastructure CLI 3

Command Modes in the Prime Infrastructure CLI 7

EXEC Commands 7

EXEC or System-Level Commands 7

show Commands 9

Configuration Commands 11

CLI Audit 14

CHAPTER 2

Using the Command-Line Interface 15

Before Accessing the CLI 16

Running the Setup Utility to Configure the Appliance 17

Accessing the Prime Infrastructure CLI 20

Supported Hardware and Software Platforms 20

Opening the CLI with Secure Shell 21

Opening the CLI Using a Local PC	21
Understanding Command Modes	23
EXEC Mode	23
Configuration Mode	24
Configuration Submodes	24
Navigating the CLI Commands	27
Getting Help	27
Using the No and Default Forms of Commands	27
Command-Line Conventions	28
Command-Line Editing Key Conventions	28
Command Line Completion	28
Continuing Output at the --More-- Prompt	29
Where to Go Next	30

APPENDIX A

Command Reference	31
EXEC Commands	31
application start	32
application stop	32
application upgrade	33
backup	34
backup-logs	36
banner	37
change-password	37
clock	38
configure	38
copy	39
debug	43
delete	47
dir	48
exit	48
forceout	49
halt	49
lms	50
mkdir	51

ncs run client-auth	52
ncs run list	52
ncs run test iops	53
ncs run reset	53
ncs run csrf	55
ncs run livelogs	55
ncs run loghistory	56
ncs run ssh-server-legacy-algorithms	58
ncs run tls-server-versions	58
ncs start	59
ncs status	62
ncs stop	63
ncs run tls-server-ciphers	66
ncs password ftpuser	66
ncs password root password	67
ncs ha authkey	67
ncs ha remove	68
ncs ha status	69
ncs key genkey	70
ncs key importkey	72
ncs key importsignedcert	72
ncs certvalidation certificate-check	73
ncs certvalidation custom-ocsp-responder	74
ncs certvalidation revocation-check	74
ncs certvalidation tofu-certs	75
ncs certvalidation trusted-ca-store	75
ncs cleanup	77
nslookup	78
ocsp	78
ping	79
ping6	80
reload	81
restore	82
rmdir	85

rsakey	86
show	86
ssh	89
tech dumptcp	90
telnet	90
terminal length	91
terminal session-timeout	91
terminal session-welcome	92
terminal terminal-type	92
traceroute	93
undebg	93
write	96
show Commands	96
show application	96
show backup history	98
show banner pre-login	99
show cdp	99
show clock	101
show cpu	101
show disks	103
show icmp_status	104
show ip route	105
show interface	106
show inventory	107
show logging	108
show logins	111
show memory	111
show netstat	112
show ntp	113
show ports	113
show process	115
show repository	117
show restore	117
show restore log	118

show running-config	119
show startup-config	120
show security-status	121
show tech-support	122
show terminal	124
show timezone	124
show timezones	125
show udi	126
show uptime	127
show users	127
show version	128
Configuration Commands	128
aaa authentication	129
backup-staging-url	129
cdp holdtime	130
cdp run	130
cdp timer	131
clock timezone	132
do	134
end	137
exit	137
hostname	138
icmp echo	139
interface	139
ipv6 address autoconfig	141
ipv6 address dhcp	143
ipv6 address static	144
ip address	144
ip default-gateway	145
ip domain-name	146
ip name-server	146
ip route	147
logging	148
ntp server	149

password-policy 150
repository 152
service 154
shutdown 155
snmp-server community 155
snmp-server contact 156
snmp-server host 157
snmp-server location 158
username 159
firewall 160

Glossary ?



Preface

This guide describes how you can configure and maintain the Cisco Prime Infrastructure using the command-line interface (CLI). Each topic provides a high-level summary of the tasks required for using the CLI for the Prime Infrastructure in the Unified Network Solution that runs on supported appliances for small, medium, and large Cisco Prime Infrastructure deployments.

- [Who Should Read This Guide, on page ix](#)
- [How to Use This Guide, on page ix](#)
- [How This Guide Is Organized, on page x](#)
- [Document Conventions, on page x](#)
- [Related Documentation, on page xi](#)
- [Obtaining Documentation and Submitting a Service Request, on page xi](#)

Who Should Read This Guide

The majority of the instructions in this guide are straightforward; however, a few are complex. Therefore, only experienced users should use these instructions.



Note Use this guide in conjunction with the documentation listed in [Related Documentation, on page xi](#).

How to Use This Guide

We recommend that you use the information in this guide as follows:

- Read the document in its entirety. Subsequent sections build on information and recommendations discussed in previous sections.
- Use this document for all-inclusive information about the Prime Infrastructure appliance.
- Do not vary the command-line conventions.

How This Guide Is Organized

The following table lists the major sections of this guide.

Chapter	Title	Description
Overview of the Cisco Prime Infrastructure Command-Line Interface	Overview of the Cisco Prime Infrastructure Command-Line Interface	Provides an overview of the Prime Infrastructure CLI environment and command modes.
Using the Command-Line Interface	Using the Cisco Prime Infrastructure Command-Line Interface	Describes how you can access and administer Prime Infrastructure using the CLI.
Command Reference	Cisco Prime Infrastructure Command Reference	Provides a complete description of all Prime Infrastructure CLI commands.

Document Conventions

This guide uses the following conventions to convey instructions and information.

Convention	Description
bold font	Commands and keywords.
<i>italic font</i>	Variables for which you supply values.
[.....]	Keywords or arguments that appear within square brackets are optional.
{x y z}	A choice of required keywords appears in braces separated by vertical bars. You must select one.
<code>courier font</code>	Examples of information displayed on the screen.
bold courier font	Examples of information you must enter.
<.....>	Nonprinting characters (for example, passwords) appear in angle brackets.
[...]	Default responses to system prompts appear in square brackets.



Note Means reader take note. Notes contain helpful suggestions or references to material not covered in the manual.



Tip Means the following information will help you solve a problem.

**Caution**

Means reader be careful. In this situation, you might perform an action that could result in equipment damage or loss of data.

Related Documentation

The tables lists the Cisco Prime Infrastructure documents.

Table 1: Product Documentation

Document Title	Location
<i>Cisco Prime Infrastructure Release Notes</i>	http://www.cisco.com/en/US/products/enterprise/primeinfra/products.html
<i>Cisco Prime Infrastructure Quick Start Guide</i>	http://www.cisco.com/en/US/products/enterprise/primeinfra/products/quickstartguide.html
<i>Cisco Prime Infrastructure Command Reference Guide</i>	http://www.cisco.com/en/US/products/enterprise/primeinfra/products/commandreference.html
<i>Cisco Prime Infrastructure User Guide</i>	http://www.cisco.com/en/US/products/enterprise/primeinfra/products/userguide.html
<i>Cisco Prime Infrastructure Administrator Guide</i>	http://www.cisco.com/en/US/products/enterprise/primeinfra/products/administratorguide.html

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly What's New in Cisco Product Documentation, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.



Overview of the Cisco Prime Infrastructure Command-Line Interface

This chapter provides an overview of how to access the Cisco Prime Infrastructure command-line interface (CLI), the different command modes, and the commands that are available in each mode.

You can configure and monitor the Prime Infrastructure through the web interface. You can also use the CLI to perform the configuration and monitoring tasks described in this guide.

- [Accessing the Prime Infrastructure Command Environment, on page 2](#)
- [User Accounts and Modes in Cisco Prime Infrastructure CLI, on page 3](#)
- [Command Modes in the Prime Infrastructure CLI, on page 7](#)
- [CLI Audit, on page 14](#)

Accessing the Prime Infrastructure Command Environment

You can access the Prime Infrastructure CLI through a secure shell (SSH) client or the console port using one of the following machines:

- Windows PC running Windows 7, 8, and 10.
- Apple Computer running Mac OS X 10.4 or later
- PC running Linux

User Accounts and Modes in Cisco Prime Infrastructure CLI

Two different types of accounts are available on the Prime Infrastructure CLI:

- Admin (administrator)
- Network Admin
- Security Admin
- Operator (user)

When you power on the Prime Infrastructure appliance for the first time, you are prompted to run the setup utility to configure the appliances. During this setup process, an administrator user account, also known as an Admin account, is created. After you enter the initial configuration information, the appliance automatically reboots and prompts you to enter the username and the password that you specified for the Admin account. You must use this Admin account to log in to the Prime Infrastructure CLI for the first time.

An Admin can create and manage Operator (user) accounts (which have limited privileges and access to the Prime Infrastructure server). An Admin account also provides the functionality that is needed to use the Prime Infrastructure CLI.

To create more users (with admin, security-admin, network-admin, and operator privileges) with SSH access to the Prime Infrastructure CLI, you must enter the **username** command in configuration mode (see [Command Modes in the Prime Infrastructure CLI](#)).

[Table 2: Command Privileges](#) lists the command privileges for each type of user account: Admin and Operator (user).

Table 2: Command Privileges

	User Account	
	Admin	Operator (User)
application commands	*	
backup	*	
backup-logs	*	
banner	*	
clock	*	
configure terminal	*	
copy commands	*	
debug	*	
delete	*	
dir	*	

	User Account	
	Admin	Operator (User)
exit	*	*
forceout	*	
halt	*	
lms	*	
mkdir	*	
ncs	*	
nslookup	*	*
ocsp	*	
patch	*	
patch install	*	
patch remove	*	
ping	*	*
ping6	*	*
reload	*	
repository	*	
restore commands	*	
rmdir	*	
rsakey	*	
shell	*	
show application	*	
show backup	*	
show cdp	*	*
show clock	*	*
show cpu	*	*
show disks	*	*
show icmp_status	*	*

	User Account	
	Admin	Operator (User)
show icmp_status	*	*
show interface	*	*
show ip route	*	
show logging	*	*
show logins	*	*
show memory	*	*
show ntp	*	*
show ports	*	*
show process	*	*
show repository	*	
show restore	*	
show running-config	*	
show startup-config	*	
show tech-support	*	
show terminal	*	*
show timezone	*	*
show timezones	*	
show udi	*	*
show uptime	*	*
show users	*	
show version	*	*
ssh	*	*
tech	*	
telnet	*	*
terminal	*	*
traceroute	*	*

	User Account	
	Admin	Operator (User)
undebug	*	
write	*	

Logging in to the Prime Infrastructure server places you in operator (user) mode or admin (EXEC) mode, which always requires a username and password for authentication.

You can tell which mode you are in by looking at the prompt. A right angle bracket (>) appears at the end of operator (user) mode prompt; a pound sign (#) appears at the end of admin mode prompt, regardless of the submode.

Command Modes in the Prime Infrastructure CLI

This section describes the command modes supported in Prime Infrastructure.

EXEC Commands

EXEC commands primarily include system-level commands such as **show** and **reload** (for example, application installation, application start and stop, copy files and installations, restore backups, and display information).

- [Table 3: Summary of EXEC Commands](#) describes the EXEC commands
- [Table 4: Summary of show Commands](#) describes the show commands in EXEC mode

For detailed information on EXEC commands, see [Understanding Command Modes](#).

EXEC or System-Level Commands

[Table 3: Summary of EXEC Commands](#) describes EXEC mode commands.

Table 3: Summary of EXEC Commands

	Description
application install	Installs a specific application bundle.
application start	Starts or enables a specific application.
application stop	Stops or disables a specific application.
application upgrade	Upgrades a specific application bundle.
backup	Performs a backup and places the backup in a repository.
backup-logs	Performs a backup of all of the logs on the Prime Infrastructure to a remote location.
banner	Sets messages while logging in to CLI (pre-login).
clock	Sets the system clock on the Prime Infrastructure server.
configure	Enters configuration mode.
copy	Copies any file from a source to a destination.
debug	Displays any errors or events for various command situations; for example, backup and restore, configuration, copy, resource locking, file transfer, and user management.
delete	Deletes a file in the Prime Infrastructure server.

	Description
dir	Lists the files in the Prime Infrastructure server.
exit	Disconnects the encrypted session with a remote system. Exits from the current command mode to the previous command mode.
forceout	Forces the logout of all of the sessions of a specific Prime Infrastructure server system user.
halt	Disables or shuts down the Prime Infrastructure server.
lms	Migrates data from LMS server to PI server.
mkdir	Creates a new directory.
ncs	NCS-related commands used to start, stop and back up the server.
nslookup	Queries the IPv4 address or hostname of a remote system.
ocsp	Enables certificate-based authentication for web clients using OCSP responders.
patch	Installs System or Application patch.
ping	Determines the IPv4 network connectivity to a remote system.
ping6	Determines the IPv6 network connectivity to a remote system.
reload	Reboots the Prime Infrastructure server.
restore	Restores a previous backup.
rmdir	Removes an existing directory.
rsakey	Displays a configured RSA key or sets a new RSA public key for user authentication.
show	Provides information about the Prime Infrastructure server.
ssh	Starts an encrypted session with a remote system.
tech	Provides Cisco Technical Assistance Center (TAC) commands.
telnet	Establishes a Telnet connection to a remote system.
terminal length	Sets terminal line parameters.

	Description
terminal session-timeout	Sets the inactivity timeout for all terminal sessions.
terminal session-welcome	Sets the welcome message on the system for all terminal sessions.
terminal terminal-type	Specifies the type of terminal connected to the current line of the current session.
traceroute	Traces the route of a remote IP address.
undebug	Disables the output (display of errors or events) of the debug command for various command situations; for example, backup and restore, configuration, copy, resource locking, file transfer, and user management.
write	Erases the startup configuration that forces to run the setup utility and prompt the network configuration, copies the running configuration to the startup configuration, and displays the running configuration on the console.

show Commands

The **show** commands are used to display the Prime Infrastructure settings and are among the most useful commands. See [Table 4: Summary of show Commands](#) for a summary of the **show** commands. The **show** commands must be followed by a keyword; for example, **show application status**. Some **show** commands require an argument or variable after the keyword to function; for example, **show application version**.

Table 4: Summary of show Commands

	Description
application (requires keyword)	Displays information about the installed application; for example, status information or version information.
backup (requires keyword)	Displays information about the backup.
banner (requires keyword)	Sets up messages when logging in to CLI.
cdp (requires keyword)	Displays information about the enabled Cisco Discovery Protocol interfaces.
clock	Displays the day, date, time, time zone, and year of the system clock.
cpu	Displays CPU information.
disks	Displays file-system information of the disks.
icmp-status	Displays the Internet Control Message Protocol (ICMP) echo response configuration information.

	Description
interface	Displays statistics for all of the interfaces configured on the Prime Infrastructure.
inventory	Displays information about the hardware inventory, including the Prime Infrastructure appliance model and serial number.
ip route	Displays s ip route details of the application.
logging (requires keyword)	Displays the Prime Infrastructure server logging information.
logins (requires keyword)	Displays the login history of the Prime Infrastructure server.
memory	Displays memory usage by all running processes.
ntp	Displays the status of the Network Time Protocol (NTP) servers.
ports	Displays all of the processes listening on the active ports.
process	Displays information about the active processes of the Prime Infrastructure server.
repository (requires keyword)	Displays the file contents of a specific repository.
restore (requires keyword)	Displays the restore history in the Prime Infrastructure.
running-config	Displays the contents of the configuration file that currently runs in the Prime Infrastructure.
startup-config	Displays the contents of the startup configuration in the Prime Infrastructure.
tech-support	Displays system and configuration information that you can provide to the TAC when you report a problem.
terminal	Displays information about the terminal configuration parameter settings for the current terminal line.
timezone	Displays the current time zone in the Prime Infrastructure.
timezones	Displays all of the time zones available for use in the Prime Infrastructure.
udi	Displays information about the unique device identifier (UDI) of the Prime Infrastructure.

	Description
uptime	Displays how long the system you are logged in to has been up and running.
users	Displays information about the system users.
version	Displays information about the currently loaded software version, along with hardware and device information.

Configuration Commands

Configuration commands include **interface** and **repository**. To access configuration mode, run the **configure** command in EXEC mode.

Some of the configuration commands require that you enter the configuration submode to complete the configuration.

[Table 5: Summary of Configuration Commands](#) describes the configuration commands.

Table 5: Summary of Configuration Commands

	Description
aaa authentication	Logs in to Prime Infrastructure server remotely.
backup-staging-url	Specifies a Network File System (NFS) temporary space or staging area for the remote directory for backup and restore operations.
cdp holdtime	Specifies the amount of time the receiving device should hold a Cisco Discovery Protocol packet from the Prime Infrastructure server before discarding it.
cdp run	Enables Cisco Discovery Protocol.
cdp timer	Specifies how often the Prime Infrastructure server sends Cisco Discovery Protocol updates.
clock timezone	Sets the time zone for display purposes.
do	Executes an EXEC-level command from configuration mode or any configuration submode. Note To initiate, the do command precedes the EXEC command.
end	Returns to EXEC mode.
exit	Exits configuration mode.
hostname	Sets the hostname of the system.

	Description
icmp echo	Configures the ICMP echo requests.
interface	Configures an interface type and enters interface configuration mode.
ipv6 address autoconfig	Enables IPv6 stateless autoconfiguration in interface configuration mode.
ipv6 address dhcp	Enables IPv6 address DHCP in interface configuration mode.
ip address	Sets the IP address and netmask for the Ethernet interface. Note This is an interface configuration command.
ip default-gateway	Defines or sets a default gateway with an IP address.
ip domain-name	Defines a default domain name that a Prime Infrastructure server uses to complete hostnames.
ip name-server	Sets the Domain Name System (DNS) servers for use during a DNS query.
kron occurrence	Schedule one or more Command Scheduler commands to run at a specific date and time or a recurring level.
kron policy-list	Specifies a name for a Command Scheduler policy.
logging	Enables the system to forward logs to a remote system.
logging loglevel	Configures the log level for the logging command.
no	Disables or removes the function associated with the command.
ntp	Synchronizes the software clock through the NTP server for the system.
password-policy	Enables and configures the password policy.
repository	Enters repository submode.
service	Specifies the type of service to manage.
snmp-server community	Sets up the community access string to permit access to the Simple Network Management Protocol (SNMP).
snmp-server contact	Configures the SNMP contact the Management Information Base (MIB) value on the system.

	Description
snmp-server host	Sends SNMP traps to a remote system.
snmp-server location	Configures the SNMP location MIB value on the system.
username	Adds a user to the system with a password and a privilege level.

For detailed information on configuration mode and submode commands, see [Understanding Command Modes](#).

CLI Audit

You must have administrator access to execute the Prime Infrastructure configuration commands. Whenever an administrator logs in to configuration mode and executes a command that causes configurational changes in the Prime Infrastructure server, the information related to those changes is logged in the Prime Infrastructure operational logs.

[Table 6: Configuration Mode Commands for the Operation Log](#) describes configuration mode commands that generate operational logs.

Table 6: Configuration Mode Commands for the Operation Log

	Description
clock	Sets the system clock on the Prime Infrastructure server.
ip name-server	Sets the DNS servers for use during a DNS query.
hostname	Sets the hostname of the system.
ip address	Sets the IP address and netmask for the Ethernet interface.
ntp server	Allows synchronization of the software clock by the NTP server for the system.

In addition to configuration mode commands, some commands in EXEC mode generate operational logs.

[Table 7: EXEC Mode Commands for the Operation Log](#) describes EXEC mode commands that generate operational logs.

Table 7: EXEC Mode Commands for the Operation Log

	Description
backup	Performs a backup and places the backup in a repository.
restore	Restores from backup the file contents of a specific repository.
backup-logs	Backs up system logs.



Using the Command-Line Interface

This chapter provides helpful tips for understanding and configuring the Cisco Prime Infrastructure from the command-line interface (CLI). The Prime Infrastructure can be deployed for small, medium, and large deployments and is available on different platforms and also as a software that can run on VMware.

- [Before Accessing the CLI, on page 16](#)
- [Running the Setup Utility to Configure the Appliance, on page 17](#)
- [Accessing the Prime Infrastructure CLI, on page 20](#)
- [Understanding Command Modes, on page 23](#)
- [Navigating the CLI Commands, on page 27](#)
- [Where to Go Next, on page 30](#)

Before Accessing the CLI

Before logging in to the Prime Infrastructure CLI, ensure that you have completed the installation tasks as specified in the *Cisco Prime Infrastructure 3.8 Quick Start Guide* at : <http://www.cisco.com/c/en/us/support/cloud-systems-management/prime-infrastructure/products-installation-guides-list.html>.

Running the Setup Utility to Configure the Appliance

When you power on the Prime Infrastructure appliances for the first time, you are prompted to run the setup utility to configure the Prime Infrastructure appliances. Before you run the utility using the **setup** command, ensure that you have values for the following network configuration prompts:

- Hostname
- IP address
- Netmask
- Gateway
- Domain
- Nameserver
- Network Time Protocol (NTP) server (optional)
- User ID
- Password

The following is a sample output from the **setup** command:

```
*****
Please type 'setup' to configure the appliance
*****
localhost login: setup
Press 'Ctrl-C' to abort setup
Enter hostname[]: pi-33-aws-100
Enter IP address[10.126.168.100]:
Enter IP default netmask[]: 255.255.255.0
Enter IP default gateway[]: 10.126.168.1
Enter default DNS domain[]: cisco.com
Enter primary nameserver[]: 72.163.128.140
Add/Edit another nameserver? Y/N : n
Enter primary NTP server[time.nist.gov]: 10.81.254.202
Add/Edit secondary NTP server? Y/N : n
Enter system timezone[UTC]: Asia/Calcutta
Current system clock time : 2018-11-27 07:59:14 IST
Change system clock time? Y/N : n
Enter username[admin]:
Enter password:
Enter password again:
*****
* High Availability (HA) Role Selection *
*****
HA refers to a system that is continuously operating during failure.
To configure HA, go to the primary server's user interface.
Choose Administration > High Availability > HA Configuration.
For more information, click the context-sensitive online help.
Will this server be used as a Secondary for HA? (yes/no) : no
*****
* Web Interface Root Password Selection *
*****
Expected :
```

```
* Cisco Prime Infrastructure Setup *
```

```

Enter "^" to return to previous question.

*****
* High Availability (HA) Role Selection          *
*****
HA refers to a system that is continuously operating during failure.
To configure HA, go to the primary server's user interface.
Choose Administration > High Availability > HA Configuration.
For more information, click the context-sensitive online help.

Will this server be used as a Secondary for HA? (yes/no):no

*****
* Advanced Security Selection                  *
*****
Do you want to allow access to root shell? (yes/no) :yes

*****
* Web Interface Root Password Selection      *
*****
Enter Web Interface - root password:
Enter Web Interface - root password again:

*****
* Summary                                     *
*****
Server will not be a Secondary
Root shell will be enabled.
Web Interface - root password is set.
Apply these settings? (y/n)y
Settings Applied.

```

After you enter the required information, the Prime Infrastructure appliance automatically reboots and the following login prompt appears:

```
machine_name login:
```

where *machine_name* identifies the hostname that you specified when you ran the **setup** command.

In this example, this prompt appears:

```
NCS login:
```

To log in, use the administrator user account (and the corresponding password) that you created during the setup process. You must also use this Admin account to log in to the Prime Infrastructure CLI for the first time. After accessing the CLI as an administrator, you can create more users (with admin and operator privileges) with SSH access to the CLI by running the **username** command in configuration mode.



Note

The administrator user account and the corresponding password (a CLI user account) that you created during the initial setup wizard can be used to manage the Prime Infrastructure application using the CLI. The CLI user has privileges to start and stop the application software, backup and restore the Prime Infrastructure application data, apply software patches and upgrades to the Prime Infrastructure application software, view all of the system and the application logs, and reload or shut down the Prime Infrastructure appliance. To protect the CLI user credentials, explicitly create users with access to the CLI.



Note Any users that you create from the Prime Infrastructure web interface cannot automatically log in to the Prime Infrastructure CLI. You must explicitly create users with access to the CLI. To create these users, you must log in to the CLI using the Admin account that you created during setup; then, enter configuration mode, and run the **username** command.

Accessing the Prime Infrastructure CLI

Before logging in to the Prime Infrastructure CLI, ensure that you have completed the hardware installation and configuration process outlined in the [Before Accessing the CLI, on page 16](#)

To log in to the Prime Infrastructure server and access the CLI, use an SSH secure shell client or the console port. You can log in from:

- A PC running Windows 7, 8, and 10.
- A PC running Linux.
- An Apple computer running Mac OS X 10.4 or later.
- Any terminal device compatible with VT100 or ANSI characteristics. On the VT100-type and ANSI devices, you can use cursor-control and cursor-movement key. Keys include left arrow, up arrow, down arrow, right arrow, Delete, and Backspace. The CLI senses the use of the cursor-control keys and automatically uses the optimal device characteristics.

To exit the CLI, use the **exit** command from EXEC mode. If you are currently in one of the configuration modes and you want to exit the CLI, enter the **end**, **exit**, or press **Ctrl z** command to return to EXEC mode, and then enter the **exit** command.

Supported Hardware and Software Platforms

The following valid terminal types can access the Prime Infrastructure:

- 1178
- 2621
- 5051
- 6053
- 8510
- altos5
- amiga
- ansi
- apollo
- Apple_Terminal
- att5425
- ibm327x
- kaypro
- vt100

You can also access the Prime Infrastructure through an SSH client or the console port.

Opening the CLI with Secure Shell



Note To access the Prime Infrastructure CLI environment, use any SSH client that supports SSH v2.

The following example shows you how to log in with a Secure Shell (SSH) client (connection to a wired WAN) via a PC by using Windows XP. Assuming that Prime Infrastructure is preconfigured through the setup utility to accept an Admin (administrator) user, log in as Admin.

-
- Step 1** Use any SSH client and start an SSH session.
The SSH window appears.
- Step 2** Press **Enter** or **Spacebar** to connect.
The Connection to Remote Host window appears.
- Step 3** Enter a hostname, username, port number, and authentication method.
In this example, you enter **ncs** for the hostname, **admin** for the username, and **22** for the port number; and, for the authentication method, choose **Password** from the drop-down list.
- Step 4** Click **Connect**, or press **Enter**.
The Enter Password window appears.
- Step 5** Enter your assigned password for the administrator.
The SSH with the Add Profile window appears.
- Step 6** (Optional) Enter a profile name in the text box and click **Add to Profile**.
- Step 7** Click **Close** in the Add Profile window.
The Prime Infrastructure command prompt appears. You can now enter Prime Infrastructure CLI commands.
-

Opening the CLI Using a Local PC

If you need to configure Prime Infrastructure locally (without connecting to a wired LAN), you can connect a PC to the console port on the Prime Infrastructure appliance by using a null-modem cable.

The serial console connector (port) provides access to the CLI locally by connecting a terminal to the console port. The terminal is a PC running terminal-emulation software or an ASCII terminal. The console port (EIA/TIA-232 asynchronous) requires only a null-modem cable.

To connect a PC running terminal-emulation software to the console port, use a DB-9 female to DB-9 female null-modem cable.

To connect an ASCII terminal to the console port, use a DB-9 female to DB-25 male straight-through cable with a DB-25 female to DB-25 female gender changer.

The default parameters for the console port are 9600 baud, 8 data bits, no parity, 1 stop bit, and no hardware flow control.



Note If you are using a Cisco switch on the other side of the connection, set the switchport to duplex auto, speed auto (the default).

-
- Step 1** Connect a null-modem cable to the console port on the Cisco ISE-3315 and to the COM port on your PC.
- Step 2** Set up a terminal emulator to communicate with the Prime Infrastructure. Use the following settings for the terminal emulator connection: 9600 baud, 8 data bits, no parity, 1 stop bit, and no flow control.
- Step 3** When the terminal emulator activates, press **Enter**.
- Step 4** At the console, enter your username, then press **Enter**.
- Step 5** Enter the password, then press **Enter**.
- When the CLI activates, you can enter CLI commands to configure the Prime Infrastructure.
-

Understanding Command Modes

This section describes the Prime Infrastructure command modes in detail.

EXEC Mode

When you start a session on the Prime Infrastructure, you begin in admin or EXEC mode. From EXEC mode, you can enter configuration mode. Most of the EXEC commands (one-time commands), such as **show** commands, display the current configuration status. The admin or EXEC mode prompt consists of the device name or hostname before a pound sign (#), as shown:

```
ncs/admin# (Admin or EXEC mode)
```



Note Throughout this guide, the Prime Infrastructure server uses the name *ncs* in place of the hostname and *admin* of the Prime Infrastructure server for the user account.

You can always tell when you are in EXEC mode or configuration mode by looking at the prompt.

- In EXEC mode, a pound sign (#) appears after the NCS server hostname and your username.

For example:

```
ncs/admin#
```

- In configuration mode, the 'config' keyword and a pound sign (#) appear after the hostname of the Prime Infrastructure server and your username.

For example:

```
ncs/admin# configure  
Enter configuration commands, one per line. End with CNTL/Z.  
ncs/admin(config)# (configuration mode)
```

If you are familiar with UNIX, you can equate EXEC mode to *root* access. You could also equate it to the administrator level in Windows NT or the supervisor in NetWare. In this mode, you have permission to access everything in the Prime Infrastructure server, including the configuration commands. However, you cannot enter configuration commands directly. Before you can change the actual configuration of the Prime Infrastructure server, you must enter configuration mode by entering the **configure** or **configure terminal (conf t)** command. Enter this command only when in EXEC mode.

For example:

```
ncs/admin# conf t  
Enter configuration commands, one per line. End with CNTL-Z.  
ncs(config)# (configuration mode)
```

The configuration mode has several submodes; each has its own prompt. To enter these submodes, you must first enter configuration mode by entering the **configure terminal** command.

To exit configuration mode, enter the **end**, **exit**, or **Ctrl-z** command. To exit EXEC mode, enter the **exit** command. To exit both configuration and EXEC modes, enter this sequence of commands:

```
ncs/admin(config)# exit
ncs/admin# exit
```

To obtain a listing of commands in EXEC mode, enter a question mark (?):

```
ncs/admin# ?
```

Configuration Mode

Use configuration mode to make changes to the existing configuration. When you save the configuration, these commands remain across Prime Infrastructure server reboots, but only if you run either of these commands:

- **copy running-config startup-config**
- **write memory**

To enter configuration mode, run the **configure** or **configure terminal (conf t)** command in EXEC mode. When in configuration mode, the Prime Infrastructure expects configuration commands.

For example:

```
ncs/admin# configure
Enter configuration commands, one per line. End with CNTL-Z.
ncs/admin(config)# (configuration mode)
```

From this level, you can enter commands directly into the Prime Infrastructure configuration. To obtain a listing of commands in this mode, enter a question mark (?):

```
ncs/admin(config)# ?
```

The configuration mode has several configuration submodes. Each of these submodes places you deeper in the prompt hierarchy. When you enter the **exit** command the Prime Infrastructure backs you out one level and returns you to the previous level. When you enter the **exit** command again, the Prime Infrastructure backs you out to the EXEC level.



Note In configuration mode, you can alternatively press the **Ctrl-z** instead of entering the **end** or **exit** command.

Configuration Submodes

In the configuration submodes, you can enter commands for specific configurations. For example:

```
ncs/admin# config t
ncs/admin(config)# interface GigabitEthernet 0
ncs/admin(config-GigabitEthernet)#
```

To obtain a list of commands in this mode, enter a question mark (?):

```
ncs/admin(config-GigabitEthernet)# ?
```

Use the **exit** or **end** command to exit this prompt and return to the configuration prompt.

The following table lists the commands in the interface GigabitEthernet 0 configuration submode. Other configuration submodes exist including those specific to the **kron**, **repository**, and **password policy** commands.

Table 8: Command Options in the Interface GigabitEthernet 0 Configuration Submode

	Comment
<pre>ncs/admin(config)# interface GigabitEthernet 0 ncs/admin(config-GigabitEthernet)# ? Configure ethernet interface: do EXEC command end Exit from configure mode exit Exit from this submode ip Configure IP features ipv6 Configure IPv6 features no Negate a command or set its defaults shutdown Shutdown the interface ncs/admin(config-GigabitEthernet)#</pre>	<p>Enter the command that you want to configure for the interface. This example uses the interface GigabitEthernet command.</p> <p>Enter ? to display what you must enter next on the command line. This example shows the available interface GigabitEthernet configuration submode commands.</p>
<pre>ncs/admin(config-GigabitEthernet)# ip ? address Configure IP address ncs/admin(config-GigabitEthernet)# ip</pre>	<p>Enter the command that you want to configure for the interface. This example uses the ip command.</p> <p>Enter ? to display what you must enter next on the command line. This example shows the available ip configuration submode commands.</p>
<pre>ncs/admin(config-GigabitEthernet)# ip address ? <A.B.C.D> IPv4 address ncs/admin(config-GigabitEthernet) ip address</pre>	<p>Enter the command that you want to configure for the interface. This example uses the ip address command.</p> <p>Enter ? to display what you must enter next on the command line. In this example, you must enter an IPv4 address.</p> <p>A carriage return <cr> does not appear; therefore, you must enter additional arguments to complete the command.</p>
<pre>ncs/admin(config-GigabitEthernet)# ip address 172.16.0.1 ? <A.B.C.D> Network mask ncs/admin(config-GigabitEthernet)# ip address 172.16.0.1</pre>	<p>Enter the keyword or argument that you want to use. This example uses the 172.16.0.1 IP address.</p> <p>Enter ? to display what you must enter next on the command line. In this example, you must enter a network mask.</p> <p>A carriage return <cr> does not display; therefore, you must enter additional arguments to complete the command.</p>

	Comment
<pre>ncs/admin(config-GigabitEthernet)# ip address 172.16.0.1 255.255.255.224 ? <cr> Carriage Return</pre>	Enter the network mask. This example uses the 255.255.255.224 IP address.
<pre>ncs/admin(config-GigabitEthernet)# ip address 172.16.0.1 255.255.255.224 ?</pre>	Enter ? to display what you must enter next on the command line. In this example, you can press Enter . A carriage return <cr> displays; you can press Enter to complete the command.

Navigating the CLI Commands

This section describes how to navigate the commands and modes on the

Getting Help

Use the question mark (?) and the arrow keys to help you enter commands:

- For a list of available commands, enter a question mark (?):

```
ncs/admin# ?
```

- To complete a command, enter a few known characters before ? (with no space):

```
ncs/admin# s?
```

- To display keywords and arguments for a command, enter ? at the prompt or after entering part of a command followed by a space:

```
ncs/admin# show ?
```

The Prime Infrastructure displays a list and brief description of available keywords and arguments.



Note The <cr> symbol in command help stands for “carriage return”, which means to press the **Return** or the **Enter** key). The <cr> at the end of command help output indicates that you have the option to press **Enter** to complete the command and that the arguments and keywords in the list preceding the <cr> symbol are optional. The <cr> symbol by itself indicates that no more arguments or keywords are available, and that you must press **Enter** to complete the command.

- To redisplay a command that you previously entered, press the **Up Arrow** key. Continue to press the **Up Arrow** key to see more commands.

Using the No and Default Forms of Commands

Some EXEC or configuration commands have a **no** form. In general, use the **no** form to disable a function. Use the command without the **no** keyword to re-enable a disabled function or to enable a function disabled by default; for example, an IP address enabled by default. To disable the IP address, use the **no ip address** command; to re-enable the IP address, use the **ip address** command.

Configuration commands can also have a **default** form, which returns the command settings to the default values. Most commands disable by default, so in such cases using the **default** form has the same result as using the **no** form of the command. However, some commands are enabled by default and have variables set to certain default values. In these cases, the **default** form of the command enables the command and sets the variables to their default values.

See [Command Reference, on page 31](#) for a description of the complete syntax of the configuration commands, and the **no** and **default** forms of a command.

Command-Line Conventions

This section contains some basic command-line convention and operation information that is essential to the use of this guide.

Command-Line Editing Key Conventions

The Prime Infrastructure provides a number of keyboard shortcuts that you can use to edit an entered line.

Tab

Press **Tab** to try to finish the current command.

If you press the **Tab** key:

- At the beginning of a line, the system lists all of the short-form options.
- When you enter a partial command, the system lists all of the short form options beginning with those characters.
- When only one possible option is available, the system fills in the option automatically.

Ctrl-c

Press **Ctrl-c** to abort the sequence. Pressing this key sequence breaks out of any executing command and returns to the previous mode.

Ctrl-z

Press **Ctrl-z** to exit configuration mode and return to previous configuration mode.

?

Enter a question mark (?) at the prompt to list the available commands.

Command Line Completion

Command-line completion makes the Prime Infrastructure CLI more user-friendly. It saves you extra key strokes and helps out when you cannot remember the syntax of a command.

For example, for the **show running-config** command:

```
ncs/admin# show running-config
```

You can:

```
ncs/admin# sh run
```

The Prime Infrastructure expands the command **sh run** to **show running-config**.

Another shortcut is to press the **Tab** key after you type **sh**; the Cisco NCS CLI fills in the rest of the command, in this case **show**.

If the Cisco NCS CLI does not understand a command, it repeats the entire command line and places a caret symbol (^) under the point at which it is unable to parse the command.

For example:

```
ncs/admin# show unning-configuration
      ^
% Invalid input detected at '^' marker.
```

The caret symbol (^) points to the first letter in the command line that the Prime Infrastructure does not understand. Usually, this means that you need to provide additional arguments to complete the command or you misspelled the command. In this case, you omitted the “r” in the “unning” command. To fix the error, retype the command.

In another form of command-line completion, you can start a command by entering the first few characters, then pressing the **Tab** key. As long as you can match one command, the Prime Infrastructure CLI will complete the command. For example, if you type **sh** and press **Tab**, the Prime Infrastructure completes the **sh** with **show**. If Prime Infrastructure does not complete the command, you can enter a few more letters and press **Tab** again.

Continuing Output at the --More-- Prompt

When working with the Prime Infrastructure CLI, output often extends beyond the visible screen length. For cases where output continues beyond the bottom of the screen, such as with the output of many **?** or **show** commands, the output pauses and a --More-- prompt appears at the bottom of the screen. To resume output, press **Return** to scroll down one line, or press the **spacebar** to display the next full screen of output.



Tip If the output pauses on your screen but you do not see the --More-- prompt, try entering a smaller value for the screen length by using the **terminal length EXEC** command. Command output will not pause if you set the length value to zero (0).

Where to Go Next

Now that you are familiar with some of the Prime Infrastructure CLI basics, you can begin to configure the Prime Infrastructure by using the CLI.

Remember that:

- You can use the question mark (?) and arrow keys to help you enter commands.
- Each command mode restricts you to a set of commands. If you have difficulty entering a command, check the prompt and then enter the question mark (?) to see a list of available commands.
- To disable a feature, enter the keyword **no** before the command; for example, **no ip address**.
- You must save your configuration changes so that you preserve them during a system reload or power outage.

Proceed to [Command Reference, on page 31](#) for command listings, descriptions, syntax, usage guidelines, and sample output.



APPENDIX A

Command Reference

This appendix contains necessary information on disk space management for all types of Cisco Prime Infrastructure deployments and an alphabetical listing of the commands specific to the Prime Infrastructure. The Prime Infrastructure comprise the following modes:

- EXEC
 - System-level
 - Show
- Configuration
 - configuration submode

Use EXEC mode system-level **config** or **configure** command to access configuration mode.

Each of the commands in this appendix is followed by a brief description of its use, command syntax, any command defaults, command modes, usage guidelines, and one or more examples. Throughout this appendix, the Prime Infrastructure server uses the name *ncs* in place of the Prime Infrastructure server's hostname.



Note If an error occurs in any command usage, use the **debug** command to determine the cause of the error.

- [EXEC Commands, on page 31](#)
- [show Commands, on page 96](#)
- [Configuration Commands, on page 128](#)

EXEC Commands

This section lists each EXEC command and each command page includes a brief description of its use, command syntax, any command defaults, command modes, usage guidelines, and an example of the command and any related commands.

application start

To start the application process, use the **application start** command in EXEC mode. There is **no** form of this command.



Note This command does not work in FIPS release.

application start *application-name*

Syntax Description

application-name Name of the predefined application that you want to enable. Up to 255 alphanumeric characters.

Command Default

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Enables an application.

You cannot use this command to start the Prime Infrastructure application. If you use this command to start the application, you can see that the Prime Infrastructure is already running.

```
pi-system-168/admin# application start NCS
Starting Prime Infrastructure...
This may take a while (10 minutes or more) ...
Prime Infrastructure started successfully.
Redirecting to /bin/systemctl restart rsyslog.service
Completed in 1029 seconds
```

Related Commands

Command	Description
application stop	Stops or disables an application.
application upgrade	Upgrades an application bundle.
show application	Shows application information for the installed application packages on the system.

application stop

To stop the PI process, use the **application stop** command in EXEC mode. There is no **No** form of this command.

application stop *application-name*

Syntax Description

application-name Name of the predefined application that you want to disable. Up to 255 alphanumeric characters.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines Disables an application.

```
pi-system-117/admin# application stop NCS
pi-system/admin# application stop NCS
Stopping Prime Infrastructure...
This may take a few minutes...
Prime Infrastructure successfully shutdown.
Stopping SAM daemon...
Checking for SAM daemon again ...
SAM Daemon not found...
Stopping DA daemon ...
Checking for DA daemon again ...
DA Daemon not found...
Completed shutdown of all services
```

Related Commands

	Description
application start	Starts or enables an application.
application upgrade	Upgrades an application bundle.
show application	Shows application information for the installed application packages on the system.

application upgrade

To upgrade lower version to higher version (supported version), use the **application upgrade** command in EXEC mode.

application upgrade *application-bundle repository-name*

Syntax Description

<i>application-bundle</i>	Enter the upgrade bundle name.
<i>remote-repository-name</i>	Remote repository name (up to 80 alphanumeric characters).

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines Upgrades an application bundle, and preserves any application configuration data.

If you enter the **application upgrade** command when another application upgrade operation is in progress, you will see the following warning message:

```
An existing application install, remove, or upgrade is in progress. Try again shortly.
```



Caution Do not enter the **backup** or **restore** commands when the upgrade is in progress. This action might cause the database to be corrupted.

```
pi-system-196/admin# application upgrade
PI-Upgrade-36x_37x_to_3.8.0.0.310.tar.gz defaultRepo
```

Related Commands

Command	Description
application start	Starts or enables an application.
application stop	Stops or disables an application.
show application	Shows application information for the installed application packages on the system.

backup

Appliance Backup: To perform a backup (including the Prime Infrastructure and Cisco ADE OS data) and place the backup in a repository, use the **backup** command in EXEC mode.

Application Backup: To perform a backup of only the Prime Infrastructure application data without the Cisco ADE OS data, use the **application** keyword command.

Command for Appliance Backup:

backup *backup-name* **repository** *repository-name*

Command for Application Backup

backup *backup-name* **repository** *repository-name* **application** *application-name*

Syntax Description

<i>backup-name</i>	Name of the backup file. Up to 26 alphanumeric characters is recommended.
<i>repository-name</i>	Name of the location where the files should be backed up to. Up to 80 alphanumeric characters.
<i>application-name</i>	Application name. Up to 255 alphanumeric characters.
Note	Enter the application name as 'NCS' in uppercase.

Command Default

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Performs a backup of the Prime Infrastructure and Cisco ADE OS data and places the backup in a repository.

To perform a backup of only the Prime Infrastructure application data without the Cisco ADE OS data, use the **application** command.

Example for Appliance Backup

```
pi-system/admin# backup Appliancebcp repository test
```

DO NOT press ^C while the backup is in progress
Aborting backup with a ^C may terminate the backup operation or the backup file may be corrupted

To restore this backup you will have to enter this password

Password :

Password Again :

```
Backup Started at : 11/27/18 19:08:57
Stage 1 of 7: Database backup ...
Database size: 7.1G
-- completed at 11/27/18 19:10:20
Stage 2 of 7: Database copy ...
-- completed at 11/27/18 19:10:20
Stage 3 of 7: Backing up support files ...
-- completed at 11/27/18 19:10:24
Stage 4 of 7: Compressing Backup ...
-- completed at 11/27/18 19:10:46
Stage 5 of 7: Building backup file ...
-- completed at 11/27/18 19:11:03
Stage 6 of 7: Encrypting backup file ...
-- completed at 11/27/18 19:11:09
Stage 7 of 7: Transferring backup file ...
-- completed at 11/27/18 19:11:11
% Backup file created is:
Appliancebcp-181127-1908__VER3.8.0.0.310_BKSZ5G_CPU4_MEM3G_RAM11G_SWAP15G_SYS_CK525526487.tar.gpg
Total Backup duration is: 0h:2m:18s
pi-system/admin#
```

Example for Application Backup

```
pi-system/admin# backup Applicationbcp repository test application NCS
```

DO NOT press ^C while the backup is in progress
Aborting backup with a ^C may terminate the backup operation or the backup file may be corrupted

To restore this backup you will have to enter this password

Password :

Password Again :

```
Backup Started at : 11/27/18 19:13:33
Stage 1 of 7: Database backup ...
Database size: 7.1G
-- completed at 11/27/18 19:14:17
Stage 2 of 7: Database copy ...
-- completed at 11/27/18 19:14:17
Stage 3 of 7: Backing up support files ...
-- completed at 11/27/18 19:14:19
Stage 4 of 7: Compressing Backup ...
-- completed at 11/27/18 19:14:34
Stage 5 of 7: Building backup file ...
```

```

-- completed at 11/27/18 19:14:50
Stage 6 of 7: Encrypting backup file ...
-- completed at 11/27/18 19:14:55
Stage 7 of 7: Transferring backup file ...
-- completed at 11/27/18 19:14:56
% Backup file created is:
Applicationbkp-181127-1913__VER3.8.0.0.310_BKSZ5G_CPU4_MEM3G_RAM11G_SWAP15G_APP_CK3453119464.tar.gpg

Total Backup duration is: 0h:1m:26s
pi-system/admin#

```

Related Commands	Command	Description
	delete	Deletes a file from the Prime Infrastructure server.
	repository	Enters the repository submode for configuration of backups.
	restore	Restores from backup the file contents of a specific repository.
	show backup history	Displays the backup history of the system.
	show repository	Displays the available backup files located on a specific repository.

backup-logs

To back up system logs, use the **backup-logs** command in EXEC mode. There is no **no** form of this command.

backup-logs *backup-name* **repository** *repository-name*

Syntax Description	<i>backup-name</i>	Name of one or more files to back up. Up to 100 alphanumeric characters.
	<i>repository-name</i>	Location where files should be backed up to. Up to 80 alphanumeric characters.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines Backs up system logs.

```

pi-admin/admin# backup-logs log-backup repository defaultRepo
% Creating log backup with timestamped filename: log-backup-150621-1618.tar.gz
Transferring file ...
-- complete.
pi-system/admin#

```


Related Commands	Command	Description
	repository	Enters the repository submode for configuration of backups.
	show repository	Shows the available backup files located on a specific repository.

banner

To set up messages while logging (pre-login) in to CLI, use the **banner install pre-login** command.

banner install pre-login *banner-text-filename* **repository** *Repository-name*

Syntax Description		
	<i>banner-text-filename</i>	Banner text file name.
	<i>repository-name</i>	Repository name.

Command Default No default behavior or values.

Command Modes EXEC

```
admin# banner install pre-login test.txt repository defaultRepo
```

Related Commands	Command	Description
	show banner pre-login, on page 99	Enables you to display a pre-login banner.

change-password

To change the password you use to log in to CLI interface, use the **change-password** command.

change-password *password*

Syntax Description		
	<i>password</i>	New password

Command Default No default behavior or values.

Command Modes EXEC

```
pi-system/admin# change-password
Changing password for user admin.
Changing password for admin.
(current) UNIX password:
New password:
Retype new password:
passwd: all authentication tokens updated successfully.
```

clock

To set the system clock, use the **clock** command in EXEC mode. You cannot remove this function but reset the clock.

clock set [*mmm dd hh:mm:ss yyyy*]

Syntax Description		
<i>mmm</i>		Current month of the year by name. Up to three alphabetic characters. For example, Jan for January.
<i>dd</i>		Current day (by date) of the month. Value = 0 to 31. Up to two numbers.
<i>hh:mm:ss</i>		Current time in hours (24-hour format), minutes, and seconds.
<i>yyyy</i>		Current year (no abbreviation).

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines Sets the system clock. You must restart the Prime Infrastructure server after you reset the clock for the change to take effect.

```
pi-system-196/admin# clock set Jan 28 04:11:35 2020
pi-system-196/admin# show clock
Tue Jan 28 04:11:38 IST 2020
pi-system-196/admin#
```

Related Commands

Command	Description
show clock	Displays the time and date set on the system software clock.

configure

To enter configuration mode, use the **configure** command in EXEC mode. If the **replace** option is used with this command, copies a remote configuration to the system which overwrites the existing configuration.

configure terminal

Syntax Description		
terminal		Executes configuration commands from the terminal.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines

Use this command to enter configuration mode. Note that commands in this mode write to the running configuration file as soon as you enter them (press **Enter**).

To exit configuration mode and return to EXEC mode, enter **end**, **exit**, or press **Ctrl-z**.

To view the changes that you have made to the configuration, use the **show running-config** command in EXEC mode.

Example 1

```
ncs/admin# configure
Enter configuration commands, one per line. End with CNTL/Z.
ncs/admin(config)#
```

Example 2

```
ncs/admin# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ncs/admin(config)#
```

Related Commands

Command	Description
show running-config	Displays the contents of the currently running configuration file or the configuration.
show startup-config	Displays the contents of the startup configuration file or the configuration.

copy

To copy any file from a source to a destination, use the **copy** command in EXEC mode.

Syntax Description

<code>running-config</code>	Represents the current running configuration file.
<code>startup-config</code>	Represents the configuration file used during initialization (startup).
<i>protocol</i>	See Table 9: Protocol Prefix Keywords for protocol keyword options.
<i>hostname</i>	Hostname of destination.
<i>location</i>	Location of disk: /<dirpath>.
<code>logs</code>	The system log files.
<code>all</code>	Copies all Prime Infrastructure log files from the system to another location. All logs are packaged as ncslogs.tar.gz and transferred to the specified directory on the remote host.

filename	Allows you to copy a single Prime Infrastructure log file and transfer it to the specified directory on the remote host, with its original name.
<i>log_filename</i>	Name of the Prime Infrastructure log file, as displayed by the show logs command (up to 255 characters).
mgmt	Copies the Prime Infrastructure management debug logs and Tomcat logs from the system, bundles them as mgmtlogs.tar.gz, and transfers them to the specified directory on the remote host.
runtime	Copies the Prime Infrastructure runtime debug logs from the system, bundles them as runtimelogs.tar.gz, and transfers them to the specified directory on the remote host.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines The fundamental function of the **copy** command allows you to copy a file (such as a system image or configuration file) from one location to another location. The source and destination for the file specified uses the file system, through which you can specify any supported local or remote file location. The file system being used (a local memory source or a remote system) dictates the syntax used in the command.

You can enter on the command line all of the necessary source and destination information and the username and password to use; or, you can enter the **copy** command and have the server prompt you for any missing information. You can enter up to a maximum of 2048 characters of source and destination URL information on the command line.

The **copy** command in the copies a configuration (running or startup).

The active configuration stores itself in the RAM. Every configuration command you enter resides in the running configuration. If you reboot your server, you lose the running configuration. If you make changes that you want to save, you must copy the running configuration to a safe location, such as a network server, or save it as the server startup configuration.

You cannot edit a startup configuration directly. All commands that you enter store themselves in the running configuration, which you can copy into the startup configuration.

In other words, when you boot a server, the startup configuration becomes the initial running configuration. As you modify the configuration, the two diverge: the startup configuration remains the same; the running configuration reflects the changes that you have made. If you want to make your changes permanent, you must save the running configuration to the startup configuration using the **write memory** command. The **write memory** command makes the current running configuration permanent.



Note If you do not save the running configuration, you will lose all your configuration changes during the next reboot of the server. You can also save a copy of the running and startup configurations using the following commands, to recover in case of loss of configuration:

copy startup-config *location*

copy running-config *location*



Note The **copy** command is supported only for the local disk and not for a repository.



Tip Aliases reduce the amount of typing that you need to do. For example, type **copy run start** (the abbreviated form of the **copy running-config startup-config** command).

The entire copying process might take several minutes and differs from protocol to protocol and from network to network.

Use the filename relative to the directory for file transfers.

Possible error is the standard FTP error message.

Table 9: Protocol Prefix Keywords

Keyword	Destination
ftp	URL for FTP network server. The syntax for this alias: ftp://location/directory

Keyword	Destination
sftp	<p>URL for an SFTP network server. The syntax for this alias: <code>sftp://location/directory</code></p> <p>SFTP Repositories may require the // between the IP address/FQDN and the physical path on the SFTP store. If you find that you cannot access the SFTP repository with single slashes, add the additional slash and try the operation again. For example: <code>url sftp://server/path</code></p> <p>Note The remote sftp servers need to be enabled for 'password authentication' (keyboard-interactive mode does not work for sftp transfers). See the documentation on sshd server used at the remote end, to enable password authentication.</p> <p>Depending on the SFTP software used with the remote server, you may need to enable "password authentication" instead of "keyboard-interactive mode". Enabling "password authentication" is required; copy to remote SFTP servers will not work unless it is enabled. For example: With OpenSSH 6.6x, "keyboard-interactive mode" is the default. To enable "password authentication", edit the OpenSSH <code>sshd_config</code> file to set the <code>PasswordAuthentication</code> parameter to "yes", as follows: <code>PasswordAuthentication yes.</code></p>
tftp	<p>URL for a TFTP network server. The syntax for this alias:</p> <p><code>tftp://location/directory</code></p>

Example 1

```
ncs/admin# copy run start
Generating configuration...
ncs/admin#
```

Example 2

```
ncs/admin# copy running-config startup-config
Generating configuration...
ncs/admin#
```

Example 3

```
ncs/admin# copy start run
ncs/admin#
```

Example 4

```
ncs/admin# copy startup-config running-config
ncs/admin#
```

Example 5

```
ncs/admin# copy logs disk:/
Collecting logs...
ncs/admin#
```

Example 6

This command is used to copy the certificate from tftp to pnp.

```
copy tftp://<PI Server IP Address>/server.key disk:/
copy tftp://<PI Server IP Address>/server.crt disk:/
copy tftp://<PI Server IP Address>/ncs_server_certificate.crt disk:/
```

Related Commands

Command	Description
delete	Deletes a file from the server.
dir	Lists a file from the server.

debug

To display errors or events for command situations, use the **debug** command in EXEC mode.

debug{all | application | backup-restore | cdp | config | icmp | copy | locks | logging | snmp | system | transfer | user | utils}

Syntax Description

all	Enables all debugging.
application	<p>Application files.</p> <ul style="list-style-type: none"> • <i>all</i>—Enables all application debug output. Set level between 0 and 7, with 0 being severe and 7 being all. • <i>install</i>—Enables application install debug output. Set level between 0 and 7, with 0 being severe and 7 being all. • <i>operation</i>—Enables application operation debug output. Set level between 0 and 7, with 0 being severe and 7 being all. • <i>uninstall</i>—Enables application uninstall debug output. Set level between 0 and 7, with 0 being severe and 7 being all.

backup-restore

Backs up and restores files.

- *all*—Enables all debug output for backup-restore. Set level between 0 and 7, with 0 being severe and 7 being all.
- *backup*—Enables backup debug output for backup-restore. Set level between 0 and 7, with 0 being severe and 7 being all.
- *backup-logs*—Enables backup-logs debug output for backup-restore. Set level between 0 and 7, with 0 being severe and 7 being all.
- *history*—Enables history debug output for backup-restore. Set level between 0 and 7, with 0 being severe and 7 being all.
- *restore*—Enables restore debug output for backup-restore. Set level between 0 and 7, with 0 being severe and 7 being all.

cdp

Cisco Discovery Protocol configuration files.

- *all*—Enables all Cisco Discovery Protocol configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.
 - *config*—Enables configuration debug output for Cisco Discovery Protocol. Set level between 0 and 7, with 0 being severe and 7 being all.
 - *infra*—Enables infrastructure debug output for Cisco Discovery Protocol. Set level between 0 and 7, with 0 being severe and 7 being all.
-

config	<p>Configuration files.</p> <ul style="list-style-type: none">• <i>all</i>—Enables all configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.• <i>backup</i>—Enables backup configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.• <i>clock</i>—Enables clock configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.• <i>infra</i>—Enables configuration infrastructure debug output. Set level between 0 and 7, with 0 being severe and 7 being all.• <i>kron</i>—Enables command scheduler configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.• <i>network</i>—Enables network configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.• <i>repository</i>—Enables repository configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.• <i>service</i>—Enables service configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.
icmp	<p>Internet Control Message Protocol (ICMP) echo response configuration.</p> <p><i>all</i>—Enable all debug output for ICMP echo response configuration. Set level between 0 and 7, with 0 being severe and 7 being all.</p>
copy	<p>Copy commands. Set level between 0 and 7, with 0 being severe and 7 being all.</p>
locks	<p>Resource locking.</p> <ul style="list-style-type: none">• <i>all</i>—Enables all resource locking debug output. Set level between 0 and 7, with 0 being severe and 7 being all.• <i>file</i>—Enables file locking debug output. Set level between 0 and 7, with 0 being severe and 7 being all.

logging	<p>Logging configuration files.</p> <p><i>all</i>—Enables all logging configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.</p>
snmp	<p>SNMP configuration files.</p> <p><i>all</i>—Enables all SNMP configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.</p>
system	<p>System files.</p> <ul style="list-style-type: none"> • <i>all</i>—Enables all system files debug output. Set level between 0 and 7, with 0 being severe and 7 being all. • <i>id</i>—Enables system ID debug output. Set level between 0 and 7, with 0 being severe and 7 being all. • <i>info</i>—Enables system info debug output. Set level between 0 and 7, with 0 being severe and 7 being all. • <i>init</i>—Enables system init debug output. Set level between 0 and 7, with 0 being severe and 7 being all.
transfer	<p>File transfer. Set level between 0 and 7, with 0 being severe and 7 being all.</p>
user	<p>User management.</p> <ul style="list-style-type: none"> • <i>all</i>—Enables all user management debug output. Set level between 0 and 7, with 0 being severe and 7 being all. • <i>password-policy</i>—Enables user management debug output for password-policy. Set level between 0 and 7, with 0 being severe and 7 being all.
utils	<p>Utilities configuration files.</p> <p><i>all</i>—Enables all utilities configuration debug output. Set level between 0 and 7, with 0 being severe and 7 being all.</p>

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines

Use the **debug** command to identify various failures within the Prime Infrastructure server; for example, setup failures or configuration failures.

```
ncs/admin# debug all
ncs/admin# mkdir disk:/1
ncs/admin# 6 [15347]: utils: vsh_root_stubs.c[2742] [admin]: mkdir operation success

ncs/admin# rmdir disk:/1
6 [15351]: utils: vsh_root_stubs.c[2601] [admin]: Invoked Remove Directory disk:/1 command
6 [15351]: utils: vsh_root_stubs.c[2663] [admin]: Remove Directory operation success
ncs/admin#

ncs/admin# undebug all
ncs/admin#
```

Related Commands

Command	Description
undebug	Disables the output (display of errors or events) of the debug command for various command situations.

delete

To delete a file from the Prime Infrastructure server, use the **delete** command in EXEC mode. There is no **no** form of this command.

delete *filename* [*disk:/path*]

Syntax Description

<i>filename</i>	Filename.
<i>disk:/path</i>	Location.

Command Default

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

If you attempt to delete the configuration file or image, the system prompts you to confirm the deletion. Also, if you attempt to delete the last valid system image, the system prompts you to confirm the deletion.

```
ncs/admin# delete disk:/hs_err_pid19962.log
ncs/admin#
```

Related Commands

Command	Description
dir	Lists all of the files on the Prime Infrastructure server.

dir

To list a file from the Prime Infrastructure server, use the **dir** command in EXEC mode. To remove this function, use the **no** form of this command.

dir [*word*]/[**recursive**]

Syntax Description	<i>word</i>	Directory name. Up to 80 alphanumeric characters. Requires disk:/ preceding the directory name.
	recursive	Lists a local directory or filename recursively.

Command Default No default behavior or values.

Command Modes EXEC

```

pi-system/admin# dir
Directory of disk:/
 8957994151 Jan 28 04:11:35 2020 \
pi-system-284-200126-0334__VER3.8.0.0.284_BKSZ24G_CPU4_MEM3G_RAM11G_SWAP15G_APP_CK4209384478.tar.gpg

 2624272 Nov 13 2018 19:02:22 ADElogs.tar.gz
      20 Nov 09 2018 12:37:50 crash
   4096 Nov 14 2018 03:44:47 defaultRepo/
   4096 Nov 09 2018 18:40:04 ftp/
 16384 Nov 09 2018 05:28:27 lost+found/
   4096 Nov 10 2018 02:15:10 sftp/
   4096 Nov 09 2018 12:36:08 ssh/
   4096 Nov 09 2018 12:36:08 telnet/
   4096 Nov 13 2018 21:00:47 tftp/
      Usage for disk: filesystem
      15534272512 bytes total used
      28416839680 bytes free
      46310408192 bytes available

```

Related Commands	Command	Description
	delete	Deletes a file from the Prime Infrastructure server.

exit

To close an active terminal session by logging out of the Prime Infrastructure server or to move up one mode level from configuration mode, use the **exit** command in EXEC mode.

exit

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines

Use the **exit** command in EXEC mode to exit an active session (log out of the Prime Infrastructure server) or to move up from configuration mode.

```
pi-system/admin# exit
Connection closing...Socket close.
Connection closed by foreign host.
Disconnected from remote host(10.197.71.160:22) at 10:51:43.
```

Related Commands

Command	Description
end	Exits configuration mode.
exit	Exits configuration mode or EXEC mode.
Ctrl-z	Exits configuration mode.

forceout

To force users out of an active terminal session by logging them out of the Prime Infrastructure server, use the **forceout** command in EXEC mode.

forceout *username*

Syntax Description

<i>username</i>	The name of the user. Up to 31 alphanumeric characters.
-----------------	---

Command Default

No default behavior or values.

Command Modes

EXEC

```
ncs/admin# forceout user1
ncs/admin#
```

halt

To shut down and power off the system, use the **halt** command in EXEC mode.

halt

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Before you enter the **halt** command, ensure that the Prime Infrastructure is not performing any backup, restore, installation, upgrade, or remove operation. If you enter the **halt** command while the Prime Infrastructure is performing any of these operations, you will get one of the following warning messages:

WARNING: A backup or restore is currently in progress! Continue with halt?

WARNING: An install/upgrade/remove is currently in progress! Continue with halt?

If you get any of these warnings, enter **YEs** to halt the operation, or enter **NO** to cancel the halt.

If no processes are running when you use the **halt** command or if you enter **Yes** in response to the warning message displayed, the Prime Infrastructure asks you to respond to the following option:

Do you want to save the current configuration ?

Enter **YES** to save the existing Prime Infrastructure configuration. The Prime Infrastructure displays the following message:

Saved the running configuration to startup successfully

```
pi-system/admin# halt
Save the current ADE-OS running configuration? (yes/no) [yes] ? yes
Generating configuration...
Saved the ADE-OS running configuration to startup successfully
Continue with shutdown? [y/n] y
Broadcast message from root (pts/0) (Wed May  5 18:37:02 2010):
The system is going down for system halt NOW!
Server is shutting down...
```

Related Commands

Command	Description
reload	Reboots the system.

lms

To migrate data from lms server to PI server, use **lms** command in EXEC mode.

lms migrate repository *repository-name*

Syntax Description

repository-name Name of the PI repository.

Command Default

No default values or behaviour.

Command Modes

EXEC

```
pi-cluster-160/admin# lms migrate repository test
Repository name : test
Initiating LMS data restore . Please wait...
INFO: no staging url defined, using local space.
LMS Migration Normal Flow Started : == true
INFO: Backup Status : SUCCESS

Enter the password to unlock the zip file : *****
INFO: Password validation successful.
Enter the Cisco Prime Infrastructure Login Username : root
Enter the Cisco Prime Infrastructure Login Password : ***** (here roZes123)
HTTPS port used is 443
Connecting to The Server...
```

```

Login success.
Updating the credentials...
The following data types are available in the given exported data.
Choose an option using comma separated values to migrate.
    1 network
    2 settings
    3 All of the above
Enter an option or comma-separated options :3
3
Checking for all option ...
Updating the downloading files list ...
Started downloading the files to import from repository ...

```

mkdir

To create a new directory on the Prime Infrastructure server, use the **mkdir** command in EXEC mode.

mkdir *directory-name* [*disk:/path*]

Syntax Description	<i>directory-name</i>	The name of the directory to create. Up to 80 alphanumeric characters.
	<i>disk:/path</i>	Use <i>disk:/path</i> with the directory name.
Command Default	No default behavior or values.	
Command Modes	EXEC	
Usage Guidelines	Use <i>disk:/path</i> with the directory name; otherwise, an error appears that indicates that the <i>disk:/path</i> must be included.	

```

ncs/admin# mkdir disk:/test
ncs/admin# dir

Directory of disk:/

   4096 May 06 2010 13:34:49  activemq-data/
   4096 May 06 2010 13:40:59  logs/
 16384 Mar 01 2010 16:07:27  lost+found/
   4096 May 06 2010 13:42:53  target/
   4096 May 07 2010 12:26:04  test/

Usage for disk: filesystem
      181067776 bytes total used
      19084521472 bytes free
      20314165248 bytes available
ncs/admin#

```

Related Commands	Command	Description
	dir	Displays a list of files on the Prime Infrastructure server.
	rmdir	Removes an existing directory.

ncs run client-auth

You can enable client certificate authentication on your Prime Infrastructure application using **ncs run client-auth** command.

ncs run client-auth enable

ncs run client-auth disable

Command Default No default behavior or values.

Command Modes EXEC

```
pi-system-117/admin# ncs run client-auth enable
```

```
WARNING :
```

```
This feature requires the CA certificate to be installed on the system.
Please use the command 'ncs key importcacert ...' to
import the certificate of the CA used to sign the client certificates.
Ignore this warning if the CA certificate is already installed.
```

```
Use the 'disable' option of this command, to disable client authentication,
if not required.
```

```
client_auth status : enabled
pi-system-117/admin#
```

```
pi-system-117/admin# ncs run client-auth disable
client_auth status : disabled
pi-system-117/admin#
```

ncs run list

To display the list of commands associated with NCS, use **ncs run list** command in EXEC mode.

ncs run list

Command Default No default behavior or arguments

Command Modes EXEC

```
pi-system/admin# ncs run list
commands :
  list - prints this list
```

```
test iops - tests the disk write performance
reset [db|keys] - reset database and keys to default factory settings
```

```
csrf [disable|enable] - enable or disable CSRF protection
client-auth [disable|enable] - enable or disable client certificate based authentication
jms [disable|enable] - enable or disable message bus connectivity (port 61617)
```

```
sshclient-nonfips-ciphers [disable|enable] - enable or disable non fips compliant ciphers
for outgoing ssh client connections to devices
ssh-server-legacy-algorithms [disable|enable] - enable or disable legacy algorithms for
SSH service.
tls-server-versions <tls_versions> - set the TLS versions to be enabled for TLS service
```



```

- TLSv1.2 TLSv1.1 TLSv1
  tls-server-ciphers <tls_cipher_groups> - set the TLS cipher group to be enabled for TLS
service - tls-ecdh-sha2 tls-ecdh-sha1 tls-dhe-sha2 tls-dhe-sha1 tls-static-sha2
tls-static-sha1
  livelogs [all|secure|ade|messages] - view live audit logs
  loghistory [all|secure|ade|messages] - view audit logs
  firewall [-block|-unblock|-list] - block and unblock source ip address

```

ncs run test iops

To test and view details of the input output operations on your Prime Infrastructure, use **ncs run test iops** command in EXEC mode.

ncs run test iops

Command Default No default behavior or values.

Command Modes EXEC

```

pi-242/admin# ncs run test iops
Testing disk write speed ...
8388608+0 records in
8388608+0 records out
8589934592 bytes (8.6 GB) copied, 33.4561 s, 257 MB/s

```

ncs run reset

You can use **ncs run reset** command to delete all private keys from your Prime Infrastructure server and to clean a corrupted Database. Resetting the DB clears all existing data and replaces it with empty data.

ncs run reset { db | keys }

Syntax Description	db	Resets DB with empty data.
	keys	Deletes all private keys from Prime Infrastructure server.

Command Default No default behavior or values.

Command Modes EXEC

```

pi-system-160/admin# ncs run reset db
***** Warning *****
This script will delete the existing data in database (network data) and reset
database to default factory settings.
Do you want to proceed [yes/no] [no]? yes
Stopping Prime Infrastructure...
This may take a few minutes...
Prime Infrastructure successfully shutdown.
Stopping SAM daemon...
Checking for SAM daemon again ...
SAM Daemon not found...

```

```

Stopping DA daemon ...
Checking for DA daemon again ...
DA Daemon not found...
Completed shutdown of all services
Listener wctns is down.
Listener already stopped.
Database is already stopped. Cannot stop again.
This script is intended to run database configuration utilities
to provision and create the embedded database
Running database network config assistant tool (netca)...
Running oracle ZIP DB creation script...
configuring Oracle memory size
Running standby database creation script...
currentState is ...
sid being set wcs
SQL*Plus: Release 12.1.0.2.0 Production on Wed Nov 14 11:25:18 2018
Copyright (c) 1982, 2014, Oracle. All rights reserved.
Connected to an idle instance.
SQL> ORACLE instance started.
Total System Global Area 2147483648 bytes
Fixed Size          2926472 bytes
Variable Size       1023412344 bytes
Database Buffers    1107296256 bytes
Redo Buffers        13848576 bytes
Database mounted.
Database opened.
SQL>
User altered.
SQL> Database closed.
Database dismounted.
ORACLE instance shut down.
SQL> Disconnected from Oracle Database 12c Enterprise Edition Release 12.1.0.2.0 - \
64bit Production
With the Partitioning, OLAP, Advanced Analytics and Real Application Testing options
SQL*Plus: Release 12.1.0.2.0 Production on Wed Nov 14 11:25:52 2018
Copyright (c) 1982, 2014, Oracle. All rights reserved.
Connected to an idle instance.
SQL> ORACLE instance started.
Total System Global Area 1287651328 bytes
Fixed Size          2934984 bytes
Variable Size       331351864 bytes
Database Buffers    947912704 bytes
Redo Buffers        5451776 bytes
Database mounted.
Database opened.
SQL>
User altered.
SQL> Database closed.
Database dismounted.
ORACLE instance shut down.
SQL> Disconnected from Oracle Database 12c Enterprise Edition Release 12.1.0.2.0 - \
64bit Production
With the Partitioning, OLAP, Advanced Analytics and Real Application Testing options
Listener wctns is up
Database is already stopped. Cannot stop again.
INFO: reset db command executed successfully. Please restore the system data from a \
backup file

```

This example shows how to delete all private keys in Prime Infrastructure server:

```

pi-system-61/admin# ncs run reset keys
This will delete all the private keys and may impact webserver, SSH service etc.

```

```
Do you want to proceed [yes/no] [no]? yes
```

ncs run csrf

The cross-site request forgery check can be disabled (not recommended). The CLI provided only for backward compatibility with API clients which are not programmed for CSRF protection. For CSRF protection, this option should be enabled using the following command.

ncs run csrf enable

To disable, use the following command:

ncs run csrf disable

Command Default No default behavior or values.

Command Modes EXEC

```
pi-cluster-93/admin# ncs run csrf enable
```

```
pi-cluster-93/admin# ncs run csrf disable
```

ncs run livelogs

You can run **ncs run livelogs** command to view live audit logs.

ncs run livelogs { *all* | *secure* | *ade* | *messages* }

Command Default No default behavior or values.

Command Modes EXEC

```
pi-system-120/admin# ncs run livelogs
***Available filter options to limit logs - all secure ade messages***
*****Press Ctrl+C for stop logging*****
2018-02-28T01:48:39.407787+05:30 pi-system-120 sshd[10309]: pam_unix(sshd:session): \
session closed for user admin
2018-02-28T01:50:14.109435+05:30 pi-system-120 sshd[32038]: \
pam_tally2(sshd:account): option unlock_time=60 allowed in auth phase only
2018-02-28T01:50:14.109456+05:30 pi-system-120 sshd[32038]: \
pam_tally2(sshd:account): unknown option: no_reset
2018-02-28T01:50:14.112152+05:30 pi-system-120 sshd[32038]: pam_unix(sshd:session): \
session opened for user admin by (uid=0)
2018-02-28T02:00:57.499844+05:30 pi-system-120 sshd[32038]: pam_unix(sshd:session): \
session closed for user admin
2018-02-28T02:04:28.870085+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-28T02:04:28.976462+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-28T02:21:30.485537+05:30 pi-system-120 sshd[6381]: \
pam_tally2(sshd:account): option unlock_time=60 allowed in auth phase only
2018-02-28T02:21:30.485556+05:30 pi-system-120 sshd[6381]: \
pam_tally2(sshd:account): unknown option: no_reset
2018-02-28T02:21:30.488589+05:30 pi-system-120 sshd[6381]: pam_unix(sshd:session): \
```

```

session opened for user admin by (uid=0)

2018-02-28T02:25:04.370446+05:30 pi-system-120 debugd[3229]: [7471]: \
config:network: sysconfig.c[1116] [admin]: Getting ipaddress for eth1
2018-02-28T02:25:04.377607+05:30 pi-system-120 debugd[3229]: [7471]: \
config:network: syscfg_cli.c[1098] [admin]: No ipaddress for interface eth1
2018-02-28T02:25:04.384642+05:30 pi-system-120 ADEOSShell[7471]: Change Audit \
Details:SUCCESS:CARS
CLI:carsGetIfState::root:/opt/system/bin/carssh:NotFromTerminal:5:
2018-02-28T02:25:04.384720+05:30 pi-system-120 debugd[3229]: [7471]: \
config:network: syscfg_cli.c[1105] [admin]: Interface eth1 is down
2018-02-28T02:25:04.384777+05:30 pi-system-120 debugd[3229]: [7471]: \
config:network: syscfg_cli.c[1011] [admin]: Getting dhcpv6 enabled for eth1
2018-02-28T02:25:04.405866+05:30 pi-system-120 ADEOSShell[7471]: Change Audit \
Details:SUCCESS:CARS
CLI:carsGetNameserver::root:/opt/system/bin/carssh:NotFromTerminal:6:
2018-02-28T02:25:04.412912+05:30 pi-system-120 ADEOSShell[7471]: Change Audit \
Details:SUCCESS:CARS
CLI:carsGetNameserver::root:/opt/system/bin/carssh:NotFromTerminal:7:
2018-02-28T02:25:04.420049+05:30 pi-system-120 ADEOSShell[7471]: Change Audit \
Details:SUCCESS:CARS
CLI:carsGetNameserver::root:/opt/system/bin/carssh:NotFromTerminal:8:
2018-02-28T02:25:04.427224+05:30 pi-system-120 ADEOSShell[7471]: Change Audit \
Details:SUCCESS:CARS
CLI:carsGetGateway::root:/opt/system/bin/carssh:NotFromTerminal:9:
2018-02-28T02:28:16.411167+05:30 pi-system-120 ADEOSShell[8312]: Change Audit \
Details:SUCCESS:CARS CLI:run_command::root:/opt/system/bin/carssh:/dev/pts/1:1:

2018-02-28T02:21:25.649026+05:30 pi-system-120 sshd[6381]: Operating in CiscoSSL \
Common Criteria mode
2018-02-28T02:21:25.654950+05:30 pi-system-120 sshd[6381]: FIPS mode initialized
2018-02-28T02:21:25.806409+05:30 pi-system-120 sshd[6381]: Outbound-ReKey for \
10.77.144.125:16285 [preauth]
2018-02-28T02:21:25.889051+05:30 pi-system-120 sshd[6381]: Inbound-ReKey for \
10.77.144.125:16285 [preauth]
2018-02-28T02:21:30.487757+05:30 pi-system-120 sshd[6381]: Accepted password for \
admin from 10.77.144.125 port 16285 ssh2
2018-02-28T02:21:30.490420+05:30 pi-system-120 sshd[6390]: Inbound-ReKey for \
10.77.144.125:16285
2018-02-28T02:21:30.490437+05:30 pi-system-120 sshd[6390]: Outbound-ReKey for \
10.77.144.125:16285
2018-02-28T02:21:32.124237+05:30 pi-system-120 rsyslogd: [origin \
software="rsyslogd" swVersion="5.8.10" x-pid="3216" \
x-info="http://www.rsyslog.com ] rsyslogd was HUPed
2018-02-28T02:25:04.601075+05:30 pi-system-120 rsyslogd-2177: imuxsock begins to \
drop messages from pid 3229 due to rate-limiting
2018-02-28T02:25:30.938945+05:30 pi-system-120 rsyslogd-2177: imuxsock lost 463 \
messages from pid 3229 due to rate-limiting
^CERROR: cmd '/opt/CSColumos/bin/run_command.sh livelogs' failed
pi-system-120/admin#

```

ncs run loghistory

You can run **ncs run loghistory** command to view a list of audit logs.

```
ncs run loghistory { all | secure | ade | messages }
```

Command Default No default behavior or values.

Command Modes EXEC

```

pi-system-120/admin# ncs run loghistory
***Available filter options to limit logs - all secure ade messages***
:::::::::::::
/var/log/secure
:::::::::::::
2018-02-25T04:22:03.091312+05:30 pi-system-120 passwd: pam_unix(passwd:chauthtok): \
password changed for scpuser
2018-02-25T05:47:52.693460+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T05:47:52.746896+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-25T07:48:08.551061+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T07:48:08.607276+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-25T09:48:29.616066+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T09:48:29.675890+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-25T11:48:49.792055+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T11:48:49.845594+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-25T13:49:13.712070+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T13:49:13.764692+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-25T15:49:28.165108+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T15:49:28.231362+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-25T17:49:46.089296+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T17:49:46.143475+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-25T19:50:06.775083+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T19:50:06.828332+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-25T21:50:33.338183+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T21:50:33.393056+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-25T23:50:59.225069+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-25T23:50:59.278849+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-26T01:51:23.433628+05:30 pi-system-120 su: pam_unix(su-l:session): session \
opened for user oracle by (uid=0)
2018-02-26T01:52:00.541797+05:30 pi-system-120 su: pam_unix(su-l:session): session \
closed for user oracle
2018-02-26T01:52:00.582068+05:30 pi-system-120 su: pam_unix(su:session): session \
opened for user oracle by (uid=0)
2018-02-26T01:52:00.635314+05:30 pi-system-120 su: pam_unix(su:session): session \
closed for user oracle
2018-02-26T03:30:00.737839+05:30 pi-system-120 su: pam_unix(su-l:session): session \
opened for user oracle by (uid=0)
2018-02-26T03:30:01.308384+05:30 pi-system-120 su: pam_unix(su-l:session): session \
closed for user oracle
2018-02-26T03:30:01.318405+05:30 pi-system-120 su: pam_unix(su-l:session): session \
opened for user oracle by (uid=0)
2018-02-26T03:30:01.373111+05:30 pi-system-120 su: pam_unix(su-l:session): session \
closed for user oracle
2018-02-26T03:30:01.411957+05:30 pi-system-120 su: pam_unix(su-l:session): session \

```


Command Modes EXEC

The following example illustrates the use of the `ncs run set-tls-versions` command:

```
pi-system-168/admin# ncs run set-tls-versions TLSv1 TLSv1.1 TLSv1.2
Enabled TLS version are - TLSv1,TLSv1.1,TLSv1.2
Restart is required for the changes to take effect
pi-system-168/admin#
```

**Warning**

Running this command requires an immediate software restart. It is suggested you perform a failover and failback so that changes are reflected in both primary and secondary servers.

Related Topics

[Ensuring Primary HA Server Changes are Replicated](#)

ncs start

To start the Prime Infrastructure server, use the **ncs start** command.

ncs start [verbose]

Syntax Description	verbose	Displays the detailed messages during the start process.
---------------------------	---------	--

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	EXEC
----------------------	------

Usage Guidelines	To see the messages in the console, use the ncs start verbose command.
-------------------------	---

This example shows how to start the server:

```
pi-common-133/admin# ncs start verbose

Starting Prime Infrastructure...

Reporting Server Heap size = 4096m
XMP Server Heap size = 6656m
Starting Health Monitor

Starting Health Monitor as a primary
Checking for Port 8082 availability... OK
CERT MATCHED :
Updating web server configuration file ...
Starting Health Montior Web Server...
Health Monitor Web Server Started.
Setting UID to 499:110
UID set to 499:110
Starting Health Monitor Server...
Health Monitor Server Started.
Database server started for instance : wcs
```

```

Processing Service Name: Database
Database is already running.

Processing Service Name: FTP Service

Processing Service Name: TFTP Service

Processing Service Name: Matlab
FTP Service is disabled.

Processing Service Name: Matlab1
Starting Remoting Service: Matlab Server

Processing Service Name: Matlab2

Processing Service Name: NMS Server
Starting Remoting Service: Matlab Server Instance 1
Starting Remoting Service: Matlab Server Instance 2
Checking /tmp/remoting_launchout_Matlab1.lock...
Checking /tmp/remoting_launchout_Matlab.lock...
Checking /tmp/remoting_launchout_Matlab2.lock...
Executing startRemoting for Matlab2 ...
Executing startRemoting for Matlab1 ...
Executing startRemoting for Matlab ...
DEPENDENCY CHECK: Database
DB scheme update process starting..
DB scheme update process finished.
Starting NMS Server
Started TFTP Service
/opt/CSColumos/classloader-conf:/opt/CSColumos/lib/xmp/XMPCClassLoader-11.0.1.jar

Checking for running servers.
  Checking if DECAP is running.
    00:00 DECAP is not running.
00:00 Check complete. No servers running.
Unable to initialize com.mathworks.mwswing.MJStartup
Matlab pid = 9696
system property before init instance: null
Starting Remoting Instance: Matlab Server
Checking for Port 10555 availability... OK
Starting Remoting Service Web Server Matlab Server...
Warning: MATLAB does not support bit depths less than or equal to 8.
Figure windows may not be usable
Warning: latest version of matlab app-defaults file not found.
Contact your system administrator to have this file installed
Warning: Duplicate directory name: /opt/CSColumos/matlab/toolbox/compiler.
Remoting Service Web Server Matlab Server Started.
Starting Remoting Service Matlab Server...
Remoting 'Matlab Server' started successfully.
Unable to initialize com.mathworks.mwswing.MJStartup
Matlab1 pid = 9692
system property before init instance: null
Starting Remoting Instance: Matlab Server Instance 1
Checking for Port 10755 availability... OK
Starting Remoting Service Web Server Matlab Server Instance 1...
Warning: MATLAB does not support bit depths less than or equal to 8.
Figure windows may not be usable
Warning: latest version of matlab app-defaults file not found.
Contact your system administrator to have this file installed
Warning: Duplicate directory name: /opt/CSColumos/matlab/toolbox/compiler.
Remoting Service Web Server Matlab Server Instance 1 Started.
Starting Remoting Service Matlab Server Instance 1...
  00:09 DECAP setup complete.

```



```

Started executing compliance_db_set_up.sh Input = checkAndCreatePariTableOnSID
Remoting 'Matlab Server Instance 1' started successfully.
No Pari table creation needed on SID wcs
Setting/Clearing remote database parameters
Done waiting DB initialization
_outputHdlr check:log4j:WARN No appenders could be found for logger
(com.cisco.ciscoss1.provider.ciscojce.CiscoJCENativeCrypto).
Starting SAM daemon...
Done.
Done. Setting/Clearing remote database parameters
Starting DA daemon...
Starting Server ...
DASH_HOME = /opt/CSColumos/compliance
NCCMHOME = /opt/CSColumos/compliance
Asia/Kolkata
Starting NCCM server with Java memory 1024
Unable to initialize com.mathworks.mwswing.MJStartup
Matlab2 pid = 9693
system property before init instance: null
Starting Remoting Instance: Matlab Server Instance 2
Checking for Port 10756 availability... OK
Starting Remoting Service Web Server Matlab Server Instance 2...
Warning: MATLAB does not support bit depths less than or equal to 8.
Figure windows may not be usable
Warning: latest version of matlab app-defaults file not found.
Contact your system administrator to have this file installed
Warning: Duplicate directory name: /opt/CSColumos/matlab/toolbox/compiler.
Remoting Service Web Server Matlab Server Instance 2 Started.
Starting Remoting Service Matlab Server Instance 2...
Remoting 'Matlab Server Instance 2' started successfully.
Creating Application Context
Attempt 1: checking /opt/CSColumos/logs/remotingMatlab1-0-0.log and
/opt/CSColumos/logs/remoting_launchout_Matlab1.log whether Remoting Service Web
Server Matlab.* Started.
Detected: /opt/CSColumos/logs/remotingMatlab1-0-0.log:02/28/18 01:21:27.147 INFO
[system] [main] Remoting Service Web Server Matlab Server Instance 1 Started.
/opt/CSColumos/logs/remoting_launchout_Matlab1.log:Remoting Service Web Server
Matlab Server Instance 1 Started.
Completed launchout Matlab1 as 9692
Attempt 1: checking /opt/CSColumos/logs/remotingMatlab-0-0.log and
/opt/CSColumos/logs/remoting_launchout_Matlab.log whether Remoting Service Web
Server Matlab.* Started.
Detected: /opt/CSColumos/logs/remotingMatlab-0-0.log:02/28/18 01:21:21.247 INFO
[system] [main] Remoting Service Web Server Matlab Server Started.
/opt/CSColumos/logs/remoting_launchout_Matlab.log:Remoting Service Web Server
Matlab Server Started.
Completed launchout Matlab as 9696
Attempt 1: checking /opt/CSColumos/logs/remotingMatlab2-0-0.log and
/opt/CSColumos/logs/remoting_launchout_Matlab2.log whether Remoting Service Web
Server Matlab.* Started.
Detected: /opt/CSColumos/logs/remotingMatlab2-0-0.log:02/28/18 01:21:37.344 INFO
[system] [main] Remoting Service Web Server Matlab Server Instance 2 Started.
/opt/CSColumos/logs/remoting_launchout_Matlab2.log:Remoting Service Web Server
Matlab Server Instance 2 Started.
Completed launchout Matlab2 as 9693
Starting servlet container.
NMS Server started successfully

Processing Service Name: Compliance engine
Compliance Engine is enabled in this server
Compliance engine is already running.
Invoked post init hook - com.cisco.ifm.telemetry.config.UpdateProxyInitHook@5d67dec7

Prime Infrastructure started successfully.

```

```
iptables: Saving firewall rules to /etc/sysconfig/iptables:[ OK ]
Completed in 577 seconds
pi-common-133/admin#
```

```
pi-system-120/admin# ncs start
Starting Prime Infrastructure...
This may take a while (10 minutes or more) ...
_outputHdlr check:log4j:WARN No appenders could be found for logger \
(com.cisco.ciscossl.provider.ciscojce.CiscoJCENativeCrypto).
Prime Infrastructure started successfully.
iptables: Saving firewall rules to /etc/sysconfig/iptables:[ OK ]
Completed in 490 seconds
pi-system-120/admin#
```

Related Commands

Command	Description
ncs stop	Stops the Prime Infrastructure server.
ncs status	Displays the current status of the Prime Infrastructure server.

ncs status

To display the Prime Infrastructure server status, use the **ncs status** command in EXEC mode.

ncs status

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

EXEC

This example shows how to display the status of the server:

```
pi-system-117/admin# ncs status
Health Monitor Server is running. ( [Role] Primary [State] HA not Configured )
Database server is running
FTP Service is running
TFTP Service is running
Matlab Server is running
Matlab Server Instance 1 is running
NMS Server is running.
Coral Service is running.
WSA Service is running.
SAM Daemon is running ...
DA Daemon is running ...
```

Related Commands

Command	Description
ncs start	Starts the server.
ncs stop	Stops the server.

ncs stop

To stop the Prime Infrastructure server, use the **ncs stop** command in EXEC mode. To see the detailed messages, use the **ncs stop verbose** command.

ncs stop [verbose]

Syntax Description	verbose	Displays the detailed messages during the stop process.
Command Default	No default behavior or values.	
Command Modes	EXEC	
Usage Guidelines	To see the detailed messages, use the ncs stop verbose command.	

This example shows how to stop the Prime Infrastructure server:

```
pi-system-120/admin# ncs stop
Stopping Prime Infrastructure...
This may take a few minutes...
Database is not running.
FTP Service is not running.
TFTP Service is not running.
Matlab is not running.
Matlab1 is not running.
Matlab2 is not running.
Matlab3 is not running.
NMS Server is not running!.
Compliance engine is not running!.
Prime Infrastructure successfully shutdown.
log4j:WARN No appenders could be found for logger
(com.cisco.ciscoss1.provider.ciscojce.CiscoJCENativeCrypto).
log4j:WARN Please initialize the log4j system properly.
Stopping SAM daemon...
Checking for SAM daemon again ...
SAM Daemon not found...
Stopping DA daemon ...
Checking for DA daemon again ...
DA Daemon not found...
Compliance engine stopped
Completed shutdown of all services
pi-system-120/admin#
```

```
pi-common-133/admin# ncs stop verbose
Stopping Prime Infrastructure...
```

```
Status:Creating
ServerStartupStatus:Creating
ServerStartupStatus:Creating
ServerStartupStatus:Creating
ServerStartupStatus:Creating
ServerStartupStatus:Creating
ServerStartupStatus:Creating
ServerStartupStatus:Creating
ServerStartupStatus:Creating
ServerStartupStatus:Creating
ServerStartupStatus:Creating
```



```
Stopping DA daemon ...
Checking for DA daemon again ...
DA Daemon not found...
Completed shutdown of all services
```

Related Commands	Command	Description
	ncs start	Starts the Prime Infrastructure server.
	ncs status	Displays the current status of the Prime Infrastructure server.

ncs run tls-server-ciphers

You can enable a TLS cipher group using **ncs run tls-server-ciphers** command in EXEC mode.

```
ncs run tls-server-ciphers { tls-ecdhe-sha2 | tls-ecdhe-sha1 | tls-dhe-sha2 | tls-dhe-sha1 | tls-static-sha2 | tls-static-sha1 }
```

Syntax Description		
	tls-ecdhe-sha2	Refers to tls cipher group, ecdhe sha2
	tls-ecdhe-sha1	Refers to tls cipher group, ecdhe sha1
	tls-dhe-sha2	Refers to tls cipher group, dhe sha2
	tls-dhe-sha1	Refers to tls cipher group, dhe sha1
	tls-static-sha2	Refers to tls cipher group, static sha2
	tls-static-sha1	Refers to tls cipher group, static sha1

Command Default

The default cipher group is **tls-ecdhe-sha2**

EXEC

```
pi/admin# ncs run tls-server-ciphers tls-ecdhe-sha1
```

```
Enabled TLS cipher groups are - tls-ecdhe-sha1
```

```
Restart is required for the changes to take effect
```

ncs password ftpuser

To change the FTP username and password, use the **ncs password ftpuser** command in EXEC mode.



Note

The value for ftpuser in the above command should always be set to ftp-user.

After you enable the ftp-user, you can FTP files to and from the /localdisk/ftp folder on standalone or, if configured, High Availability primary servers only. You cannot use change directory (cd) or list directory (ls) functionality with ftp-user.

ncs password ftpuser *ftp-user password password*

Syntax Description	<i>ftp-user</i>	The FTP user name
Command Default	No default behavior or values.	
Command Modes	EXEC	

This example shows how to change the FTP username and password:

```
pi-system-65/admin# ncs password ftpuser ftp-user password Password123
Updating FTP password
Saving FTP account password in credential store
Synching FTP account passwd to database store - location-ftp-user
Synching FTP account password to system store
Completed FTP password update
pi-system-65/admin#
```

ncs password root password

To change the root password, use the **ncs password root password** command in EXEC mode.

ncs password root password *userpassword*

Syntax Description	<i>userpassword</i>	Password for the root user.
Command Default	No default behavior or values.	
Command Modes	EXEC	

Prime Infrastructure

This example shows how to migrate archived files to server:

```
pi-systems/admin# ncs password root password Userpassword
Password updated for web root user
pi-systems/admin#
```

ncs ha authkey

To enter the authentication key for high availability (HA), use the **ncs ha authkey** command in EXEC mode.

ncs ha authkey *authorization key*

Syntax Description *authorization key* The authorization key for high availability. Up to 81 alphanumeric characters.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines The **ncs ha authkey** command changes the authorization for the health monitor.

This example shows how to set up the authorization key for high availability:

```
pi-system/admin#ncs ha authkey cisco123
Going to update primary authentication key
Successfully updated primary authentication key
Successfully intimated Primary updated authentication key to Secondary Server
pi-system/admin#
```

Related Commands

Command	Description
ncs ha remove	Removes the high availability configuration settings from Prime Infrastructure.
ncs ha status	Provides the current status of high availability.

ncs ha remove

To remove the high availability configuration settings from Prime Infrastructure, use the **ncs ha remove** command in EXEC mode.

ncs ha remove

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines The **ncs ha remove** command removes the high availability configuration settings from Prime Infrastructure. If you enter this command, you will see the following confirmation message:

```
High availability configuration will be removed.
Do you wish to continue? (Y/N)
```

Example

```
pi-system/admin# ncs ha remove
High availability configuration will be removed
Do you wish to continue? (y/N) y

Removing primary configuration will remove all database information
Primary is attempting to remove high availability configuration from both primary \
```



```
and secondary
Successfully removed high availability configuration
pi-system/admin#
```

Related Commands	Command	Description
	ncs ha authkey	Allows you to enter the authentication key for high availability in Prime Infrastructure. This command also changes the authorization for the health monitor.
	ncs ha status	Provides the current status of high availability.

ncs ha status

To display the current status of high availability (HA), use the **ncs ha status** command in EXEC mode.

ncs ha status

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Displays the current status of HA.

If you enter the **ncs ha status** command when HA is not configured, you will see the following response:

```
[State] Stand Alone
```

Example 1: When HA is not configured

```
pi-system/admin# ncs ha status
[Role] Primary [State] HA not Configured
pi-systems/admin#
```

Example 2: When HA is configured

In Primary server:

```
pi-system/admin# ncs ha status
[Role] Primary [Secondary Server] 10.197.71.162(10.197.71.162) [State] Primary
Active [Failover Type] Automatic
pi-system/admin#
```

In Secondary server:

```
pi-system/admin# ncs ha status
[Role] Secondary [Primary Server] pi-system-161(10.197.71.161) [State] Secondary
Syncing [Failover Type] Automatic
pi-system/admin#
```

Related Commands

Command	Description
ncs ha authkey	Allows you to enter the authentication key for high availability in Prime Infrastructure. This command also changes the authorization for the health monitor.
ncs ha remove	Removes the high availability configuration.

ncs key genkey

To generate a new RSA key and self-signed certificate, use the **ncs key genkey** command. You can use this command in the following ways:

ncs key genkey -newdn -csr csrfilename repository repositoryname

Syntax Description

genkey	Generates a new RSA key and self-signed certificate. You can use the following options with this command: -csr : Generate Certificate Signing Request(CSR) file -newdn : Generate new RSA key and self-signed certificate with domain information <cr>: Carriage return.
-newdn	Generates a new RSA key and self-signed cert with domain information. You can use the following options with this command: -csr : Generate Certificate Signing Request(CSR) file <cr>: Carriage return.
-csr	Generates new CSR certificate file. You can use the following option with this command: <WORD>: Type in certificate file name (Max Size - 80)
<i>csrfilename</i>	CSR filename.
repository	Repository command. This option is available when you use the -csr option.
<i>repositoryname</i>	Location where the files should be backed up to. Up to 80 alphanumeric characters.

Command Default

No default behavior or values.

Command Modes EXEC

This example shows how to generate new rsa key and certificate files in the Prime Infrastructure server:

```
pi-cluster-88/admin# ncs key genkey -newdn -csr test.csr repository defaultRepo

Changes will take affect on the next server restart
Enter the fully qualified domain name of the server !!!!!: pi-cluster-88.cisco.com
Enter the name of your organization unit !!!!!!!!!!!!!!!: cisco
Enter the name of your organization !!!!!!!!!!!!!!!: hcl
Enter the name of your city or locality !!!!!!!!!!!!!!!: chennai
Enter the name of your state or province !!!!!!!!!!!!!!!: tn
Enter the two letter code for your country !!!!!!!!!!!!!!!: US
Specify subject alternate names.
If none specified, CN will be used.
Use comma separated list - DNS:<name>,IP:<address> !!!!!: \
DNS:pi-cluster-88.cisco.com,IP:10.126.168.88

Specify the public key algorithm [rsa/ec] !!!!!!!!!!!!!!!: rsa
Specify the RSA key size [2048/4096/8192] !!!!!!!!!!!!!!!: 4096
Specify the signature algorithm [sha256/sha512] !!!!!!!!!!!!!!!: sha256

Key and CSR/Certificate will be generated with following details
Subject : \
/C=US/ST=tn/L=chennai/O=hcl/OU=cisco/CN=pi-cluster-88.cisco.com
Subject Alternate Name : DNS:pi-cluster-88.cisco.com,IP:10.126.168.88
Public Key Alg : rsa, 4096
Signature Alg : sha256

Continue [yes] : yes
Generating...
Completed generating new key...Changes will take affect on the next server restart
Note: You can provide comma separated list of FQDN and IP of PI servers where you want to
import the same certificate received from CA.
To import same CA in other server, you need to import the key from the server where you
generate CSR and them import the CA certiificates.
```



Note You will get csr file generated in location where repository is pointing. Use that csr file get CA certificate or signed certificate from any CA agent.

Related Commands

Command	Description
ncs key importsignedcert	Applies an RSA key and signed certificate to Prime Infrastructure.
ncs key importkey	Applies an RSA key and certificate to Prime Infrastructure.



Note After entering this command, enter the **ncs stop** and **ncs start** command to restart the Prime Infrastructure server to make changes take effect.

ncs key importkey

To apply an RSA key and signed certificate to the Prime Infrastructure, use the **ncs key importkey** command in EXEC mode.

To export key:

```
ncs key exportkey key-filename cert-filename repository repositoryname
```

To import key:

```
ncs key importkey key-filename cert-filename repository repositoryname
```

Syntax Description

<i>key-filename</i>	RSA private key file name.
<i>cert-filename</i>	Certificate file name.
repository	Repository command
<i>repositoryname</i>	The repository name configured in the Prime Infrastructure where the key-file and cert-file is hosted.

Command Default

No default behavior or values.

Command Modes

EXEC

This example shows how to apply the new RSA key and certificate files to the server.

```
ncs key exportkey private.key server.cer repository defaultRepo
```

```
ncs key importkey keyfile certfile repository ncs-sftp-repo
```



Note

After applying this command, enter the **ncs stop** and **ncs start** command to restart the server to make the changes take effect.

Related Commands

Command	Description
ncs key genkey	Generates a new RSA key and self-signed certificate.
ncs key importsigncert	Applies an RSA key and signed certificate to Prime Infrastructure.

ncs key importsigncert

To apply an RSA key and signed certificate, use the **ncs key importsigncert** command EXEC mode.

```
ncs key importsigncert signed-cert-filename repository repositoryname
```

Syntax Description	<i>signed-cert-filename</i>	Signed certificate filename.
	repository	Repository command
	<i>repositoryname</i>	The repository name configured in Prime Infrastructure where the key-file and cert-file is hosted.

Command Default No default behavior or values.

Command Modes EXEC

This example shows how to apply signed certificate files to the Prime Infrastructure server:

```
> ncs key importsingedcert signed-certfile repository ncs-sftp-repo
```



Note After applying this command, enter the **ncs stop** and the **ncs start** command to restart the Prime Infrastructure server to make changes take effect.

Related Commands	Command	Description
	ncs key genkey	Generates a new RSA key and self-signed certificate.
	ncs key importkey	Applies an RSA key and signed certificate to Prime Infrastructure.

ncs certvalidation certificate-check

To enable or disable certificate validation, use **ncs certvalidation certificate-check** command in EXEC mode.

```
ncs certvalidation certificate-check {disable | enable | trust-on-first-use } trustzone trustzone_name
```

Syntax Description	<i>disable</i>	Disable certificate validation
	<i>enable</i>	Enable certificate validation
	<i>trust-on-first-use</i>	Trust and pin the host certificate on first use
	<i>trustzone_name</i>	Name of the trustzone

Command Default No default behavior or values.

Command Modes EXEC

```
pi-system/admin# ncs certvalidation certificate-check trust-on-first-use trustzone system
```

```
ncs certvalidation certificate-check enable trustzone system
```

ncs certvalidation custom-ocsp-responder

To configure a custom OCSP responder, use **ncs certvalidation custom-ocsp-responder** command in EXEC mode.

```
ncs certvalidation custom-ocsp-responder { clear url | disable | enable | set url }
```

Syntax Description

clear	Clear OCSP responder URL
disable	Disable custom OCSP responder
enable	Enable custom OCSP responder
set	Set OCSP responder URL

Command Default

No default behavior or values.

Command Modes

EXEC

```
pi-system/admin# ncs certvalidation custom-ocsp-responder enable
pi-system/admin# ncs certvalidation custom-ocsp-responder set url1 http://10.104.119.201
pi-system/admin# ncs certvalidation custom-ocsp-responder clear url1
pi-system/admin# ncs certvalidation custom-ocsp-responder disable
```

ncs certvalidation revocation-check

To enable or disable revocation check using OCSP or CRL, use **ncs certvalidation revocation-check** command in EXEC mode.

```
ncs certvalidation revocation-check { disable | enable } trustzone { devicemgmt | pubnet | system | user }
```

Syntax Description

<i>disable</i>	Disable certificate revocation
<i>enable</i>	Enable certificate revocation

Command Default

No default behavior or values.

Command Modes

EXEC

```
pi-system/admin# ncs certvalidation revocation-check enable trustzone system
pi-system/admin#
```

ncs certvalidation tofu-certs

To view and delete certificates trusted on first use, use **ncs certvalidation tofu-certs** command in EXEC mode.

ncs certvalidation tofu-certs { **listcerts** | **deletecert host** *host_name* }

Syntax Description		
<i>deletecert</i>		Delete a trust-on-first-use cert for a host
<i>listcerts</i>		List certificates trusted on first use
<i>trust-on-first-use</i>		Trust and pin the host certificate on first use
<i>trustzone_name</i>		Name of the trustzone

Command Default No default behavior or values.

Command Modes EXEC

Example 1: listcert

```
pi-system/admin# ncs certvalidation tofu-certs listcerts
Host certificate are automatically added to this list on first connection, if
trust-on-first-use is configured - ncs certvalidation certificate-check ...
host=10.197.71.121_8082; subject= /C=US/ST=CA/L=SJ/O=Cisco Systems/OU=Prime
Infra/CN=pi-system-121
pi-system/admin#
```

Example 2: deletecerts

```
pi-system/admin# ncs certvalidation tofu-certs deletecert host 10.197.71.121_8082
Deleted entry for 10.197.71.121_8082
pi-system/admin#
```

ncs certvalidation trusted-ca-store

To configure a trusted CA certificate store, use **ncs certvalidation trusted-ca-store** command in EXEC mode.

ncs certvalidation trusted-ca-store { **auto-ca-update** { **enable** | **disable truststore** *truststore_name* } | **deletecert alias** { *alias_name* **truststore** *truststore_name* { **devicemgmt** | **pubnet** | **system** | **user** } } | **importcert alias** *alias_name* **repository** *repository_name* **truststore** *truststore_name* | **listcerts truststore** *truststore_name* }

Syntax Description		
<i>auto-ca-update</i>		Auto update list of trusted CA certs during software update
<i>deletecert</i>		Enable certificate validation
<i>importcert</i>		Import a certificate to the trust store
<i>listcerts</i>		List all trusted CA certificates
<i>truststore_name</i>		Name of the truststore

devicemgmt	Trust store used for validating cert from managed devices
pubnet	Trust store used for validating cert from public internet
system	Trust store used for validating cert from other peer systems
user	Trust store used for validating cert for user login

Command Default No default behavior or values.

Command Modes Configuration

Example 1: auto-ca-update

```
pi-system/admin# ncs certvalidation trusted-ca-store auto-ca-update enable truststore system
pi-system/admin# ncs certvalidation trusted-ca-store auto-ca-update disable truststore
system
pi-system/admin#
```

Example 2: deletecacert

```
pi-system/admin# ncs certvalidation trusted-ca-store deletecacert alias quovadisroot
truststore system
Deleted CA certificate from trust store. Changes will take affect on the next server restart
pi-system/admin#
```

Example 3: importcacert

```
pi-system/admin# ncs certvalidation trusted-ca-store importcacert alias ALIAS repository
defaultRepo prime.cer truststore system
Imported CA certificate to trust store. Changes will take affect on the next server restart
pi-system/admin#
```

Example 3: listcacert

```
pi-system/admin# ncs certvalidation trusted-ca-store listcacerts truststore pubnet
ciscoeccrootca, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): 52:EC:7D:BB:5C:65:11:DD:C1:C5:46:DB:BC:29:49:B5:AB:E9:D0:EE
ciscorootcam2, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): 93:3D:63:3A:4E:84:0D:A4:C2:8E:89:5D:90:0F:D3:11:88:86:F7:A3
ciscorootca2048, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): DE:99:0C:ED:99:E0:43:1F:60:ED:C3:93:7E:7C:D5:BF:0E:D9:E5:FA
ciscorootcam1, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): 45:AD:6B:B4:99:01:1B:B4:E8:4E:84:31:6A:81:C2:7D:89:EE:5C:E7
quovadisrootca2, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): CA:3A:FB:CF:12:40:36:4B:44:B2:16:20:88:80:48:39:19:93:7C:F7
ciscorootca2099, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): AC:1E:DE:2E:1C:97:0F:ED:3E:E8:5F:8C:3A:CF:E2:BA:C0:4A:13:76
ciscolicensingrootca, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): 5C:A9:5F:B6:E2:98:0E:C1:5A:FB:68:1B:BB:7E:62:B5:AD:3F:A8:B8
verisignclass3publicprimarycertificationauthorityg5, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): 4E:B6:D5:78:49:9B:1C:CF:5F:58:1E:AD:56:BE:3D:9B:67:44:A5:E5
ciscorxcr2, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): 2C:8A:FF:CE:96:64:30:BA:04:C0:4F:81:DD:4B:49:C7:1B:5B:81:A0
digicertglobalrootca, Nov 28, 2018, trustedCertEntry,
Certificate fingerprint (SHA1): A8:98:5D:3A:65:E5:E5:C4:B2:D7:D6:6D:40:C6:DD:2F:B1:9C:54:36
pi-system/admin#
```


ncs cleanup

To clean up the following data, below data free up and reclaim the disk space, use the **ncs cleanup** command in EXEC mode.

- Files under /opt/backup
- *.m-n.logs, *.n.logs, *.log.n log files under /opt/CSCOLumos/logs
- Regular files under /localdisk
- .hprof file under opt/CSCOLumos/crash
- Matlab*.log under /opt/tmp/
- .trm and .trc files under /opt/oracle/base/diag/rdbms/**/trace
- Older expired Archive logs and backup set under /opt/oracle/base/fast_recovery_area/WCS

ncs cleanup

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

When Prime Infrastructure does not have enough disk space, an alarm is raised to free up and reclaim the disk space. If you enter the **ncs cleanup** command, you will see the following confirmation message:

```
Do you want to delete all the files in the local disk partition? (Y/N)
```

```
pi-system-117/admin# ncs cleanup
Starting Cleanup: Wed Feb 28 01:50:44 IST 2019
=====
{Wed Aug 12 01:50:47 IST 2019} Removing all files in backup staging directory
{Wed Aug 12 01:50:47 IST 2019} Removing all Matlab core related files
  {Wed Aug 12 01:50:47 IST 2019} Removing all older log files
  {Wed Aug 12 01:50:47 IST 2019} Cleaning older archive logs
{Wed Aug 12 01:51:03 IST 2019} Cleaning database backup and all archive logs
{Wed Aug 12 01:51:03 IST 2019} Cleaning older database trace files
{Wed Aug 12 01:51:03 IST 2019} Removing all user local disk files
{Wed Aug 12 01:51:03 IST 2019} Cleaning database
{Wed Aug 12 01:51:05 IST 2019} Stopping server
{Wed Aug 12 01:52:05 IST 2019} Not all server processes stop. Attempting to stop \ remaining

  {Wed Aug 12 01:52:05 IST 2019} Stopping database
  {Wed Aug 12 01:52:07 IST 2019} Starting database
  {Wed Aug 12 01:52:20 IST 2019} Starting database clean
  {Wed Aug 12 01:58:50 IST 2019} Completed database clean
{Wed Aug 12 01:58:50 IST 2019} Stopping database
{Wed Aug 12 01:59:14 IST 2019} Starting server
=====
Completed Cleanup
Start Time: Mon Aug 28 01:50:44 IST 2019
Completed Time: Mon Aug 28 02:07:07 IST 2019
pi-system-117/admin#
```

nslookup

To look up the hostname of a remote system on the Prime Infrastructure server, use the **nslookup** command in EXEC mode.

nslookup *word*

Syntax Description	<i>word</i>	IPv4 address or hostname of a remote system. Up to 63 alphanumeric characters.
Command Default	No default behavior or values.	
Command Modes	EXEC	

Example 1

```
ncs/admin# nslookup 209.165.200.225
Trying "209.165.200.225.in-addr.arpa"
Received 127 bytes from 172.16.168.183#53 in 1 ms
Trying "209.165.200.225.in-addr.arpa"
Host 209.165.200.225.in-addr.arpa. not found: 3(NXDOMAIN)
Received 127 bytes from 172.16.168.183#53 in 1 ms
```

```
ncs/admin#
```

Example 2

```
ncs/admin# nslookup 209.165.200.225
Trying "225.200.165.209.in-addr.arpa"
;; ->>HEADER<<- opcode: QUERY, status: NOERROR, id: 65283
;; flags: qr rd ra; QUERY: 1, ANSWER: 1, AUTHORITY: 2, ADDITIONAL: 0

;; QUESTION SECTION:
;225.200.165.209.in-addr.arpa. IN PTR

;; ANSWER SECTION:
225.200.165.209.in-addr.arpa. 86400 IN PTR 209-165-200-225.got.net.

;; AUTHORITY SECTION:
192.168.209.in-addr.arpa. 86400 IN NS ns1.got.net.
192.168.209.in-addr.arpa. 86400 IN NS ns2.got.net.
```

```
Received 119 bytes from 172.16.168.183#53 in 28 ms
```

```
ncs/admin#
```

ocsp

Online Certificate Status Protocol (OCSP) enables certificate-based authentication for web clients using OCSP responders. Typically, the OCSP responder's URL is read from the certificate's Authority Information Access (AIA). As a failover mechanism, you can configure the same URL on the Prime Infrastructure server as well.

You can enable or disable a custom OCSP responder, and set or remove OCSP responder URLs, using **ocsp responder** command in EXEC mode.

ocsp responder { *remove* | *set* | *show* }

Syntax Description	clear	Clear OCSP responder URL
	custom	Enable or disable custom OCSP responder
	set	Set OCSP responder URL.

Command Default No default behaviour.

Command Modes EXEC

```
ncs/admin# ocs p responder
ncs/admin# ocs p responder custom enable

ncs/admin# ocs p responder set url1 <WORD>
<WORD> Enter ocs p url (Max Size - 1024)

ncs/admin# ocs p responder clear url1
```

ping

To diagnose the basic IPv4 network connectivity to a remote system, use the **ping** command in EXEC mode.

ping {*ip-address* | *hostname*} [**Df**df][**packetsize**packetsize][**pingcount**pingcount]

Syntax Description	<i>ip-address</i>	IP address of the system to ping. Up to 32 alphanumeric characters.
	<i>hostname</i>	Hostname of the system to ping. Up to 32 alphanumeric characters.
	df	Specification for packet fragmentation.
	<i>df</i>	Specifies the value as 1 to prohibit packet fragmentation, or 2 to fragment the packets locally, or 3 to not set df.
	packetsize	Size of the ping packet.
	<i>packetsize</i>	Specifies the size of the ping packet; the value can be between 0 and 65507.
	pingcount	Number of ping echo requests.
	<i>pingcount</i>	Specifies the number of ping echo requests; the value can be between 1 and 10.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines The **ping** command sends an echo request packet to an address, then awaits a reply. The ping output can help you evaluate path-to-host reliability, delays over the path, and whether you can reach a host.

```
ncs/admin# ping 172.16.0.1 df 2 packetsize 10 pingcount 2
PING 172.16.0.1 (172.16.0.1) 10(38) bytes of data.
18 bytes from 172.16.0.1: icmp_seq=0 ttl=40 time=306 ms
18 bytes from 172.16.0.1: icmp_seq=1 ttl=40 time=300 ms

--- 172.16.0.1 ping statistics ---
2 packets transmitted, 2 received, 0% packet loss, time 1001ms
rtt min/avg/max/mdev = 300.302/303.557/306.812/3.255 ms, pipe 2
ncs/admin#
```

Related Commands

Command	Description
ping6	Pings a remote IPv6 address.

ping6

To diagnose the basic IPv6 network connectivity to a remote system, use the **ping6** command in EXEC mode.

ping6 *{ip-address | hostname}* [**GigabitEthernet***packetsize*]*[pingcount]*

Syntax Description		
<i>ip-address</i>		IP address of the system to ping. Up to 64 alphanumeric characters.
<i>hostname</i>		Hostname of the system to ping. Up to 64 alphanumeric characters.
GigabitEthernet		Selects the ethernet interface.
packetsize		Size of the ping packet.
<i>packetsize</i>		Specifies the size of the ping packet; the value can be between 0 and 65507.
pingcount		Number of ping echo requests.
<i>pingcount</i>		Specifies the number of ping echo requests; the value can be between 1 and 10.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines The IPv6 **ping6** command sends an echo request packet to an address, then awaits a reply. The ping output can help you evaluate path-to-host reliability, delays over the path, and whether you can reach a host.

The IPv6 **ping6** command is similar to the existing IPv4 ping command that does not support the IPv4 ping fragmentation (df in IPv4) options, but allows an optional specification of an interface. The interface option is primarily useful for pinning with link-local addresses that are interface-specific. The packetsize and pingcount options work identically the same as they do with the IPv4 command.

Example 1

```
ncs/admin# ping6 3ffe:302:11:2:20c:29ff:feaf:da05
PING 3ffe:302:11:2:20c:29ff:feaf:da05(3ffe:302:11:2:20c:29ff:feaf:da05) from
3ffe:302:11:2:20c:29ff:feaf:da05 eth0: 56 data bytes
64 bytes from 3ffe:302:11:2:20c:29ff:feaf:da05: icmp_seq=0 ttl=64 time=0.599 ms
64 bytes from 3ffe:302:11:2:20c:29ff:feaf:da05: icmp_seq=1 ttl=64 time=0.150 ms
64 bytes from 3ffe:302:11:2:20c:29ff:feaf:da05: icmp_seq=2 ttl=64 time=0.070 ms
64 bytes from 3ffe:302:11:2:20c:29ff:feaf:da05: icmp_seq=3 ttl=64 time=0.065 ms

--- 3ffe:302:11:2:20c:29ff:feaf:da05 ping statistics ---
4 packets transmitted, 4 received, 0% packet loss, time 3118ms
rtt min/avg/max/mdev = 0.065/0.221/0.599/0.220 ms, pipe 2

ncs/admin#
```

Example 2

```
ncs/admin# ping6 3ffe:302:11:2:20c:29ff:feaf:da05 GigabitEthernet 0 packetsize 10 pingcount
2
PING 3ffe:302:11:2:20c:29ff:feaf:da05(3ffe:302:11:2:20c:29ff:feaf:da05) from
3ffe:302:11:2:20c:29ff:feaf:da05 eth0: 10 data bytes
18 bytes from 3ffe:302:11:2:20c:29ff:feaf:da05: icmp_seq=0 ttl=64 time=0.073 ms
18 bytes from 3ffe:302:11:2:20c:29ff:feaf:da05: icmp_seq=1 ttl=64 time=0.073 ms

--- 3ffe:302:11:2:20c:29ff:feaf:da05 ping statistics ---
2 packets transmitted, 2 received, 0% packet loss, time 1040ms
rtt min/avg/max/mdev = 0.073/0.073/0.073/0.000 ms, pipe 2

ncs/admin#
```

Related Commands

	Description
ping	Pings a remote IP address.

reload

To reload the Prime Infrastructure operating system, use the **reload** command in EXEC mode.

reload

Syntax Description

This command has no arguments or keywords.

Command Default

The command has no default behavior or values.

Command Modes

EXEC

Usage Guidelines

The **reload** command reboots the system. Use the **reload** command after you enter configuration information into a file and save the running-configuration to the persistent startup-configuration on the CLI and save any settings in the web Administration user interface session.

Before you enter the **reload** command, ensure that the Prime Infrastructure is not performing any backup, restore, installation, upgrade, or remove operation. If the Prime Infrastructure performs any of these operations and you enter the **reload** command, you will notice any of the following warning messages:

```
WARNING: A backup or restore is currently in progress! Continue with reload?
```

```
WARNING: An install/upgrade/remove is currently in progress! Continue with reload?
```

If you get any of these warnings, enter YES to halt the operation, or enter NO to cancel the halt.

If no processes are running when you use the **reload** command or you enter YES in response to the warning message displayed, the Prime Infrastructure asks you to respond to the following option:

```
Do you want to save the current configuration ?
```

Enter YES to save the existing Prime Infrastructure configuration. The Prime Infrastructure displays the following message:

```
Saved the running configuration to startup successfully
```

```
ncs/admin# reload
Do you want to save the current configuration ? (yes/no) [yes] ? yes
Generating configuration...
Saved the running configuration to startup successfully
Continue with reboot? [y/n] y
```

```
Broadcast message from root (pts/0) (Fri Aug 7 13:26:46 2010):
```

```
The system is going down for reboot NOW!
```

```
ncs/admin#
```

Related Commands

Command	Description
halt	Disables the system.

restore

To perform a restore of a previous backup, use the **restore** command in EXEC mode.

Application Backup Restore:

Use the following command to restore data related only to Prime Infrastructure application:

```
restore filename repository repository-name application application-name
```

Application Backup Restore

Use the following command to restore data related to the Prime Infrastructure application and Cisco ADE OS:

restore *filename* **repository** *repository-name*

Syntax Description	<i>filename</i>	Name of the backed-up file that resides in the repository. Up to 120 alphanumeric characters. Note You must add the .tar.gpg extension after the filename (for example, myfile.tar.gpg).
	repository	The repository keyword.
	<i>repository-name</i>	Name of the repository you want to restore from backup.
	application	The application keyword.
	<i>application-name</i>	The name of the application data to be restored. Up to 255 alphanumeric characters. Note Enter the application name as 'PI' in upper case.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines A restore operation restores data related to the Prime Infrastructure as well as the Cisco ADE OS. To perform a restore of a previous backup of the application data of the Prime Infrastructure only, add the **application** command to the **restore** command in EXEC mode.

When you use these two commands in the Prime Infrastructure, the Prime Infrastructure server restarts automatically.

```
pi-system-120/admin# restore
pi-system-173-190908-0334__VER3.7.0.0.159_BKSZ26G_CPU4_MEM3G_RAM11G_SWAP15G_APP_CK218281319.tar.gpg
 repository defaultRepo application NCS
* NOTE *
If the system console is disconnected or got cleared on session timeout
run 'show restore log' to see the output of the last restore session.

Restore will restart the application services. Continue? (yes/no) [yes] ?

DO NOT press ^C while the restoration is in progress
Aborting restore with a ^C may leave the system in a unrecoverable state

Enter the backup password, if your backup is password protected. Otherwise, press Enter to
continue the data restoration.

Password :
Initiating restore. Please wait...
Restore Started at 08/09/19 22:59:05
Stage 1 of 9: Transferring backup file ...
-- completed at 08/09/19 22:59:15
Stage 2 of 9: Decrypting backup file ...
-- completed at 08/09/19 23:02:24
Stage 3 of 9: Unpacking backup file ...
-- completed at 08/09/19 23:02:25
Stopping PI server ...
```

```

Stage 4 of 9: Decompressing backup ...
-- completed at 08/09/19 23:18:58
Stage 5 of 9: Restoring Support Files ...
-- completed at 08/09/19 23:19:07
Stage 6 of 9: Restoring Database Files ...
-- completed at 08/09/19 23:19:43
Stage 7 of 9: Recovering Database ...
-- completed at 08/09/19 23:28:42
Stage 8 of 9: Updating Database Schema ...
  This could take long time based on the existing data size.
    Stage 1 of 5: Pre Migration Schema Upgrade ...
-- completed at: 2019-08-09 23:32:46.091, Time Taken
: 0 hr, 4 min, 1 sec
    Stage 2 of 5: Schema Upgrade ...
-- completed at: 2019-08-09 23:53:56.668, Time Taken
: 0 hr, 21 min, 9 sec
    Stage 3 of 5: Post Migration Schema Upgrade ...
-- completed at: 2019-08-09 23:54:17.489, Time Taken
: 0 hr, 0 min, 19 sec
    Stage 4 of 5: Enabling DB Constraints ...
-- completed at: 2019-08-09 23:54:53.179, Time Taken
: 0 hr, 0 min, 34 sec
    Stage 5 of 5: Finishing Up ...
-- completed at: 2019-08-09 23:55:12.431, Time Taken
: 0 hr, 0 min, 18 sec
-- completed at 08/09/19 23:55:43
Stage 9 of 9: Re-enabling Database Settings ...
-- completed at 08/10/19 00:24:32
Total Restore duration is: 01h:25m:27s
INFO: Restore completed successfully.

Starting Prime Infrastructure...

This may take a while (10 minutes or more) ...

Prime Infrastructure started successfully.

Redirecting to /bin/systemctl restart rsyslog.service
Completed in 1207 seconds

```

Related Commands

Command	Description
backup	Performs a backup (Prime Infrastructure and Cisco ADE OS) and places the backup in a repository.
show restore, on page 117	Displays the restore history.
repository	Enters the repository submode for configuration of backups.
show repository	Displays the available backup files located on a specific repository.
show backup history	Displays the backup history of the system.

rmdir

To remove an existing directory, use the **rmdir** command in EXEC mode.

rmdir *word*

Syntax Description	<i>word</i>	Directory name. Up to 80 alphanumeric characters.
---------------------------	-------------	---

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	EXEC
----------------------	------

```

ncs/admin# mkdir disk:/test
ncs/admin# dir

Directory of disk:/

   4096 May 06 2010 13:34:49  activemq-data/
   4096 May 06 2010 13:40:59  logs/
 16384 Mar 01 2010 16:07:27  lost+found/
   4096 May 06 2010 13:42:53  target/
   4096 May 07 2010 12:26:04  test/

Usage for disk: filesystem
      181067776 bytes total used
      19084521472 bytes free
      20314165248 bytes available

ncs/admin#

ncs/admin# rmdir disk:/test
ncs/admin# dir

Directory of disk:/

   4096 May 06 2010 13:34:49  activemq-data/
   4096 May 06 2010 13:40:59  logs/
 16384 Mar 01 2010 16:07:27  lost+found/
   4096 May 06 2010 13:42:53  target/

Usage for disk: filesystem
      181063680 bytes total used
      19084525568 bytes free
      20314165248 bytes available

ncs/admin#

```

Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>dir</td> <td>Displays a list of files on the Prime Infrastructure server.</td> </tr> <tr> <td>mkdir</td> <td>Creates a new directory.</td> </tr> </tbody> </table>	Command	Description	dir	Displays a list of files on the Prime Infrastructure server.	mkdir	Creates a new directory.
Command	Description						
dir	Displays a list of files on the Prime Infrastructure server.						
mkdir	Creates a new directory.						

rsakey

To display a configured RSA key or to set a new RSA public key for user authentication, use **rsakey** command in EXEC mode. You can also use it to remove a configured RSA key.

rsakey { remove | set | show }

Syntax Description	remove	Description
	remove	Remove RSA public key for user authentication.
	set	Set RSA public key for user authentication.
	show	Show RSA public key for user authentication.

Command Default No default behaviour.

Command Modes EXEC

```
ncs/admin# rsakey
ncs/admin# rsakey show
No RSA key configured for user 'admin'
```

```
ncs/admin# rsakey remove
No RSA key configured for user 'admin'
```

```
ncs/admin# rsakey set <WORD>
<WORD> Filename of RSA public key (Max Size - 256)
```

show

To show the running system information, use the **show** command in EXEC mode. The **show** commands are used to display the Prime Infrastructure settings and are among the most useful commands.

The commands in [Table A-6](#) require the **show** command to be followed by a keyword; for example, **show application status**. Some **show** commands require an argument or variable after the keyword to function; for example, **show application version**.

For detailed information on all of the Prime Infrastructure **show** commands, see [show Commands](#).

show keyword

Syntax Description

Table 10: Summary of show Commands

Command(1)	Description
application (requires keyword)(2)	Displays information about the installed application; for example, status or version.
backup (requires keyword)	Displays information about the backup.

Command(1)	Description
cdp (requires keyword)	Displays information about the enabled Cisco Discovery Protocol interfaces.
clock	Displays the day, date, time, time zone, and year of the system clock.
cpu	Displays CPU information.
disks	Displays file-system information of the disks.
interface	Displays statistics for all of the interfaces configured on the Cisco ADE OS.
logging (requires keyword)	Displays system logging information.
logins (requires keyword)	Displays login history.
memory	Displays memory usage by all running processes.
ntp	Displays the status of the Network Time Protocol (NTP).
ports	Displays all of the processes listening on the active ports.
process	Displays information about the active processes of the Prime Infrastructure server.
repository (requires keyword)	Displays the file contents of a specific repository.
restore (requires keyword)	Displays restore history on the Prime Infrastructure server.
running-config	Displays the contents of the currently running configuration file on the Prime Infrastructure server.
startup-config	Displays the contents of the startup configuration on the Prime Infrastructure server.
tech-support	Displays system and configuration information that you can provide to the TAC when you report a problem.
terminal	Displays information about the terminal configuration parameter settings for the current terminal line.

Command(1)	Description
timezone	Displays the time zone of the Prime Infrastructure server.
timezones	Displays all of the time zones available for use on the Prime Infrastructure server.
udi	Displays information about the unique device identifier (UDI) of the Prime Infrastructure.
uptime	Displays how long the system you are logged in to has been up and running.
users	Displays information for currently logged in users.
version	Displays information about the installed application version.

[12](#)

- ¹ (1) The commands in this table require that the show command precedes a keyword; for example, show application.
- ² (2) Some show commands require an argument or variable after the keyword to function; for example, show application version. This show command displays the version of the application installed on the system (see [show application](#)).

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines All **show** commands require at least one keyword to function.

```
pi-system-117/admin# show application
name          Description
NCS           Cisco Prime Infrastructure
pi-system-117/admin#

pi-system-226/admin# show version
Cisco Application Deployment Engine OS Release: 4.1
ADE-OS Build Version: 4.1.0.001
ADE-OS System Architecture: x86_64
Copyright (c) 2009-2020 by Cisco Systems, Inc.
All rights reserved.
Hostname: pi-system-226

Version information of installed applications
-----
Cisco Prime Infrastructure
*****
Version : 3.8.0 [FIPS not Enabled]
Build : 3.8.0.0.310
pi-system-226/admin#
```

ssh

To start an encrypted session with a remote system, use the **ssh** command in EXEC mode.



Note An Admin or Operator (user) can use this command (see [Table 2: Command Privileges](#)).

```
ssh [ip-address | hostname] usernameport[number]version[1|2] delete hostkeyword
```

Syntax Description

<i>ip-address</i>	IP address of the remote system. Up to 64 alphanumeric characters.
<i>hostname</i>	Hostname of the remote system. Up to 64 alphanumeric characters.
<i>username</i>	Username of the user logging in through SSH.
port [<i>number</i>]	(Optional) Indicates the port number of the remote host. From 0 to 65,535. Default 22.
version [1 2]	(Optional) Indicates the version number. Default 2.
delete host <i>key</i>	Deletes the SSH fingerprint of a specific host.
<i>word</i>	IPv4 address or hostname of a remote system. Up to 64 alphanumeric characters.

Command Default

Disabled.

Command Modes

EXEC (Admin or Operator).

Usage Guidelines

The **ssh** command enables a system to make a secure, encrypted connection to another remote system or server. This connection provides functionality similar to that of an outbound Telnet connection except that the connection is encrypted. With authentication and encryption, the SSH client allows for secure communication over an insecure network.

Example 1

```
ncs/admin# ssh ncs1 admin
admin@ncs1's password:
Last login: Wed Jul 11 05:53:20 2008 from ncs.cisco.com

ncs1/admin#
```

Example 2

```
ncs/admin# ssh delete host ncs
ncs/admin#
```

tech dumptcp

To dump a Transmission Control Protocol (TCP) package to the console, use the **tech dumptcp** command in EXEC mode.

tech dumptcp *gigabit-ethernet*

Syntax Description	<i>gigabit-ethernet</i>	Gigabit Ethernet interface number 0 to 1.
Command Default	Disabled.	
Command Modes	EXEC	

```

ncs/admin# tech dumptcp 0
140816:141088(272) ack 1921 win 14144
08:26:12.034630 IP NCS.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141088:141248(160)
  ack 1921 win 14144
08:26:12.034635 IP dhcp-64-102-82-153.cisco.com.2221 > NCS.cisco.com.ssh: . ack 139632 win
  64656
08:26:12.034677 IP NCS.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141248:141520(272)
  ack 1921 win 14144
08:26:12.034713 IP NCS.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141520:141680(160)
  ack 1921 win 14144
08:26:12.034754 IP NCS.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141680:141952(272)
  ack 1921 win 14144
08:26:12.034756 IP dhcp-64-102-82-153.cisco.com.2221 > NCS.cisco.com.ssh: . ack 140064 win
  65520
08:26:12.034796 IP NCS.cisco.com.ssh > dhcp-64-102-82-153.cisco.com.2221: P 141952:142112(160)
  ack 1921 win 14144
1000 packets captured
1000 packets received by filter
0 packets dropped by kernel
ncs/admin#

```

telnet

To log in to a host that supports Telnet, use the **telnet** command in operator (user) or EXEC mode.

telnet [*ip-address* | *hostname*] *port number*

Syntax Description	<i>ip-address</i>	IP address of the remote system. Up to 64 alphanumeric characters.
	<i>hostname</i>	Hostname of the remote system. Up to 64 alphanumeric characters.
	<i>port number</i>	(Optional) Indicates the port number of the remote host. From 0 to 65,535.
Command Default	No default behavior or values.	

Command Modes EXEC

```

ncs/admin# telnet 172.16.0.11 port 23
ncs.cisco.com login: admin
password:
Last login: Mon Jul  2 08:45:24 on ttyS0
ncs/admin#

```

terminal length

To set the number of lines on the current terminal screen for the current session, use the **terminal length** command in EXEC mode.

terminal length *integer*

Syntax Description	<i>integer</i>	Number of lines on the screen. Contains between 0 to 511 lines, inclusive. A value of zero (0) disables pausing between screens of output.
Command Default	24 lines.	
Command Modes	EXEC	
Usage Guidelines	The system uses the length value to determine when to pause during multiple-screen output.	

```

ncs/admin# terminal length 0
ncs/admin#

```

terminal session-timeout

To set the inactivity timeout for all sessions, use the **terminal session-timeout** command in EXEC mode.

terminal session-timeout *minutes*

Syntax Description	<i>minutes</i>	Sets the number of minutes for the inactivity timeout. From 0 to 525,600. Zero (0) disables the timeout.
Command Default	30 minutes.	
Command Modes	EXEC	
Usage Guidelines	Setting the terminal session-timeout command to zero (0) results in no timeout being set.	

```

ncs/admin# terminal session-timeout 40
ncs/admin#

```

Related Commands	Command	Description
	terminal session-welcome	Sets a welcome message on the system for all users who log in to the system.

terminal session-welcome

To set a welcome message on the system for all users who log in to the system, use the **terminal session-welcome** command in EXEC mode.

terminal session-welcome *string*

Syntax Description	<i>string</i>	Welcome message. Up to 2,023 alphanumeric characters.
Command Default	No default behavior or values.	
Command Modes	EXEC	
Usage Guidelines	Specify a message using up to 2048 characters.	
	<pre>ncs/admin# terminal session-welcome Welcome ncs/admin#</pre>	

Related Commands	Command	Description
	terminal session-timeout	Sets the inactivity timeout for all sessions.

terminal terminal-type

To specify the type of terminal connected to the current line for the current session, use the **terminal terminal-type** command in EXEC mode.

terminal terminal-type *type*

Syntax Description	<i>type</i>	Defines the terminal name and type, and permits terminal negotiation by hosts that provide that type of service. Up to 80 alphanumeric characters.
Command Default	VT100.	
Command Modes	EXEC	
Usage Guidelines	Indicate the terminal type if it is different from the default of VT100.	


```
ncs/admin# terminal terminal-type vt220
ncs/admin#
```

traceroute

To discover the routes that packets take when traveling to their destination address, use the **traceroute** command in EXEC mode.

traceroute [*ip-address* | *hostname*]

Syntax Description

<i>ip-address</i>	IP address of the remote system. Up to 32 alphanumeric characters.
<i>hostname</i>	Hostname of the remote system. Up to 32 alphanumeric characters.

Command Default

No default behavior or values.

Command Modes

EXEC

```
ncs/admin# traceroute 172.16.0.11
traceroute to 172.16.0.11 (172.16.0.11), 30 hops max, 38 byte packets
 1 172.16.0.11 0.067 ms 0.036 ms 0.032 ms
ncs/admin#
```

undebug

To disable debugging functions, use the **undebug** command in EXEC mode.

undebug {*all* | *application* | *backup-restore* | *cdp* | *config* | *copy* | *icmp* | *locks* | *logging* | *snmp* | *system* | *transfer* | *user* | *utils*}

Syntax Description

<i>all</i>	Disables all debugging.
<i>application</i>	Application files. <ul style="list-style-type: none"> <i>all</i>—Disables all application debug output. <i>install</i>—Disables application install debug output. <i>operation</i>—Disables application operation debug output. <i>uninstall</i>—Disables application uninstall debug output.

<i>backup-restore</i>	<p>Backs up and restores files.</p> <ul style="list-style-type: none">• <i>all</i>—Disables all debug output for backup-restore.• <i>backup</i>—Disables backup debug output for backup-restore.• <i>backup-logs</i>—Disables backup-logs debug output for backup-restore.• <i>history</i>—Disables history debug output for backup-restore.• <i>restore</i>—Disables restore debug output for backup-restore.
<i>cdp</i>	<p>Cisco Discovery Protocol configuration files.</p> <ul style="list-style-type: none">• <i>all</i>—Disables all Cisco Discovery Protocol configuration debug output.• <i>config</i>—Disables configuration debug output for Cisco Discovery Protocol.• <i>infra</i>—Disables infrastructure debug output for Cisco Discovery Protocol.
<i>config</i>	<p>Configuration files.</p> <ul style="list-style-type: none">• <i>all</i>—Disables all configuration debug output.• <i>backup</i>—Disables backup configuration debug output.• <i>clock</i>—Disables clock configuration debug output.• <i>infra</i>—Disables configuration infrastructure debug output.• <i>kron</i>—Disables command scheduler configuration debug output.• <i>network</i>—Disables network configuration debug output.• <i>repository</i>—Disables repository configuration debug output.• <i>service</i>—Disables service configuration debug output.
<i>copy</i>	<p>Copy commands.</p>

<i>icmp</i>	ICMP echo response configuration. <i>all</i> —Disable all debug output for ICMP echo response configuration. Set level between 0 and 7, with 0 being severe and 7 being all.
<i>locks</i>	Resource locking. <ul style="list-style-type: none"> • <i>all</i>—Disables all resource locking debug output. • <i>file</i>—Disables file locking debug output.
<i>logging</i>	Logging configuration files. <i>all</i> —Disables all debug output for logging configuration.
<i>snmp</i>	SNMP configuration files. <i>all</i> —Disables all debug output for SNMP configuration.
<i>system</i>	System files. <ul style="list-style-type: none"> • <i>all</i>—Disables all system files debug output. • <i>id</i>—Disables system ID debug output. • <i>info</i>—Disables system info debug output. • <i>init</i>—Disables system init debug output.
<i>transfer</i>	File transfer.
<i>user</i>	User management. <ul style="list-style-type: none"> • <i>all</i>—Disables all user management debug output. • <i>password-policy</i>—Disables user management debug output for password-policy.
<i>utils</i>	Utilities configuration files. <i>all</i> —Disables all utilities configuration debug output.

Command Default No default behavior or values.

Command Modes EXEC

```
ncs/admin# undebug all
ncs/admin#
```

Related Commands

Command	Description
debug	Displays errors or events for command situations.

write

To copy, display, or erase Prime Infrastructure server configurations, use the **write** command with the appropriate argument in EXEC mode.

write {*erase* | *memory* | *terminal*}

Syntax Description		
<i>erase</i>		Erases the startup configuration. This command is disabled by default.
<i>memory</i>		Copies the running configuration to the startup configuration.
<i>terminal</i>		Copies the running configuration to console.

Command Default No default behavior or values.

Command Modes EXEC

The following is an example of the write command with the erase keyword:



Note write erase command functionality is disabled from Cisco Prime Infrastructure Release 2.0 and later. If you try to write erase, then the following warning message is displayed.

```
pi-system/admin# write erase
% Warning: 'write erase' functionality has been disabled by application: NCS
pi-system/admin#
```

show Commands

This section lists Prime Infrastructure **show** commands. Each command includes a brief description of its use, any command defaults, command modes, usage guidelines, an example of the command syntax and any related commands.

show application

To show application information of the installed application packages on the system, use the **show application** command in EXEC mode.

show application [*status* | *version* [app_name]]

Syntax Description		
<i>status</i>		Displays the status of the installed application.
<i>version</i>		Displays the application version for an installed application—the Prime Infrastructure.

<i>app_name</i>	Name of the installed application.
-----------------	------------------------------------

Table 11: Output Modifier Variables for Count or Last

	<p>Output modifier variables:</p> <ul style="list-style-type: none"> • <i>begin</i>—Matched pattern. Up to 80 alphanumeric characters. • <i>count</i>—Counts the number of lines in the output. Add number after the word <i>count</i>. —Output modifier variables. • <i>end</i>—Ends with line that matches. Up to 80 alphanumeric characters. • <i>exclude</i>—Excludes lines that match. Up to 80 alphanumeric characters. • <i>include</i>—Includes lines that match. Up to 80 alphanumeric characters. • <i>last</i>—Displays last few lines of output. Add number after the word <i>last</i>. Up to 80 lines to display. Default 10. —Output modifier variables (see Table A-8).
--	--

Command Default No default behavior or values.

Command Modes EXEC

Examples

Example 1

```
pi-system/admin# show application
<name>          <Description>
NCS             Cisco Prime Infrastructure
pi-system/admin#
```

Related Commands

	Description
application start	Starts or enables an application.
application stop	Stops or disables an application.
application upgrade	Upgrades an application bundle.

show backup history

To display the backup history of the system, use the **show backup history** command in EXEC mode.

show backup history

Syntax Description	This command has no arguments or keywords.
Command Default	No default behavior or values.
Command Modes	EXEC

Example 1

```
pi-system-168/admin# show restore log
Started at : Thu Aug 1 14:48:08 2019
Initiating restore. Please wait...
  Restore Started at 08/01/19 14:48:08
  Stage 1 of 9: Transferring backup file ...
  -- completed at 08/01/19 14:48:56
  Stage 2 of 9: Decrypting backup file ...
  -- completed at 08/01/19 14:50:16
  Stage 3 of 9: Unpacking backup file ...
  -- completed at 08/01/19 14:50:19
  Stopping PI server ...
  Stage 4 of 9: Decompressing backup ...
  -- completed at 08/01/19 14:52:12
  Stage 5 of 9: Restoring Support Files ...
  -- completed at 08/01/19 14:52:21
  Stage 6 of 9: Restoring Database Files ...
  -- completed at 08/01/19 14:53:04
  Stage 7 of 9: Recovering Database ...
  -- completed at 08/01/19 15:21:01
  Stage 8 of 9: Updating Database Schema ...
  This could take long time based on the existing data size.
  -- completed at 08/01/19 16:10:50
  Stage 9 of 9: Re-enabling Database Settings ...
  -- completed at 08/01/19 16:49:13
  Total Restore duration is: 02h:01m:05s
INFO: Restore completed successfully.

Starting Prime Infrastructure...

This may take a while (10 minutes or more) ...

Prime Infrastructure started successfully.

Completed in 1477 seconds
Finished at : Thu Aug 1 17:14:13 2019
```

Example 2

```
pi-system-284/admin# show backup history
Sat Jan 25 03:59:28 IST 2020: backup
pi-system-284-200125-0334__VER3.8.0.0.310_BKSZ25G_CPU4_MEM3G_RAM11G_SWAP15G_APP_CK2130717572.tar.gpg
to repository defaultRepo: success
Sun Jan 26 04:06:54 IST 2020: backup
pi-system-284-200126-0334__VER3.8.0.0.310_BKSZ24G_CPU4_MEM3G_RAM11G_SWAP15G_APP_CK4209384478.tar.gpg
to repository defaultRepo: success
```

```

Mon Jan 27 03:58:16 IST 2020: backup
pi-system-284-200127-0334_VER3.8.0.0.310_BKSZ24G_CPU4_MEM3G_RAM11G_SWAP15G_APP_CK482645775.tar.gpg
to repository defaultRepo: success
Tue Jan 28 03:56:13 IST 2020: backup
pi-system-284-200128-0334_VER3.8.0.0.310_BKSZ25G_CPU4_MEM3G_RAM11G_SWAP15G_APP_CK599302789.tar.gpg
to repository defaultRepo: success

```

Related Commands	Command	Description
	backup	Performs a backup (Prime Infrastructure and Cisco ADE OS) and places the backup in a repository.
	restore	Restores from backup the file contents of a specific repository.
	repository	Enters the repository submode for configuration of backups.
	show repository	Displays the available backup files located on a specific repository.

show banner pre-login

To display the banner that you installed, use the **show banner pre-login** command in EXEC mode.

show banner pre-login

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes EXEC

Example

```

pi-system/admin# show banner pre-login
Banner-Test
pi-system/admin#

```

Related Commands	Command	Description
	banner, on page 37	Enables you to install a pre-login banner.

show cdp

To display information about the enabled Cisco Discovery Protocol interfaces, use the **show cdp** command in EXEC mode.

show cdp {all | neighbors}

Syntax Description	all	Shows all of the enabled Cisco Discovery Protocol interfaces.
	neighbors	Shows the Cisco Discovery Protocol neighbors.

Command Default No default behavior or values.

Command Modes EXEC

Example 1

```
ncs/admin# show cdp all
CDP protocol is enabled ...
    broadcasting interval is every 60 seconds.
    time-to-live of cdp packets is 180 seconds.

    CDP is enabled on port GigabitEthernet0.
ncs/admin#
```

Example 2

```
ncs/admin# show cdp neighbors
CDP Neighbor : 000c297840e5
    Local Interface   : GigabitEthernet0
    Device Type      : L-NCS-1.0-50
    Port             : eth0
    Address          : 172.23.90.114

CDP Neighbor : isexp-esw5
    Local Interface   : GigabitEthernet0
    Device Type      : cisco WS-C3560E-24TD
    Port             : GigabitEthernet0/5
    Address          : 172.23.90.45

CDP Neighbor : 000c29e29926
    Local Interface   : GigabitEthernet0
    Device Type      : L-NCS-1.0-50
    Port             : eth0
    Address          : 172.23.90.115

CDP Neighbor : 000c290fba98
    Local Interface   : GigabitEthernet0
    Device Type      : L-NCS-1.0-50
    Port             : eth0
    Address          : 172.23.90.111

ncs/admin#
```

Related Commands

Command	Description
cdp holdtime	Specifies the length of time that the receiving device should hold a Cisco Discovery Protocol packet from your router before discarding it.
cdp run	Enables the Cisco Discovery Protocol.

Command	Description
cdp timer	Specifies how often the Prime Infrastructure server sends Cisco Discovery Protocol updates.

show clock

To display the day, month, date, time, time zone, and year of the system software clock, use the **show clock** command in EXEC mode.

show clock

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes EXEC

```
pi-system-196/admin# show clock
Tue Jan 28 04:11:38 IST 2020
```



Note The **show clock** output in the previous example includes Coordinated Universal Time (UTC) or Greenwich Mean Time (GMT), Great Britain, or Zulu time (see [Tables A-16](#), [Table 15: Australia Time Zones](#), and [Table 16: Asia Time Zones](#) on pages A-84 and A-85 for sample time zones).

Related Commands

Command	Description
clock	Sets the system clock for display purposes.

show cpu

To display CPU information, use the **show cpu** command in EXEC mode.

show cpu [statistics] [[]] [[]]

Syntax Description statistics Displays CPU statistics.

Output modifier variables:

- *begin*—Matched pattern. Up to 80 alphanumeric characters.
- *count*—Counts the number of lines in the output. Add number after the word *count*.
|—Output modifier variables (see [Table A-9](#)).
- *end*—Ends with line that matches. Up to 80 alphanumeric characters.
- *exclude*—Excludes lines that match. Up to 80 alphanumeric characters.
- *include*—Includes lines that match. Up to 80 alphanumeric characters.
- *last*—Displays last few lines of output. Add number after the word *last*. Up to 80 lines to display. Default 10.
|—Output modifier variables (see [Table A-9](#)).

Command Default

No default behavior or values.

Command Modes

EXEC

Example 1

```
ncs/admin# show cpu

processor : 0
model      : Intel(R) Xeon(R) CPU           E5320 @ 1.86GHz
speed(MHz): 1861.914
cache size: 4096 KB

ncs/admin#
```

Example 2

```
ncs/admin# show cpu statistics
user time:          265175
kernel time:        166835
idle time:          5356204
i/o wait time:      162676
irq time:           4055

ncs/admin#
```

Related Commands

Command	Description
show disks	Displays the system information of all disks.

Command	Description
show memory	Displays the amount of system memory that each system process uses.

show disks

To display the disks file-system information, use the **show disks** command in EXEC mode.

show disks [[] []]

Syntax Description

	<p>Output modifier variables:</p> <ul style="list-style-type: none"> • <i>begin</i>—Matched pattern. Up to 80 alphanumeric characters. • <i>count</i>—Counts the number of lines in the output. Add number after the word <i>count</i>. —Output modifier variables (see Table A-10). • <i>end</i>—Ends with line that matches. Up to 80 alphanumeric characters. • <i>exclude</i>—Excludes lines that match. Up to 80 alphanumeric characters. • <i>include</i>—Includes lines that match. Up to 80 alphanumeric characters. • <i>last</i>—Displays last few lines of output. Add number after the word <i>last</i>. Up to 80 lines to display. Default 10. —Output modifier variables (see Table A-10).
--	--

Command Default

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

Only platforms that have a disk file system support the **show disks** command.

```
ncs/admin# show disks

temp. space 2% used (17828 of 988116)
disk: 3% used (143280 of 5944440)

Internal filesystems:
  all internal filesystems have sufficient free space

ncs/admin#
```

Related Commands	Command	Description
	show cpu	Displays CPU information.
	show memory	Displays the amount of system memory that each system process uses.

show icmp_status

To display the Internet Control Message Protocol echo response configuration information, use the **show icmp_status** command in EXEC mode.

```
show icmp_status {> file | |}
```

Syntax Description		
	>	Output direction.
	<i>file</i>	Name of file to redirect standard output (stdout).
		Output modifier commands: <ul style="list-style-type: none"> • <i>begin</i>—Matched pattern. Up to 80 alphanumeric characters. • <i>count</i>—Counts the number of lines in the output. Add number after the word count. <ul style="list-style-type: none"> • —Output modifier commands (see Table A-11). • <i>end</i>—Ends with line that matches. Up to 80 alphanumeric characters. • <i>exclude</i>—Excludes lines that match. Up to 80 alphanumeric characters. • <i>include</i>—Includes lines that match. Up to 80 alphanumeric characters. • <i>last</i>—Displays last few lines of output. Add number after the word last. Up to 80 lines to display. Default 10. <ul style="list-style-type: none"> • —Output modifier commands (see Table A-11).

Command Default No default behavior or values.

Command Modes EXEC

Example 1

```
ncs/admin# show icmp_status
```

```
icmp echo response is turned on
ncs/admin#
```

Example 2

```
ncs/admin# show icmp_status
icmp echo response is turned off
ncs/admin#
```

Related Commands	Command	Description
	icmp echo	Configures the Internet Control Message Protocol (ICMP) echo requests.

show ip route

To display details the ip route details of the application, use **show ip route** command in EXEC mode.

```
show ip route { | }
```

Syntax Description		
	>	Output redirection
		Output modifiers

Command Default No default behaviour.

Command Modes EXEC

```
ncs/admin# show ip route
Kernel IP routing table
Destination      Gateway          Genmask          Flags Metric Ref    Use Iface
10.126.168.0    0.0.0.0         255.255.255.0   U        0      0      0 eth0
0.0.0.0         10.126.168.1   0.0.0.0         UG       0      0      0 eth0
Kernel IPv6 routing table
Destination      Metric Ref    Use Iface          Next Hop          Flags
2001::/64       256 0      0 eth0              ::                UA
fe80::/64       256 0      0 eth0              ::                U
::/0            1024 18     0 eth0              fe80::217:dfff:fe29:9800 UGDA
::1/128         0      10127 1 lo                ::                U
2001::20c:29ff:fe6c:8f28/128 0      0      1 lo                ::                U
2001::813d:2d75:7d6:564f/128 0      37     1 lo                ::                U
2001::d992:4889:c9e1:f238/128 0      0      1 lo                ::                U
fe80::20c:29ff:fe6c:8f28/128 0      3      1 lo                ::                U
ff00::/8
```

show interface

To display the usability status of interfaces configured for IP, use the **show interface** command in EXEC mode.

show interface [GigabitEthernet] |

Syntax Description	GigabitEthernet	Shows the Gigabit Ethernet interface. Either 0 or 1.
		Output modifier variables: <ul style="list-style-type: none"> • <i>begin</i>—Matched pattern. Up to 80 alphanumeric characters. • <i>count</i>—Counts the number of lines in the interface. Add number after the word <i>count</i>. • <i>end</i>—Ends with line that matches. Up to 80 alphanumeric characters. • <i>exclude</i>—Exclude lines that match. Up to 80 alphanumeric characters. • <i>include</i>—Includes lines that match. Up to 80 alphanumeric characters. • <i>last</i>—Displays last few lines of output. Add number after the word <i>last</i>. Up to 80 lines to display. Default 10.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines In the **show interface GigabitEthernet 0** output, you can find that the interface has three IPv6 addresses. The first internet address (starting with 3ffe) is the result of using stateless autoconfiguration. For this to work, you need to have IPv6 route advertisement enabled on that subnet. The next address (starting with fe80) is a link local address that does not have any scope outside the host. You always see a link local address regardless of the IPv6 autoconfiguration or DHCPv6 configuration. The last address (starting with 2001) is the result obtained from an IPv6 DHCP server.

Example 1

```

ncs/admin# show interface
eth0      Link encap:Ethernet  HWaddr 00:0C:29:6A:88:C4
          inet addr:172.23.90.113  Bcast:172.23.90.255  Mask:255.255.255.0
          inet6 addr: fe80::20c:29ff:fe6a:88c4/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:48536 errors:0 dropped:0 overruns:0 frame:0
          TX packets:14152 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:6507290 (6.2 MiB)  TX bytes:12443568 (11.8 MiB)
          Interrupt:59 Base address:0x2000

lo        Link encap:Local Loopback

```

```

inet addr:127.0.0.1 Mask:255.0.0.0
inet6 addr: ::1/128 Scope:Host
UP LOOPBACK RUNNING MTU:16436 Metric:1
RX packets:1195025 errors:0 dropped:0 overruns:0 frame:0
TX packets:1195025 errors:0 dropped:0 overruns:0 carrier:0
collisions:0 txqueuelen:0
RX bytes:649425800 (619.3 MiB) TX bytes:649425800 (619.3 MiB)

sit0 Link encap:IPv6-in-IPv4
NOARP MTU:1480 Metric:1
RX packets:0 errors:0 dropped:0 overruns:0 frame:0
TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
collisions:0 txqueuelen:0
RX bytes:0 (0.0 b) TX bytes:0 (0.0 b)

ncs/admin#

```

Example 2

```

ncs/admin# show interface GigabitEthernet 0
eth0 Link encap:Ethernet HWaddr 00:0C:29:AF:DA:05
inet addr:172.23.90.116 Bcast:172.23.90.255 Mask:255.255.255.0
inet6 addr: 3ffe:302:11:2:20c:29ff:feaf:da05/64 Scope:Global
inet6 addr: fe80::20c:29ff:feaf:da05/64 Scope:Link
inet6 addr: 2001:558:ff10:870:8000:29ff:fe36:200/64 Scope:Global
UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
RX packets:77848 errors:0 dropped:0 overruns:0 frame:0
TX packets:23131 errors:0 dropped:0 overruns:0 carrier:0
collisions:0 txqueuelen:1000
RX bytes:10699801 (10.2 MiB) TX bytes:3448374 (3.2 MiB)
Interrupt:59 Base address:0x2000

```

Related Commands	Command	Description
	interface	Configures an interface type and enters the interface configuration submode.
	ipv6 address autoconfig	Enables IPv6 stateless autoconfiguration on an interface.
	ipv6 address dhcp	Enables IPv6 address DHCP on an interface.

show inventory

To display information about the hardware inventory, including the Prime Infrastructure appliance model and serial number, use the **show inventory** command in EXEC mode.

show inventory |

Syntax Description	<p>Output modifier variables:</p> <ul style="list-style-type: none"> • <i>begin</i>—Matched pattern. Up to 80 alphanumeric characters. • <i>count</i>—Counts the number of lines in the interface. Add number after the word <i>count</i>. • <i>end</i>—Ends with line that matches. Up to 80 alphanumeric characters. • <i>exclude</i>—Exclude lines that match. Up to 80 alphanumeric characters. • <i>include</i>—Includes lines that match. Up to 80 alphanumeric characters. • <i>last</i>—Displays last few lines of output. Add number after the word <i>last</i>. Up to 80 lines to display. Default 10.
Command Default	No default behavior or values.
Command Modes	EXEC

```

pi-system/admin# show inventory

NAME: "Cisco-VM chassis", DESCR: "Cisco-VM chassis"
PID: Cisco-VM-SPID      , VID: V01 , SN: GITQA6QC26B
Total RAM Memory: 12167972 kB
CPU Core Count: 4
CPU 0: Model Info: Intel(R) Xeon(R) CPU E5-4640 0 @ 2.40GHz
CPU 1: Model Info: Intel(R) Xeon(R) CPU E5-4640 0 @ 2.40GHz
CPU 2: Model Info: Intel(R) Xeon(R) CPU E5-4640 0 @ 2.40GHz
CPU 3: Model Info: Intel(R) Xeon(R) CPU E5-4640 0 @ 2.40GHz
Hard Disk Count(*): 1
Disk 0: Device Name: /dev/sda
Disk 0: Capacity: 322.10 GB
Disk 0: Geometry: 255 heads 63 sectors/track 39162 cylinders
NIC Count: 1
NIC 0: Device Name: eth0
NIC 0: HW Address: 00:0C:29:11:51:83
NIC 0: Driver Descr: e1000: eth0: e1000_probe: Intel(R) PRO/1000 Network Connection

(*) Hard Disk Count may be Logical.
pi-system-61/admin#

```

show logging

To display the state of system logging (syslog) and the contents of the standard system logging buffer, use the **show logging** command in EXEC mode.

show logging {**application** [*application-name*]} {**internal**} {**system**} |

Syntax Description	application	Displays application logs.
---------------------------	--------------------	----------------------------

<i>application-name</i>	Application name. Up to 255 alphanumeric characters. <ul style="list-style-type: none"> • <i>tail</i>—Tail system syslog messages. • <i>count</i>—Tail last count messages. From 0 to 4,294,967,295. <p>—Output modifier variables (see below).</p>
internal	Displays the syslogs configuration.
system	Displays the system syslogs.
	Output modifier variables: <ul style="list-style-type: none"> • <i>begin</i>—Matched pattern. Up to 80 alphanumeric characters. • <i>count</i>—Counts the number of lines in the interface. Add number after the word <i>count</i>. • <i>end</i>—Ends with line that matches. Up to 80 alphanumeric characters. • <i>exclude</i>—Excludes lines that match. Up to 80 alphanumeric characters. • <i>include</i>—Includes lines that match. Up to 80 alphanumeric characters. • <i>last</i>—Displays last few lines of output. Add number after the word <i>last</i>. Up to 80 lines to display. Default 10.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines This command displays the state of syslog error and event logging, including host addresses, and for which, logging destinations (console, monitor, buffer, or host) logging is enabled.

Example 1

```
ncs/admin# show logging system
```

```
ADEOS Platform log:
```

```
-----
```

```
Aug  5 10:44:32 localhost debugd[1943]: [16618]: config:network: main.c[252] [setup]: Setup
is complete
Aug  5 10:45:02 localhost debugd[1943]: [17291]: application:install cars_install.c[242]
[setup]: Install initiated with bundle - ncs.tar.gz,
repo - SystemDefaultPkgRepos
Aug  5 10:45:02 localhost debugd[1943]: [17291]: application:install cars_install.c[256]
[setup]: Stage area - /storeddata/Installing/.1281030
302
Aug  5 10:45:02 localhost debugd[1943]: [17291]: application:install cars_install.c[260]
```

```

[setup]: Getting bundle to local machine
Aug 5 10:45:03 localhost debugd[1943]: [17291]: transfer: cars_xfer.c[58] [setup]: local
copy in of ncs.tar.gz requested
Aug 5 10:45:46 localhost debugd[1943]: [17291]: application:install cars_install.c[269]
[setup]: Got bundle at - /storeddata/Installing/.1281
030302/ncs.tar.gz
Aug 5 10:45:46 localhost debugd[1943]: [17291]: application:install cars_install.c[279]
[setup]: Unbundling package ncs.tar.gz
Aug 5 10:47:06 localhost debugd[1943]: [17291]: application:install cars_install.c[291]
[setup]: Unbundling done. Verifying input parameters.
..
Aug 5 10:47:06 localhost debugd[1943]: [17291]: application:install cars_install.c[313]
[setup]: Manifest file is at - /storeddata/Installing
/.1281030302/manifest.xml
Aug 5 10:47:07 localhost debugd[1943]: [17291]: application:install cars_install.c[323]
[setup]: Manifest file appname - ncs
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install cars_install.c[386]
[setup]: Manifest file pkgtype - CARS
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install cars_install.c[398]
[setup]: Verify dependency list -
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install cars_install.c[410]
[setup]: Verify app license -
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install cars_install.c[420]
[setup]: Verify app RPM's
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install cars_install.c[428]
[setup]: No of RPM's - 9
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install cars_install.c[439]
[setup]: Disk - 50
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install ci_util.c[325] [setup]:
Disk requested = 51200 KB
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install ci_util.c[345] [setup]:
More disk found Free = 40550400, req_disk = 51200
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install cars_install.c[450]
[setup]: Mem requested by app - 100
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install ci_util.c[369] [setup]:
Mem requested = 102400
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install ci_util.c[384] [setup]:
Found MemFree = MemFree: 13028 kB
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install ci_util.c[390] [setup]:
Found MemFree value = 13028
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install ci_util.c[393] [setup]:
Found Inactive = Inactive: 948148 kB
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install ci_util.c[399] [setup]:
Found Inactive MemFree value = 948148
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install ci_util.c[409] [setup]:
Sufficient mem found
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install ci_util.c[415] [setup]:
Done checking memory...
Aug 5 10:47:09 localhost debugd[1943]: [17291]: application:install cars_install.c[461]
[setup]: Verifying RPM's...
--More--
(prompt Spacebar to continue)

```

Example 2

```

ncs/admin# show logging internal

log server:          localhost
Global loglevel:    6
Status:             Enabled
ncs/admin#

```

Example 3

```

ncs/admin# show logging internal

log server:          localhost
Global loglevel:    6
Status:             Disabled
ncs/admin#

```

show logins

To display the state of system logins, use the **show logins** command in EXEC mode.

show logins cli

Syntax Description	cli	Lists the cli login history.
Command Default	No default behavior or values.	
Command Modes	EXEC	
Usage Guidelines	Requires the cli keyword; otherwise, an error occurs.	

```

ncs/admin# show logins cli
root pts/2 10.126.184.230 Fri Aug 9 14:50 still logged in
admin pts/3 10.126.184.230 Thu Aug 1 14:41 - 10:25 (3+19:44)
admin pts/3 10.126.184.230 Thu Aug 1 12:59 - 13:10 (00:10)
admin pts/2 10.126.184.230 Wed Jul 31 19:33 - 10:25 (4+14:51)
admin tty1 Tue Jul 30 20:16 - 08:18 (12:01)
reboot system boot 3.10.0-957.21.3. Wed Jul 31 01:01 - 20:17 (12+19:15)
setup tty1 Thu Jul 25 00:59 - 19:31 (5+18:31)
reboot system boot 3.10.0-957.21.3. Wed Jul 24 17:48 - 19:31 (6+01:42)

wtmp begins Wed Jul 24 17:48:44 2019

```

show memory

To display the memory usage of all of the running processes, use the **show memory** command in EXEC mode.

show memory

Syntax Description	This command has no arguments or keywords.
Command Default	No default behavior or values.
Command Modes	EXEC

```

ncs/admin# show memory
total memory: 1035164 kB
free memory: 27128 kB
cached: 358888 kB

```

```
swap-cached:      142164 kB
ncs/admin#
```

show netstat

To display statistics about your network connection, use **show netstat** command in EXEC mode.

show netstat{>||}

Syntax Description

>	Output redirection.
	Output modifiers.

Command Default

No default behavior.

Command Modes

EXEC

```
ncs/admin# show netstat
TCP Listeners -----
Active Internet connections (only servers)
Proto Recv-Q Send-Q Local Address           Foreign Address         State
tcp      0      0 0.0.0.0:65000          0.0.0.0:*               LISTEN
tcp      0      0 0.0.0.0:39949          0.0.0.0:*               LISTEN
tcp      0      0 0.0.0.0:111            0.0.0.0:*               LISTEN
tcp      0      0 127.0.0.1:2000         0.0.0.0:*               LISTEN
tcp      0      0 0.0.0.0:6100           0.0.0.0:*               LISTEN
tcp      0      0 0.0.0.0:21             0.0.0.0:*               LISTEN
tcp      0      0 0.0.0.0:22             0.0.0.0:*               LISTEN
tcp      0      0 0.0.0.0:2012           0.0.0.0:*               LISTEN
tcp      0      0 0.0.0.0:2013           0.0.0.0:*               LISTEN
tcp      0      0 :::61603                :::*                     LISTEN
tcp      0      0 :::10755                 :::*                     LISTEN
tcp      0      0 :::61604                 :::*                     LISTEN
tcp      0      0 :::31204                 :::*                     LISTEN
tcp      0      0 :::9992                  :::*                     LISTEN
tcp      0      0 :::65000                 :::*                     LISTEN
tcp      0      0 :::8009                  :::*                     LISTEN
tcp      0      0 :::5001                  :::*                     LISTEN
tcp      0      0 :::1199                  :::*                     LISTEN
tcp      0      0 :::111                   :::*                     LISTEN
tcp      0      0 :::80                     :::*                     LISTEN
tcp      0      0 :::35088                 :::*                     LISTEN
tcp      0      0 :::21648                 :::*                     LISTEN
tcp      0      0 :::16113                 :::*                     LISTEN
tcp      0      0 :::2001                  :::*                     LISTEN
tcp      0      0 :::61617                 :::*                     LISTEN
tcp      0      0 :::1522                  :::*                     LISTEN
tcp      0      0 :::8082                  :::*                     LISTEN
tcp      0      0 :::6100                  :::*                     LISTEN
tcp      0      0 :::21                    :::*                     LISTEN
tcp      0      0 :::22                    :::*                     LISTEN
tcp      0      0 :::48504                 :::*                     LISTEN
tcp      0      0 :::443                   :::*                     LISTEN
tcp      0      0 :::10555                 :::*                     LISTEN

TCP Connections -----
Active Internet connections (w/o servers)
```

```

Proto Recv-Q Send-Q Local Address           Foreign Address         State
tcp          0      0 10.126.168.61:22      10.65.57.243:55027    ESTABLISHED

```

show ntp

To show the status of the NTP associations, use the **show ntp** command in EXEC mode.

show ntp

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

EXEC ncs/admin# **show ntp** pi-system-241/admin# show ntp NTP Server 1 : 10.81.254.202 NTP Server 2 : 10.64.58.50 synchronised to NTP server (10.81.254.202) at stratum 2 time correct to within 173 ms polling server every 1024 s remote refid st t when poll reach delay offset jitter

```

=====
==== *10.81.254.202 .GPS. 1 u 255 1024 377 272.081 1.756 1.850 +10.64.58.50 10.67.68.33 2 u 27 1024
377 0.388 -0.936 1.904 Warning: Output results may conflict during periods of changing synchronization.

```

Related Commands

Command	Description
ntp server	Allows synchronization of the software clock by the NTP server for the system.

show ports

To display information about all of the processes listening on active ports, use the **show ports** command in EXEC mode.

show ports [[] []]

Syntax Description

Output modifier variables:

- *begin*—Matched pattern. Up to 80 alphanumeric characters.
- *count*—Counts the number of lines in the interface. Add number after the word *count*.
|—Output modifier variables (see [Table A-12](#)).
- *end*—Ends with line that matches. Up to 80 alphanumeric characters.
- *exclude*—Excludes lines that match. Up to 80 alphanumeric characters.
- *include*—Includes lines that match. Up to 80 alphanumeric characters.
- *last*—Displays last few lines of output. Add number after the word *last*. Up to 80 lines to display. Default 10.
|—Output modifier variables (see [Table A-12](#)).

Command Default

No default behavior or values.

Command Modes

EXEC

Usage Guidelines

When you run the **show ports** command, the port must have an associated active session.

```
ncs/admin# show ports
Process : timestensubd (21372)
      tcp: 127.0.0.1:11298
Process : timestenorad (21609)
      tcp: 127.0.0.1:51715
      udp: ::1:28314, ::1:59055, ::1:45113, ::1:49082, ::1:64737, ::1:62570, ::1:19577,
      ::1:29821
Process : ttcserver (21382)
      tcp: 127.0.0.1:16612, 0.0.0.0:53385
Process : timestenrepd (21579)
      tcp: 127.0.0.1:62504, 0.0.0.0:18047
      udp: ::1:51436
Process : timestend (21365)
      tcp: 0.0.0.0:53384
Process : rpc.statd (2387)
      tcp: 0.0.0.0:873
      udp: 0.0.0.0:867, 0.0.0.0:870
Process : timestensubd (21373)
      tcp: 127.0.0.1:43407
Process : portmap (2350)
      tcp: 0.0.0.0:111
      udp: 0.0.0.0:111
Process : Decap_main (21468)
      tcp: 0.0.0.0:2000
      udp: 0.0.0.0:9993
Process : timestensubd (21369)
      tcp: 127.0.0.1:37648
```

```
Process : timestensubd (21374)
      tcp: 127.0.0.1:64211
Process : sshd (2734)
      tcp: 172.23.90.113:22
Process : java (21432)
      tcp: 127.0.0.1:8888, :::2080, :::2020, ::ffff:127.0.0.1:8005, :::8009, :::8905, :::8010,
      :::2090, :::1099, :::9999, :::61616, :::8080, ::
      :80, :::60628, :::8443, :::443
      udp: 0.0.0.0:1812, 0.0.0.0:1813, 0.0.0.0:1700, 0.0.0.0:10414, 0.0.0.0:3799, 0.0.0.0:1645,
      0.0.0.0:1646, :::8905, :::8906
Process : monit (21531)
      tcp: 127.0.0.1:2812
Process : java (21524)
      tcp: :::62627
Process : java (21494)
      tcp: ::ffff:127.0.0.1:20515
      udp: 0.0.0.0:20514
Process : tnslsnr (21096)
      tcp: :::1521
Process : ora_d000_ncs1 (21222)
      tcp: :::26456
      udp: ::1:63198
Process : ntpd (2715)
      udp: 172.23.90.113:123, 127.0.0.1:123, 0.0.0.0:123, ::1:123, fe80::20c:29ff:fe6a:123,
      :::123
Process : ora_pmon_ncs1 (21190)
      udp: ::1:51994
Process : ora_mmon_ncs1 (21218)
      udp: :::38941
Process : ora_s000_ncs1 (21224)
      udp: ::1:49864

ncs/admin#
```

show process

To display information about active processes, use the **show process** command in the EXEC mode.

show process |

Syntax Description

(Optional) Output modifier variables:

- *begin*—Matched pattern. Up to 80 alphanumeric characters.
- *count*—Count the number of lines in the interface. Add number after the word *count*.
- *end*—Ends with line that matches. Up to 80 alphanumeric characters.
- *exclude*—Excludes lines that match. Up to 80 alphanumeric characters.
- *include*—Includes lines that match. Up to 80 alphanumeric characters.
- *last*—Displays last few lines of output. Add number after the word *last*. Up to 80 lines to display. Default 10.

Command Default

No default behavior or values.

Command Modes

EXEC

```

/adminin# show process
USER      PID      TIME TT      COMMAND
root      1 00:00:02 ?      init
root      2 00:00:00 ?      migration/0
root      3 00:00:00 ?      ksoftirqd/0
root      4 00:00:00 ?      watchdog/0
root      5 00:00:00 ?      events/0
root      6 00:00:00 ?      khelper
root      7 00:00:00 ?      kthread
root      10 00:00:01 ?      kblockd/0
root      11 00:00:00 ?      kacpid
root      170 00:00:00 ?      cqueue/0
root      173 00:00:00 ?      khubd
root      175 00:00:00 ?      kseriod
root      239 00:00:32 ?      kswapd0
root      240 00:00:00 ?      aio/0
root      458 00:00:00 ?      kpsmoused
root      488 00:00:00 ?      mpt_poll_0
root      489 00:00:00 ?      scsi_eh_0
root      492 00:00:00 ?      ata/0
root      493 00:00:00 ?      ata_aux
root      500 00:00:00 ?      kstriped
root      509 00:00:07 ?      kjournald
root      536 00:00:00 ?      kauditd
root      569 00:00:00 ?      udevd
root      1663 00:00:00 ?      kmpathd/0
root      1664 00:00:00 ?      kmpath_handlerd
root      1691 00:00:00 ?      kjournald
root      1693 00:00:00 ?      kjournald
root      1695 00:00:00 ?      kjournald
root      1697 00:00:00 ?      kjournald
root      2284 00:00:00 ?      auditd
root      2286 00:00:00 ?      audispd

```



```

root      2318 00:00:10 ?      debugd
rpc       2350 00:00:00 ?      portmap
root      2381 00:00:00 ?      rpciod/0

```

```
pi-admin/admin#
```

Table 12: Show Process Field Descriptions

Field	Description
USER	Logged-in user.
PID	Process ID.
TIME	The time that the command was last used.
TT	Terminal that controls the process.
COMMAND	Type of process or command used.

show repository

To display the file contents of the repository, use the **show repository** command in EXEC mode.

show repository repository-name

Syntax Description

repository-name Name of the repository whose contents you want to view. Up to 30 alphanumeric characters.

Command Default

No default behavior or values.

Command Modes

EXEC

Related Commands

Command	Description
backup	Performs a backup (Prime Infrastructure and Cisco ADE OS) and places the backup in a repository.
restore	Restores from backup the file contents of a specific repository.
repository	Enters the repository submode for configuration of backups.
show backup history	Displays the backup history of the system.

show restore

To display the restore history, use the **show restore** command in EXEC mode.

show restore {history}

show restore log

Syntax Description	history	Displays the restore history.
Command Default	No default behavior or values.	
Command Modes	EXEC	

```
pi-system-284/admin# show restore history
Fri Jan 24 18:35:37 IST 2020: restore pi-system-173-190908-
0334__VER3.8.0.0.310_BKSZ26G_CPU4_MEM3G_RAM11G_SWAP15G_APP_CK218281319.tar.gpg from repository

test: success
pi-system-284/admin#
```

Related Commands	Command	Description
	backup	Performs a backup (Prime Infrastructure and Cisco ADE OS) and places the backup in a repository.
	restore	Restores from backup the file contents of a specific repository.
	repository	Enters the repository submode for configuration of backups.
	show backup history	Displays the backup history of the system.

show restore log

To display the last restore operation in the case of Auto logout console, use the **show restore log** command in EXEC mode. You can run this command even while performing a restore operation and a successful restore operation.

show restore log

Syntax Description	This command has no arguments or keywords.
Command Default	No default behavior or values.
Command Modes	EXEC

Example 1

```
pi-system/admin# show restore log
Started at : Thu Aug 1 14:48:08 2019
Initiating restore. Please wait...
  Restore Started at 08/01/19 14:48:08
  Stage 1 of 9: Transferring backup file ...
  -- completed at 08/01/19 14:48:56
  Stage 2 of 9: Decrypting backup file ...
  -- completed at 08/01/19 14:50:16
  Stage 3 of 9: Unpacking backup file ...
  -- completed at 08/01/19 14:50:19
  Stopping PI server ...
```

```

Stage 4 of 9: Decompressing backup ...
-- completed at 08/01/19 14:52:12
Stage 5 of 9: Restoring Support Files ...
-- completed at 08/01/19 14:52:21
Stage 6 of 9: Restoring Database Files ...
-- completed at 08/01/19 14:53:04
Stage 7 of 9: Recovering Database ...
-- completed at 08/01/19 15:21:01
Stage 8 of 9: Updating Database Schema ...
  This could take long time based on the existing data size.
-- completed at 08/01/19 16:10:50
Stage 9 of 9: Re-enabling Database Settings ...
-- completed at 08/01/19 16:49:13
Total Restore duration is: 02h:01m:05s
INFO: Restore completed successfully.

Starting Prime Infrastructure...

This may take a while (10 minutes or more) ...

Prime Infrastructure started successfully.

Completed in 1477 seconds
Finished at : Thu Aug 1 17:14:13 2019

```

Related Commands

Command	Description
restore	Restores from backup the file contents of a specific repository.

show running-config

To display the contents of the currently running configuration file or the configuration, use the **show running-config** command in EXEC mode.

showrunning-config**Syntax Description**

This command has no arguments or keywords.

Command Default

The **show running-config** command displays all of the configuration information.

Command Modes

EXEC

```

ncs/admin# show running-config
Generating configuration...
!
hostname ncs
!
ip domain-name cisco.com
!
interface GigabitEthernet 0
 ip address 172.23.90.113 255.255.255.0
 ipv6 address autoconfig
!
ip name-server 172.16.168.183
!

```

```

ip default-gateway 172.23.90.1
!
clock timezone UTC
!
ntp server time.nist.gov
!
username admin password hash $1$JbbHvKVG$xMZ/XL4tH15Knf.FfcZZr. role admin
!
service sshd
!
password-policy
  lower-case-required
  upper-case-required
  digit-required
  no-username
  disable-cisco-passwords
  min-password-length 6
!
logging localhost
logging loglevel 6
!
cdp timer 60
cdp holdtime 180
cdp run GigabitEthernet 0
!
icmp echo on
!

ncs/admin#

```

Related Commands

Command	Description
configure	Enters configuration mode.
show startup-config	Displays the contents of the startup configuration file or the configuration.

show startup-config

To display the contents of the startup configuration file or the configuration, use the **show startup-config** command in EXEC mode.

showstartup-config**Syntax Description**

This command has no arguments or keywords.

Command Default

The **show startup-config** command displays all of the startup configuration information.

Command Modes

EXEC

```

ncs/admin# show startup-config
!
hostname ncs
!
ip domain-name cisco.com
!

```

```

interface GigabitEthernet 0
  ip address 172.23.90.113 255.255.255.0
  ipv6 address autoconfig
  !
ip name-server 172.16.168.183
!
ip default-gateway 172.23.90.1
!
clock timezone UTC
!
ntp server time.nist.gov
!
username admin password hash $1$JbbHvKVG$xMZ/XL4tH15Knf.FfcZZr. role admin
!
service sshd
!
password-policy
  lower-case-required
  upper-case-required
  digit-required
  no-username
  disable-cisco-passwords
  min-password-length 6
!
logging localhost
logging loglevel 6
!
cdp timer 60
cdp holdtime 180
cdp run GigabitEthernet 0
!
icmp echo on
!
ncs/admin#

```

Related Commands	Command	Description
	configure	Enters configuration mode.
	show running-config	Displays the contents of the currently running configuration file or the configuration.

show security-status

To display the security-related configuration information, use the **show security-status** command in EXEC mode.

show security-status

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes EXEC

Example

```

pi-system/admin# show security-status

Open TCP Ports : 21 22 80 443 1522 8078 8080 8082 8087 9992 20828 61617
Open UDP Ports : 69 162 514 9991

FIPS Mode      : disabled
SSH Legacy     :
Algorithms    : enabled

TFTP Service   : enabled
FTP Service    : enabled

JMS port(61617) : enabled
Root Access    : enabled

Certificate validation settings for pubnet
Cert check     : enabled
OCSP check     : disabled
Auto CA update : enabled

Certificate validation settings for system
Cert check     : trust-on-first-use
OCSP check     : disabled
Auto CA update : disabled

Certificate validation settings for devicemgmt
Cert check     : enabled
OCSP check     : disabled
Auto CA update : enabled

Certificate validation settings for user
Cert check     : enabled
OCSP check     : disabled
Auto CA update : disabled

Algorithm settings enabled for SSH service
KexAlgorithms :
diffie-hellman-group16-sha512,diffie-hellman-group14-sha256,ecdh-sha2-nistp521,ecdh-sha2-nistp384,ecdh-s
ha2-nistp256,diffie-hellman-group18-sha512,diffie-hellman-group14-sha1,diffie-hellman-group-exchange-sha256,diffie-hellman
-group-exchange-sha1,diffie-hellman-group1-sha1
MACs           : hmac-sha2-512,hmac-sha2-256,hmac-sha1
Ciphers        :
aes128-gcm@openssh.com,aes128-ctr,chacha20-poly1305@openssh.com,aes256-ctr,aes256-gcm@openssh.com,aes192
-ctr,3des-cbc,aes128-cbc,aes256-cbc

TLS versions   : TLSv1.2
TLS ciphers    : tls-ecdhe-sha1

Note : Shows currently configured values
Changes made after last system start if any,
will be effective after next restart

```

show tech-support

To display technical support information, including email, use the **show tech-support** command in EXEC mode.

show tech-support file [word]

Syntax Description	file	Saves any technical support data as a file in the local disk.
	word	Filename to save. Up to 80 alphanumeric characters.

Command Default Passwords and other security information do not appear in the output.

Command Modes EXEC

Usage Guidelines The **show tech-support** command is useful for collecting a large amount of information about your Prime Infrastructure server for troubleshooting purposes. You can then provide output to technical support representatives when reporting a problem.

```

ncs/admin# show tech-support
#####
Application Deployment Engine(ADE) - 2.0.0.568
Technical Support Debug Info follows...
#####

*****
Checking dmidecode Serial Number(s)
*****
None
VMware-56 4d 14 cb 54 3d 44 5d-49 ee c4 ad a5 6a 88 c4

*****
Displaying System Uptime...
*****
12:54:34 up 18:37, 1 user, load average: 0.14, 0.13, 0.12

*****
Display Memory Usage(KB)
*****
total used free shared buffers cached
Mem: 1035164 1006180 28984 0 10784 345464
-/+ buffers/cache: 649932 385232
Swap: 2040244 572700 1467544

*****
Displaying Processes(ax --forest)...
*****
PID TTY STAT TIME COMMAND
1 ? Ss 0:02 init [3]
2 ? S< 0:00 [migration/0]
3 ? SN 0:00 [ksoftirqd/0]
4 ? S< 0:00 [watchdog/0]
5 ? S< 0:00 [events/0]
--More--
(press Spacebar to continue)

ncs/admin#
    
```

Related Commands	Command	Description
	show interface	Displays the usability status of the interfaces.

Command	Description
show process	Displays information about active processes.
show running-config	Displays the contents of the current running configuration.

show terminal

To obtain information about the terminal configuration parameter settings, use the **show terminal** command in EXEC mode.

show terminal

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes EXEC

```
ncs/admin# show terminal
TTY: /dev/pts/0 Type: "vt100"
Length: 27 lines, Width: 80 columns
Session Timeout: 30 minutes
ncs/admin#
```

show terminal describes the fields of the **show terminal** output.

Table 13: Show Terminal Field Descriptions

Field	Description
TTY: /dev/pts/0	Displays standard output to type of terminal.
Type: "vt100"	Type of current terminal used.
Length: 24 lines	Length of the terminal display.
Width: 80 columns	Width of the terminal display, in character columns.
Session Timeout: 30 minutes	Length of time, in minutes, for a session, after which the connection closes.

show timezone

To display the time zone set on the system, use the **show timezone** command in EXEC mode.

show timezone

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes EXEC

```
pi-system/admin# show timezone
Asia/Kolkata
pi-system/admin#
```

Related Commands

Command	Description
clock timezone	Sets the time zone on the system.
show timezones	Displays the time zones available on the system.

show timezones

To obtain a list of time zones from which you can select, use the **show timezones** command in EXEC mode.

show timezones

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines See the [clock timezone](#) command, for examples of the time zones available for the Prime Infrastructure server.

```
ncs/admin# show timezones
Africa/Blantyre
Africa/Dar_es_Salaam
Africa/Dakar
Africa/Asmara
Africa/Timbuktu
Africa/Maputo
Africa/Accra
Africa/Kigali
Africa/Tunis
Africa/Nouakchott
Africa/Ouagadougou
Africa/Windhoek
Africa/Douala
Africa/Johannesburg
Africa/Luanda
Africa/Lagos
Africa/Djibouti
Africa/Khartoum
Africa/Monrovia
Africa/Bujumbura
Africa/Porto-Novo
Africa/Malabo
Africa/Ceuta
Africa/Banjul
Africa/Cairo
```

```

Africa/Mogadishu
Africa/Brazzaville
Africa/Kampala
Africa/Sao_Tome
Africa/Algiers
Africa/Addis_Ababa
Africa/Ndjamena
Africa/Gaborone
Africa/Bamako
Africa/Freetown
--More--
(press Spacebar to continue)

ncs/admin#

```

Related Commands

Command	Description
show timezone	Displays the time zone set on the system.
clock timezone	Sets the time zone on the system.

show udi

To display information about the UDI of the Cisco ISE 3315 appliance, use the **show udi** command in EXEC mode.

show udi**Syntax Description**

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

EXEC

The following output appears when you run the **show udi** on **Hyper V** appliance server.

Example 1

```

pi-system/admin# sh udi
SPID: Cisco-HY-SPID
VPID: V02
Serial: KDGLLPDJDC

pi-system-241/admin#

```

The following output appears when you run the **show udi** on **Gen 2** appliance server.

Example 2

```

pi-system/admin# sh udi
PID: PI-UCS-APL-K9
VPID: A0
Serial: FCH1842V1EH

pi-system-117/admin#

```

show uptime

To display the length of time that you have been logged in to the Prime Infrastructure server, use the **show uptime** command in EXEC mode.

show uptime |

Syntax Description	<p>(Optional) Output modifier variables:</p> <ul style="list-style-type: none"> • <i>begin</i>—Matched pattern. Up to 80 alphanumeric characters. • <i>count</i>—Counts the number of lines in the output. Add number after the word <i>count</i>. • <i>end</i>—Ends with line that matches. Up to 80 alphanumeric characters. • <i>exclude</i>—Excludes lines that match. Up to 80 alphanumeric characters. • <i>include</i>—Include lines that match. Up to 80 alphanumeric characters. • <i>last</i>—Displays last few lines of output. Add number after the word <i>last</i>. Up to 80 lines to display. Default 10.
Command Default	No default behavior or values.
Command Modes	EXEC
	<pre>ncs/admin# show uptime 3 day(s), 18:55:02 ncs/admin#</pre>

show users

To display the list of users logged in to the Prime Infrastructure server, use the **show users** command in EXEC mode.

show users

Syntax Description	This command has no arguments or keywords.
Command Default	No default behavior or values.
Command Modes	EXEC
	<pre>ncs/admin# show users USERNAME ROLE HOST TTY LOGIN DATETIME</pre>

```
admin Admin 10.77.137.60 pts/0 Fri0000 Aug 6 09:45:47 2019
ncs/admin#
```

show version

To display information about the software version of the system, use the **show version** command in EXEC mode.

show version

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes EXEC

Usage Guidelines This command displays version information about the Cisco ADE-OS software running on the Prime Infrastructure server, and displays the Prime Infrastructure version.

```
pi-system-226/admin# show version

Cisco Application Deployment Engine OS Release: 4.1
ADE-OS Build Version: 4.1.0.001
ADE-OS System Architecture: x86_64

Copyright (c) 2009-2020 by Cisco Systems, Inc.
All rights reserved.
Hostname: pi-system-226

Version information of installed applications
-----

Cisco Prime Infrastructure
*****
Version : 3.8.0 [FIPS not Enabled]
Build : 3.8.0.0.310
pi-system-226/admin#
```

Configuration Commands

This section lists the **configuration commands** along with a brief description of their use, command defaults, command syntax, command modes, usage guidelines, command examples, and related commands, where applicable.

Configuration commands include **interface** and **repository**.



Note Some of the configuration commands require you to enter the configuration submode to complete the command configuration.

To access configuration mode, you must use the **configure** command in EXEC mode.

aaa authentication

To configure external authentication, use the **aaa authentication** command in configuration mode.

aaa authentication tacacs+ server *TACACS server address* **key plain** *shared-key*

Syntax Description	<i>TACACS server address</i>	IP address or hostname of the TACACS+ server.
	<i>shared-key</i>	Indicates the shared secret text string.

Command Default No default behavior or values.

Command Modes Configuration

```
admin# aaa authentication tacacs+ server 1.1.1.5 key plain Secret
admin# username tacacsuser password remote role admin
```

Ensure that the TACACS+ server has the same user name of the Prime Infrastructure server, and Prime Infrastructure and TACACS+ servers are integrated properly.

backup-staging-url

You can use this option to configure a Network File System (NFS) share on Cisco Prime Infrastructure when partition is low on disk space and a backup cannot be taken. You can do so by using the **backup-staging-url** command in configuration mode.

backup-staging-url *word*

Syntax Description	<i>word</i>	NFS URL for staging area. Up to 2048 alphanumeric characters. Use nfs://server:path(1) .
---------------------------	-------------	---

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines The URL is NFS only. The format of the command is **backup-staging-url nfs://server:path**.



Caution Ensure that you secure your NFS server in such a way that the directory can be accessed only by the IP address of the Prime Infrastructure server.

```
ncs/admin(config)# backup-staging-url nfs://loc-filer02a:/vol/local1/private1/jdoe
ncs/admin(config)#
```

cdp holdtime

To specify the amount of time for which the receiving device should hold a Cisco Discovery Protocol packet from the Prime Infrastructure server before discarding it, use the **cdp holdtime** command in configuration mode. To revert to the default setting, use the **no** form of this command.

[no] cdp holdtime *seconds*

Syntax Description	<i>seconds</i>	Specifies the hold time, in seconds. Value from 10 to 255 seconds.
---------------------------	----------------	--

Command Default 180 seconds

Command Modes Configuration

Usage Guidelines Cisco Discovery Protocol packets transmit with a time to live, or hold time, value. The receiving device will discard the Cisco Discovery Protocol information in the Cisco Discovery Protocol packet after the hold time has elapsed.

The **cdp holdtime** command takes only one argument; otherwise, an error occurs.

```
ncs/admin(config)# cdp holdtime 60
ncs/admin(config)#
```

Related Commands	Description
cdp timer	Specifies how often the Prime Infrastructure server sends Cisco Discovery Protocol updates.
cdp run	Enables the Cisco Discovery Protocol.

cdp run

To enable the Cisco Discovery Protocol, use the **cdp run** command in configuration mode. To disable the Cisco Discovery Protocol, use the **no** form of this command.

[no] cdp run [*GigabitEthernet*]

Syntax Description	<i>GigabitEthernet</i>	Specifies the Gigabit Ethernet interface on which to enable the Cisco Discovery Protocol.
---------------------------	------------------------	---

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines The command has one optional argument, which is an interface name. Without an optional interface name, the command enables the Cisco Discovery Protocol on all interfaces.



Note The default for this command is on interfaces that are already up and running. When you are bringing up an interface, stop the Cisco Discovery Protocol first; then, start the Cisco Discovery Protocol again.

```
ncs/admin(config)# cdp run GigabitEthernet 0
ncs/admin(config)#
```

Related Commands

	Description
cdp holdtime	Specifies the length of time that the receiving device should hold a Cisco Discovery Protocol packet from the Prime Infrastructure server before discarding it.
cdp timer	Specifies how often the Prime Infrastructure server sends Cisco Discovery Protocol updates.

cdp timer

To specify how often the Prime Infrastructure server sends Cisco Discovery Protocol updates, use the **cdp timer** command in configuration mode. To revert to the default setting, use the **no** form of this command.

[no] cdp timer *seconds*

Syntax Description

<i>seconds</i>	Specifies how often, in seconds, the Prime Infrastructure server sends Cisco Discovery Protocol updates. Value from 5 to 254 seconds.
----------------	---

Command Default

60 seconds

Command Modes

Configuration

Usage Guidelines

Cisco Discovery Protocol packets transmit with a time to live, or hold time, value. The receiving device will discard the Cisco Discovery Protocol information in the Cisco Discovery Protocol packet after the hold time has elapsed.

The **cdp timer** command takes only one argument; otherwise, an error occurs.

```
ncs/admin(config)# cdp timer 60
ncs/admin(config)#
```

Related Commands

	Description
cdp holdtime	Specifies the amount of time that the receiving device should hold a Cisco Discovery Protocol packet from the Prime Infrastructure server before discarding it.

	Description
<code>cdp run</code>	Enables the Cisco Discovery Protocol.

clock timezone

To set the time zone, use the **clock timezone** command in configuration mode. To disable this function, use the **no** form of this command.

clock timezone *timezone*

Syntax Description

timezone Name of the time zone visible when in standard time. Up to 64 alphanumeric characters.

Command Default

UTC

Command Modes

Configuration

Usage Guidelines

The system internally keeps time in Coordinated Universal Time (UTC). If you do not know your specific time zone, you can enter the region, country, and city (see Tables [Table 14: Common Time Zones](#), [Table 15: Australia Time Zones](#), and [Table 16: Asia Time Zones](#) for sample time zones to enter on your system).

Table 14: Common Time Zones

Acronym or name	Time Zone Name
Europe	
GMT, GMT0, GMT-0, GMT+0, UTC, Greenwich, Universal, Zulu	Greenwich Mean Time, as UTC
GB	British
GB-Eire, Eire	Irish
WET	Western Europe Time, as UTC
CET	Central Europe Time, as UTC + 1 hour
EET	Eastern Europe Time, as UTC + 2 hours
United States and Canada	
EST, EST5EDT	Eastern Standard Time, as UTC -5 hours
CST, CST6CDT	Central Standard Time, as UTC -6 hours
MST, MST7MDT	Mountain Standard Time, as UTC -7 hours
PST, PST8PDT	Pacific Standard Time, as UTC -8 hours
HST	Hawaiian Standard Time, as UTC -10 hours

Table 15: Australia Time Zones

AustraliaFootnote.			
ACTFootnote.	Adelaide	Brisbane	Broken_Hill
Canberra	Currie	Darwin	Hobart
Lord_Howe	Lindeman	LHIFootnote.	Melbourne
North	NSWFootnote.	Perth	Queensland
South	Sydney	Tasmania	Victoria
West	Yancowinna		

³ (1) Enter the country and city together with a forward slash (/) between them; for example, Australia/Currie.

⁴ (2) ACT = Australian Capital Territory

⁵ (3) LHI = Lord Howe Island

⁶ (4) NSW = New South Wales

Table 16: Asia Time Zones

AsiaFootnote.			
AdenFootnote.	Almaty	Amman	Anadyr
Aqtau	Aqtobe	Ashgabat	Ashkhabad
Baghdad	Bahrain	Baku	Bangkok
Beirut	Bishkek	Brunei	Calcutta
Choibalsan	Chongqing	Columbo	Damascus
Dhakar	Dili	Dubai	Dushanbe
Gaza	Harbin	Hong_Kong	Hovd
Irkutsk	Istanbul	Jakarta	Jayapura
Jerusalem	Kabul	Kamchatka	Karachi
Kashgar	Katmandu	Kuala_Lumpur	Kuching
Kuwait	Krasnoyarsk		

⁷ (1) The Asia time zone includes cities from East Asia, Southern Southeast Asia, West Asia, and Central Asia.

⁸ (2) Enter the region and city or country together separated by a forward slash (/); for example, Asia/Aden.



Note Several more time zones are available to you. On your Prime Infrastructure server, enter the **show timezones** command. A list of all of the time zones available in the Prime Infrastructure server appears. Choose the most appropriate one for your time zone.

```
pi-admin/admin(config)# conf t
Enter configuration commands, one per line. End with CNTL/Z.
pi-admin/admin(config)# clock timezone Asia/Kolkata
pi-admin/admin(config)#
```

Related Commands

	Description
show timezones, on page 125	Displays a list of available time zones on the system.
show timezone, on page 124	Displays the current time zone set on the system.

do

To execute an EXEC-level command from configuration mode or any configuration submode, use the **do** command in any configuration mode.

do

Syntax Description

This command has no arguments or keywords.

Table 17: Command Options for the Do Command

	Description
application install	Installs a specific application.
application remove	Removes a specific application.
application start	Starts or enables a specific application
application stop	Stops or disables a specific application.
application upgrade	Upgrades a specific application.
backup	Performs a backup (Prime Infrastructure and Cisco ADE OS) and places the backup in a repository.
backup-logs	Performs a backup of all of the logs on the Prime Infrastructure server to a remote location.
clock	Sets the system clock on the Prime Infrastructure server.
configure	Enters configuration mode.

	Description
copy	Copies any file from a source to a destination.
debug	Displays any errors or events for various command situations; for example, backup and restore, configuration, copy, resource locking, file transfer, and user management.
delete	Deletes a file on the Prime Infrastructure server.
dir	Lists files on the Prime Infrastructure server.
forceout	Forces the logout of all of the sessions of a specific Prime Infrastructure node user.
halt	Disables or shuts down the Prime Infrastructure server.
mkdir	Creates a new directory.
nslookup	Queries the IPv4 address or hostname of a remote system.
patch	Install System or Application patch.
pep	Configures the Inline PEP node.
ping	Determines the IPv4 network activity on a remote system.
ping6	Determines the IPv6 network activity on a IPv6 remote system.
reload	Reboots the Prime Infrastructure server.
restore	Performs a restore and retrieves the backup out of a repository.
rmdir	Removes an existing directory.
show	Provides information about the Prime Infrastructure server.
ssh	Starts an encrypted session with a remote system.
tech	Provides Technical Assistance Center (TAC) commands.
telnet	Establishes a Telnet connection to a remote system.
terminal length	Sets terminal line parameters.
terminal session-timeout	Sets the inactivity timeout for all terminal sessions.

	Description
terminal session-welcome	Sets the welcome message on the system for all terminal sessions.
terminal terminal-type	Specifies the type of terminal connected to the current line of the current session.
traceroute	Traces the route of a remote IP address.
undebug	Disables the output (display of errors or events) of the debug command for various command situations; for example, backup and restore, configuration, copy, resource locking, file transfer, and user management.
write	Erases the startup configuration that forces the setup utility to run and prompts the network configuration, copies the running configuration to the startup configuration, and displays the running configuration on the console.

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines Use this command to execute EXEC commands (such as **show**, **clear**, and **debug** commands) while configuring your server. After the EXEC command executes, the system will return to the configuration mode that you were using.

```

ncs/admin(config)# do show run
Generating configuration...
!
hostname ncs
!
ip domain-name cisco.com
!
interface GigabitEthernet 0
  ip address 172.23.90.113 255.255.255.0
  ipv6 address autoconfig
!
ip name-server 172.16.168.183
!
ip default-gateway 172.23.90.1
!
clock timezone EST
!
ntp server time.nist.gov
!
username admin password hash $1$JbbHvKVG$xMZ/XL4tH15Knf.FfcZZr. role admin
!
service sshd
!
backup-staging-url nfs://loc-filer02a:/vol/local1/private1/jdoe
!
password-policy
  lower-case-required

```

```

upper-case-required
digit-required
no-username
disable-cisco-passwords
min-password-length 6
!
logging localhost
logging loglevel 6
!
--More--

ncs/admin(config)#

```

end

To end the current configuration session and return to EXEC mode, use the **end** command in configuration mode.

end

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines This command brings you back to EXEC mode regardless of what configuration mode or submode you are in.

Use this command when you finish configuring the system and you want to return to EXEC mode to perform verification steps.

```

ncs/admin(config)# end
ncs/admin#

```

Related Commands

Command	Description
exit	Exits configuration mode.
exit (EXEC)	Closes the active terminal session by logging out of the Prime Infrastructure server.

exit

To exit any configuration mode to the next-highest mode in the CLI mode hierarchy, use the **exit** command in configuration mode.

exit

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines The **exit** command is used in the Prime Infrastructure server to exit the current command mode to the next highest command mode in the CLI mode hierarchy.

For example, use the **exit** command in configuration mode to return to EXEC mode. Use the **exit** command in the configuration submodes to return to configuration mode. At the highest level, EXEC mode, the **exit** command exits the EXEC mode and disconnects from the Prime Infrastructure server (see [exit](#), for a description of the **exit** (EXEC) command).

```
ncs/admin(config)# exit
ncs/admin#
```

Related Commands

Command	Description
end	Exits configuration mode.
exit (EXEC)	Closes the active terminal session by logging out of the Prime Infrastructure server.

hostname

To set the hostname of the system, use the **hostname** command in configuration mode. To delete the hostname from the system, use the **no** form of this command, which resets the system to localhost.

[no] hostname word

Syntax Description

<i>word</i>	Name of the host. Contains at least 2 to 64 alphanumeric characters and an underscore (_). The hostname must begin with a character that is not a space.
-------------	--

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines A single instance type of command, **hostname** only occurs once in the configuration of the system. The hostname must contain one argument; otherwise, an error occurs.

```
ncs/admin(config)# hostname ncs-1
Changing the hostname or IP may result in undesired side effects,
such as installed application(s) being restarted.
Are you sure you want to proceed? [y/n] y
Stopping NCS Monitoring & Troubleshooting Log Processor...
Stopping NCS Monitoring & Troubleshooting Log Collector...
Stopping NCS Monitoring & Troubleshooting Alert Process...
Stopping NCS Application Server...
Stopping NCS Monitoring & Troubleshooting Session Database...
Stopping NCS Database processes...
```

```
Starting NCS Database processes...
Starting NCS Monitoring & Troubleshooting Session Database...
Starting NCS Application Server...
Starting NCS Monitoring & Troubleshooting Log Collector...
Starting NCS Monitoring & Troubleshooting Log Processor...
Starting NCS Monitoring & Troubleshooting Alert Process...
Note: NCS Processes are initializing. Use 'show application status ncs'
      CLI to verify all processes are in running state.
```

```
ncs-1/admin(config)#
```

```
ncs-1/admin# show application status ncs
```

```
NCS Database listener is running, PID: 11142
NCS Database is running, number of processes: 29
NCS Application Server is still initializing.
NCS M&T Session Database is running, PID: 11410
NCS M&T Log Collector is running, PID: 11532
NCS M&T Log Processor is running, PID: 11555
NCS M&T Alert Process is running, PID: 11623
```

```
ncs-1/admin#
```

icmp echo

To configure the Internet Control Message Protocol (ICMP) echo responses, use the **icmp echo** command in configuration mode.

```
icmp echo {off | on}
```

Syntax Description

off	Disables ICMP echo response.
on	Enables ICMP echo response.

Command Default

The system behaves as if the ICMP echo response is on (enabled).

Command Modes

Configuration

```
ncs/admin(config)# icmp echo off
ncs/admin(config)#
```

Related Commands

Command	Description
show icmp_status	Display ICMP echo response configuration information.

interface

To configure an interface type and enter interface configuration mode, use the **interface** command in configuration mode.



Note VMware virtual machine may have a number of interfaces available. This depends on how many network interfaces (NIC) are added to the virtual machine.

interface GigabitEthernet ip-address

Syntax Description

GigabitEthernet	Configures the Gigabit Ethernet interface.
0 - 3	Number of the Gigabit Ethernet port to configure.



Note After you enter the Gigabit Ethernet port number in the **interface** command, you enter config-GigabitEthernet configuration submode (see the following Syntax Description).

do	EXEC command. Allows you to perform any EXEC commands in this mode (see do).
end	Exits config-GigabitEthernet submode and returns you to EXEC mode.
exit	Exits the config-GigabitEthernet configuration submode.
ip	Sets IP address and netmask for the Ethernet interface (see ip address).
ipv6	Configures the IPv6 autoconfiguration address and IPv6 address from DHCPv6 server. (see ipv6 address autoconfig and ipv6 address dhcp).
no	Negates the command in this mode. Two keywords are available: <ul style="list-style-type: none"> • ip—Sets the IP address and netmask for the interface. • shutdown—Shuts down the interface.
shutdown	Shuts down the interface (see shutdown).

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines You can use the **interface** command to configure subinterfaces to support various requirements.

```
ncs/admin(config)# interface GigabitEthernet 0
ncs/admin(config-GigabitEthernet)#
```


Related Commands	Command	Description
	show interface	Displays information about the system interfaces.
	ip address (interface configuration mode)	Sets the IP address and netmask for the interface.
	shutdown (interface configuration mode)	Shuts down the interface (see shutdown).

ipv6 address autoconfig

To enable IPv6 stateless autoconfiguration, use the **ipv6 address autoconfig** command in configuration mode. To remove the address from the interface, use the **no** form of this command.

[no] ipv6 address autoconfig [default]0

Syntax Description	default	(Optional) If a default router is selected on this interface, the default keyword causes a default route to be installed using that default router.
		The default keyword can be specified only on one interface.

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines IPv6 stateless autoconfiguration has the security downfall of having predictable IP addresses. This downfall is resolved with privacy extensions. You can verify that the privacy extensions feature is enabled using the **show** command.

IPv6 address autoconfiguration is enabled by default in Linux. Cisco ADE 2.0 shows the IPv6 address autoconfiguration in the running configuration for any interface that is enabled.

Example 1

```
ncs/admin# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
ncs/admin(config)# interface GigabitEthernet 0
ncs/admin(config)# (config-GigabitEthernet)# ipv6 address autoconfig
ncs/admin(config)# (config-GigabitEthernet)# end
ncs/admin#
```

When IPv6 autoconfiguration is enabled, the running configuration shows the interface settings similar to the following:

```
!
interface GigabitEthernet 0
 ip address 172.23.90.116 255.255.255.0
 ipv6 address autoconfig
!
```

You can use the **show interface GigabitEthernet 0** command to display the interface settings. In example 2, you can see that the interface has three IPv6 addresses. The first address (starting with 3ffe) is obtained using the stateless autoconfiguration. For the stateless autoconfiguration to work,

you must have IPv6 route advertisement enabled on that subnet. The next address (starting with fe80) is a link-local address that does not have any scope outside the host. You will always see a link local address regardless of the IPv6 autoconfiguration or DHCPv6 configuration. The last address (starting with 2001) is obtained from a IPv6 DHCP server.

Example 2

```
ncs/admin# show interface GigabitEthernet 0
eth0      Link encap:Ethernet HWaddr 00:0C:29:AF:DA:05
          inet addr:172.23.90.116 Bcast:172.23.90.255 Mask:255.255.255.0
          inet6 addr: 3ffe:302:11:2:20c:29ff:feaf:da05/64 Scope:Global
          inet6 addr: fe80::20c:29ff:feaf:da05/64 Scope:Link
          inet6 addr: 2001:558:ff10:870:8000:29ff:fe36:200/64 Scope:Global
          UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
          RX packets:77848 errors:0 dropped:0 overruns:0 frame:0
          TX packets:23131 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:10699801 (10.2 MiB) TX bytes:3448374 (3.2 MiB)
          Interrupt:59 Base address:0x2000
```

```
ncs/admin#
```

To verify that the privacy extensions feature is enabled, you can use the **show interface GigabitEthernet 0** command. You can see two autoconfiguration addresses: one address is without the privacy extensions, and the other is with the privacy extensions.

In the example 3 below, the MAC is 3ffe:302:11:2:20c:29ff:feaf:da05/64 and the non-RFC3041 address contains the MAC, and the privacy-extension address is 302:11:2:9d65:e608:59a9:d4b9/64.

The output appears similar to the following:

Example 3

```
ncs/admin# show interface GigabitEthernet 0
eth0      Link encap:Ethernet HWaddr 00:0C:29:AF:DA:05
          inet addr:172.23.90.116 Bcast:172.23.90.255 Mask:255.255.255.0
          inet6 addr: 3ffe:302:11:2:9d65:e608:59a9:d4b9/64 Scope:Global
          inet6 addr: 3ffe:302:11:2:20c:29ff:feaf:da05/64 Scope:Global
          inet6 addr: fe80::20c:29ff:feaf:da05/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
          RX packets:60606 errors:0 dropped:0 overruns:0 frame:0
          TX packets:2771 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:9430102 (8.9 MiB) TX bytes:466204 (455.2 KiB)
          Interrupt:59 Base address:0x2000
```

```
ncs/admin#
```

Related Commands

Command	Description
show interface	Displays information about the system interfaces.
ip address (interface configuration mode)	Sets the IP address and netmask for the interface.
shutdown (interface configuration mode)	Shuts down the interface (see shutdown).
ipv6 address dhcp	Enables IPv6 address DHCP on an interface.

Command	Description
show running-config	Displays the contents of the currently running configuration file or the configuration.

ipv6 address dhcp

To enable IPv6 address DHCP, use the **ipv6 address dhcp** command in configuration mode. To remove the address from the interface, use the **no** form of this command.

[no] ipv6 address dhcp [rapid-commit] 0

Syntax Description	[rapid-commit]	(Optional) Allows the two-message exchange method for address assignment.
	0	Gigabit Ethernet port number to be configured.
Command Default	No default behavior or values.	
Command Modes	Configuration	
Usage Guidelines	None.	

```

ncs/admin# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ncs/admin(config)# interface GigabitEthernet 0
ncs/admin(config-GigabitEthernet)# ipv6 address dhcp
ncs/admin(config-GigabitEthernet)# end
ncs/admin#

```

When IPv6 DHCPv6 is enabled, the running configuration shows the interface settings similar to the following:

```

!
interface GigabitEthernet 0
 ip address 172.23.90.116 255.255.255.0
  ipv6 address dhcp
!

```



Note The IPv6 stateless autoconfiguration and IPv6 address DHCP are not mutually exclusive. It is possible to have both IPv6 stateless autoconfiguration and IPv6 address DHCP on the same interface. You can use the **show interface** to display what IPv6 addresses are in use for a particular interface.

When both the IPv6 stateless autoconfiguration and IPv6 address DHCP are enabled, the running configuration shows the interface settings similar to the following:

```

!
interface GigabitEthernet 0
 ip address 172.23.90.116 255.255.255.0

```

ipv6 address static

```
ipv6 address dhcp
!
```

Related Commands

Command	Description
show interface	Displays information about the system interfaces.
ip address (interface configuration mode)	Sets the IP address and netmask for the interface.
shutdown (interface configuration mode)	Shuts down the interface (see shutdown).
ipv6 address autoconfig	Enables IPv6 stateless autoconfiguration on an interface.
show running-config	Displays the contents of the currently running configuration file or the configuration.

ipv6 address static

To assign static IPv6 address, use the **ipv6 address static** command in configuration mode. To remove the address from the interface, use the **no** form of this command.

ipv6 address static [ipv6 address] 0

Command Default

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

None.

```
admin(config-GigabitEthernet)# ipv6 address static 0:0:0:0:ffff:a7e:a9d2
admin(config-GigabitEthernet)# ipv6 default-gateway 0:0:0:0:ffff:ffff:ffe0
```

Related Commands

Command	Description
ipv6 address autoconfig	Enables IPv6 stateless autoconfiguration on an interface.
ipv6 address dhcp, on page 143	Enables IPv6 address DHCP on an interface.

ip address

To set the IP address and netmask for the Ethernet interface, use the **ip address** command in interface configuration mode. To remove an IP address or disable IP processing, use the **no** form of this command.

[no] ip address ip-address netmask



Note You can configure the same IP address on multiple interfaces. You might want to do this to limit the configuration steps that are needed to switch from using one interface to another.

Syntax Description	ip-address	IPv4 version IP address.
	netmask	Mask of the associated IP subnet.

Command Default Enabled.

Command Modes Interface configuration

Usage Guidelines Requires exactly one address and one netmask; otherwise, an error occurs.

```

ncs/admin(config)# interface GigabitEthernet 1
ncs/admin(config-GigabitEthernet)# ip address 209.165.200.227 255.255.255.224
Changing the hostname or IP may result in undesired side effects,
such as installed application(s) being restarted.
.....
To verify that NCS processes are running, use the
'show application status ncs' command.
ncs/admin(config-GigabitEthernet)#

```

Related Commands	Command	Description
	shutdown (interface configuration mode)	Disables an interface (see shutdown).
	ip default-gateway	Sets the IP address of the default gateway of an interface.
	show interface	Displays information about the system IP interfaces.
	interface	Configures an interface type and enters the interface mode.

ip default-gateway

To define or set a default gateway with an IP address, use the **ip default-gateway** command in configuration mode. To disable this function, use the **no** form of this command.

[no] ip default-gateway ip-address

Syntax Description	ip-address	IP address of the default gateway.
---------------------------	------------	------------------------------------

Command Default Disabled.

Command Modes Configuration

Usage Guidelines

If you enter more than one argument or no arguments at all, an error occurs.

```
ncs/admin(config)# ip default-gateway 209.165.202.129
ncs/admin(config)#
```

Related Commands

Command	Description
ip address (interface configuration mode)	Sets the IP address and netmask for the Ethernet interface.

ip domain-name

To define a default domain name that the Prime Infrastructure server uses to complete hostnames, use the **ip domain-name** command in configuration mode. To disable this function, use the **no** form of this command.

[no] ip domain-name word

Syntax Description

word	Default domain name used to complete the hostnames. Contains at least 2 to 64 alphanumeric characters.
------	--

Command Default

Enabled.

Command Modes

Configuration

Usage Guidelines

If you enter more or fewer arguments, an error occurs.

```
ncs/admin(config)# ip domain-name cisco.com
ncs/admin(config)#
```

Related Commands

	Description
ip name-server	Sets the DNS servers for use during a DNS query.

ip name-server

To set the Domain Name Server (DNS) servers for use during a DNS query, use the **ip name-server** command in configuration mode. You can configure one to three DNS servers. To disable this function, use the **no** form of this command.

**Note**

Using the **no** form of this command removes all of the name servers from the configuration. Using the **no** form of this command and one of the IP names removes only that IP name server.

[no] ip name-server *ip-address [ip-address*]}*

Syntax Description	<i>ip-address</i>	Address of a name server.
	<i>ip-address*</i>	(Optional) IP addresses of additional name servers.
	Note	You can configure a maximum of three name servers.
Command Default	No default behavior or values.	
Command Modes	Configuration	
Usage Guidelines	<p>The first name server that is added with the ip name-server command occupies the first position and the system uses that server first to resolve the IP addresses.</p> <p>You can add name servers to the system one at a time or all at once, until you reach the maximum (3). If you already configured the system with three name servers, you must remove at least one server to add additional name servers.</p> <p>To place a name server in the first position so that the subsystem uses it first, you must remove all name servers with the no form of this command before you proceed.</p> <pre>ncs/admin(config)# ip name-server 209.165.201.1</pre> <p>To verify that NCS processes are running, use the 'show application status ncs' command.</p> <pre>ncs/admin(config)#</pre> <p>You can choose not to restart the Prime Infrastructure server; nevertheless, the changes will take effect.</p>	

Related Commands	Command	Description
	ip domain-name	Defines a default domain name that the server uses to complete hostnames.

ip route

To configure the static routes, use the **ip route** command in configuration mode. To remove static routes, use the **no** form of this command.

ip route prefix mask **gateway** ip-address

no ip route prefix mask

Syntax Description	prefix	IP route prefix for the destination.
	mask	Prefix mask for the destination.
	gateway	Route-specific gateway

<i>ip-address</i>	IP address of the next hop that can be used to reach that network.
-------------------	--

Command Default

No default behavior or values.

Configuration.

Usage Guidelines

Static routes are manually configured, which makes them inflexible (they cannot dynamically adapt to network topology changes), but extremely stable. Static routes optimize bandwidth utilization, because no routing updates need to be sent to maintain them. They also make it easy to enforce routing policy.

```
ncs/admin(config)# ip route 192.168.0.0 255.255.0.0 gateway 172.23.90.2
ncs/admin(config)#
```

logging

To enable the system to forward logs to a remote system or to configure the log level, use the **logging** command in configuration mode. To disable this function, use the **no** form of this command.

[no] logging *{ip-address | hostname}* **{loglevel level}**

Syntax Description

<i>ip-address</i>	IP address of remote system to which you forward logs. Up to 32 alphanumeric characters.
<i>hostname</i>	Hostname of remote system to which you forward logs. Up to 32 alphanumeric characters.
loglevel	The command to configure the log level for the logging command.
<i>level</i>	Number of the desired priority level at which you set the log messages. Priority levels are (enter the number for the keyword): <ul style="list-style-type: none"> • 0-emerg—Emergencies: System unusable. • 1-alert—Alerts: Immediate action needed. • 2-crit—Critical: Critical conditions. • 3-err—Error: Error conditions. • 4-warn—Warning: Warning conditions. • 5-notif—Notifications: Normal but significant conditions. • 6-inform—(Default) Informational messages. • 7-debug—Debugging messages.

Command Default

No default behavior or values.

Command Modes Configuration

Usage Guidelines This command requires an IP address or hostname or the **loglevel** keyword; an error occurs if you enter two or more of these arguments.

Example 1

```
ncs/admin(config)# logging 209.165.200.225
ncs/admin(config)#
```

Example 2

```
ncs/admin(config)# logging loglevel 0
ncs/admin(config)#
```

Related Commands

Command	Description
show logging	Displays the list of logs for the system.

ntp server

To allow for software clock synchronization by the NTP server for the system, use the **ntp server** command in configuration mode. Allows up to three servers.

ntp server { *ntp-server* }

For the unauthenticated NTP servers, use the following command:

ntp server { *ntp-server* }

Syntax Description

<i>ntp-server</i>	IP address or hostname of the server providing the clock synchronization. Arguments are limited to 255 alphanumeric characters.
-------------------	---

Command Default

No servers are configured by default.

Command Modes

Configuration

Usage Guidelines

Use this command if you want to allow the system to synchronize with a specified server.



Note

The synchronization process can take up to 20 minutes to complete.

Related Commands

Command	Description
show ntp	Displays the status information about the NTP associations.

Example - NTP Server Addition

```
ncs/admin(config)# ntp server 192.0.2.1 10 plain password
ncs/admin(config)# ntp server 192.0.2.2 20 plain pass123
```

Example - NTP Server Initialization

```
ncs/admin# sh ntp
pi-ha-test-237-75/admin# sh ntp
NTP Server 1 : 192.0.2.1 : keyid=10
NTP Server 2 : 192.0.2.2
NTP Server 3 : 192.0.2.3 : keyid=10

unsynchronised
time server re-starting
polling server every 64 s

      remote          refid      st t when poll reach  delay  offset jitter
=====
192.0.2.1  .INIT.          16 u  -  64   0   0.000   0.000  0.000
192.0.2.2  .GPS.            1 u  43  64   7 250.340   0.523  1.620
192.0.2.3  192.0.2.2       2 u  41  64   7 231.451   7.517  3.434
```

Example - NTP Synchronization

```
ncs/admin# sh ntp
NTP Server 1 : 192.0.2.1 : keyid=10
NTP Server 2 : 192.0.2.2
NTP Server 3 : 192.0.2.3 : keyid=10

synchronised to NTP server (10.81.254.131) at stratum 2
time correct to within 569 ms
polling server every 64 s

      remote          refid      st t when poll reach  delay  offset jitter
=====
192.0.2.1  .INIT.          16 u  -  64   0   0.000   0.000  0.000
*192.0.2.2  .GPS.            1 u  12  64  37 243.863   3.605  4.240
192.0.2.3  192.0.2.2       2 u   8  64  37 231.451   7.517  3.784

Warning: Output results may conflict during periods of changing synchronization.
```

password-policy

To enable or configure the passwords on the system, use the **password-policy** command in configuration mode. To disable this function, use the **no** form of this command.

[no] password-policy option



Note The **password-policy** command requires a policy option (see Syntax Description). You must enter the **password-expiration-enabled** command before the other password-expiration commands.

Syntax Description

option Different command options.



Note After you enter the **password-policy** command, you can enter config-password-policy configuration submode.

digit-required	Requires a digit in the password.
disable-repeat-characters	Disables the ability of the password to contain more than four identical characters.
disable-cisco-password	Disables the ability to use the word Cisco or any combination as the password.
do	EXEC command.
end	Exits from configure mode.
exit	Exits from this submode.
lower-case-required	Requires a lowercase letter in the password.
min-password-length	Specifies a minimum number of characters for a valid password. Integer length from 1 to 40.
no	Negates a command or set its defaults.
no-previous-password	Prevents users from reusing a part of their previous password.
no-username	Prohibits users from reusing their username as a part of a password.
password-expiration-days	Number of days until a password expires. Integer length from 1 to 3600.
password-expiration-enabled	Enables password expiration. Note You must enter the password-expiration-enabled command before the other password-expiration commands.
password-expiration-warning	Number of days before expiration that warnings of impending expiration begin. Integer length from 0 to 3600.

password-lock-enabled	Locks a password after several failures.
password-lock-retry-count	Number of failed attempts before password locks. Integer length from 1 to 20.
upper-case-required	Requires an uppercase letter in the password.
special-required	Requires a special character in the password.

Command Default No default behavior or values.

Command Modes Configuration

```
ncs/admin(config)# password-policy
ncs/admin(config-password-policy)# password-expiration-days 30
ncs/admin(config-password-policy)# exit
ncs/admin(config)#
```

repository

To enter the repository submode for configuration of backups, use the **repository** command in configuration mode.

repository *repository-name*

Syntax Description *repository-name* Name of repository. Up to 80 alphanumeric characters.



Note After you enter the name of the repository in the **repository** command, you enter repository configuration submode.

do	EXEC command.
end	Exits repository config submode and returns you to EXEC mode.
exit	Exits this mode.
no	Negates the command in this mode. Two keywords are available: <ul style="list-style-type: none"> • url—Repository URL. • user—Repository username and password for access.
url	URL of the repository. Up to 80 alphanumeric characters (see Table A-20).

user	Configure the username and password for access. Up to 30 alphanumeric characters.
------	---

Table 18: URL Keywords

Keyword	Source of Destination
<i>word</i>	Enter the repository URL, including server and path info. Up to 80 alphanumeric characters.
cdrom:	Local CD-ROM drive (read only).
disk:	<p>Local storage.</p> <p>You can enter the show repository <i>repository_name</i> command to view all of the files in the local repository.</p> <p>Note All local repositories are created on the /localdisk partition. When you specify disk:/ in the repository URL, the system creates directories in a path that is relative to /localdisk. For example, if you entered disk:/backup, the directory is created at /localdisk/backup.</p>
ftp:	Source or destination URL for an FTP network server. Use url ftp://server/path(1) .
nfs:	Source or destination URL for an NFS network server. Use url nfs://server:path1.
sftp:	<p>Source or destination URL for an SFTP network server. Use url sftp://server/path1.</p> <p>Note SFTP Repositories may require the // between the ip address/FQDN and the physical path on the SFTP store. If you find that you cannot access the SFTP repository with single slashes, add the additional slash and try the operation again.</p> <p>Example:</p> <p>Repository SFTP-Store</p> <p>url sftp://server//path</p>
tftp:	<p>Source or destination URL for a TFTP network server. Use url tftp://server/path1.</p> <p>Note You cannot use a TFTP repository for performing a Prime Infrastructure upgrade.</p>

Command Default No default behavior or values.

Command Modes Configuration

Example 1

```
ncs/admin#
ncs/admin(config)# repository myrepository
ncs/admin(config-Repository)# url sftp://example.com/repository/system1
ncs/admin(config-Repository)# user abcd password plain example
ncs/admin(config-Repository)# exit
ncs/admin(config)# exit
ncs/admin#
```

Example 2

```
ncs/admin# configure terminal
ncs/admin(config)# repository myrepository
ncs/admin(config-Repository)# url disk:/
ncs/admin(config-Repository)# exit
ncs/admin(config)# exit
```

Related Commands

Command	Description
backup	Performs a backup (Prime Infrastructure and Cisco ADE OS) and places the backup in a repository.
restore	Performs a restore and takes the backup out of a repository.
show backup history	Displays the backup history of the system.
show repository	Displays the available backup files located on a specific repository.

service

To specify a service to manage, use the **service** command in configuration mode. To disable this function, use the **no** form of this command.

[no] service sshd

Syntax Description `sshd` Secure Shell Daemon. The daemon program for SSH.

Command Default No default behavior or values.

Command Modes Configuration

```
ncs/admin(config)# service sshd
ncs/admin(config)#
```

shutdown

To shut down an interface, use the **shutdown** command in interface configuration mode. To disable this function, use the **no** form of this command.

[no] shutdown

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Interface

Usage Guidelines When you shut down an interface using this command, you lose connectivity to the Cisco ISE-3315 appliance through that interface (even though the appliance is still powered on). However, if you have configured the second interface on the appliance with a different IP and have not shut down that interface, you can access the appliance through that second interface.

To shut down an interface, you can also modify the `ifcfg-eth[0,1]` file, which is located at `/etc/sysconfig/network-scripts`, using the `ONBOOT` parameter:

- Disable an interface: `set ONBOOT="no"`
- Enable an interface: `set ONBOOT="yes"`

You can also use the **no shutdown** command to enable an interface.

```
ncs/admin(config)# interface GigabitEthernet 0
ncs/admin(config-GigabitEthernet)# shutdown
```

Related Commands

Command	Description
interface	Configures an interface type and enters interface mode.
ip address (interface configuration mode)	Sets the IP address and netmask for the Ethernet interface.
show interface	Displays information about the system IP interfaces.
ip default-gateway	Sets the IP address of the default gateway of an interface.

snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP), use the **snmp-server community** command in configuration mode. To disable this function, use the **no** form of this command.

[no] snmp-server community word ro

Syntax Description	<i>word</i>	Accessing string that functions much like a password and allows access to SNMP. No blank spaces allowed. Up to 255 alphanumeric characters.
	<i>ro</i>	Specifies read-only access.

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines The **snmp-server community** command requires a community string and the **ro** argument; otherwise, an error occurs.

```
ncs/admin(config)# snmp-server community new ro
ncs/admin(config)#
```

Related Commands

Command	Description
snmp-server host	Sends traps to a remote system.
snmp-server location	Configures the SNMP location MIB value on the system.
snmp-server contact	Configures the SNMP contact MIB value on the system.

snmp-server contact

To configure the SNMP contact Management Information Base (MIB) value on the system, use the **snmp-server contact** command in configuration mode. To remove the system contact information, use the **no** form of this command.

[no] snmp-server contact *word*

Syntax Description	<i>word</i>	String that describes the system contact information of the node. Up to 255 alphanumeric characters.
---------------------------	-------------	--

Command Default No default behavior or values.

Command Modes Configuration

Usage Guidelines None.

```
ncs/admin(config)# snmp-server contact Abcd
ncs/admin(config)#
```


Related Commands	Command	Description
	snmp-server host	Sends traps to a remote system.
	snmp-server community	Sets up the community access string to permit access to the SNMP.
	snmp-server location	Configures the SNMP location MIB value on the system.

snmp-server host

To send SNMP traps to a remote user, use the **snmp-server host** command in configuration mode. To remove trap forwarding, use the **no** form of this command.

[no] snmp-server host {*ip-address* | *hostname*} **version** {1 | 2c} *community*

Syntax Description		
<i>ip-address</i>		IP address of the SNMP notification host. Up to 32 alphanumeric characters.
<i>hostname</i>		Name of the SNMP notification host. Up to 32 alphanumeric characters.
version {1 2c}		(Optional) Version of the SNMP used to send the traps. Default = 1. If you use the version keyword, specify one of the following keywords: <ul style="list-style-type: none"> • 1—SNMPv1. • 2c—SNMPv2C.
<i>community</i>		Password-like community string that is sent with the notification operation.

Command Default Disabled.

Command Modes Configuration

Usage Guidelines The command takes arguments as listed; otherwise, an error occurs.

```
ncs/admin(config)# snmp-server community new ro
ncs/admin(config)# snmp-server host 209.165.202.129 version 1 password
ncs/admin(config)#
```

Related Commands	Command	Description
	snmp-server community	Sets up the community access string to permit access to SNMP.

Command	Description
snmp-server location	Configures the SNMP location MIB value on the system.
snmp-server contact	Configures the SNMP contact MIB value on the system.

snmp-server location

To configure the SNMP location MIB value on the system, use the **snmp-server location** command in configuration mode. To remove the system location information, use the **no** form of this command.

[no] snmp-server location *word*

Syntax Description

word String that describes the physical location information of the system. Up to 255 alphanumeric characters.

Command Default

No default behavior or values.

Command Modes

Configuration

Usage Guidelines

We recommend that you use underscores (_) or hyphens (-) between the terms within the *word* string. If you use spaces between terms within the *word* string, you must enclose the string in quotation marks ("").

Example 1

```
ncs/admin(config)# snmp-server location Building_3/Room_214
ncs/admin(config)#
```

Example 2

```
ncs/admin(config)# snmp-server location "Building 3/Room 214"
ncs/admin(config)#
```

Related Commands

Command	Description
snmp-server host	Sends traps to a remote system.
snmp-server community	Sets up the community access string to permit access to SNMP.
snmp-server contact	Configures the SNMP location MIB value on the system.

username

To add a user who can access the Cisco ISE-3315 using SSH, use the **username** command in configuration mode. If the user already exists, the password, the privilege level, or both change with this command. To delete the user from the system, use the **no** form of this command.

[no] username *username* **password** {**hash** | **plain**} *password* **role** {**admin** | **user**} [**disabled** [**email** *email-address*]] [**email** *email-address*]

For an existing user, use the following command option:

username *username* **password** **role** {**admin** | **user**} *password*

Syntax Description

<i>username</i>	You should enter only one word which can include hyphen (-), underscore (_) and period (.). Note Only alphanumeric characters are allowed at an initial setup.
password	The command to use specify password and user role.
<i>password</i>	Password character length up to 40 alphanumeric characters. You must specify the password for all new users.
hash plain	Type of password. Up to 34 alphanumeric characters.
role admin user	Sets the privilege level for the user.
disabled	Disables the user according to the user's email address.
email <i>email-address</i>	The user's email address. For example, <i>user1@example.com</i> .

Command Default

The initial user during setup.

Command Modes

Configuration

Usage Guidelines

The **username** command requires that the username and password keywords precede the hash | plain and the admin | user options.

Example 1

```
ncs/admin(config)# username admin password hash ##### role admin
ncs/admin(config)#
```

Example 2

```
ncs/admin(config)# username admin password plain Secr3tp@swd role admin
ncs/admin(config)#
```

Example 3

```
ncs/admin(config)# username admin password plain Secr3tp@swd role admin email
admin123@example.com
ncs/admin(config)#
```

Related Commands

	Description
password-policy	Enables and configures the password policy.
show users	Displays a list of users and their privilege level. It also displays a list of logged-in users.

firewall

Command Modes

Firewall show command

```
ncs run firewall show -- It will show the firewall list
pi-system-152/admin# ncs run firewall show
```

Command Modes

Firewall Export

```
ncs run firewall export -- It will export the Iptables to defaultRepo location
pi-system-152/admin# ncs run firewall export
22102019_11_18_24
iptables_22102019_11_18_24 exported to defaultRepo repository
```

Command Modes

Firewall Import

```
ncs run firewall import (filename) defaultRepo -- It will import the file
pi-system-152/admin# ncs run firewall import iptables_22102019_11_18_24 defaultRepo
```

Command Modes

Firewall Reset

```
ncs run firewall reset -- It will reset all the changes and it goes to default state
pi-system-152/admin# ncs run firewall reset
```



INDEX

- A**
- accessing, CLI **16, 20, 21**
 - about **20**
 - prerequisites **16**
 - hardware installation **16**
 - SSH **21**
 - accounts, user **3**
- C**
- CLI **16, 27**
 - accessing **16**
 - commands, navigating **27**
 - CLI audit logs **14**
 - command **7, 9, 11, 23**
 - modes **7, 9, 11, 23**
 - configuration **11**
 - EXEC **7, 9**
 - understanding **23**
 - types of **7**
 - command-line **28**
 - editing, key **28**
 - commands **9, 32, 33, 34, 36, 37, 38, 39, 43, 47, 48, 49, 50, 51, 52, 53, 55, 56, 58, 66, 73, 74, 75, 78, 79, 80, 81, 82, 85, 86, 89, 90, 91, 92, 93, 96, 98, 99, 101, 103, 104, 105, 106, 107, 108, 111, 112, 113, 115, 117, 118, 119, 120, 121, 122, 124, 125, 126, 127, 128, 129, 130, 131, 132, 134, 137, 138, 139, 141, 143, 144, 145, 146, 147, 148, 149, 150, 152, 154, 155, 156, 157, 158, 159**
 - configuration **37, 53, 73, 74, 75, 129, 130, 131, 132, 134, 137, 138, 139, 141, 143, 144, 145, 146, 147, 148, 149, 150, 152, 154, 155, 156, 157, 158, 159**
 - aaa authentication **129**
 - backup-staging-url **129**
 - banner install pre-login **37**
 - cdp holdtime **130**
 - cdp run **130**
 - cdp timer **131**
 - clock timezone **132**
 - do **134**
 - end **137**
 - exit **137**
 - hostname **138**
 - icmp echo **139**
 - interface **139**
 - commands (*continued*)
 - configuration (*continued*)
 - ip address **144**
 - ip default-gateway **145**
 - ip domain-name **146**
 - ip name-server **146**
 - ip route **147**
 - ipv6 autoconfig **141**
 - ipv6 dhcp **143**
 - ipv6 static **144**
 - logging **148**
 - ncs certvalidation **73, 74, 75**
 - ncs run reset db **53**
 - ntp server **149**
 - password-policy **150**
 - repository **152**
 - service **154**
 - shutdown **155**
 - snmp-server community **155**
 - snmp-server contact **156**
 - snmp-server host **157**
 - snmp-server location **158**
 - username **159**
 - EXEC **32, 33, 34, 36, 38, 39, 43, 47, 48, 49, 51, 78, 79, 80, 81, 82, 85, 89, 90, 91, 92, 93, 96**
 - application start **32**
 - application stop **32**
 - application upgrade **33**
 - backup **34**
 - backup-logs **36**
 - clock **38**
 - configure **38**
 - copy **39**
 - debug **43**
 - delete **47**
 - dir **48**
 - exit **48**
 - forceout **49**
 - halt **49**
 - mkdir **51**
 - nslookup **78**
 - ping **79, 80**
 - reload **81**
 - restore **82**
 - rmdir **85**

commands (*continued*)EXEC (*continued*)

show 96

ssh 89

tech 90

telnet 90

terminal length 91

terminal session-timeout 91

terminal session-welcome 92

terminal terminal-type 92

traceroute 93

undebg 93

write 96

ncs 52

run 52

list 52

ncs run 58, 66

ssh-server-legacy-algorithms 58

tls-server-ciphers 66

ncs run client-auth 52

ncs run csrf 53, 55

ncs run livelogs 55, 56

password 37

change password 37

show 9, 50, 78, 86, 96, 98, 99, 101, 103, 104, 105, 106, 107, 108, 111, 112, 113, 115, 117, 118, 119, 120, 121, 122, 124, 125, 126, 127, 128

ip route 105

lms 50

netstat 112

ocsp 78

rsa-key 86

show application 96

show backup history 98

show banner pre-login 99

show cdp 99

show clock 101

show cpu 101

show disks 103

show icmp-status 104

show interface 106

show inventory 107

show logging 108

show logins 111

show memory 111

show ntp 113

show ports 113

show process 115

show repository 117

show restore 117

show restore log 118

show running-configuration 119

show security-status 121

show startup-configuration 120

show tech-support 122

show terminal 124

commands (*continued*)show (*continued*)

show timezone 124

show timezones 125

show udi 126

show uptime 127

show users 127

show version 128

configuration commands 11, 128

console port 2

conventions 28, 29

command-line, completion 28

command-line, editing 28

more prompt 29

D

default forms of commands, using 27

document:audience; audience ix

document:conventions;conventions:document x

document:organization x

document:related;related documentation xi

document:using ix

E

EXEC commands 7, 31

H

help, getting 27

M

mode 6, 23, 24

about 6

configuration 24

configuration, submodes 24

EXEC 23

N

navigating, commands 27

no forms of commands, using 27

S

setup utility 3, 17

show commands 9

supported platforms 20

hardware 20

T

types of commands [7](#)

U

user [3,6](#)

 accounts [3](#)

user (*continued*)

 modes [6](#)

using [21](#)

 PC locally [21](#)

 SSH [21](#)

utility, setup [17](#)

