



Configuring the Cisco Fourth-Generation Voice and Fax Network Interface Module

[Configuring Cisco Fourth-Generation Voice and Fax Network Interface Moduls](#) 2

[Supported Features](#) 2

[Restrictions](#) 3

[Supported Platforms](#) 3

[Configuring the Network Interface Module](#) 3

[Troubleshooting](#) 14

[Related Documents](#) 15

Revised: December 18, 2018

Configuring Cisco Fourth-Generation Voice and Fax Network Interface Moduls

The following Cisco Fourth-Generation Voice & Fax Network Interface Modules provide voice and Unified Communications services on the Cisco 4400/4300 Series Integrated Services Router:

- NIM-2FXS
- NIM-4FXS
- NIM-2FXO
- NIM-4FXO
- NIM-2FXS/4FXO
- NIM-4E/M
- NIM-2BRI
- NIM-4BRI

Supported Features

- Support for Foreign Exchange Office (FXO) and Foreign Exchange Station (FXS).
- Support for recEive and transMit or Ear and Mouth (E&M) and Basic Rate Interface (BRI) analog ports.
- Support for Cisco Unified Communications Manager Express (CME) and Media Gateway Control Protocol (MGCP).
- Support for STC application supplementary services.



Note For a list of features not supported on the Cisco Fourth-Generation Voice & Fax Network Interface Module in the Cisco IOS XE Release 3.14S, see the [Unsupported Features, on page 2](#) section.

Unsupported Features

Following is a list of features not supported on the Cisco Fourth-Generation Voice & Fax Network Interface Module in Cisco IOS XE Release 3.14S:

- Codecs: iLBC, iSAC, G.723.1
- Connection trunk
- Hoot and holler, voice multicasting
- Music on hold (MoH) from a live feed
- Noise Reduction (NR)
- Secure Cisco Unified CME
- Secure Cisco Unified SRST
- Signal LMR (under E&M port)
- SIP supplementary call features with analog phones
- Trunk connection for tie lines, nailed up calls

Restrictions

- Surprise OIR is not supported.
- Managed OIR is not supported with active calls.

To determine whether there are any active calls before proceeding with managed OIR, use a command such as **show voice call summary**. Ensure that all ports are in an “ONHOOK” state. After module insertion, check if the voice ports are in a shutdown state and issue **no shutdown** commands to bring each port back online.

Supported Platforms

The Cisco Fourth-Generation Voice & Fax Network Interface Module is supported on the Cisco 4451-X Integrated Services Router and runs on Cisco IOS XE Release 3.13S and later.

Configuring the Network Interface Module

Prerequisites for Configuring the Cisco Fourth-Generation Voice and Fax Network Interface Module

- Obtain two- or four-wire line service from your service provider or from a PBX.
- Complete your company’s dial plan.
- Establish a working telephony network based on your company’s dial plan.
- Install at least one other network module or WAN interface card to provide the connection to the network LAN or WAN.
- Establish a working connection to the network.
- Install appropriate voice interface hardware on the router
- Gather the following information about the telephony connection of the voice port:
 - Telephony signaling interface: FXO and FXS
 - Locale code (usually the country) for call progress tones
 - For FXO, type of dialing: DTMF (touch-tone) or pulse and type of signal: loop-start or ground-start
- Disconnect signaling by performing the following set of tasks:
 - supervisory disconnect signal
 - battery-reversal
 - no supervisory disconnect signal. See [Understanding FXO Disconnect Problem for detailed configuration information](#).

If you are connecting a voice-port interface to a PBX, it is important to understand the PBX’s wiring scheme and timing parameters. You can gather this information from your PBX vendor or the reference manuals that accompany your PBX.

Configuring an FXO Interface

To configure the Cisco Fourth-Generation Voice & Fax Network Interface Module as an FXO interface, perform the following task.

Procedure

	Command or Action	Purpose
Step 1	enable Example: <pre>Router> enable</pre>	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: <pre>Router# configure terminal</pre>	Enters global configuration mode.
Step 3	voice-port slot/subunit/subslot Example: Example: <pre>Router(config)# voice-port 0/2/0</pre>	Enters voice-port configuration mode.
Step 4	signal {groundStart loopStart} Example: <pre>Router(config-voiceport)# signal groundStart</pre>	Selects the access signaling type to match that of the telephony connection that you are making. The default setting for FXO and FXS voice ports in loopStart . <ul style="list-style-type: none"> • groundStart — Specifies the use of groundstart signaling used for FXO and FXS interfaces. Groundstart signaling allows both sides of a connection to place a call and to hang up. • loopStart — Specifies the use of loop start signaling used for FXO and FXS interfaces. With loopstart signaling, only one side of a connection can hang up. <p>Note The CAMA version of the keywords groundStart and loopStart are groundstart and loopstart respectively.</p>
Step 5	cptone locale Example: Example: <pre>Router(config-voiceport)# cptone us</pre>	Selects the two-letter locale for the voice call progress tones and other locale-specific parameters to be used on this voice port. The default is us.
Step 6	dial-type {dtmf mf pulse} Example: <pre>Router(config-voiceport)# dial-type dtmf</pre>	Specifies the dialing method for outgoing calls. The default dialing method is dtmf touch-tone dialing. <ul style="list-style-type: none"> • dtmf — Specifies the dual tone multifrequency (DTMF) touch-tone dialing.

	Command or Action	Purpose
		<ul style="list-style-type: none"> • mf — Specifies the multifrequency tone dialing. • pulse — Specifies the pulse (rotary) dialing.
Step 7	ring number number Example: Example: <pre>Router(config-voiceport)# ring number 1</pre>	Specifies the maximum number of rings to be detected before an incoming call is answered by the router. The default is 1.
Step 8	description string Example: <pre>Router(config-voiceport)# description Voice Port One</pre>	Attaches a text string to the configuration that describes the connection for this voice port. This description appears in various displays and is useful for tracking the purpose or use of the voice port. The string argument is a character string from 1 to 255 characters in length. By default, there is no text string (describing the voice port) attached to the configuration.
Step 9	no shutdown Example: <pre>Router(config-voiceport)# no shutdown</pre>	Activates the voice port. If a voice port is not being used, shut down the voice port by using shutdown command.

Examples

The following example shows two options for configuring an FXO interface.

```
1)
voice-port 0/1/0
  st4451(config-voiceport)#secondary ?
  dialtone Secondary dialtone option for FXO port
st4451(config-voiceport)#secondary dialtone ?
<cr>
2) voice-port 0/1/0
  st4451(config-voiceport)#connection ?
  plar Private Line Auto Ringdown
  st4451(config-voiceport)#connection plar ?
  WORD A string of digits including wild cards
  opx Off-Premises eXtension PLAR
st4451(config-voiceport)#connection plar opx ?
  WORD A string of digits including wild cards
st4451(config-voiceport)#connection plar opx 2345
```

Configuring an FXS Interface

To configure the Cisco Fourth-Generation Voice & Fax Network Interface Module as an FXS interface, perform the following task.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	voice-card 0/2 Example: Router(config)# local-bypass	Configures local bypass on the voice-port. When a call is made across two different ports under the same FXS voice-cards, configuring the local bypass command allows the call to bypass the backplane and DSPs. However, when call is made across voice-ports belonging to two different voice-cards, the NIM card DSPs are invoked irrespective of the local bypass configuration.
Step 4	voice-port slot/subunit/subslot Example: Router(config)# voice-port 0/2/0	Enters voice-port configuration mode.
Step 5	signal {did {delay-dial immediate loopStart} groundStart loopStart} Example: Router(config-voiceport)# signal groundStart	Selects the access signaling type to match that of the telephony connection that you are making. Note Cisco IOS XE Release 3.13S supports only groundStart and loopStart signaling types.
Step 6	cptone locale Example: Example: Router(config-voiceport)# cptone us	Selects the two-letter locale for the voice call progress tones and other locale-specific parameters to be used on this voice port. The default is us .
Step 7	ring frequency {20 25 30 50} Example: Router(config-voiceport)# ring frequency 50	Selects the ring frequency, in hertz, used on the FXS interface. The frequency must match the connected telephony equipment and may be country-dependent. If the ring frequency is not set properly, the attached telephony device may not ring or it may buzz.
Step 8	Do one of the following: <ul style="list-style-type: none"> • ring cadence {<i>pattern-number</i> [[define pulse interval]]} Example:	Specifies an existing ring pattern or defines a new one. The following ring cadence patterns have a predefined ring-pulse time and a ring-interval time.

	Command or Action	Purpose
	<pre>Router(config-voiceport)# ring cadence pattern01</pre> <p>Example:</p> <p>Example:</p> <p>Example:</p> <pre>Router(config-voiceport)# ring cadence define 2 4 3 1</pre>	<ul style="list-style-type: none"> • pattern01—2 seconds on, 4 seconds off • pattern02—1 second on, 4 seconds off • pattern03—1.5 seconds on, 3.5 seconds off • pattern04—1 second on, 2 seconds off • pattern05—1 second on, 5 seconds off • pattern06—1 second on, 3 seconds off • pattern07—0.8 second on, 3.2 seconds off • pattern08—1.5 seconds on, 3 seconds off • pattern09—1.2 seconds on, 3.7 seconds off • pattern10—1.2 seconds on, 4.7 seconds off • pattern11—0.4 second on, 0.2 second off, 0.4 second on, 2 seconds off • pattern12—0.4 second on, 0.2 second off, 0.4 second on, 2.6 seconds off <p>The default is the pattern specified by the cptone locale that has been configured.</p> <ul style="list-style-type: none"> • define—User-definable ring cadence pattern. Each number pair specifies one ring-pulse time and one ring-interval time. You must enter numbers in pairs, and you can enter from 1 to 6 pairs. The second number in the last pair that you enter specifies the interval between rings.
Step 9	<pre>description string</pre> <p>Example:</p> <pre>Router(config-voiceport)# description Voice Port One</pre>	<p>Attaches a text string to the configuration that describes the connection for this voice port. This description appears in various displays and is useful for tracking the purpose or use of the voice port. The <i>string</i> argument is a character string from 1 to 255 characters in length.</p> <p>By default, there is no text string (describing the voice port) attached to the configuration.</p>
Step 10	<pre>no shutdown</pre> <p>Example:</p> <pre>Router(config-voiceport)# no shutdown</pre>	<p>Activates the voice port. If a voice port is not being used, shut down the voice port by using the shutdown command</p>

Configuration Examples

The following example shows a partial running configuration of an FXS interface.

```
voice-card 0/2
# using default local-bypass
!
voice-port 0/2/0
cptone CA
!
voice-port 0/2/1
signal groundStart
```

```

!
voice-port 0/2/2
  signal did loop-start
  cptone CA
!
voice-port 0/2/3
  connection plar 12345
  dial-peer voice 20 pots
    destination pattern 33020
    port 0/2/0
  dial-peer voice 21 pots
    destination pattern 33021
    port 0/2/1
  dial-peer voice 22 pots
    destination pattern 33022
    port 0/2/2
  dial-peer voice 23 pots
    destination pattern 33023
    port 0/2/3
  dial-peer voice 12345 voip
    destination pattern 12345
    session target ipv4:1.5.25.100

```

The following example shows a partial running configuration of an FXO interface.

```

voice-card 0/3
  no local-bypass
!
voice-port 0/3/0
  cptone CA
  connection plar opx 12345
!
voice-port 0/3/1
  signal groundStart
  connect plar 12345
!
voice-port 0/3/2
  secondary dialtone
  cptone CA
!
voice-port 0/2/3
  connect plar 12345
  dial-peer voice 30 pots
    destination pattern 33030
    port 0/3/0
  dial-peer voice 31 pots
    destination pattern 33031
    port 0/3/1
  dial-peer voice 32 pots
    destination pattern 33032
    port 0/3/2
  dial-peer voice 23 pots
    destination pattern 33033
    port 0/3/3
  dial-peer voice 12345 voip
    destination pattern 12345
    session target ipv4:1.5.25.100

```

Configuring an E and M Interface

To configure the Cisco Fourth-Generation Voice & Fax Network Interface Module as an E&M interface, perform the following task.

Procedure

	Command or Action	Purpose
Step 1	enable Example: <pre>Router> enable</pre>	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: <pre>Router# configure terminal</pre>	Enters global configuration mode.
Step 3	voice-port slot/subunit/subslot Example: <pre>Router(config)# voice-port 0/2/0</pre>	Enters voice-port configuration mode.
Step 4	signal {wink-start immediate-start delay-dial} Example: <pre>Router(config-voiceport)# signal wink-start</pre>	The keywords are as follows: <ul style="list-style-type: none"> • wink-start—(default) Indicates that the calling side seizes the line, then waits for a short off-hook wink from the called side before proceeding. • immediate-start—Indicates that the calling side seizes the line and immediately proceeds; used for E&M tie trunk interfaces. • delay-dial—Indicates that the calling side seizes the line and waits, then checks to determine whether the called side is on-hook before proceeding; if not, it waits until the called side is on-hook before sending digits. Used for E&M tie trunk interfaces.
Step 5	cptone locale Example: <pre>Router(config-voiceport)# cptone us</pre>	Selects the two-letter locale for the voice call progress tones and other locale-specific parameters to be used on this voice port. The default is us .
Step 6	operation {2-wire 4-wire} Example: <pre>Router(config-voiceport)# operation 4-wire</pre>	Specifies the number of wires used for voice transmission at this interface (the audio path only, not the signaling path). The default is 2-wire.
Step 7	type {1 2 3 5} Example: <pre>Router(config-voiceport)# type 2</pre>	Specifies the type of E&M interface to which this voice port is connecting. See Table 5 for an explanation of E&M types. The default is 1.
Step 8	description string Example:	Attaches a text string to the configuration that describes the connection for this voice port. This description appears in various displays and is useful for tracking the purpose or

	Command or Action	Purpose
	Router(config-voiceport)# description Voice Port One	use of the voice port. The <i>string</i> argument is a character string from 1 to 255 characters in length. By default, there is no text string (describing the voice port) attached to the configuration.
Step 9	no shutdown Example: Router(config-voiceport)# no shutdown	Activates the voice port. If a voice port is not being used, shut down the voice port by using the shutdown command

Configuration Examples

The following example shows a partial running configuration of an E&M interface.

```

1) Select the signal protocol
st4451(config-voiceport)#signal ?
  delay-dial  delay before dialing
  immediate   start immediately
  wink-start  start upon wink (default)
2) Specify the E&M interface type
st4451(config-voiceport)#type ?
  1  E&M type I (default)
  2  E&M type II
  3  E&M type III
  5  E&M type V
3) Specify the operation of the E&M signal
   st4451(config-voiceport)#operation ?
  2-wire  2-wire operation (default)
  4-wire  4-wire operation
voice-port 0/3/0
operation 4-wire
type 2

```

Configuring a BRI Interface

To configure the Cisco Fourth-Generation Voice & Fax Network Interface Module as a BRI interface, perform the following task:

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	isdn switch-type <i>switch-type</i>	Configures the telephone company ISDN switch type.

	Command or Action	Purpose
	Example: <pre>Router(config)# isdn switch-type basic-net3</pre>	Note The BRI switch types that are supported are: net3 and qsig.
Step 4	interface bri slot/subslot/port: 0 Example: <pre>Router(config)# interface bri 0/1/0:0</pre>	Enter interface configuration mode to configure parameters for the specified interface. <ul style="list-style-type: none"> • <i>slot</i>—Slot location in which the BRI module resides (0 to 4). • <i>subslot</i>—Subslot location in which the BRI module resides (1 to 3). • <i>port</i>—Port number of the BRI module (0 to 3).
Step 5	no ip address Example: <pre>Router(config-if)# no ip address</pre>	Specifies that there is no IP address for this interface.
Step 6	isdn overlap-receiving Example: <pre>Router(config-if)# isdn overlap-receiving</pre>	(Optional) Activates overlap signaling to send to the destination PBX. In this mode, the interface waits for possible additional call-control information.
Step 7	isdn spid2 spid-number [ldn] Example: <pre>Router(config-if)# isdn spid2 spid-number 415988488202</pre>	(Optional; TE only) Specifies a SPID and optional local directory number for the B2 channel.
Step 8	shutdown Example: <pre>Router(config-if)# shutdown</pre>	Turns off the port (prior to setting the port emulation).
Step 9	isdn layer1-emulate {user network} Example: <pre>Router(config-if)# isdn layer1-emulate network</pre>	Configures the Layer 1 port mode emulation and clock settings. <ul style="list-style-type: none"> • <i>user</i>—Configures the port as TE and sets it to function as a clock slave. This is the default. • <i>network</i>—Configures the port as NT and sets it to function as a clock master.
Step 10	no shutdown Example: <pre>Router(config-if)# no shutdown</pre>	Turns on the port.
Step 11	isdn protocol-emulate {user network} Example:	Configures the Layer 2 and Layer 3 port protocol emulation. The keywords are as follows:

	Command or Action	Purpose
	Router(config-if)# isdn protocol-emulate network	<ul style="list-style-type: none"> • user—Configures the port as TE; the PBX is the master. This is the default. • network—Configures the port as NT; the PBX is the slave.
Step 12	isdn sending-complete Example: Router(config-if)# isdn sending-complete	(Optional) Configures the voice port to include the “Sending Complete” information element in the outgoing call setup message. This command is used in some geographic locations, such as Hong Kong and Taiwan, where the “Sending Complete” information element is required in the outgoing call setup message.
Step 13	isdn static-tei tei-number Example: Router(config-if)# isdn static-tei 0	(Optional) Configures a static ISDN Layer 2 terminal endpoint identifier (TEI). The value of tei-number can be from 0 to 64.
Step 14	isdn point-to-point-setup Example: Router(config-if)# isdn point-to-point-setup	(Optional) Configures the ISDN port to send SETUP messages on the static TEI. Note A static TEI must be configured in order for this command to be effective.
Step 15	end Example: Router(config-if)# end	Exits interface configuration mode.
Step 16	clear interface bri slot/subslot/port:0 Example: Router# clear interface bri 0/1/0:0	(Optional) Resets the specified interface. The interface needs to be reset if the static TEI number has been configured in Step 16. <ul style="list-style-type: none"> • <i>slot</i>—Slot location in which the BRI module resides (0 to 4). • <i>subslot</i>—Subslot location in which the BRI module resides (1 to 3). • <i>port</i>—Port number of the BRI module (0 to 3).

Configuration Examples

The following example shows a partial running configuration of a BRI interface.

```
interface BRI0/1/0:0
  isdn switch-type basic-net3
  isdn protocol-emulate network
  isdn point-to-point-setup
  isdn layer1-emulate network
  isdn skipsend-idverify
!
interface BRI0/1/1:0
  isdn switch-type basic-net3
  isdn point-to-point-setup
```

```

    isdn skipsend-idverify
!
interface BRI0/1/2:0
    isdn switch-type basic-qsig
    isdn point-to-point-setup
    isdn skipsend-idverify
!
interface BRI0/1/3:0
    isdn switch-type basic-qsig
    isdn protocol-emulate network
    isdn point-to-point-setup
    isdn layer1-emulate network
    isdn skipsend-idverify
dial-peer voice 100 pots
    destination-pattern 100
    direct-inward-dial
    forward-digits all
    port 0/1/0

dial-peer voice 200 pots
    destination-pattern 200
    direct-inward-dial
    forward-digits all
    port 0/1/1
dial-peer voice 300 pots
    destination-pattern 300
    direct-inward-dial
    forward-digits all
    port 0/1/2
dial-peer voice 400 pots
    destination-pattern 400
    direct-inward-dial
    forward-digits all
    port 0/1/3

```

Media Gateway Control Protocol

Media Gateway Control Protocol (MGCP) defines a centralized architecture for creating multimedia applications, including Voice over IP (VoIP). See the [Cisco IOS MGCP and Related Protocols Configuration Guide](#).

The Cisco ISRs are configured primarily as residential gateways (RGWs) under MGCP. For residential gateway configuration information, see the “[Configuring an RGW](#)” section of the “Basic MGCP Configuration” chapter of the [Cisco IOS MGCP and Related Protocols Configuration Guide](#).

Configuring Cisco Unified CME

Cisco Unified Communications Manager Express is a feature-rich, entry-level IP telephony solution that is integrated directly into Cisco IOS software. Cisco Unified CME allows small business customers and autonomous small enterprise branch offices to deploy voice, data, and IP telephony on a single platform for small offices, thereby streamlining operations and lowering network costs.

Cisco Unified CME is ideal for customers who have data connectivity requirements and also need a telephony solution in the same office. Whether offered through a service provider’s managed services or purchased directly by a corporation, Cisco Unified CME offers most of the core telephony features required in the small office and also many advanced features not available with traditional telephony solutions. The ability to deliver IP telephony and data routing using a single converged solution allows customers to optimize their operations and maintenance costs, resulting in a very cost-effective solution that meets office needs.

A Cisco Unified CME system is extremely flexible because it is modular. A Cisco Unified CME system consists of a router that serves as a gateway and one or more VLANs that connect IP phones and phone devices to the router.

For more information on Cisco Unified CME, see the [Cisco Unified Communications Manager Express System Administrator Guide](#)

Supported Cisco Unified Communications Manager Release for FXS, FXO, and BRI NIMs

The following table shows the Cisco Unified Communications Manager releases that are required to support FXS, FXO and BRI NIMs on the ISR 4000 series.

Table 1: Supported Cisco Unified Communications Manager Release

Cisco ISR 4000 Series	Cisco Unified Communications Manager Release
ISR 44xx	10.5
ISR 43xx	10.5.2

STC Application Supplementary Services

The SCCP telephony control (STC) application on the Cisco 4400 Series ISR functions as a proxy to translate call-control messages between the Cisco call-control system and the voice gateway. The SCCP telephony control (STC) application on the Cisco voice gateway presents the locally attached analog telephones as individual endpoints to the call-control system, which allows the analog phones to be controlled in the same way as IP phones. With this capability, gateway-attached endpoints share the same telephony features that are available on IP phones directly connected to Cisco Unified CME and Cisco Unified Communications Manager.

Calls through analog FXS ports are controlled by a Cisco call-control system, such as Cisco Unified Communications Manager or Cisco Unified CME. The SCCP telephony control (STC) application on the Cisco voice gateway functions as a proxy to translate call-control messages between the Cisco call-control system and the Cisco voice gateway. See the [Overview of Supplementary Services Features for FXS Ports on Cisco Voice Gateways](#) for more information.

Troubleshooting

Use the following commands to check the status and troubleshoot the modules.

- debug mgcp packets
- **debug vpm sig**
- **debug voip vtsp default**
- show ccm-manager
- **show controller**
- show call active voice
- show call history voice
- show dial-peer voice summary
- show dialplan number
- **show hw-module subslot**
- **show interface serial**
- **show interface**
- show mgcp
- show mgcp connection

- show mgcp statistics
- **show platform hardware subslot (4400)**
- show voice call summary
- show voice call status
- show voice dsp
- show voice dsp channel operational-status
- show voice port
- show voice port summary
- show voice port 0/3/0 (example port)

Related Documents

Related Topic	Document Title
Installation guide for the Cisco PVDM4	Installing the Cisco PVDM4
Installation guide for the Cisco Network Interface Module	Installing the Cisco Fourth-generation Voice and WAN Network Interface Module
Command reference information for interface and hardware components	Cisco IOS Interface and Hardware Component Command Reference
Configuration of the Cisco 4400/4300 Series Integrated Services Router	Cisco 4400 Series ISRs and Cisco 4300 Series ISRs Software Configuration Guide
Installation of the Cisco 4400/4300 Series Integrated Services Router	Hardware Installation Guide for the Cisco ISR 4400 and Cisco ISR 4300 Series Integrated Services Router
System administrator's guide for Cisco Unified SRST	Cisco Unified SCCP and SIP SRST System Administrator Guide (All Versions)
MGCP and Related Protocols Configuration Guide	Cisco IOS MGCP and Related Protocols Configuration Guide
MGCP Gateway Verification and Troubleshooting	Verify and Troubleshoot the Cisco IOS MGCP Gateway
Regulatory compliance and safety information	Cisco Network Modules and Interface Cards Regulatory Compliance and Safety Information

MIBs

MIB	MIBs Link
<ul style="list-style-type: none">• CISCO ENTITY MIB• CISCO-ENTITY-ALARM-MIB• CISCO-ENTITY-SENSOR-MIB• CISCO-SIP-UA-MIB• CISCO-SYSLOG-MIB• CISCO-VOICE-ANALOG-IF-MIB• CISCO-VOICE-DIAL-CONTROL-MIB• CISCO-VOICE-IF-MIB• ENTITY-MIB• IF-MIB	<p>To locate and download MIBs for selected platforms, Cisco software releases, and feature sets, use Cisco MIB Locator found at the following URL:</p> <p>http://www.cisco.com/go/mibs</p>

RFCs

RFC	Title
RFC 1315	<i>Management Information Base for Frame Delay DTEs</i>
RFC 1406	Definitions of Managed Objects for the DS1 and E1 Interface Types



Americas Headquarters
Cisco Systems, Inc.
San Jose, CA 95134-1706
USA

Asia Pacific Headquarters
CiscoSystems(USA)Pte.Ltd.
Singapore

Europe Headquarters
CiscoSystemsInternationalBV
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.