Administración de dispositivos de Cisco WLC mediante TACACS+

Contenido

Introducción Prerequisites Requirements Componentes Utilizados Configuración Paso 1. Verifique Device Administration License. Paso 2. Habilite la administración de dispositivos en nodos PSN ISE. Paso 3. Cree un grupo de dispositivos de red. Paso 4. Agregue el WLC como dispositivo de red. Paso 5. Cree un perfil TACACS para el WLC. Paso 6. Cree un conjunto de políticas. Paso 7. Cree políticas de autenticación y autorización. Paso 8. Configure el WLC para la Administración del Dispositivo. Verificación Troubleshoot

Introducción

Este documento describe cómo configurar TACACS+ para la administración de dispositivos de Cisco Wireless LAN Controller (WLC) con Identity Service Engine (ISE).

Prerequisites

Requirements

Cisco recomienda que tenga conocimiento sobre estos temas:

- Conocimientos básicos de Identity Service Engine (ISE)
- Conocimiento básico de Cisco Wireless LAN Controller (WLC)

Componentes Utilizados

La información que contiene este documento se basa en las siguientes versiones de software y hardware.

- Cisco Identity Service Engine 2.4
- Controlador de LAN inalámbrica de Cisco 8.5.135

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is

live, make sure that you understand the potential impact of any command.

Configuración

Paso 1. Verifique Device Administration License.

Vaya a Administration > System > Licensing tab y verifique que se haya instalado la licencia Device Admin, como se muestra en la imagen.

≺ System → Identity Management → Network Resources → Device Portal Management	ement pxGrid Services							
	b Declare & Dectare b Admin An							
Deployment Licensing → Certificates → Logging → Maintenance Upgrade → Backup & Restore → Admin Access → Settings								
Traditional Licensing is currently in use.								
Click below to switch to Cisco Smart Licensing								
Cisco Smart Licensing								
License Usage (i) How are licenses consumed? Current Usage Over Time								
Base		Licensed +100 (Consumed +0)						
		period too (consense to)						
Plus								
Advanced								
Apex								
Updated : Aug 20,2019 09:30:00 UTC () Licensed Consumed	Exceeded							
Licenses (i) How do I register, modify or lookup my licenses?								
Import License Delete License Ouestitu	Tores	Evolution Data						
License File Quantity	Term	Expiration Date						
OSITRONFEAT20190820025931403.lic								
Base 100	Term	19-Aug-2020 (365 days remaining)						
POSITRONFEAT20190820025911402.lic								
Device Admin 50	Term	19-Aug-2020 (365 days remaining)						

Nota: La licencia de administrador de dispositivos es necesaria para utilizar la función TACACS+ en ISE.

Paso 2. Habilite la administración de dispositivos en nodos PSN ISE.

Navegue hasta **Centros de Trabajo > Administración de Dispositivos > Descripción General**, haga clic en la pestaña **Implementación**, **Seleccione el botón de opción Nodo PSN específico**. Habilite Device Administration en el nodo ISE seleccionando la **casilla** y haga clic en **guardar**, como se muestra en la imagen:

dentity Services Engine	Home Context Visibility Operations Policy Administration Work Centers
Network Access Guest Access	TrustSec Tevice Administration PassiveID
Overview Identities User Identities	tity Groups Ext Id Sources Network Resources Policy Elements Device Admin Policy Sets Reports Settings
Introduction	Device Administration Deployment
TACACS Livelog Deployment	Activate ISE Nodes for Device Administration None All Policy Service Nodes Specific Nodes
	□ ISE Nodes ✓ ISE-PSN.panlab.local
	Only ISE Nodes with Policy Service are displayed.
	TACACS Ports * 49
	Save Reset

Paso 3. Cree un grupo de dispositivos de red.

Para agregar el WLC como un dispositivo de red en el ISE, navegue hasta Administración > Recursos de Red > Grupos de Dispositivos de Red > Todos los Tipos de Dispositivo, cree un nuevo grupo para el WLC, como se muestra en la imagen:

altalta cisco	Identity Services Engine	Home	Context Visibility	► Operations	▶ Policy	- Administration	▶ Work Centers
▶ Sy	stem Identity Managemen	nt 🔻 Network	k Resources Dev	ice Portal Management	pxGrid S	ervices Feed Se	rvice
► Ne	etwork Devices Network Dev	rice Groups	Network Device Profile	es External RADIUS	Servers F	RADIUS Server Seque	ences NAC Managers Ex
Netw All C	ork Device Groups	oup -					
	July 1						
SF	Refresh 🕂 Add Dupli	cate 🖸 Ec	dit 📋 Trash 🧔	Show group member	s 🚊 Imp	ort 🔄 Export 🗸	EFlat Table 🦨 Expand
	Name			De	scription		
	 All Device Types 			All	Device Type:	5	
	All Locations			All	Locations		
	Is IPSEC Device			ls t	his a RADIU	S over IPSEC Device	

Add Group		\succ
Name *	WLC	
Description		
Parent Group *	All Device Types	x v
		Cancel Save

Paso 4. Agregue el WLC como dispositivo de red.

Vaya a Centros de trabajo > Administración de dispositivos > Recursos de red > Dispositivos de red. Haga clic en Agregar, proporcione el nombre, la dirección IP y seleccione el tipo de dispositivo como WLC, seleccione la casilla de verificación TACACS+ Authentication Settings y proporcione la clave Secreto Compartido, como se muestra en la imagen:

dentity Services Engine	Home	Context \	/isibility	 Operations 	Policy	- Administration	Work Centers
System Identity Management	✓ Networ	k Resources	Device	Portal Manageme	nt pxGrid S	Services	
✓ Network Devices Network Device	Groups	Network Devic	e Profiles	External RADIU	S Servers	RADIUS Server Seque	ences
Network Devices	Netwo	ork Devices List >	New Netv	vork Device			
Default Device	Net	work Device	s				
Device Security Settings				Name Flo	orWLC		
		IP Address	* *	IP: 10.106.37.	180		/ 32
			* D	evice Profile	Cisco 👻 🕀	(
			N	Model Name		r	
			Softv	vare Version		r	
		* Network Devi	ce Group				
		Location	All Locations	5 📀	Set To Default	t	
	L .	IPSEC I	s IPSEC De	vice 📀	Set To Default	t	
		Device Type	WLC	0	Set To Default	t	
		► RADIUS A	uthenticatio	n Settings			
		- TACACS A	uthenticatio	on Settings			
				si	hared Secret	•••••	Show
				Enable Single Co	onnect Mode		
						 Legacy Cisco Dev TACACS Draft Co 	rice mpliance Single Connect Support
		► SNMP Set	tings				

Paso 5. Cree un perfil TACACS para el WLC.

Vaya a Centros de Trabajo > Administración de Dispositivos > Elementos de Política > Resultados > Perfiles TACACS. Haga clic en Agregar y proporcione un nombre. En la pestaña Vista de atributo de tarea, seleccione WLC para Tipo de tarea común. Existen perfiles predeterminados entre los que se selecciona Monitor para permitir el acceso limitado a los usuarios, como se muestra en la imagen.

cisco Identity Services Engine	Home	Administration Work Centers
Network Access Guest Access	TrustSec BYOD Profiler Posture Posture Posture	ministration PassiveID
Overview Identities User Identit	ty Groups Ext Id Sources Network Resources Policy I	Elements Device Admin Policy Sets Reports Settings
0		
Conditions	IAGAGS Profiles > WEG MONITOR	
Network Conditions	TACACS Profile	
	Name WLC MONITOR	ł.
✓ Results		
Allowed Protocols	Description WLC MONITOR	2
TACACS Command Sets		
TACACS Profiles	Task Attribute View Raw View	
	Common Tasks	
	Common Task Type WLC	
	 Monitor 	
	CLobby	
	Selected	
	WLAN Controller W	ireless Security Management Commands
	The configured options give a right title Debug	
	Custom Attributes	

Hay otro perfil predeterminado **All** que permite el acceso completo al usuario como se muestra en la imagen.

cisco Identity Services Engine	Home Context Visibility Operations Policy Administration Work Centers
Network Access Guest Access	TrustSec BYOD Profiler Posture ▼Device Administration PassiveID
Overview Identities User Ident	ty Groups Ext Id Sources Network Resources Policy Elements Device Admin Policy Sets Reports Settings
Conditions Network Conditions	TACACS Profiles > WLC ALL TACACS Profile
	Name WLC ALL
✓ Results	
Allowed Protocols	Description WLC ALL
TACACS Command Sets	
TACACS Profiles	Task Attribute View Raw View
	Common Tasks Common Task Type WLC
	All Monitor Lobby Selected WLAN Controller Wireless Security Management Commands The configured options give a mgmtRole Debug value of: 0xffffffff8
	Custom Attributes

Paso 6. Cree un conjunto de políticas.

Vaya a Centros de trabajo > Administración de dispositivos > Conjuntos de políticas de administración de dispositivos. Haga clic (+) y asigne un nombre al conjunto de políticas. En la condición de política seleccione Device Type as WLC, Allowed Protocols puede ser Default Device Admin, como se muestra en la imagen.

cisco Identity Servi	ices Engine Home I	Context Visibility	Policy Administration Work Centers	License Warning 🔺 🔍 🐵 🗢 🗘
Network Access Overview Ident	Guest Access TrustSec ities User Identity Groups E	BYOD Profiler Posture Xt Id Sources Network Resource	Device Administration PassiveID Policy Elements Device Admin Policy Sets Reports Settings	Click here to do wireless setup Do not show this again.X
Policy Sets				Reset Save
+ Status Po	olicy Set Name	Description	Conditions	Allowed Protocols / Server Sequence Hits Actions View
Search				
Øw	LC		DEVICE-Device Type EQUALS All Device Types#WLC	Default Device Admin x v + 0 🌣 🕨

Paso 7. Cree políticas de autenticación y autorización.

En este documento, se configuran dos grupos de ejemplo Admin-Read-Write y Admin-Read-Only en el directorio activo y un usuario dentro de cada grupo admin1, admin2 respectivamente. Active Directory se integra con ISE a través de un punto de unión denominado AD-JointName.

Cree dos políticas de autorización, como se muestra en la imagen:

/	Ø	Default			AD-JointName × ▼ > Options	0	٥
> Auth	orization F	Policy - Local Exceptions					
> Auth	orization F	Policy - Global Exceptions					
♥ Auth	orization F	Policy (3)					
+	Status	Rule Name	Conditions	Results Command Sets	Shell Profiles		Actions
Search	1						
	ø	WLCAdmin	AD-JointName-ExternalGroups EQUALS panlab.local/Users/Admin-Read- Write	+	WLC ALL × 👻 🕇	0	٥
	ø	WLCMonitor	AD-JointName-ExternalGroups EQUALS panlab.local/Users/Admin-Read- Only	+	WLC MONITOR * * +	0	٥
	ø	Default		× DenyAllCommands +	Deny All Shell Profile × v +	0	٥

Paso 8. Configure el WLC para la Administración del Dispositivo.

Navegue hasta **Seguridad > AAA > TACACS+** haga clic en **Nuevo** y agregue Authentication, Accounting server, como se muestra en la imagen.

cisco	MONITOR	<u>W</u> LANs		WIRELESS	<u>S</u> ECURITY	MANAGEMENT	С <u>о</u> мм		
Security	TACACS	F Auther	ntication Serv	ers > New					
 AAA General RADIUS Authentication Accounting Fallback DNS Downloaded AVP 	Server Ind Server IP Shared Se Shared Se Confirm S	Server Index (Priority) Server IP Address(Ipv4/Ipv6) Shared Secret Format Shared Secret			1 10.106.37.180 ASCII •••••				
TACACS+ Authentication Accounting Authorization Fallback DNS	Port Numi Server Sta Server Tir	ber atus neout		49 Enabled 🗘 5 second	is				

CISCO		LANs		WIRELESS	<u>S</u> ECURITY	MANAGEMENT	C <u>O</u> MMANDS
Security	TACACS+ A	CCOUN	ting Servers	> New			
General RADIUS Authentication Accounting Fallback DNS Downloaded AVP TACACS+ Authentication Accounting Authorization Fallback DNS	Server IP Address(Ipv4, Shared Secret Shared Secret Confirm Share Port Number Server Status Server Timeor	/Ipv6) t Format t ed Secre	10.10 ASC ••••• 49 Enat 5	06.37.180			

Cambie el orden de prioridad y haga TACACS+ arriba y Local abajo, como se muestra en la imagen:

CISCO	MONITOR	<u>W</u> LANs	CONTROLLER	WIRELESS	<u>S</u> ECURITY	MANAGEMENT	С
Security	Priority C	order > N	lanagement U	lser			
AAALocal EAP	Authentic	ation					
Advanced EAP Priority Order 	Not	Used		Order U	sed for Authe	entication	
Management User	RAD	IUS	>		TACACS+ LOCAL	Up Dow	n
Access Control Lists							
Wireless Protection Policies	If LOCAL is s	elected as	second priority the	en user will be a	authenticated a	against	
Web Auth	LUCAL UNITY I	i nisc prior	ity is unreachable.				

Precaución: No cierre la sesión actual de WLC GUI. Se recomienda abrir la GUI del WLC en diferentes navegadores web y verificar si el login con las credenciales TACACS+ funciona o no. Si no es así, verifique la configuración y conectividad con el nodo ISE en el puerto TCP 49.

Verificación

Navegue hasta **Operaciones > TACACS > Registros en directo** y monitoree los **Registros en directo**. Abra la GUI del WLC e inicie sesión con las credenciales del usuario de Active Directory, como se muestra en la imagen

ululu cisco	Identity Services Engine	Home ► C	ontext Visibility	✓ Operations	Policy ► Add	ninistration	Centers	
▶ R	ADIUS Threat-Centric NAC Live L	.ogs TACAC	S Froubles	hoot + Adaptive N	letwork Control Re	ports		
Live Logs								
Refresh Never Show Latest 20 record C Refresh Z Export To ▼								
	Logged Time	Status	Details	Identity	Туре	Authentication Polic	cy Authorization Policy	Network Device
×		•		Identity		Authentication Policy	Authorization Policy	Network Device Name
	Oct 03, 2019 03:15:55.969 PM		à	admin2	Authorization		WLC >> WLCAdmin	FloorWLC
	Oct 03, 2019 03:15:55.938 PM		Q	admin2	Authentication	WLC >> Default		FloorWLC
	Oct 03, 2019 03:15:39.298 PM	~	o	admin1	Authorization		WLC >> WLCMonitor	FloorWLC
	Oct 03, 2019 03:15:39.268 PM		0	admin1	Authentication	WLC >> Default		FloorWLC
Last Updated: Thu Oct 03 2019 15:16:26 GMT+0530 (India Standard Time)								

Troubleshoot

Actualmente, no hay información específica de troubleshooting disponible para esta configuración.