

# SG350XG和SG550XG交換機上的頻寬配置

## 目標

Bandwidth頁允許使用者定義兩個值：入口速率限制和出口整形速率，它們決定系統可以接收和傳送的流量大小。

本文檔的目標是向您展示如何在SG350XG和SG550XG交換機上配置頻寬。

**附註：**本文檔中的步驟在「高級顯示模式」下執行。要更改高級顯示模式，請轉到右上角，然後在顯示模式下拉選單中選擇**高級**。

## 適用裝置

- SG350XG
- SG550XG

## 軟體版本

- V2.0.0.73

## 配置頻寬

步驟1.登入到Web配置實用程式，然後選擇**Quality of Service > General > Bandwidth**。將開啟*Bandwidth*頁面。

### Bandwidth

**Bandwidth Table**

Filter: *Interface Type equals to*

|                       | Entry No. | Interface | Ingress Rate Limit |                        |   | Egress Shaping Rates |          |                 |             |
|-----------------------|-----------|-----------|--------------------|------------------------|---|----------------------|----------|-----------------|-------------|
|                       |           |           | Status             | Rate Limit (KBits/sec) | % | CBS (Bytes)          | Status   | CIR (KBits/sec) | CBS (Bytes) |
| <input type="radio"/> | 1         | XG1       | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 2         | XG2       | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 3         | XG3       | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 4         | XG4       | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 5         | XG5       | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 6         | XG6       | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 7         | XG7       | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 8         | XG8       | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 9         | XG9       | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 10        | XG10      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 11        | XG11      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 12        | XG12      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 13        | XG13      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 14        | XG14      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 15        | XG15      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 16        | XG16      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 17        | XG17      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 18        | XG18      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 19        | XG19      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 20        | XG20      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 21        | XG21      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 22        | XG22      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 23        | XG23      | Disabled           |                        |   |                      | Disabled |                 |             |
| <input type="radio"/> | 24        | XG24      | Disabled           |                        |   |                      | Disabled |                 |             |

步驟2.在 *Filter:Interface Type equals to* 下拉清單，選擇所需的 **Port of Unit** 或 **LAG**。Port of Unit 選項表示您正在選擇堆疊中特定裝置上的埠，而 LAG 表示您正在選擇鏈路聚合組。選擇所需選項後，按一下 **Go**。

| Bandwidth Table   |           |         |          |                        |   |             |                      |                 |             |
|---|-----------|---------|----------|------------------------|---|-------------|----------------------|-----------------|-------------|
| Filter: <i>Interface Type</i> equals to <span>Port of Unit 1</span> <span>Go</span> |           |         |          |                        |   |             |                      |                 |             |
| Entry No.   | Interface | Ingress |          |                        |   |             | Egress Shaping Rates |                 |             |
|   |           |         | Status   | Rate Limit (KBits/sec) | % | CBS (Bytes) | Status               | CIR (KBits/sec) | CBS (Bytes) |
| <input checked="" type="radio"/>  | 1         | XG1     | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 2         | XG2     | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 3         | XG3     | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 4         | XG4     | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 5         | XG5     | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 6         | XG6     | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 7         | XG7     | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 8         | XG8     | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 9         | XG9     | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 10        | XG10    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 11        | XG11    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 12        | XG12    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 13        | XG13    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 14        | XG14    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 15        | XG15    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 16        | XG16    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 17        | XG17    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 18        | XG18    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 19        | XG19    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 20        | XG20    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 21        | XG21    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 22        | XG22    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 23        | XG23    | Disabled |                        |   |             |                      | Disabled        |             |
| <input type="radio"/>   | 24        | XG24    | Disabled |                        |   |             |                      | Disabled        |             |

附註：如果堆疊中有更多裝置，則會有更多選項(例如裝置2的連線埠)。

步驟3.按一下要配置頻寬設定的介面的單選按鈕，然後按一下Edit...

| Bandwidth Table   |           |           |                    |                        |   |             |                      |                 |            |
|---|-----------|-----------|--------------------|------------------------|---|-------------|----------------------|-----------------|------------|
| Filter: <i>Interface Type</i> equals to <input type="text" value="Port of Unit 1"/> <input type="button" value="Go"/> |           |           |                    |                        |   |             |                      |                 |            |
|   | Entry No. | Interface | Ingress Rate Limit |                        |   |             | Egress Shaping Rates |                 |            |
|   |           |           | Status             | Rate Limit (KBits/sec) | % | CBS (Bytes) | Status               | CIR (KBits/sec) | CBS (Byte) |
| <input checked="" type="radio"/>  | 1         | XG1       | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 2         | XG2       | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 3         | XG3       | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 4         | XG4       | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 5         | XG5       | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 6         | XG6       | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 7         | XG7       | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 8         | XG8       | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 9         | XG9       | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 10        | XG10      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 11        | XG11      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 12        | XG12      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 13        | XG13      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 14        | XG14      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 15        | XG15      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 16        | XG16      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 17        | XG17      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 18        | XG18      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 19        | XG19      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 20        | XG20      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 21        | XG21      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 22        | XG22      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 23        | XG23      | Disabled           |                        |   |             |                      | Disabled        |            |
| <input type="radio"/>   | 24        | XG24      | Disabled           |                        |   |             |                      | Disabled        |            |

Copy Settings...

出現Edit Bandwidth視窗：

|   |  |   |  |
|---|--|---|--|
| Interface:  | <input checked="" type="radio"/> Unit <input type="text" value="1"/> | Port <input type="text" value="XG1"/>           | <input type="radio"/> LAG <input type="text" value="1"/> |
| Ingress Rate Limit:   | <input type="checkbox"/> Enable                                      |   |  |
| * Ingress Rate Limit:   | <input type="text" value="100"/>                                     | KBits/sec (Range: 100 - 10000000, Default: 100) |  |
| * Ingress Committed Burst Size (CBS):                                     | <input type="text" value="128000"/>                                  | Bytes (Range: 3000 - 19173960, Default: 128000) |  |
| Egress Shaping Rate:  | <input type="checkbox"/> Enable                                      |   |  |
| * Committed Information Rate (CIR):                                       | <input type="text" value="64"/>                                      | KBits/sec (Range: 64 - 10000000, Default: 64)   |  |
| * Egress Committed Burst Size (CBS):                                      | <input type="text" value="128000"/>                                  | Bytes (Range: 4096 - 16762902, Default: 128000) |  |
| <input type="button" value="Apply"/> <input type="button" value="Close"/> |  |   |  |

附註：當介面型別為LAG時，不會顯示Ingress Rate Limit欄位。如果介面型別為LAG，請跳至[步驟7](#)。

步驟4.在Ingress Rate Limit欄位中，如果要啟用輸入速率限制，請勾選Enable覆取方塊。入口速率限制限制介面上的傳入流量量。如果您不想啟用它，請跳至[步驟7](#)。

|   |  |   |  |
|---|--|---|--|
| Interface:  | <input checked="" type="radio"/> Unit <input type="text" value="1"/> | Port <input type="text" value="XG1"/>           | <input type="radio"/> LAG <input type="text" value="1"/> |
| Ingress Rate Limit:   | <input checked="" type="checkbox"/> Enable                           |   |  |
| Ingress Rate Limit:   | <input type="text" value="100"/>                                     | KBits/sec (Range: 100 - 10000000, Default: 100) |  |
| Ingress Committed Burst Size (CBS):                                       | <input type="text" value="128000"/>                                  | Bytes (Range: 3000 - 19173960, Default: 128000) |  |
| Egress Shaping Rate:  | <input type="checkbox"/> Enable                                      |   |  |
| Committed Information Rate (CIR):   | <input type="text" value="64"/>                                      | KBits/sec (Range: 64 - 10000000, Default: 64)   |  |
| Egress Committed Burst Size (CBS):  | <input type="text" value="128000"/>                                  | Bytes (Range: 4096 - 16762902, Default: 128000) |  |
| <input type="button" value="Apply"/> <input type="button" value="Close"/> |  |   |  |

步驟5.如果您選擇在步驟4中啟用輸入速率限制，請在輸入速率限制欄位中輸入介面上允許的所需最大頻寬量。最小值為100 KBits/sec，最大值為10000000 KBits/sec。

|   |  |   |  |
|---|--|---|--|
| Interface:  | <input checked="" type="radio"/> Unit <input type="text" value="1"/> | Port <input type="text" value="XG1"/>           | <input type="radio"/> LAG <input type="text" value="1"/> |
| Ingress Rate Limit:   | <input checked="" type="checkbox"/> Enable                           |   |  |
| Ingress Rate Limit:   | <input type="text" value="200"/>                                     | KBits/sec (Range: 100 - 10000000, Default: 100) |  |
| Ingress Committed Burst Size (CBS):                                       | <input type="text" value="128000"/>                                  | Bytes (Range: 3000 - 19173960, Default: 128000) |  |
| Egress Shaping Rate:  | <input type="checkbox"/> Enable                                      |   |  |
| Committed Information Rate (CIR):   | <input type="text" value="64"/>                                      | KBits/sec (Range: 64 - 10000000, Default: 64)   |  |
| Egress Committed Burst Size (CBS):  | <input type="text" value="128000"/>                                  | Bytes (Range: 4096 - 16762902, Default: 128000) |  |
| <input type="button" value="Apply"/> <input type="button" value="Close"/> |  |   |  |

步驟6.如果您選擇在步驟4中啟用輸入速率限制，請輸入入口介面所需的最大資料突發大小（以位元組為單位）。即使臨時增加頻寬超過允許的限制，也可以傳送此數量。最小範圍為3000位元組，最大範圍為10000000位元組。

|   |  |   |  |
|---|--|---|--|
| Interface:  | <input checked="" type="radio"/> Unit <input type="text" value="1"/> | Port <input type="text" value="XG1"/>           | <input type="radio"/> LAG <input type="text" value="1"/> |
| Ingress Rate Limit:   | <input checked="" type="checkbox"/> Enable                           |   |  |
| Ingress Rate Limit:   | <input type="text" value="200"/>                                     | KBits/sec (Range: 100 - 10000000, Default: 100) |  |
| Ingress Committed Burst Size (CBS):                                       | <input type="text" value="128000"/>                                  | Bytes (Range: 3000 - 19173960, Default: 128000) |  |
| Egress Shaping Rate:  | <input type="checkbox"/> Enable                                      |   |  |
| Committed Information Rate (CIR):   | <input type="text" value="64"/>                                      | KBits/sec (Range: 64 - 10000000, Default: 64)   |  |
| Egress Committed Burst Size (CBS):  | <input type="text" value="128000"/>                                  | Bytes (Range: 4096 - 16762902, Default: 128000) |  |
| <input type="button" value="Apply"/> <input type="button" value="Close"/> |  |   |  |

步驟7.在Egress Shaping Rate欄位中，如果要啟用傳出流量限制，請勾選Enable覆取方塊。如果您不想啟用它，請跳至步驟10。

|   |  |   |   |     |                           |   |
|---|--|---|---|-----|---------------------------|---|
| Interface:  | <input checked="" type="radio"/> Unit      | 1 | Port  | XG1 | <input type="radio"/> LAG | 1 |
| Ingress Rate Limit:   | <input checked="" type="checkbox"/> Enable |   |   |     |                           |   |
| Ingress Rate Limit:   | 200  |   | KBits/sec (Range: 100 - 10000000, Default: 100) |     |                           |   |
| Ingress Committed Burst Size (CBS):                                       | 128000                                     |   | Bytes (Range: 3000 - 19173960, Default: 128000) |     |                           |   |
| Egress Shaping Rate:  | <input checked="" type="checkbox"/> Enable |   |   |     |                           |   |
| Committed Information Rate (CIR):   | 64   |   | KBits/sec (Range: 64 - 10000000, Default: 64)   |     |                           |   |
| Egress Committed Burst Size (CBS):  | 128000                                     |   | Bytes (Range: 4096 - 16762902, Default: 128000) |     |                           |   |
| <input type="button" value="Apply"/> <input type="button" value="Close"/> |  |   |   |     |                           |   |

步驟8。如果您選擇在步驟7中啟用輸出整形速率，請在 *Committed Information Rate(CIR)* 欄位中輸入輸出介面所需的最大頻寬。最小值為64 KBits/sec，最大值為10000000 KBits/sec。

|   |  |   |   |     |                           |   |
|---|--|---|---|-----|---------------------------|---|
| Interface:  | <input checked="" type="radio"/> Unit      | 1 | Port  | XG1 | <input type="radio"/> LAG | 1 |
| Ingress Rate Limit:   | <input checked="" type="checkbox"/> Enable |   |   |     |                           |   |
| Ingress Rate Limit:   | 200  |   | KBits/sec (Range: 100 - 10000000, Default: 100) |     |                           |   |
| Ingress Committed Burst Size (CBS):                                       | 128000                                     |   | Bytes (Range: 3000 - 19173960, Default: 128000) |     |                           |   |
| Egress Shaping Rate:  | <input checked="" type="checkbox"/> Enable |   |   |     |                           |   |
| Committed Information Rate (CIR):   | 100  |   | KBits/sec (Range: 64 - 10000000, Default: 64)   |     |                           |   |
| Egress Committed Burst Size (CBS):  | 128000                                     |   | Bytes (Range: 4096 - 16762902, Default: 128000) |     |                           |   |
| <input type="button" value="Apply"/> <input type="button" value="Close"/> |  |   |   |     |                           |   |

步驟9。如果您選擇在步驟7中啟用輸出整形速率，請在輸出承諾突發大小(CBS)欄位中輸入輸出介面所需的資料最大突發大小。即使臨時增加頻寬超過允許的限制，也可以傳送此數量。最小範圍為4096位元組，最大範圍為16762902位元組。

|   |  |   |   |     |                           |   |
|---|--|---|---|-----|---------------------------|---|
| Interface:  | <input checked="" type="radio"/> Unit      | 1 | Port  | XG1 | <input type="radio"/> LAG | 1 |
| Ingress Rate Limit:   | <input checked="" type="checkbox"/> Enable |   |   |     |                           |   |
| Ingress Rate Limit:   | 200  |   | KBits/sec (Range: 100 - 10000000, Default: 100) |     |                           |   |
| Ingress Committed Burst Size (CBS):                                       | 128000                                     |   | Bytes (Range: 3000 - 19173960, Default: 128000) |     |                           |   |
| Egress Shaping Rate:  | <input checked="" type="checkbox"/> Enable |   |   |     |                           |   |
| Committed Information Rate (CIR):   | 100  |   | KBits/sec (Range: 64 - 10000000, Default: 64)   |     |                           |   |
| Egress Committed Burst Size (CBS):  | 180000                                     |   | Bytes (Range: 4096 - 16762902, Default: 128000) |     |                           |   |
| <input type="button" value="Apply"/> <input type="button" value="Close"/> |  |   |   |     |                           |   |

步驟10.按一下Apply。頻寬設定將寫入運行配置檔案。

## 複製設定

步驟1.按一下要從其中複製頻寬配置的介面的單選按鈕。然後按一下複製設定.....

| Bandwidth Table  |           |           |                    |                        |       |             |                      |                 |             |
|--|-----------|-----------|--------------------|------------------------|-------|-------------|----------------------|-----------------|-------------|
| Filter: Interface Type equals to <span>Port of Unit 1</span> <span>Go</span> |           |           |                    |                        |       |             |                      |                 |             |
|  | Entry No. | Interface | Ingress Rate Limit |                        |       |             | Egress Shaping Rates |                 |             |
|  |           |           | Status             | Rate Limit (KBits/sec) | %     | CBS (Bytes) | Status               | CIR (KBits/sec) | CBS (Bytes) |
| <input checked="" type="radio"/>   | 1         | XG1       | Enabled            | 200                    | 0.002 | 128000      | Enabled              | 100             | 180000      |
| <input type="radio"/>  | 2         | XG2       | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 3         | XG3       | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 4         | XG4       | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 5         | XG5       | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 6         | XG6       | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 7         | XG7       | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 8         | XG8       | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 9         | XG9       | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 10        | XG10      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 11        | XG11      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 12        | XG12      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 13        | XG13      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 14        | XG14      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 15        | XG15      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 16        | XG16      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 17        | XG17      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 18        | XG18      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 19        | XG19      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 20        | XG20      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 21        | XG21      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 22        | XG22      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 23        | XG23      | Disabled           |                        |       |             | Disabled             |                 |             |
| <input type="radio"/>  | 24        | XG24      | Disabled           |                        |       |             | Disabled             |                 |             |

Copy Settings... Edit...

出現「Copy Settings」視窗：

Copy configuration from entry 1 (XG1)

to:  (Example: 1,3,5-10 or: XG1,XG3-XG5)

步驟2.在到欄位中，輸入要複製選定埠設定的埠或埠範圍。然後按一下「Apply」。

Copy configuration from entry 1 (XG1)

to:  (Example: 1,3,5-10 or: XG1,XG3-XG5)