

HTTP

HTTP

```

Router# show running-config | include ip http
server|secure|active
ip http server
ip http secure-server

```

```

Router# show running-config | include ip http
server|secure|active

```

<#root>

Router#

```
show running-config | include ip http server|secure|active
```

```
ip http server
ip http secure-server
```

```

Router# show running-config | include ip http
server|secure|active

```

```

ip http server
ip http active-session-modules none

```

```

ip http secure-server
ip http secure-active-session-modules none

```

```

ip http secure-server
ip http secure-active-session-modules none

```

```

ip http secure-server
ip http secure-active-session-modules none

```

```

ip http secure-server
ip http secure-active-session-modules none

```

- IOS
- IOS XR
- NX-OS

翻訳について

シスコは世界中のユーザにそれぞれの言語でサポート コンテンツを提供するために、機械と人による翻訳を組み合わせて、本ドキュメントを翻訳しています。ただし、最高度の機械翻訳であっても、専門家による翻訳のような正確性は確保されません。シスコは、これら翻訳の正確性について法的責任を負いません。原典である英語版（リンクからアクセス可能）もあわせて参照することを推奨します。