

使用SPA500系列IP電話的幫助配置SPA500上的話務台按鍵LED模式

目標

話務台按鍵LED是SPA500系列IP電話話務台的一項功能。它幫助使用者通過視覺指示區分一般狀態和工作狀態。當您輸入某些特定的字母或顏色模式來指示控制檯的可視狀態時，會配置控制檯金鑰LED。LED模式指示SPA500S話務台按鍵的顏色和閃爍模式。

本文檔的目的是向您展示如何在SPA500系列IP電話上配置話務台按鍵LED設定。

附註： SPA500DS不能與UC500系列統一通訊裝置一起使用，只能與UC320統一通訊裝置一起使用。

適用裝置

- SPA500系列IP電話
- SPA500S Att.主控台

軟體版本

- 8.6.0版[UC540]
- v3.2(1)[Cisco Configuration Assistant]
- v7-5-2a [SPA 525G IP電話]

LED指令碼

LED指令碼提供有關線路鍵LED的顏色和閃爍模式的資訊。

· 顏色指令碼的格式為 $c = o / r / g$ 其中：

- o — 表示LED顏色選項已關閉。
- r — 代表紅色。
- g — 表示綠色。

· 閃爍模式的指令碼的格式為 $p = nb / 某人 / fb / ud$ 其中：

- nb — 表示不發生閃爍。
- sb — 代表慢閃。(1開1關)
- fb — 代表快速閃爍。(100毫秒開，100毫秒關)
- ud — 表示使用者定義的閃爍模式。

使用者定義的閃爍模式的格式為 $u = on / off / on / off$ ，其中每個值以秒為單位。

使用Web介面配置話務台按鍵LED模式

步驟1.登入到Web配置實用程式，然後選擇Admin Login > Advanced > Attendant Console > Att Console Key LED Pattern。

Info	System	SIP	Provisioning	Regional	Phone	Ext 1	Ext 2	Ext 3	Ext 4	Ext 5	User	Att Console	TR-069
Attendant Console Status User Login basic advanced													
General													
Subscribe Expires:	1800			Subscribe Retry Interval:	30								
Unit 1 Enable:	yes			Subscribe Delay:	1								
Unit 2 Enable:	yes			Server Type:	Broadsoft								
Test Mode Enable:	no			Attendant Console Call Pickup Code:	*98								
Attendant Console Call Park Code:	*68			Attendant Console Call unPark Code:	*88								
BLF List URI:													
Call Pickup Audio Notification:	no			Attendant Console Font Size:	10								
Attendant Console LCD Contrast:	1												
Att Console Key LED Pattern													
Application LED:				Serv Subscribe Failed LED:									
Serv Subscribing LED:				SNRM Day Mode LED:									
SNRM Night Mode LED:				Parking Lot Idle LED:									
Parking Lot Busy LED:				BLF Idle LED:									
BLF Ringing LED:				BLF Busy LED:									
BLF Held LED:													

以下是Line Key LED Pattern區域的各個欄位的說明。

Voice	Wi-Fi	Bluetooth	Personal Address Book	Call History	Speed Dials	Firmware Upgrade							
Info	System	SIP	Provisioning	Regional	Phone	Ext 1	Ext 2	Ext 3	Ext 4	Ext 5	User	Att Console	TR-069
Attendant Console Status User Login basic advanced													
General													
Subscribe Expires:	1800			Subscribe Retry Interval:	30								
Unit 1 Enable:	yes			Subscribe Delay:	1								
Unit 2 Enable:	yes			Server Type:	Broadsoft								
Test Mode Enable:	no			Attendant Console Call Pickup Code:	*98								
Attendant Console Call Park Code:	*68			Attendant Console Call unPark Code:	*88								
BLF List URI:													
Call Pickup Audio Notification:	no			Attendant Console Font Size:	12								
Attendant Console LCD Contrast:	10												
Att Console Key LED Pattern													
Application LED:				Serv Subscribe Failed LED:	u=.1/.1/.1/.1								
Serv Subscribing LED:	c=o			SNRM Day Mode LED:									
SNRM Night Mode LED:				Parking Lot Idle LED:									
Parking Lot Busy LED:				BLF Idle LED:	c=o,p=fb								
BLF Ringing LED:	c=g,p=sb			BLF Busy LED:	u=.1/.1/.9/.1								
BLF Held LED:													

·應用程式LED — 代表LED功能。

·伺服器訂閱失敗LED — 表示對Att Console的訂閱失敗。空白欄位表示預設顏色為綠色。

·伺服器訂用LED — 表示正在預訂Att Console。空白欄位表示預設顏色為紅色。

·SNRM白天模式LED — 表示IP電話處於白天模式。空白欄位表示預設顏色為綠色。

- SNRM夜間模式LED — 表示IP電話處於夜間模式。空白欄位表示預設顏色為紅色。
- 停車場空閒LED — 表示沒有呼叫暫留，線路空閒。空白欄位表示預設顏色為紅色。
- 停車場忙碌LED指示燈 — 表示呼叫已暫留，線路正忙。空白欄位表示預設顏色為紅色。
- BLF空閒LED — 表示連線到IP電話的另一條分機線路空閒。空白欄位表示預設顏色為紅色。
- BLF振鈴LED — 表示連線到IP電話的另一條分機線路正在振鈴。空白欄位表示預設顏色為紅色。
- BLF Busy LED — 表示連線到IP電話的另一條分機線路忙。空白欄位表示預設顏色為紅色。
- BLF Hold LED — 表示連線到IP電話的另一分機處於保持狀態。空白欄位表示預設顏色為紅色。

步驟2.按一下**Submit All Changes**以儲存設定。