

Introduction to Optical Fibers, dB, Attenuation and Measurements

[TAC Notice: What's Changing on TAC Web](#)

Contents

[Introduction](#)

[Prerequisites](#)

[Requirements](#)

[Components Used](#)

[Conventions](#)

[What is a Decibel?](#)

[Base 10 Logarithm Rules](#)

[dB](#)

[Decibels in Milliwatts \(dBm\)](#)

[Decibels that Reference One Watt \(dBW\)](#)

[Power/Voltage Gains](#)

[Optical Fiber Structure](#)

[Fiber Type](#)

[Wavelength](#)

[Optical Power](#)

[Understand Insertion Loss](#)

[Calculate a Power Budget](#)

[NetPro Discussion Forums - Featured Conversations](#)

[Related Information](#)

Help us help you.

Please rate this document.

Excellent

Good

Average

Fair

Poor

This document solved my problem.

Yes

No

Just browsing

Suggestions for improvement:

(256 character limit)

Send

Introduction

This document is a quick reference to some of the formulas and important information related to optical technologies. It focuses on decibels (dB), decibels per milliwatt (dBm), attenuation and measurements, and provides an introduction to optical fibers.

Prerequisites

Requirements

There are no specific requirements for this document.

Components Used

This document is not restricted to specific software and hardware versions.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

For more information on document conventions, refer to the [Cisco Technical Tips Conventions](#).

What is a Decibel?

A decibel (dB) is a unit used to express relative differences in signal strength. A decibel is expressed as the base 10 logarithm of the ratio of the power of two signals, as shown here:

$$\text{dB} = 10 \times \text{Log}_{10} (P1/P2)$$

where Log_{10} is the base 10 logarithm, and P1 and P2 are the powers to be compared.

Note: Log_{10} is different from the Neperian Logarithm (Ln or LN) base e logarithm.

You can also express signal amplitude in dB. Power is proportional to the square of a signal's amplitude. Therefore, dB is expressed as:

$$\text{dB} = 20 \times \text{Log}_{10} (V1/V2)$$

where V1 and V2 are the amplitudes to be compared.

$$1 \text{ Bell (not currently used)} = \text{Log}_{10} (P1/P2)$$

$$1 \text{ decibel (dB)} = 1 \text{ Bell} / 10 = 10 * \text{Log}_{10} (P1/P2)$$

$$\text{dBr} = \text{dB (relative)} = \text{dB} = 10 * \text{Log}_{10} (P1/P2)$$

Base 10 Logarithm Rules

- $\text{Log}_{10} (A \times B) = \text{Log}_{10} (A) + \text{Log}_{10} (B)$
- $\text{Log}_{10} (A/B) = \text{Log}_{10} (A) - \text{Log}_{10} (B)$
- $\text{Log}_{10} (1/A) = -\text{Log}_{10} (A)$
- $\text{Log}_{10} (0,01) = -\text{Log}_{10} (100) = -2$
- $\text{Log}_{10} (0,1) = -\text{Log}_{10}(10) = -1$
- $\text{Log}_{10} (1) = 0$
- $\text{Log}_{10} (2) = 0,3$

- $\text{Log}_{10}(4) = 0,6$
- $\text{Log}_{10}(10) = 1$
- $\text{Log}_{10}(20) = 1,3$

$$\text{Log}_{10}(2 \times 10) = \text{Log}_{10}(2) + \text{Log}_{10}(10) = 1 + 0,3$$

- $\text{Log}_{10}(100) = 2$
- $\text{Log}_{10}(1000) = 3$
- $\text{Log}_{10}(10000) = 4$

dB

This table lists the Logarithm and dB (decibel) power ratios:

Power Ratio	dB = 10 x Log ₁₀ (Power Ratio)
AxB	x dB = 10 x Log ₁₀ (A) + 10 x Log ₁₀ (B)
A/B	x dB = 10 x Log ₁₀ (A) - 10 x Log ₁₀ (B)
1/A	x dB = + 10 x Log ₁₀ (1/A) = - 10 x Log ₁₀ (A)
0,01	- 20 dB = - 10 x Log ₁₀ (100)
0,1	- 10 dB = 10 x Log ₁₀ (1)
1	0 dB = 10 x Log ₁₀ (1)
2	3 dB = 10 x Log ₁₀ (2)
4	6 dB = 10 x Log ₁₀ (4)
10	10 dB = 10 x Log ₁₀ (10)
20	13 dB = 10 x (Log ₁₀ (10) + Log ₁₀ (2))
100	20 dB = 10 x Log ₁₀ (100)
1000	30 dB = 10 x Log ₁₀ (1000)
10000	40 dB = 10 x Log ₁₀ (10000)

Decibels in Milliwatts (dBm)

dBm = dB milliwatt = 10 x Log₁₀ (Power in mW / 1 mW)

--	--	--

Power	Ratio	dBm = 10 x Log₁₀ (Power in mW / 1 mW)
1 mW	1 mW/1mW=1	0 dBm = 10 x Log ₁₀ (1)
2 mW	2 mW/1mW=2	3 dBm = 10 x Log ₁₀ (2)
4 mW	4 mW/1mW=4	6 dBm = 10 x Log ₁₀ (4)
10 mW	10 mW/1mW=10	10 dBm = 10 x Log ₁₀ (10)
0,1 W	100 mW/1mW=100	20 dBm = 10 x Log ₁₀ (100)
1 W	1000 mW/1mW=1000	30 dBm = 10 x Log ₁₀ (1000)
10 W	10000mW/1mW=10000	40 dBm = 10 x Log ₁₀ (10000)

Decibels that Reference One Watt (dBW)

dBW = dB Watt = 10 x Log₁₀ (Power in W / 1 W)

Power	Ratio	dBm = 10 x Log₁₀ (Power in mW / 1 mW)
1 W	1 W / 1 W = 1	0 dBW = 10 x Log ₁₀ (1)
2 W	2 W / 1 W = 2	3 dBW = 10 x Log ₁₀ (2)
4 W	4 W / 1 W = 4	6 dBW = 10 x Log ₁₀ (4)
10 W	10 W / 1 W = 10	10 dBW = 10 x Log ₁₀ (10)
100 mW	0,1 W / 1 W = 0,1	-10 dBW = -10 x Log ₁₀ (10)
10 mW	0,01 W / 1 W = 1/100	-20 dBW = -10 x Log ₁₀ (100)
1 mW	0,001W/1W=1/1000	-30 dBW = -10 x Log ₁₀ (1000)

Power/Voltage Gains

This table compares the power and voltage gains:

dB	Power Ratio	Voltage Ratio	dB	Power Ratio	Voltage Ratio
0	1,00	1,00	10	10,00	3,16
1	1,26	1,12	11	12,59	3,55
2	1,58	1,26	12	15,85	3,98
3	2,00	1,41	13	19,95	4,47
4	2,51	1,58	14	25,12	5,01
5	3,16	1,78	15	31,62	5,62
6	3,98	2,00	16	39,81	6,31
7	5,01	2,24	17	50,12	7,08
8	6,31	2,51	18	63,10	7,94
9	7,94	2,82	19	79,43	8,91
10	10,00	3,16	20	100,00	10,00

With this information, you can define the formulas for attenuation and gain:


$$\text{Attenuation (dB)} = 10 \times \text{Log}_{10}(\text{P in}/\text{P out}) = 20 \times \text{Log}_{10}(\text{V in}/\text{V out})$$

$$\text{Gain (dB)} = 10 \times \text{Log}_{10}(\text{P out}/\text{P in}) = 20 \times \text{Log}_{10}(\text{V out}/\text{V in})$$

Optical Fiber Structure

Optical fiber is a medium to carry information. It is made of silica-based glass. It consists of a core surrounded by cladding. The central part of the fiber, called the core, has a refractive index of N_1 . The cladding that surrounds the core has a lower refractive index of N_2 . When light is launched into the fiber, the cladding confines the light to the fiber core, and the light travels down the fiber by internal reflection between the boundaries of the core and the cladding.






Figure 1 – Optical Fiber Structure



Fiber Type

Singlemode (SM) and multimode (MM) fibers are the mainstream fibers that are manufactured and marketed today. [Figure 2](#) provides information on both these fiber types.


Figure 2 – SM and MM Fibers

fiber type	MM	SM
		
fiber size	50/125 μm 62.5/125 μm 100/140 μm	9/125 μm 10/125 μm
type	Multimode Step-index fiber (SI)  Multimode Graded-index fiber (GI) 	
Application	Short Distance LAN	Long Distance Telecoms, CATV, Broadcast, Data communication

Wavelength

A small amount of light is injected into the fiber. This falls into visible wavelength (from 400nm to 700nm) and near infrared wavelength (from 700nm to 1700nm) in the electromagnetic spectrum shown in Figure 3.

Figure 3 – The Electromagnetic Spectrum



There are four special wavelengths that you can use for fiber optic transmission with low optical loss levels, as listed in this table:


Windows	Wavelength	Loss
1 st wavelength	850nm	3dB/km
2 nd wavelength	1310nm	0.4dB/km

3 rd wavelength	1550nm (C band)	0.2dB/km
4 th wavelength	1625nm (L band)	0.2dB/km

Optical Power

To measure optical loss, you can use two units, namely, dBm and dB. While dBm is the actual power level represented in milliwatts, dB (decibel) is the difference between the powers.

Figure 4 – How to Measure Optical Power



If the optical input power is P1 (dBm) and the optical output power is P2 (dBm), the power loss is P1 - P2 dB. In order to see how much power is lost between input and output, refer to the dB value in this power conversion table:

dB	Power Out as a % of Power In	% of Power lost	Remarks
1	79%	21%	-
2	63%	37%	-
3	50%	50%	1/2 the power
4	40%	60%	-
5	32%	68%	-
6	25%	75%	1/4 the power
7	20%	80%	1/5 the power
8	16%	84%	1/6 the power
9	12%	88%	1/8 the power
10	10%	90%	1/10 the power
11	8%	92%	1/12 the power
12	6.3%	93.7%	1/16 the power

13	5%	95%	1/20 the power
14	4%	96%	1/25 the power
15	3.2%	96.8%	1/30 the power

For example, when direct line (LD) optical input into the fiber is 0dBm and output power is -15dBm, optical loss for the fiber is calculated as:

$$\begin{array}{rcl} \text{Input} & \text{Output} & \text{Optical Loss} \\ 0\text{dBm} & - (-15\text{dBm}) & =15\text{dB} \end{array}$$

In the power conversion table, 15dB for optical loss equals 96.8 percent of lost optical power. Therefore, only 3.2 percent of optical power remains when it travels through the fiber.

Understand Insertion Loss

In any fiber optic interconnection, some loss occurs. Insertion loss for a connector or splice is the difference in power that you see when you insert the device into the system. For example, take a length of fiber and measure the optical power through it. Note the reading (P1). Now cut the fiber in half, terminate the fibers and connect them, and measure the power again. Note the second reading (P2). The difference between the first reading (P1) and the second (P2) is the insertion loss, or the loss of optical power that occurs when you insert the connector into the line. This is measured as:

$$\text{IL (dB)} = 10 \text{Log}_{10} (\text{P2} / \text{P1})$$

There are two important things that you must understand about insertion loss:

- **The specified insertion loss is for identical fibers.**

If the core diameter (or the NA) of the side that transmits data is larger than the NA of the fiber that receives data, there is additional loss.

$$\text{Ldia} = 10 \text{Log}_{10} (\text{diar}/\text{diat})^2$$

$$\text{LNA} = 10 \text{Log}_{10} (\text{NAr}/\text{NAt})^2$$

where:

- Ldia = Loss diameter
- diar = diameter receive
- diat = diameter transmit
- LNA = Loss on optical fiber

Additional loss can occur from Fresnel reflections. These occur when two fibers are

separated so that a discontinuity exists in the refractive index. For two glass fibers separated by an air gap, Fresnel reflections are 0.32 dB.

- **The loss depends on the launch.**

The insertion loss depends on the launch, and receives conditions in the two fibers that are joined. In a short launch, you can overfill the fiber with optical energy carried in both the cladding and core. Over distance, this excess energy is lost until the fiber reaches a condition known as equilibrium mode distribution (EMD). In a long launch, the fiber has already reached EMD, so the excess energy is already stripped away and is not present at the connector.

Light that crosses the fiber-to-fiber junction of an interconnection can again overfill the fiber with excess cladding modes. These are quickly lost. This is the short-receive condition. If you measure the power output of a short-receive fiber, you can see extra energy. However, the extra energy is not propagated far. The reading is therefore incorrect. Similarly, if the length of the receive fiber is long enough to reach EMD, the insertion loss reading can be higher, but it reflects actual application conditions.

You can easily simulate EMD (long launch and receive). For this, you must wrap the fiber around a mandrel five times. This strips the cladding modes.

Calculate a Power Budget

You can make a rough estimate of a link power budget. For this, you must allow 0.75 dB for each fiber-to-fiber connection, and assume that fiber loss is proportional with length in the fiber.

For a 100-meter run with three patch panels and 62.5/125 fiber that have a loss of 3.5 dB/km, the total loss is 2.6 dB, as shown here:

Fiber: $3.5 \text{ dB/km} = 0.35 \text{ dB}$ for 100 meters

Patch Panel 1 = 0.75 dB

Patch Panel 2 = 0.75 dB

Patch Panel 3 = 0.75 dB

Total = 2.6 dB

The measured loss is normally less. For example, the average insertion loss for an AMP SC connector is 0.3 dB. In this case, the link loss is only 1.4 dB. Regardless of whether you run Ethernet at 10 Mbps or ATM at 155 Mbps, the loss is the same.

Optical time-domain reflectometry (OTDR) is a popular certification method for fiber systems. The OTDR injects light into the fiber, and then graphically displays the results of detected back-reflected light. The OTDR measures elapsed transit time of reflected light to calculate the distance to different events. The visual display allows determination of loss per unit length, evaluation of splices and connectors, and fault location. OTDR zooms in to certain locations for a close-up picture of portions of the link.

While you can use power meters and signal injectors for many link certifications and evaluations, OTDRs provide a powerful diagnostic tool to get a comprehensive picture of the

link. But OTDR requires more training and some skill to interpret the display.

NetPro Discussion Forums - Featured Conversations

Networking Professionals Connection is a forum for networking professionals to share questions, suggestions, and information about networking solutions, products, and technologies. The featured links are some of the most recent conversations available in this technology.

NetPro Discussion Forums - Featured Conversations for Optical
Service Providers: Optical Networking
ONS 15454 cards fail in only certain slots - Apr 19, 2005
Overhead in ATM over SDH - Apr 17, 2005
Can CTC run on WinXP? - Apr 15, 2005
experience with flow control and qos? - Apr 13, 2005
15454 DS3-12E parity compatibility - Apr 8, 2005
Service Providers: Metro
about adsl 2 + - Apr 14, 2005
CPUHOG - Apr 14, 2005
Integrating Metro Ethernet to DSLAM - Apr 11, 2005
1310 nm fiber optic cable - Apr 7, 2005
Planning to Build a Metro ethernet.. need suggestions - Apr 4, 2005

Related Information

- [Optical Products Support Page](#)
- [Technical Support - Cisco Systems](#)

Home	How to Buy	Login	Profile	Feedback	Site Map	Help
----------------------	----------------------------	-----------------------	-------------------------	--------------------------	--------------------------	----------------------

All contents are Copyright © 1992-2005 Cisco Systems, Inc. All rights reserved. [Important Notices](#) and [Privacy Statement](#).