

VoIP هجوم ىلع ةيكلس اللى تاداع اللى دادع ةريغصللى تاكرشلى

تايتو حملا

ةمدقملا

[Cisco Small Business VoIP هجوم ىلع ةيكلس اللى تاداع اللى دادع اللى يننكمي فيك
ةلص تاذا تامولعم](#)

ةمدقملا

Cisco Small Business تايتو حملا دادع ىف ةدعاسم للى تالاقم ةللس ىف ةدحاو ىه ةلاقملا هذو
اهتنايصو اهحالص او اهئاظأ فاشكتساو.

[تاكرشلى VoIP هجوم ىلع ةيكلس اللى تاداع اللى دادع اللى يننكمي فيك .س. ج. Cisco؟ نم ةريغصللى](#)

(SSID) ةيكلس اللى ةكبشلى مسا ربيغتب مق ،اهنيسحتو ةيكلس اللى ةكبشلى ةراشا دادع
ةيلالى تاوطخللى لمكأ ،تاميلعت ىلع لوصحللى .ىرخأ ةانق مادختسا لواح واو:

ةانقو كيدل هجوملاب صاخلا SSID ربيغت

1: ةوطخللى

[انه](#) رقنا ،تاميلعت ىلع لوصحللى .بىولالى ةدنتسملا هجوملا دادع ةحفص ىلى لوصولا

2: ةوطخللى

يكلسال قوف رقنا ،بىولالى ةدنتسملا هجوملا دادع ةحفص روهظ دنع

3: ةوطخللى

مق ،"linksys" ىلع اطوبضم لازي ال ناك اذا .(SSID) ةيكلس اللى ةكبشلى مسا نعت حبا
تاداع اللى ظفح رقناو .ديرف عيش ىلى هريغتبا

4: ةوطخللى

ةلصفملا تاونقلا .تالخدتللا لواح فافتلالا لجا نم تاونقلا ربيغت لواح ،SSID ربيغت دعب
ةلخدتم ربيغ تاونق ربتعت اهنال 11و 6و 1 ىه مادختسالل

The screenshot shows the Linksys web interface for wireless settings. At the top left, the Linksys logo is displayed with the text "A Division of Cisco Systems, Inc." Below the logo, a yellow callout box says "Click **Wireless**." The main navigation bar includes "Setup", "Wireless", "Security", "Access Restrictions", "Applications & Gaming", "Administration", "Status", and "Voice". Under the "Wireless" tab, there are sub-links: "Basic Wireless Settings", "Wireless Security", "Wireless MAC Filter", and "Advanced Wireless Settings". The "Basic Wireless Settings" page is active, showing the following fields: "Wireless Network Mode" (set to "Disabled"), "Wireless Network Name (SSID)" (set to "linksys"), "Wireless Channel" (set to "1"), and "Wireless SSID Broadcast" (with a "Disable" radio button). A yellow callout box points to the SSID field, stating: "This is your SSID. If this is set to 'linksys,' change this to something unique." Another yellow callout box points to the "Wireless Channel" dropdown, stating: "Select 1, 6 or 11 then click **Save Settings**." At the bottom of the page, there are two buttons: "Save Settings" and "Cancel Changes". The Cisco Systems logo is visible in the bottom right corner.

5: قوطخا

ةقوطق **Save Settings**

ةلص تاذا تامولعم

- [Cisco Systems - تادنتس مل او ينقتلا معدلا](#)

ةمچرتل هذه ل و ح

ةلأل تاي نقتل ن م ة و مچ م ادخت ساب دن تسمل اذ ه Cisco ت مچرت
ملاعلاء ن أ عي مچ ي ف ن ي م دخت سمل ل معد ي و تح م مي دقت ل ة ي رش ب ل و
امك ة ق ي قد ن و ك ت ن ل ة ي ل أ ة مچرت ل ض ف أ ن أ ة ظ حال م ي ج ر ي . ة ص ا خ ل م ه ت غ ل ب
Cisco ي ل خ ت . ف ر ت ح م مچرت م ا ه م د ق ي ي ت ل ا ة ي ف ا ر ت ح ا ل ا ة مچرت ل ا ع م ل ا ح ل ا و ه
ي ل ا م ئ ا د ع و ج ر ل ا ب ي ص و ت و ت ا مچرت ل ا ه ذ ه ة ق د ن ع ا ه ت ي ل و ئ س م Cisco
Systems (رف و ت م ط بار ل ا) ي ل ص أ ل ا ي ز ي ل ج ن ا ل ا دن تسمل ا