

Aktivieren einer Leitung auf dem Telefonadapter der Serie SPA100

Ziel

Wenn die Leitung aktiviert ist, können Sprachdienste über die Leitungen für die entsprechenden Telefonanschlüsse eingerichtet werden. In diesem Artikel wird erläutert, wie verschiedene Leitungen auf dem analogen Telefonadapter der Serie SPA100 aktiviert werden, sodass zwei Benutzer direkt miteinander kommunizieren können (z. B. General Manager an Account Manager).

Anwendbares Gerät

SPA112
SPA122

Softwareversion

1,1/0

Leitung aktivieren

Schritt 1: Melden Sie sich beim Konfigurationsprogramm für Telefonadapter an, und wählen Sie **Voice > Line1** oder **Line2** aus. Die Seite *Posten 1* wird geöffnet:

The screenshot shows the 'Line 1' configuration page. The 'Line Enable' field is highlighted with a red box. The page is divided into several sections: General, Streaming Audio Server (SAS), NAT Settings, Network Settings, and SIP Settings. Each section contains various configuration options with dropdown menus and text input fields.

Section	Field Name	Value
General	Line Enable	no
	SAS Enable	no
Streaming Audio Server (SAS)	SAS Inbound RTP Sink	
	SAS DLG Refresh Intvl	30
NAT Settings	NAT Mapping Enable	no
	NAT Keep Alive Msg	\$NOTIFY
NAT Settings	NAT Keep Alive Enable	no
	NAT Keep Alive Dest	\$PROXY
Network Settings	SIP ToS/DiffServ Value	0x68
	RTP ToS/DiffServ Value	0xb8
Network Settings	Network Jitter Level	high
	SIP CoS Value	3 [0-7]
Network Settings	RTP CoS Value	6 [0-7]
	Jitter Buffer Adjustment	yes
SIP Settings	SIP Transport	UDP
	SIP Port	5060
SIP Settings	SIP 100REL Enable	no
	EXT SIP Port	
SIP Settings	Auth Resync-Reboot	yes
	SIP Proxy-Require	
SIP Settings	SIP Remote-Party-ID	yes
	SIP GUID	no
SIP Settings	SIP Debug Option	none
	RTP Log Intvl	0
SIP Settings	Restrict Source IP	no
	Referor Bye Delay	4
SIP Settings	Refer Target Bye Delay	0
	Referee Bye Delay	0

Hinweis: Die Konfigurationen für die Aktivierung von Leitung 1 gelten für Leitung 2.

The image shows a web form interface. At the top, there is a header area with the text "Line 1". Below this is a section titled "General". Inside the "General" section, there is a label "Line Enable:" followed by a dropdown menu. The dropdown menu currently displays the option "yes" with a small downward arrow to its right. This dropdown menu is highlighted with a red rectangular border. Below the "General" section, there are three buttons: "Submit", "Cancel", and "Refresh".

Schritt 2: Wählen Sie **yes (Ja)** aus der Dropdown-Liste Line Enable (Line aktivieren) aus. Dadurch können die Leitung und alle anderen Konfigurationen für diese Leitung vorgenommen werden.

Schritt 3: Klicken Sie auf **Senden**, um die Einstellungen zu speichern.