



ACL Syslog Correlation

The Access Control List (ACL) Syslog Correlation feature appends a tag (either a user-defined cookie or a device-generated MD5 hash value) to access control entry (ACE) syslog entries. This tag uniquely identifies the ACE , within the ACL, that generated the syslog entry.

- [Prerequisites for ACL Syslog Correlation, on page 1](#)
- [Information About ACL Syslog Correlation, on page 1](#)
- [How to Configure ACL Syslog Correlation, on page 2](#)
- [Configuration Examples for ACL Syslog Correlation, on page 9](#)
- [Additional References for IPv6 IOS Firewall, on page 10](#)
- [Feature Information for ACL Syslog Correlation, on page 11](#)

Prerequisites for ACL Syslog Correlation

Before you configure the ACL Syslog Correlation feature, you must understand the concepts in the "IP Access List Overview" module.

The ACL Syslog Correlation feature appends a user-defined cookie or a device-generated hash value to ACE messages in the syslog. These values are only appended to ACE messages when the log option is enabled for the ACE.

Information About ACL Syslog Correlation

ACL Syslog Correlation Tags

The ACL Syslog Correlation feature appends a tag (either a user-defined cookie or a device-generated MD5 hash value) to access control entry (ACE) syslog entries. This tag uniquely identifies an ACE that generated the syslog entry.

Network management software can use the tag to identify which ACE generated a specific syslog event. For example, network administrators can select an ACE rule in the network management application and can then view the corresponding syslog events for that ACE rule.

To append a tag to the syslog message, the ACE that generates the syslog event must have the log option enabled. The system appends only one type of tag (either a user-defined cookie or a device-generated MD5 hash value) to each message.

To specify a user-defined cookie tag, the user must enter the cookie value when configuring the ACE log option. The cookie must be in alpha-numeric form, it cannot be greater than 64 characters, and it cannot start with hex-decimal notation (such as 0x).

To specify a device-generated MD5 hash value tag, the hash-generation mechanism must be enabled on the device and the user must not enter a cookie value while configuring the ACE log option.

ACE Syslog Messages

When a packet is matched against an access control entry (ACE) in an ACL, the system checks whether the log option is enabled for that event. If the log option is enabled and the ACL Syslog Correlation feature is configured on the device, the system attaches the tag to the syslog message. The tag is displayed at the end of the syslog message, in addition to the standard information.

The following is a sample syslog message showing a user-defined cookie tag:

```
Jun 5 12:55:44.359: %SEC-6-IPACCESSLOGP: list logacl permitted tcp 192.168.16.1(38402) -> 192.168.16.2(23), 1 packet [User_permitted_ACE]
```

The following is a sample syslog message showing a hash value tag:

```
Jun 5 12:55:44.359: %SEC-6-IPACCESSLOGP: list logacl permitted tcp 192.168.16.1(38402) -> 192.168.16.2(23), 1 packet [0x723E6E12]
```

How to Configure ACL Syslog Correlation

Enabling Hash Value Generation on a Device

Perform this task to configure the device to generate an MD5 hash value for each log-enabled access control entry (ACE) in the system that is not configured with a user-defined cookie.

When the hash value generation setting is enabled, the system checks all existing ACEs and generates a hash value for each ACE that requires one. When the hash value generation setting is disabled, all previously generated hash values are removed from the system.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ip access-list logging hash-generation**
4. **end**
5. Do one of the following:
 - **show ip access-list** *access-list-number*
 - **show ip access-list** *access-list-name*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	ip access-list logging hash-generation Example: Device(config)# ip access-list logging hash-generation	Enables hash value generation on the device. <ul style="list-style-type: none"> • If an ACE exists that is log enabled, and requires a hash value, the device automatically generates the value and displays the value on the console.
Step 4	end Example: Device(config)# end	(Optional) Exits global configuration mode and returns to privileged EXEC mode.
Step 5	Do one of the following: <ul style="list-style-type: none"> • show ip access-list <i>access-list-number</i> • show ip access-list <i>access-list-name</i> Example: Device# show ip access-list 101 Example: Device# show ip access-list acl	(Optional) Displays the contents of the numbered or named IP access list. <ul style="list-style-type: none"> • Review the output to confirm that the access list for a log-enabled ACE includes the generated hash value.

Disabling Hash Value Generation on a Device

Perform this task to disable hash value generation on the device. When the hash value generation setting is disabled, all previously generated hash values are removed from the system.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **no ip access-list logging hash-generation**
4. **end**
5. Do one of the following:
 - **show ip access-list** *access-list-number*

- **show ip access-list** *access-list-name*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	no ip access-list logging hash-generation Example: Device(config)# no ip access-list logging hash-generation	Disables hash value generation on the device. <ul style="list-style-type: none"> • The system removes any previously created hash values from the system.
Step 4	end Example: Device(config)# end	(Optional) Exits global configuration mode and returns to privileged EXEC mode.
Step 5	Do one of the following: <ul style="list-style-type: none"> • show ip access-list <i>access-list-number</i> • show ip access-list <i>access-list-name</i> Example: Device# show ip access-list 101 Example: Device# show ip access-list acl	(Optional) Displays the contents of the IP access list. <ul style="list-style-type: none"> • Review the output to confirm that the access list for a log-enabled ACE does not have a generated hash value.

Configuring ACL Syslog Correlation Using a User-Defined Cookie

Perform this task to configure the ACL Syslog Correlation feature on a device for a specific access list, using a user-defined cookie as the syslog message tag.

The example in this section shows how to configure the ACL Syslog Correlation feature using a user-defined cookie for a numbered access list. However, you can configure the ACL Syslog Correlation feature using a user-defined cookie for both numbered and named access lists, and for both standard and extended access lists.



Note The following restrictions apply when choosing the user-defined cookie value:

- The maximum number of characters is 64.
- The cookie cannot start with hexadecimal notation (such as 0x).
- The cookie cannot be the same as, or a subset of, the following keywords: **reflect**, **fragment**, **time-range**. For example, reflect and ref are not valid values. However, the cookie can start with the keywords. For example, reflectedACE and fragment_33 are valid values
- The cookie must contain only alphanumeric characters.

>

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **access-list** *access-list-number* **permit** *protocol source destination* **log** *word*
4. **end**
5. **show ip access-list** *access-list-number*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	access-list <i>access-list-number</i> permit <i>protocol source destination</i> log <i>word</i> Example: Device(config)# access-list 101 permit tcp host 10.1.1.1 host 10.1.1.2 log UserDefinedValue	Defines an extended IP access list and a user-defined cookie value. <ul style="list-style-type: none"> • Enter the cookie value as the <i>word</i> argument.
Step 4	end Example: Device(config)# end	(Optional) Exits global configuration mode and returns to privileged EXEC mode.
Step 5	show ip access-list <i>access-list-number</i>	(Optional) Displays the contents of the IP access list.

	Command or Action	Purpose
	Example: Device# show ip access-list 101	<ul style="list-style-type: none"> Review the output to confirm that the access list includes the user-defined cookie value.

Examples

The following is sample output from the **show ip access-list** command for an access list with a user-defined cookie value.

```
Device# show ip access-list
101
Extended IP access list 101
30 permit tcp host 10.1.1.1 host 10.1.1.2 log (tag = UserDefinedValue)
```

Configuring ACL Syslog Correlation Using a Hash Value

Perform this task to configure the ACL Syslog Correlation feature on a device for a specific access list, using a device-generated hash value as the syslog message tag.

The steps in this section shows how to configure the ACL Syslog Correlation feature using a device-generated hash value for a numbered access list. However, you can configure the ACL Syslog Correlation feature using a device-generated hash value for both numbered and named access lists, and for both standard and extended access lists.

SUMMARY STEPS

- enable
- configure terminal
- ip access-list logging hash-generation
- access-list *access-list-number* permit *protocol source destination* log
- end
- show ip access-list *access-list-number*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	ip access-list logging hash-generation	Enables hash value generation on the device.

	Command or Action	Purpose
	<p>Example:</p> <pre>Device(config)# ip access-list logging hash-generation</pre>	<ul style="list-style-type: none"> If an ACE exists that is log enabled, and requires a hash value, the device automatically generates the value and displays the value on the console.
Step 4	<p>access-list <i>access-list-number</i> permit <i>protocol source destination</i> log</p> <p>Example:</p> <pre>Device(config)# access-list 102 permit tcp host 10.1.1.1 host 10.1.1.2 log</pre>	<p>Defines an extended IP access list.</p> <ul style="list-style-type: none"> Enable the log option for the access list, but do not specify a cookie value. The device automatically generates a hash value for the newly defined access list.
Step 5	<p>end</p> <p>Example:</p> <pre>Device(config)# end</pre>	<p>(Optional) Exits global configuration mode and returns to privileged EXEC mode.</p>
Step 6	<p>show ip access-list <i>access-list-number</i></p> <p>Example:</p> <pre>Device# show ip access-list 102</pre>	<p>(Optional) Displays the contents of the IP access list.</p> <ul style="list-style-type: none"> Review the output to confirm that the access list includes the router-generated hash value.

Examples

The following is sample output from the **show ip access-list** command for an access list with a device-generated hash value.

```
Device# show ip access-list
102
Extended IP access list 102
10 permit tcp host 10.1.1.1 host 10.1.1.2 log (hash = 0x7F9CF6B9)
```

Changing the ACL Syslog Correlation Tag Value

Perform this task to change the value of the user-defined cookie or replace a device-generated hash value with a user-defined cookie.

The steps in this section shows how to change the ACL Syslog Correlation tag value on a numbered access list. However, you can change the ACL Syslog Correlation tag value for both numbered and named access lists, and for both standard and extended access lists.

SUMMARY STEPS

- enable**
- show access-list
- configure terminal**
- access-list *access-list-number* **permit** *protocol source destination* **log** *word*

5. **end**
6. **show ip access-list** *access-list-number*

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	show access-list Example: Device(config)# show access-list	(Optional) Displays the contents of the access list.
Step 3	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 4	access-list <i>access-list-number</i> permit <i>protocol source destination log word</i> Example: Device(config)# access-list 101 permit tcp host 10.1.1.1 host 10.1.1.2 log NewUDV Example: OR Example: Example: Device(config)# access-list 101 permit tcp any any log replacehash	Modifies the cookie or changes the hash value to a cookie. <ul style="list-style-type: none"> • You must enter the entire access list configuration command, replacing the previous tag value with the new tag value.
Step 5	end Example: Device(config)# end	(Optional) Exits global configuration mode and returns to privileged EXEC mode.
Step 6	show ip access-list <i>access-list-number</i> Example: Device# show ip access-list 101	(Optional) Displays the contents of the IP access list. <ul style="list-style-type: none"> • Review the output to confirm the changes.

Troubleshooting Tips

Use the **debug ip access-list hash-generation** command to display access list debug information. The following is an example of the **debug** command output:

```
Device# debug ip access-list hash-generation
Syslog hash code generation debugging is on
Device# show debug
IP ACL:
Syslog hash code generation debugging is on
Device# no debug ip access-list hash-generation

Syslog hash code generation debugging is off
Device# show debug
Device#
```

Configuration Examples for ACL Syslog Correlation

Example: Configuring ACL Syslog Correlation Using a User-Defined Cookie

The following example shows how to configure the ACL Syslog Correlation feature on a device using a user-defined cookie.

```
Device#
Device# debug ip access-list hash-generation
Syslog MD5 hash code generation debugging is on
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# access-list 33 permit 10.10.10.6 log cook_33_std
Device(config)# do show ip access 33
Standard IP access list 33
10 permit 10.10.10.6 log (tag = cook_33_std)
Device(config)# end
```

Example: Configuring ACL Syslog Correlation using a Hash Value

The following examples shows how to configure the ACL Syslog Correlation feature on a device using a device-generated hash value.

```
Device# debug ip access-list hash-generation
Syslog MD5 hash code generation debugging is on
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# access-list 33 permit 10.10.10.7 log
Device(config)#
*Nov 7 13:51:23.615: %IPACL-HASHGEN: Hash Input: 33 standard permit 10.10.10.7
Hash Output: 0xCE87F535
Device(config)#
do show ip access 33

Standard IP access list 33
 10 permit 10.10.10.6 log (tag = cook_33_std)
 20 permit 10.10.10.7 log (hash = 0xCE87F535)
```

Example: Changing the ACL Syslog Correlation Tag Value

The following example shows how to replace an existing access list user-defined cookie with a new cookie value, and how to replace a device-generated hash value with a user-defined cookie value.

```

Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# do show ip access-list 101
Extended IP access list 101
  10 permit tcp host 10.1.1.1 host 10.1.1.2 log (tag = MyCookie)
  20 permit tcp any any log (hash = 0x75F078B9)
Device(config)# access-list 101 permit tcp host 10.1.1.1 host 10.1.1.2 log NewUDV
Device(config)# do show access-list
Extended IP access list 101
  10 permit tcp host 10.1.1.1 host 10.1.1.2 log (tag = NewUDV)
  20 permit tcp any any log (hash = 0x75F078B9)
Device(config)# access-list 101 permit tcp any any log replacehash
Device(config)# do show access-list
Extended IP access list 101
  10 permit tcp host 10.1.1.1 host 10.1.1.2 log (tag = NewUDV)
  20 permit tcp any any log (tag = replacehash)

```

Additional References for IPv6 IOS Firewall

Related Documents

Related Topic	Document Title
Security commands	<ul style="list-style-type: none"> • Cisco IOS Security Command Reference: Commands A to C • Cisco IOS Security Command Reference: Commands D to L • Cisco IOS Security Command Reference: Commands M to R • Cisco IOS Security Command Reference: Commands S to Z
IPv6 commands	Cisco IOS IPv6 Command Reference
IPv6 addressing and connectivity	IPv6 Configuration Guide
Cisco IOS IPv6 features	Cisco IOS IPv6 Feature Mapping

Standards and RFCs

Standard/RFC	Title
RFCs for IPv6	IPv6 RFCs

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

Feature Information for ACL Syslog Correlation

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1: Feature Information for ACL Syslog Correlation

Feature Name	Releases	Feature Information
ACL Syslog Correlation	Cisco IOS XE Release 3.6S	The ACL Syslog Correlation feature appends a tag (either a user-defined cookie or a router-generated MD5 hash value) to ACE syslog entries. This tag uniquely identifies the ACE, within the ACL, that generated the syslog entry.

