



Setup and Upgrade Commands

This section serves as a reference to view the list of commands related to setting up and upgrading the router. Use this section to understand the command syntaxes, default values and sample command usage with output.

- [Action Commands, on page 1](#)
- [Show Commands, on page 1](#)

Action Commands

- [clear configuration inconsistency](#)
- [install apply](#)
- [install commit](#)
- [install package](#)
- [install source](#)
- [install rollback](#)
- [install replace](#)
- [reload](#)
- [reload bootmedia](#)

Show Commands

- [show version](#)
- [show platform](#)
- [show install](#)
- [show install active](#)
- [show install committed](#)
- [show install inactive](#)

Show Commands

- [show install package](#)
- [show fpd package](#)
- [show hw-module fpd](#)
- [show interfaces \(frame relay\)](#)
- [show inventory \(Cisco IOS XR 64-bit\)](#)
- [show ipv4 interface](#)
- [show ipv6 interface](#)
- [show install boot-options](#)
- [show running-config](#)
- [show redundancy](#)
- [show media](#)