

12V DC Output for 3rd Party Device

• Enabling 12V DC Output, on page 1

Enabling 12V DC Output

The 12V DC output for 3rd party devices provides 1 Amp of power at 12V with current limiting at 1.5A and fuse protection at 5A. Output is 12V +/- 10%.



Note

PoE and 12V configuration are mutually exclusive.

To enable 12v-output, enter the following command in global configuration mode:

Router(config) #platform 12v-output enable

To disable 12v-output, enter the following command in global configuration mode:

Router(config) #no platform 12v-output enable

Enabling 12V DC Output