
Symbols

\$ matches the end of a string **1-7**
 () in commands **1-10**
 * matches 0 or more sequences of a pattern **1-7**
 + matches 1 or more sequences of a pattern **1-7**
 . matches any single character **1-7**
 ? command **1-1**
 ? matches 0 or 1 occurrence of a pattern **1-7**
 ^ matches the beginning of a string **1-7**
 _ matches a comma (,), left brace ({), left parenthesis **1-7**
 “ **1-10**

Numerics

802.1Q trunk ports and native VLANs **2-501**
 802.1Q tunnel ports
 configuring **2-462**
 802.1s Multiple Spanning Tree
 see MST
 802.1x Port Based Authentication
 allowing multiple hosts on a port **2-85**
 debugging 802.1x Port Based Authentication **2-48**
 displaying port based authentication **2-255**
 enabling accounting for authentication sessions **2-3**
 enabling authentication on the system **2-90**
 enabling guest VLAN **2-81**
 enabling manual control of auth state **2-86**
 enabling periodic re-authentication of the client **2-89**
 initializing re-authentication of dot1x ports **2-88**
 initializing state machines **2-82**
 receive session termination message upon reboot **2-4**
 setting maximum number for EAP requests **2-84**

A

abbreviating commands
 context-sensitive help **1-1**
 Access Gateway Module
 connecting to a module **2-9**
 connecting to a remote module **2-230**
 connecting to a specific remote module **2-236**
 access-group
 displaying mac interface **2-335**
 show mode interface **2-239**
 access groups
 IP **2-5**
 access lists
 clearing an access template **2-25**
 defining ARP **2-8**
 displaying ARP information **2-240**
 See also ACLs, MAC ACLs, and VACLs
 access maps
 applying with VLAN filter **2-502**
 ACLs
 access-group mode **2-5**
 displaying mac access-group interface **2-335**
 using ACL naming conventions for MAC ACLs **2-163**
 action clause
 specifying drop or forward action in a VACL **2-6**
 adjacency
 debugging the adjacency table **2-42**
 disabling the debug facility **2-42**
 displaying IPC table entries **2-42**
 aggregate policer
 displaying information **2-368**

- aging time
 displaying MAC address aging time **2-338**
 MAC address table **2-166**
- alarms
 displaying operational status **2-258**
- alternation
 description **1-9**
- anchoring
 description **1-10**
- ARP
 access list, displaying detailed information **2-240**
 defining access-lists **2-8**
- ARP inspection
 enforce certain types of checking **2-118**
- ARP packet
 deny based on DHCP bindings **2-78**
 permit based on DHCP bindings **2-190**
- authentication
 setting username **2-492**
 using an MD5-type encryption method **2-492**
 verifying MD5 signature **2-493**
 verifying the checksum for Flash memory **2-493**
- authorization state
 enabling manual control **2-86**
- authorization state of a controlled port **2-86**
- auto-QoS
 configuring for VoIP **2-10**
 displaying configuration **2-241**
-
- B**
- baby giants
 displaying the system MTU setting **2-393**
 setting the maximum Layer 2 payload size **2-477**
- BackboneFast
 displaying debugging messages **2-67**
 displaying spanning tree status **2-384**
 enabling debugging **2-67**
- bindings
 store for DHCP snooping **2-126**
- BOOT environment variable
 displaying information **2-245**
- bootflash
 displaying information **2-243**
- BPDUs
 debugging spanning tree activities **2-66**
- bridge protocol data units
 See BPDUs
- broadcast suppression level
 configuring **2-454, 2-456**
 enabling **2-454, 2-456**
-
- C**
- Catalyst 4507R **2-200**
 power redundancy mode **2-202**
- CDP
 configuring tunneling encapsulation rate **2-160**
 enabling protocol tunneling for **2-157**
 set drop threshold for **2-159**
- CEF
 displaying next-hop information **2-299**
 displaying VLAN configuration information **2-299**
- cisco-desktop
 macro apply **2-172**
- Cisco Express Forwarding
 See CEF
- cisco-phone
 macro apply **2-174**
- cisco-router
 macro apply **2-176**
- cisco-switch
 macro apply **2-178**
- clear commands
 clearing Gigabit Ethernet interfaces **2-23**
 clearing IGMP group cache entries **2-30**
 clearing interface counters **2-20**

- clearing IP access lists **2-25, 2-26**
 clearing IP ARP inspection statistics VLAN **2-27**
 clearing IP DHCP snooping database **2-28**
 clearing IP DHCP snooping database statistics **2-29**
 clearing MFIB counters and routes **2-33**
 clearing MFIB fastdrop entries **2-34**
 clearing PAgP channel information **2-37**
 clearing QoS aggregate counters **2-39**
 clearing VLAN interfaces **2-24**
- CLI string search
 anchoring **1-10**
 expressions **1-7**
 filtering **1-6**
 multiple-character patterns **1-8**
 multipliers **1-9**
 parentheses for recall **1-10**
 searching outputs **1-6**
 single-character patterns **1-7**
 using **1-6**
- command modes
 accessing privileged EXEC mode **1-4**
 exiting **1-4**
 understanding user EXEC and configuration modes **1-4**
- condition interface
 debugging interface-related activities **2-44**
- condition vlan
 debugging VLAN output **2-47**
- configuration, saving **1-11**
- configuring
 root as secondary **2-437**
- configuring a SPAN session to monitor
 limit SPAN source traffic **2-182**
- configuring forward delay **2-433**
- configuring root as primary **2-437**
- CoS
 assigning to Layer 2 protocol packets **2-158**
- CoS QoS default
 defining value on an interface **2-215**
- Cost of Service
 See QoS CoS
- counters
 clearing interface counters **2-20**
-
- D**
- DAI
 clear statistics **2-27**
- DBL
 displaying qos dbl **2-369**
 enabling DBL globally on the switch **2-216**
- debug commands
 debugging backup events **2-43**
 debugging DHCP snooping events **2-53**
 debugging DHCP snooping messages **2-54**
 debugging EtherChannel/PAgP/shim **2-49**
 debugging IPC activity **2-52**
 debugging IP DHCP snooping security messages **2-55**
 debugging NVRAM activities **2-58**
 debugging PAgP activities **2-59**
 debugging port manager activities **2-62**
 debugging software MAC filter updates **2-65**
 debugging spanning tree activities **2-66**
 debugging spanning tree backbonefast **2-67**
 debugging spanning tree UplinkFast **2-70**
 debugging supervisor redundancy **2-64**
 debugging VLAN manager activities **2-71**
 displaying monitor activity **2-57**
 displaying the adjacency table **2-42**
 enabling debug dot1x **2-48**
 enabling debugging messages for ISL VLAN IDs **2-73**
 enabling debugging messages for VTP **2-74**
 enabling debugging of UDLD activity **2-75**
 enabling switch shim debugging **2-68**
 enabling VLAN manager file system error tests **2-72**
 limiting debugging output for VLANs **2-47**
 limiting interface debugging output **2-44**

- limiting output for debugging standby state changes **2-45**
- shortcut to the debug condition interface **2-51**
- debugging
 - activity monitoring **2-57**
 - DHCP snooping events **2-53**
 - DHCP snooping packets **2-54**
 - IPC activities **2-52**
 - IP DHCP snooping security packets **2-55**
 - NVRAM activities **2-58**
 - PAgP activities **2-59**
 - PAgP shim **2-49**
 - PM activities **2-62**
 - SMF address insertions and deletions **2-65**
 - spanning tree BackboneFast events **2-67**
 - spanning tree switch shim **2-68**
 - spanning tree UplinkFast events **2-70**
 - VLAN manager activities **2-71**
 - VLAN manager IOS file system error tests **2-72**
 - VTP protocol debug messages **2-74**
 - debug spanning tree switch **2-68**
 - debug sw-vlan vtp **2-74**
 - default CoS value **2-215**
 - default form of a command, using **1-6**
 - defining egress DSCP-to-CoS mapping **2-220**
 - DHCP
 - clearing database statistics **2-29**
 - DHCP bindings
 - configuring bindings **2-125**
 - deny ARP packet based on matches **2-78**
 - permit ARP packet based on matches **2-190**
 - DHCP snooping
 - clearing database **2-28**
 - displaying **2-300**
 - displaying binding table **2-301**
 - displaying status of DHCP database **2-304**
 - displaying status of error detection **2-261**
 - enabling DHCP globally **2-124**
 - enabling IP source guard **2-155**
 - enabling on a VLAN **2-131**
 - enabling option 82 **2-128**
 - enabling rate limiting on an interface **2-129**
 - enabling trust on an interface **2-130**
 - establishing binding configuration **2-125**
 - renew binding database **2-232**
 - store generated bindings **2-126**
 - diagnostic test
 - display module-based results **2-247**
 - displaying error disable recovery **2-262**
 - displaying inline power status **2-363**
 - displaying monitoring activity **2-57**
 - displaying EEPROM information GBIC **2-269**
 - displaying SPAN session information **2-392, 2-455**
 - document conventions **xvi**
 - document organization **xv**
 - DOS attack
 - protecting system's resources **2-113**
 - drop threshold, Layer 2 protocol tunneling **2-159**
 - DSCP rewrite for IP packets
 - enable **2-223**
 - duplex mode
 - configuring autonegotiation on an interface **2-93**
 - configuring full duplex on an interface **2-93**
 - configuring half duplex on an interface **2-93**
 - dynamic ARP inspection
 - preventing **2-113**
 - Dynamic Buffer Limiting
 - See DBL
 - Dynamic Host Configuration Protocol
 - See DHCP

E

 - EAP
 - restarting authentication process **2-84**
 - enabling
 - debugging for UDLD **2-75**

-
- voice VLANs [2-457](#)
- environmental
- alarms [2-258](#)
 - displaying information [2-258](#)
 - status [2-258](#)
 - temperature [2-258](#)
- error disable detection
- enabling error disable detection [2-95](#)
- error-disabled state
- displaying [2-285](#)
- error disable recovery
- configuring recovery mechanism variables [2-97](#)
 - displaying recovery timer information [2-262](#)
 - enabling ARP inspection timeout [2-97](#)
 - specifying recovery cause [2-97](#)
- EtherChannel
- assigning interfaces to EtherChannel groups [2-14](#)
 - debugging EtherChannel [2-49](#)
 - debugging PAgP shim [2-49](#)
 - debugging spanning tree activities [2-66](#)
 - displaying information for a channel [2-263](#)
 - removing interfaces from EtherChannel groups [2-14](#)
- EtherChannel guard
- detecting STP misconfiguration [2-424](#)
- Explicit Host Tracking
- clearing the database [2-32](#)
 - displaying host membership [2-312](#)
 - enabling per-VLAN [2-142](#)
- expressions
- matching multiple expression occurrences [1-9](#)
 - multiple-character patterns [1-8](#)
 - multiplying pattern occurrence [1-10](#)
 - single-character patterns [1-7](#)
- Extensible Authentication Protocol
- See EAP
-
- F**
- field replaceable unit (FRU)
- displaying status information [2-258](#)
- Flash memory file system
- displaying file system information [2-243](#)
 - verifying checksum [2-493](#)
- flow control
- configuring a gigabit interface for pause frames [2-100](#)
 - displaying per-interface statistics for flow control [2-267](#)
-
- G**
- GBIC
- displaying SEEPROM information [2-269](#)
- Gigabit Ethernet interface
- clearing the hardware logic [2-23](#)
- global configuration mode
- using [1-5](#)
-
- H**
- hardware module
- resetting a module by toggling the power [2-103](#)
- host membership on an interface
- displaying information [2-312](#)
- hot standby protocol
- debugging [2-45](#)
 - disabling debugging [2-45](#)
 - limiting output [2-45](#)
-
- I**
- IDPROMs
- displaying SEEPROM information
 - chassis [2-269](#)
 - clock module [2-269](#)
 - fan trays [2-269](#)

- module **2-269**
- mux buffer **2-269**
- power supplies **2-269**
- supervisor engine **2-269**
- ifIndex persistence
 - clearing SNMP ifIndex commands **2-413**
 - compress SNMP ifIndex table format **2-418**
 - disabling globally **2-417**
 - disabling on an interface **2-414**
 - enabling globally **2-417**
 - enabling on an interface **2-414**
- IGMP
 - applying filters for host joining on Layer 2 interfaces **2-133**
 - clearing IGMP group cache entries **2-30**
 - configuring frequency for IGMP host-query messages **2-136**
 - creating an IGMP profile **2-135**
 - displaying IGMP interface configuration information **2-306**
 - displaying profiles **2-307**
 - setting maximum group numbers **2-134**
- IGMP profiles
 - displaying **2-307**
- IGMP snooping
 - clearing the EHT database **2-32**
 - configuring a Layer 2 interface as a group member **2-146**
 - configuring a Layer 2 interface as a multicast router **2-144**
 - configuring a static VLAN interface **2-146**
 - displaying host membership **2-312**
 - displaying multicast information **2-314**
 - displaying VLAN information **2-308, 2-315**
 - enabling **2-137**
 - enabling immediate-leave processing **2-143**
 - enabling on a VLAN **2-141**
 - enabling per-VLAN Explicit Host Tracking **2-142**
- informs
 - enabling **2-415**
- inline power
 - displaying inline power status **2-363**
- inspection log
 - clearing log buffer **2-26**
- interface
 - displaying suppressed multicast bytes **2-279**
- interface capabilities
 - displaying **2-276**
- interface configuration mode
 - summary **1-5**
- interface link
 - display cable disconnect time **2-282**
- interfaces
 - configuring dot1q tunnel ports **2-462**
 - creating an interface-range macro **2-77**
 - debugging output of interface related activities **2-44**
 - displaying description **2-281**
 - displaying error-disabled state **2-285**
 - displaying information when tunneling is enabled **2-329**
 - displaying status **2-281**
 - displaying traffic for a specific interface **2-274**
 - executing a command on multiple ports in a range **2-108**
 - setting a CoS value for Layer 2 packets **2-158**
 - setting drop threshold for Layer 2 packets **2-159**
 - setting the interface type **2-462**
- interface speed
 - configuring interface speed **2-451**
- interface transceiver
 - displaying diagnostic data **2-288**
- internal VLAN allocation
 - configuring **2-503**
 - default setting **2-503**
 - displaying allocation information **2-403**
- Internet Group Management Protocol
 - See IGMP
- IP ARP
 - applying ARP ACL to VLAN **2-111**
 - clearing inspection statistics **2-27**
 - clearing status of log buffer **2-26**

- controlling packet logging **2-121**
 - enabling dynamic inspection **2-120**
 - limit rate of incoming requests **2-113**
 - set per-port config trust state **2-117**
 - showing status of dynamic ARP inspection **2-295**
 - showing status of log buffer **2-298**
 - IPC**
 - debugging IPC activities **2-52**
 - IP DHCP Snooping**
 - See DHCP snooping
 - IP header validation**
 - disabling **2-154**
 - enabling **2-154**
 - IP multicast**
 - displaying multicast routing table information **2-319**
 - IP packets**
 - enable DSCP rewrite **2-223**
 - IP phone and standard desktop**
 - enabling Cisco-recommended features **2-174**
 - IP source binding**
 - adding or deleting **2-151**
 - displaying bindingtagging **2-324**
 - IP source guard**
 - debugging messages **2-55**
 - displaying configuration and filters **2-325**
 - enabling on DHCP snooping **2-155**

 - J**
 - Jumbo frames
 - enabling jumbo frames **2-186**

 - L**
 - l2protocol-tunnel cos command **2-158**
 - LACP**
 - deselecting channeling protocol **2-16**
 - enabling LACP on an interface **2-16**
 - setting channeling protocol **2-16**
 - Layer 2**
 - displaying ACL configuration **2-335**
 - Layer 2 interface type**
 - specifying a nontrunking, nontagged single VLAN interface **2-462**
 - specifying a trunking VLAN interface **2-462**
 - Layer 2 protocol ports**
 - displaying **2-329**
 - Layer 2 protocol tunneling error recovery** **2-160**
 - Layer 2 switching**
 - enabling voice VLANs **2-457**
 - modifying switching characteristics **2-457**
 - Layer 2 traceroute**
 - IP addresses **2-481**
 - Layer 3 switching**
 - displaying port status **2-286**
 - displaying status of native VLAN tagging **2-286**
 - log buffer**
 - show status **2-298**
 - logging**
 - ip arp inspection vlan command **2-121**
-

M**MAC Access Control Lists**

See MAC ACLs

MAC ACLs

- defining extended MAC access list **2-163**
- displaying MAC ACL information **2-400**
- naming an ACL **2-163**

MAC address filtering

- configuring **2-170**
- disabling **2-170**
- enabling **2-170**

MAC address table

- adding static entries **2-180**
- clearing dynamic entries **2-36**
- configuring aging time **2-166**

- displaying dynamic table entry information [2-340](#)
- displaying entry count [2-339](#)
- displaying information [2-336](#)
- displaying interface-based information [2-342](#)
- displaying multicast information [2-344](#)
- displaying protocol-based information [2-346](#)
- displaying static table entry information [2-348](#)
- displaying the MAC address aging time [2-338](#)
- displaying VLAN-based information [2-350](#)
- learning in the protocol buckets [2-167](#)
- removing static entries [2-180](#)
- MAC address tables
 - adding static entries [2-170](#)
 - deleting secure or specific addresses [2-38](#)
 - disabling IGMP snooping on static MAC addresses [2-170](#)
 - removing static entries [2-170](#)
- mac-address-table static [2-170](#)
- MAC address unicast filtering
 - dropping unicast traffic [2-170](#)
- macro keywords
 - help strings [2-2](#)
- mapping secondary VLANs to MST instance [2-207](#)
- mapping VLAN(s) to an MST instance [2-104](#)
- match subcommand
 - accessing [2-18](#)
- maximum transmission unit (MTU)
 - displaying the system MTU setting [2-393](#)
 - setting the maximum Layer 2 payload size [2-477](#)
- MD5
 - verifying MD5 signature [2-493](#)
- message digest 5
 - See MD5
- MFIB
 - clearing ip mfib counters [2-33](#)
 - clearing ip mfib fastdrop [2-34](#)
 - displaying all active MFIB routes [2-316](#)
 - displaying MFIB fastdrop table entries [2-318](#)
 - enabling IP MFIB fastdrops [2-148](#)
- modes
 - access-group [2-5](#)
 - show access-group interface [2-239](#)
 - switching between PVST+, MST, and Rapid PVST [2-429](#)
 - See also command modes
- module password clearing [2-22](#)
- module reset
 - resetting a module by toggling the power [2-103](#)
- More-- prompt
 - filter [1-6](#)
 - search [1-7](#)
- MST
 - designating the primary and secondary root [2-437](#)
 - displaying MST protocol information [2-389](#)
 - displaying region configuration information [2-389](#)
 - displaying spanning tree information [2-389](#)
 - entering MST configuration submode [2-431](#)
 - setting configuration revision number [2-234](#)
 - setting path cost and port priority for instances [2-430](#)
 - setting the forward delay timer for all instances [2-433](#)
 - setting the hello-time delay timer for all instances [2-434](#)
 - setting the max-age timer for all instances [2-435](#)
 - setting the MST region name [2-187](#)
 - specifying the maximum number of hops [2-436](#)
 - switching between PVST+ and Rapid PVST [2-429](#)
 - using the MST configuration submode revision command [2-234](#)
 - using the submode name command [2-187](#)
- MTU
 - displaying global MTU settings [2-393](#)
- multicast
 - enabling storm control [2-456](#)
- multicast/unicast packets
 - prevent forwarding [2-461](#)
- Multicast Forwarding Information Base
 - See MFIB
- multiple-character patterns [1-8](#)
- multiple hosts on authorized port [2-85](#)

Multiple Spanning Tree

See MST

N

native VLAN

- controlling tagging of traffic **2-473**
- displaying ports eligible for native tagging **2-402**
- displaying ports eligible for tagging **2-402**
- enabling tagging on 802.1Q trunk ports **2-501**
- specifying the tagging of traffic **2-474**

NetFlow

- enabling NetFlow statistics **2-149**
- including infer fields in routing statistics **2-149**

next-hop

- displaying CEF VLAN information **2-299**

no form of a command, using **1-6**

NVRAM

- debugging NVRAM activities **2-58**
-

O

output

- pattern searches **1-7**
-

P

packet forwarding

- prevent unknown packets **2-461**

packet memory failure

- direct switch action upon detection **2-80**

packet memory test

- bootup, displaying results **2-251**
- ongoing, displaying results **2-253**

PACL

- access-group mode **2-5**

paging prompt

- see --More-- prompt

PAgP

- clearing port channel information **2-37**
- debugging PAgP activity **2-59**
- deselecting channeling protocol **2-16**
- displaying port channel information **2-356**
- hot standby mode
 - returning to defaults **2-189**
 - selecting ports **2-189**
- input interface of incoming packets
 - learning **2-188**
 - returning to defaults **2-188**
- setting channeling protocol **2-16**

parentheses **1-10**

password

- clearing on an intelligent line module **2-22**
- establishing enhanced password security **2-492**
- setting username **2-492**

PBR

- displaying route maps **xvi**
- redistributing route maps **xvi**

PM activities

- debugging **2-62**
- disabling debugging **2-62**

Policy Based Routing

See PBR

Port Aggregation Protocol

See PAgP

port-based authentication

- displaying debug messages **2-48**
- displaying statistics and status **2-255**
- enabling 802.1X **2-86**
- manual control of authorization state **2-86**
- multiple hosts on authorized port **2-85**
- periodic re-authentication
 - enabling **2-89**

re-authenticating 802.1X-enabled ports **2-88**

switch-to-client frame-retransmission number **2-84**

port channel

- accessing **2-107**

- creating **2-107**
 - displaying information **2-356**
 - load distribution method
 - resetting to defaults **2-194**
 - setting **2-194**
 - port range
 - executing **2-108**
 - port security
 - debugging ports security **2-63**
 - deleting secure or specific addresses **2-38**
 - enabling **2-464**
 - filter source IP and MAC addresses **2-155**
 - setting action upon security violation **2-464**
 - setting the rate limit for bad packets **2-464**
 - sticky port **2-464**
 - Port Trust Device
 - displaying **2-370**
 - power status
 - displaying inline power **2-363**
 - displaying power status **2-363**
 - power supply
 - configuring combined and redundant power on the Catalyst 4507R **2-200**
 - configuring inline power **2-197**
 - configuring power consumption **2-199**
 - configuring power redundancy on the Catalyst 4507R **2-202**
 - displaying the EEPROM **2-269**
 - setting inline power state **2-196**
 - Private VLAN
 - See PVLANS
 - privileged EXEC mode, summary **1-5**
 - prompts
 - system **1-5**
 - protocol tunneling
 - configuring encapsulation rate **2-160**
 - disabling **2-157**
 - displaying port information **2-329**
 - enabling **2-157**
 - setting a CoS value for Layer 2 packets **2-158**
 - setting a drop threshold for Layer 2 packets **2-159**
 - PVLANS
 - configuring isolated and primary PVLANS **2-203**
 - controlling tagging of native VLAN traffic **2-473**
 - disabling sticky-ARP **2-152**
 - displaying map information for VLAN SVIs **2-284**
 - displaying PVLAN information **2-405**
 - enabling interface configuration mode **2-462**
 - enabling sticky-ARP **2-152**
 - mapping VLANs to the same SVI **2-205**
 - specifying host ports **2-462**
 - specifying promiscuous ports **2-462**
 - PVST+
 - switching between PVST and MST **2-429**
-
- Q**
 - QoS
 - account Layer 2 encapsulation **2-210**
 - attaching a policy-map to an interface **2-235**
 - automatic configuration **2-10**
 - clearing aggregate counters **2-39**
 - configuring a QoS policy map **2-192**
 - configuring auto **2-10**
 - defining a named aggregate policer **2-212**
 - defining default CoS value **2-215**
 - defining ingress CoS-to-DSCP mapping **2-219**
 - displaying aggregate policer information **2-368**
 - displaying auto configuration **2-241**
 - displaying class maps information **2-246**
 - displaying configuration information **2-241**
 - displaying configurations of policies **2-359**
 - displaying policy map information **2-358**
 - displaying QoS information **2-367**
 - displaying QoS map information **2-371**
 - enabling global configuration mode **2-208**
 - enabling per-VLAN QoS for a Layer 2 interface **2-226**
 - enabling QoS on an interface **2-209**

mapping DSCP values to transmit queues **2-220**
 mapping egress DSCP-to-CoS **2-220**
 mapping the DSCP-to-CoS value **2-220**
 setting the mapping of policed DSCP values **2-222**
 setting the trust state **2-224**
QoS CoS
 configuring for tunneled Layer 2 protocol packets **2-158**
 defining default CoS value **2-215**
qos dbl **2-216**
question command **1-1**
queueing information
 displaying **2-370**

R

Rapid PVST
 switching between PVST and MST **2-429**
re-authenticating 802.1X-enabled ports **2-88**
re-authentication
 periodic **2-89**
reboots
 restoring bindings across **2-125**
redundancy
 accessing the main CPU **2-227**
 changing from active to standby supervisor engine **2-228**
 displaying information **2-373**
 displaying redundancy facility information **2-373**
 displaying RF client list **2-373**
 displaying RF operational counters **2-373**
 displaying RF states **2-373**
 enabling automatic synchronization **2-13**
 forcing switchover to standby supervisor engine **2-228**
 synchronizing the route processor configurations **2-180**
related documentation **xv**
remote SPAN
 See RSPAN
renew commands
 ip dhcp snooping database **2-232**

resetting PVLAN trunk
 setting switchport to trunk **2-462**
ROM monitor mode
 summary **1-6**
root guard
 displaying root inconsistency status **2-384**
Route Processor Redundancy
 See redundancy
RSPAN
 converting VLAN to RSPAN VLAN **2-231**
 displaying list **2-407**

S

saving configuration changes **1-11**
secure ports, limitations **2-465**
show commands
 filtering parameters **1-7**
 searching and filtering **1-6**
show dot1x command **2-255**
show errdisable detect command **2-261**
show interfaces capabilities command **2-276**
show interfaces transceiver command **2-288**
show ip arp inspection command **2-295**
show ip arp inspection log command **2-298**
show l2protocol-tunnel command **2-329**
show platform commands **1-11**
show port security command **2-361**
show qos interface command **2-370**
show vlan remote-span **2-407**
Simple Network Management Protocol
 See SNMP
single-character patterns
 special characters **1-7**
slaveslot0
 displaying information on the standby supervisor **2-380**
slot0
 displaying information about the system **2-382**

- SMF
 - debugging address insertions and deletions [2-65](#)
- SNMP
 - debugging spanning tree activities [2-66](#)
 - ifIndex persistence
 - clearing SNMP ifIndex commands [2-413](#)
 - compress SNMP ifIndex table format [2-418](#)
 - disabling globally [2-417](#)
 - disabling on an interface [2-414](#)
 - enabling globally [2-417](#)
 - enabling on an interface [2-414](#)
 - informs
 - disabling [2-415](#)
 - enabling [2-415](#)
 - traps
 - configuring to send when storm occurs [2-454](#)
 - disabling [2-415](#)
 - enabling [2-415](#)
 - software MAC filter
 - See SMF
- SPAN
 - configuring a session to monitor [2-182](#)
- SPAN commands
 - displaying SPAN session information [2-392, 2-455](#)
- SPAN enhancements
 - displaying status [2-354](#)
- spanning-tree mode command [2-429](#)
- Spanning Tree Protocol
 - See STP
- SPAN session
 - displaying session information [2-354](#)
 - specifying encapsulation type [2-182](#)
 - turning off host learning based on ingress packets [2-182](#)
- special characters
 - anchoring, table [1-10](#)
- standard desktop
 - enabling Cisco-recommended features [2-172](#)
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [2-174](#)
- sticky-ARP
 - disabling on PVLANS [2-152](#)
 - enabling on PVLANS [2-152](#)
- sticky port
 - deleting [2-38](#)
 - enabling security [2-464](#)
- storm control
 - command [2-454, 2-456](#)
 - configuring for action when storm occurs [2-454](#)
 - disabling suppression mode [2-261](#)
 - displaying settings [2-391](#)
 - enabling [2-454](#)
 - enabling broadcast [2-454, 2-456](#)
 - enabling multicast [2-454, 2-456](#)
 - enabling suppression mode [2-261](#)
 - enabling timer to recover from error disable [2-97](#)
 - enabling unicast [2-454, 2-456](#)
 - multicast, enabling [2-456](#)
 - setting high and low levels [2-454](#)
 - setting suppression level [2-261](#)
- STP
 - configuring link type for a port [2-427](#)
 - configuring tunneling encapsulation rate [2-160](#)
 - debugging all activities [2-66](#)
 - debugging spanning tree activities [2-66](#)
 - debugging spanning tree BackboneFast events [2-67](#)
 - debugging spanning tree UplinkFast [2-70](#)
 - detecting misconfiguration [2-424](#)
 - displaying active interfaces only [2-384](#)
 - displaying BackboneFast status [2-384](#)
 - displaying bridge status and configuration [2-384](#)
 - displaying default path cost method [2-384](#)
 - displaying spanning tree debug messages [2-66](#)
 - displaying status information [2-384](#)
 - displaying status per VLAN [2-384](#)
 - displaying summary of interface information [2-384](#)
 - displaying UplinkFast status [2-384](#)
 - enabling BPDU filtering by default on all PortFast ports [2-442](#)

enabling BPDU filtering on an interface **2-420**
 enabling BPDU guard by default on all PortFast ports **2-444**
 enabling BPDU guard on an interface **2-422**
 enabling extended system ID **2-425**
 enabling loop guard as a default on all ports **2-428**
 enabling PortFast by default on all access ports **2-445**
 enabling PortFast mode **2-440**
 enabling protocol tunneling for **2-157**
 enabling root guard **2-426**
 enabling spanning tree BackboneFast **2-419**
 enabling spanning tree on a per VLAN basis **2-449**
 enabling spanning tree UplinkFast **2-447**
 setting an interface priority **2-446**
 setting drop threshold for **2-159**
 setting pathcost **2-423**
 setting the default pathcost calculation method **2-439**
 subinterface configuration mode, summary **1-6**
SVI
 creating a Layer 3 interface on a VLAN **2-110**
switchport **2-474**
 switchport block command **2-461**
 switchport interfaces
 displaying status of Layer 3 port **2-286**
 displaying status of native VLAN tagging **2-286**
 switchport mode command **2-462**
 switchport port-security aging command **2-468**
 switchport port-security command **2-464**
 switch shim
 debugging **2-68**
 disabling debugging **2-68**
 switch to router connection
 enabling Cisco-recommended features **2-176**
 switch to switch connection
 enabling Cisco-recommended features **2-178**
 switch virtual interface
 See **SVI**
sw-vlan **2-71**
 system prompts **1-5**

T

Tab key
 command completion **1-1**
tables
 characters with special meaning **1-7**
 mac access-list extended subcommands **2-163**
 match syntax description **2-19**
 multipliers **1-9**
 relationship between duplex and speed commands **2-452**
 show vlan command output fields **2-405**
 show vtp command output fields **2-410**
 special characters **1-9**
 special characters used for anchoring **1-10**
 speed command options **2-451**
TAC
 displaying information useful to TAC **2-394**
TCAM
 debugging spanning tree activities **2-66**
 temperature readings
 displaying information **2-258**
 timer information **2-262**
 traffic shaping
 enable on an interface **2-237**
 traps, enabling **2-415**
 trunk encapsulation
 setting format **2-474**
 trunk interfaces
 displaying trunk interfaces information **2-293**
 trust state
 setting **2-117**
 tunnel ports
 displaying information about Layer 2 protocol **2-329**
TX queues
 allocating bandwidth **2-484**
 returning to default values **2-484**
 setting priority to high **2-484**
 specifying burst size **2-484**

specifying traffic rate [2-484](#)

U

UDLD

- enabling by default on all fiber interfaces [2-486](#)
- enabling on an individual interface [2-488](#)
- preventing a fiber interface from being enabled [2-488](#)
- resetting all shutdown ports [2-490](#)
- setting the message timer [2-486](#)

Unidirectional Link Detection

See UDLD

- unknown multicast traffic, preventing [2-461](#)
- unknown unicast traffic, preventing [2-461](#)
- user EXEC mode, summary [1-5](#)
- username
 - setting password and privilege level [2-492](#)

V

VACLs

- access-group mode [2-5](#)
- applying VLAN access maps [2-502](#)
- displaying VLAN access map information [2-400](#)
- specifying an action in a VLAN access map [2-6](#)
- specifying the match clause for a VLAN access-map sequence [2-181](#)
- using a VLAN filter [2-502](#)

VLAN

- applying an ARP ACL [2-111](#)
- configuring [2-495](#)
- converting to RSPAN VLAN [2-231](#)
- displaying CEF information [2-299](#)
- displaying CEF next-hop information [2-299](#)
- displaying information on switch interfaces [2-308](#)
- displaying information on VLAN switch interfaces [2-315](#)
- displaying information sorted by group IP address [2-308](#)

displaying IP address and version information [2-308](#)

displaying Layer 2 VLAN information [2-397](#)

displaying statistical information [2-352](#)

displaying VLAN information [2-399](#)

enabling dynamic ARP inspection [2-120](#)

enabling Explicit Host Tracking [2-142](#)

enabling guest per-port [2-81](#)

entering VLAN configuration mode [2-499](#)

native frames

enabling tagging on all 802.1Q trunk ports [2-501](#)

pruning the list for VTP [2-474](#)

setting the list of allowed [2-474](#)

VLAN Access Control Lists

See VACLS

VLAN access map

See VACLS

VLAN database

resetting [2-233](#)

VLAN debugging

limiting output [2-47](#)

VLAN manager

debugging [2-71](#)

disabling debugging [2-71](#)

IOS file system error tests

debugging [2-72](#)

disabling debugging [2-72](#)

VLAN Query Protocol

See VQP

VLAN query protocol (VQPC)

debugging [2-76](#)

VLANs

clearing

counters [2-40](#)

clearing hardware logic [2-24](#)

configuring

internal allocation scheme [2-503](#)

displaying

internal VLAN allocation information [2-403](#)

RSPAN VLANs [2-407](#)

entering VLAN configuration mode [2-499](#)

VMPS

- configuring servers [2-507](#)
- reconfirming dynamic VLAN assignments [2-505](#)

vmps reconfirm (global configuration) command [2-504](#)

vmps reconfirm (privileged EXEC) command [2-505](#)

vmps retry command [2-506](#)

vmps server command [2-507](#)

voice VLANs

- enabling [2-457](#)

VoIP

- configuring auto-QoS [2-10](#)

VQP

- per-server retry count [2-506](#)
- reconfirming dynamic VLAN assignments [2-505](#)

VTP

- configuring the administrative domain name [2-511](#)
- configuring the device in VTP client mode [2-510](#)
- configuring the device in VTP server mode [2-514](#)
- configuring the device in VTP transparent mode [2-515](#)
- configuring tunnel encapsulation rate [2-160](#)
- creating a VTP domain password [2-512](#)
- displaying domain information [2-409](#)
- displaying statistics information [2-409](#)
- enabling protocol tunneling for [2-157](#)
- enabling pruning in the VLAN database [2-513](#)
- enabling VTP version 2 mode [2-516](#)
- modifying the VTP configuration storage file name [2-509](#)
- set drop threshold for [2-159](#)

VTP protocol code

- activating debug messages [2-74](#)
- deactivating debug messages [2-74](#)

