



Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-10](#)
- * matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- _ matches a comma (,), left brace ({}), left parenthesis [1-7](#)
- “ [1-10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [2-107](#)
 - showing the mode [2-299](#)
- 802.1Q trunk ports and native VLANs [2-541](#)
- 802.1Q tunnel ports
 - configuring [2-500](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X Port Based Authentication
 - allowing multiple hosts on a port [2-88](#)
 - debugging 802.1X Port Based Authentication [2-50](#)
 - displaying port based authentication [2-285](#)
 - enabling accounting for authentication sessions [2-3](#)
 - enabling authentication on the system [2-93](#)
 - enabling guest VLAN [2-83](#)
 - enabling guest VLAN supplicant [2-84](#)
 - enabling manual control of auth state [2-89](#)
 - enabling periodic re-authentication of the client [2-92](#)

- initializing re-authentication of dot1x ports [2-91](#)
- initializing state machines [2-85](#)
- receive session termination message upon reboot [2-4](#)
- setting maximum number for EAP requests [2-87](#)
- setting the reauthentication timer [2-94](#)

A

- abbreviating commands
 - context-sensitive help [1-1](#)
- Access Gateway Module
 - connecting to a module [2-11](#)
 - connecting to a remote module [2-250](#)
 - connecting to a specific remote module [2-258](#)
- access-group
 - displaying mac interface [2-372](#)
 - show mode interface [2-261](#)
- access groups
 - IP [2-5](#)
- access lists
 - clearing an access template [2-27](#)
 - defining ARP [2-10](#)
 - displaying ARP information [2-264](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [2-542](#)
- ACLs
 - access-group mode [2-5](#)
 - determining ACL hardware programming [2-6](#)
 - displaying mac access-group interface [2-372](#)
 - using ACL naming conventions for MAC ACLs [2-174](#)
- action clause
 - specifying drop or forward action in a VACL [2-8](#)

addresses, configuring a maximum [2-221](#)

adjacency

- debugging the adjacency table [2-44](#)
- disabling the debug facility [2-44](#)
- displaying information about the adjacency table [2-262](#)
- displaying IPC table entries [2-44](#)

aggregate policer

- displaying information [2-407](#)

aging time

- displaying MAC address aging time [2-375](#)
- MAC address table [2-177](#)

alarms

- displaying operational status [2-288](#)

alternation

- description [1-9](#)

anchoring

- description [1-10](#)

ARP

- access list, displaying detailed information [2-264](#)
- defining access-lists [2-10](#)

ARP inspection

- enforce certain types of checking [2-124](#)

ARP packet

- deny based on DHCP bindings [2-80](#)
- permit based on DHCP bindings [2-207](#)

authentication

- setting username [2-532](#)
- using an MD5-type encryption method [2-532](#)
- verifying MD5 signature [2-533](#)
- verifying the checksum for Flash memory [2-533](#)

authorization state

- enabling manual control [2-89](#)

authorization state of a controlled port [2-89](#)

automatic installation

- displaying status [2-265](#)

auto-negotiate interface speed

- example [2-491](#)

auto-QoS

- configuring for VoIP [2-12](#)

displaying configuration [2-266](#)

B

baby giants

- displaying the system MTU setting [2-431](#)
- setting the maximum Layer 2 payload size [2-517](#)

BackboneFast

- displaying debugging messages [2-69](#)
- displaying spanning tree status [2-423](#)
- enabling debugging [2-69](#)

bindings

- store for DHCP snooping [2-133](#)

BOOT environment variable

- displaying information [2-270](#)

bootflash

- displaying information [2-268](#)

BPDUs

- debugging spanning tree activities [2-68](#)

bridge protocol data units

- See BPDUs

broadcast suppression level

- configuring [2-492, 2-494](#)
- enabling [2-492, 2-494](#)

C

Catalyst 4507R [2-217](#)

- power redundancy mode [2-222](#)

CDP

- configuring tunneling encapsulation rate [2-170](#)
- displaying
 - neighbor information [2-271](#)
- enabling protocol tunneling for [2-166](#)
- set drop threshold for [2-168](#)

CEF

- displaying next-hop information [2-332](#)
- displaying VLAN configuration information [2-332](#)

- cisco-desktop
 - macro apply [2-183](#)
 - Cisco Express Forwarding
 - See CEF
 - cisco-phone
 - macro apply [2-185](#)
 - cisco-router
 - macro apply [2-187](#)
 - cisco-switch
 - macro apply [2-189](#)
 - clear commands
 - clearing Gigabit Ethernet interfaces [2-25](#)
 - clearing IGMP group cache entries [2-32](#)
 - clearing interface counters [2-22](#)
 - clearing IP access lists [2-27, 2-28](#)
 - clearing IP ARP inspection statistics VLAN [2-29](#)
 - clearing IP DHCP snooping database [2-30](#)
 - clearing IP DHCP snooping database statistics [2-31](#)
 - clearing MFIB counters and routes [2-35](#)
 - clearing MFIB fastdrop entries [2-36](#)
 - clearing PAgP channel information [2-39](#)
 - clearing QoS aggregate counters [2-41](#)
 - clearing VLAN interfaces [2-26](#)
 - CLI string search
 - anchoring [1-10](#)
 - expressions [1-7](#)
 - filtering [1-6](#)
 - multiple-character patterns [1-8](#)
 - multipliers [1-9](#)
 - parentheses for recall [1-10](#)
 - searching outputs [1-6](#)
 - single-character patterns [1-7](#)
 - using [1-6](#)
 - command modes
 - accessing privileged EXEC mode [1-4](#)
 - exiting [1-4](#)
 - understanding user EXEC and configuration modes [1-4](#)
 - condition interface
 - debugging interface-related activities [2-46](#)
 - condition vlan
 - debugging VLAN output [2-49](#)
 - configuration, saving [1-11](#)
 - configuring
 - root as secondary [2-475](#)
 - configuring a SPAN session to monitor
 - limit SPAN source traffic [2-199](#)
 - configuring forward delay [2-471](#)
 - configuring root as primary [2-475](#)
 - CoS
 - assigning to Layer 2 protocol packets [2-167](#)
 - CoS QoS default
 - defining value on an interface [2-235](#)
 - Cost of Service
 - See QoS CoS
 - counters
 - clearing interface counters [2-22](#)
-
- ## D
- DAI
 - clear statistics [2-29](#)
 - DBL
 - displaying qos dbl [2-408](#)
 - enabling DBL globally on the switch [2-236](#)
 - debug commands
 - debugging backup events [2-45](#)
 - debugging DHCP snooping events [2-55](#)
 - debugging DHCP snooping messages [2-56](#)
 - debugging EtherChannel/PAgP/shim [2-51](#)
 - debugging IPC activity [2-54](#)
 - debugging IP DHCP snooping security messages [2-57](#)
 - debugging NVRAM activities [2-60](#)
 - debugging PAgP activities [2-61](#)
 - debugging port manager activities [2-64](#)
 - debugging software MAC filter updates [2-67](#)
 - debugging spanning tree activities [2-68](#)
 - debugging spanning tree backbonefast [2-69](#)
 - debugging spanning tree UplinkFast [2-72](#)

- debugging supervisor redundancy [2-66](#)
- debugging VLAN manager activities [2-73](#)
- displaying monitor activity [2-59](#)
- displaying the adjacency table [2-44](#)
- enabling debug dot1x [2-50](#)
- enabling debugging messages for ISL VLAN IDs [2-75](#)
- enabling debugging messages for VTP [2-76](#)
- enabling debugging of UDLD activity [2-77](#)
- enabling switch shim debugging [2-70](#)
- enabling VLAN manager file system error tests [2-74](#)
- limiting debugging output for VLANs [2-49](#)
- limiting interface debugging output [2-46](#)
- limiting output for debugging standby state changes [2-47](#)
- shortcut to the debug condition interface [2-53](#)
- debugging
 - activity monitoring [2-59](#)
 - DHCP snooping events [2-55](#)
 - DHCP snooping packets [2-56](#)
 - IPC activities [2-54](#)
 - IP DHCP snooping security packets [2-57](#)
 - NVRAM activities [2-60](#)
 - PAgP activities [2-61](#)
 - PAgP shim [2-51](#)
 - PM activities [2-64](#)
 - SMF address insertions and deletions [2-67](#)
 - spanning tree BackboneFast events [2-69](#)
 - spanning tree switch shim [2-70](#)
 - spanning tree UplinkFast events [2-72](#)
 - VLAN manager activities [2-73](#)
 - VLAN manager IOS file system error tests [2-74](#)
 - VTP protocol debug messages [2-76](#)
- debug spanning tree switch [2-70](#)
- debug sw-vlan vtp [2-76](#)
- default CoS value [2-235](#)
- default form of a command, using [1-6](#)
- defining egress DSCP-to-CoS mapping [2-240](#)
- DHCP
 - clearing database statistics [2-31](#)
 - DHCP bindings
 - configuring bindings [2-132](#)
 - deny ARP packet based on matches [2-80](#)
 - permit ARP packet based on matches [2-207](#)
 - DHCP snooping
 - clearing database [2-30](#)
 - displaying binding table [2-334](#)
 - displaying configuration information [2-333](#)
 - displaying status of DHCP database [2-337](#)
 - displaying status of error detection [2-291](#)
 - enabling DHCP globally [2-131](#)
 - enabling IP source guard [2-164](#)
 - enabling on a VLAN [2-139](#)
 - enabling option 82 [2-135, 2-136](#)
 - enabling rate limiting on an interface [2-137](#)
 - enabling trust on an interface [2-138](#)
 - establishing binding configuration [2-132](#)
 - renew binding database [2-252](#)
 - store generated bindings [2-133](#)
 - diagnostic test
 - displaying attributes [2-275](#)
 - display module-based results [2-277](#)
 - displaying error disable recovery [2-292](#)
 - displaying inline power status [2-402](#)
 - displaying monitoring activity [2-59](#)
 - displaying SEEPROM information
 - GBIC [2-300](#)
 - displaying SPAN session information [2-430, 2-493](#)
 - document conventions [xvi](#)
 - document organization [xv](#)
 - DOS attack
 - protecting system's resources [2-119](#)
 - drop threshold, Layer 2 protocol tunneling [2-168](#)
 - DSCP rewrite for IP packets
 - enable [2-243](#)
 - dual-capable port
 - selecting a connector [2-196](#)
 - duplex mode
 - configuring autonegotiation on an interface [2-96](#)

- configuring full duplex on an interface [2-96](#)
- configuring half duplex on an interface [2-96](#)

- dynamic ARP inspection
 - preventing [2-119](#)

- Dynamic Buffer Limiting
 - See DBL

- Dynamic Host Configuration Protocol
 - See DHCP

E

EAP

- restarting authentication process [2-87](#)

enabling

- debugging for UDLD [2-77](#)
- voice VLANs [2-495](#)

environmental

- alarms [2-288](#)
- displaying information [2-288](#)
- status [2-288](#)
- temperature [2-288](#)

error disable detection

- enabling error disable detection [2-98](#)

error-disabled state

- displaying [2-318](#)

error disable recovery

- configuring recovery mechanism variables [2-100](#)
- displaying recovery timer information [2-292](#)
- enabling ARP inspection timeout [2-100](#)
- specifying recovery cause [2-100](#)

EtherChannel

- assigning interfaces to EtherChannel groups [2-16](#)
- debugging EtherChannel [2-51](#)
- debugging PAgP shim [2-51](#)
- debugging spanning tree activities [2-68](#)
- displaying information for a channel [2-293](#)
- removing interfaces from EtherChannel groups [2-16](#)

EtherChannel guard

- detecting STP misconfiguration [2-462](#)

Explicit Host Tracking

- clearing the database [2-34](#)
- enabling per-VLAN [2-151](#)

expressions

- matching multiple expression occurrences [1-9](#)
- multiple-character patterns [1-8](#)
- multiplying pattern occurrence [1-10](#)
- single-character patterns [1-7](#)

Extensible Authentication Protocol

- See EAP

F

field replaceable unit (FRU)

- displaying status information [2-288](#)

Flash memory file system

- displaying file system information [2-268](#)
- verifying checksum [2-533](#)

flow control

- configuring a gigabit interface for pause frames [2-103](#)
- displaying per-interface statistics for flow control [2-297](#)

G

GBIC

- displaying SEEPROM information [2-300](#)

Gigabit Ethernet interface

- clearing the hardware logic [2-25](#)

Gigabit Ethernet uplink

- selecting [2-107](#)
- showing the mode [2-299](#)

global configuration mode

- using [1-5](#)

H

hardware module

- resetting a module by toggling the power [2-106](#)

hardware uplink

- selecting the mode [2-107](#)

- showing the mode [2-299](#)

helper addresses, IP [2-351](#)

hot standby protocol

- debugging [2-47](#)

- disabling debugging [2-47](#)

- limiting output [2-47](#)

IDPROMs

displaying SEEPROM information

- chassis [2-300](#)

- clock module [2-300](#)

- fan trays [2-300](#)

- module [2-300](#)

- mux buffer [2-300](#)

- power supplies [2-300](#)

- supervisor engine [2-300](#)

ifIndex persistence

- clearing SNMP ifIndex commands [2-451](#)

- compress SNMP ifIndex table format [2-456](#)

- disabling globally [2-455](#)

- disabling on an interface [2-452](#)

- enabling globally [2-455](#)

- enabling on an interface [2-452](#)

IGMP

- applying filters for host joining on Layer 2 interfaces [2-141](#)

- clearing IGMP group cache entries [2-32](#)

- configuring frequency for IGMP host-query messages [2-144](#)

- creating an IGMP profile [2-143](#)

- displaying IGMP interface configuration information [2-339](#)

- displaying profiles [2-341](#)

- setting maximum group numbers [2-142](#)

IGMP profiles

- displaying [2-341](#)

IGMP snooping

- clearing the EHT database [2-34](#)

- configuring a Layer 2 interface as a group member [2-155](#)

- configuring a Layer 2 interface as a multicast router [2-153](#)

- configuring a static VLAN interface [2-155](#)

- displaying multicast information [2-348](#)

- displaying VLAN information [2-342, 2-346, 2-349](#)

- enabling [2-146](#)

- enabling immediate-leave processing [2-152](#)

- enabling on a VLAN [2-150](#)

- enabling per-VLAN Explicit Host Tracking [2-151](#)

informs

- enabling [2-453](#)

inline power

- displaying inline power status [2-402](#)

inspection log

- clearing log buffer [2-28](#)

interface

- displaying suppressed multicast bytes [2-312](#)

interface capabilities

- displaying [2-309](#)

interface configuration mode

- summary [1-5](#)

interface link

- display cable disconnect time [2-315](#)

interfaces

- configuring dot1q tunnel ports [2-500](#)

- creating an interface-range macro [2-79](#)

- debugging output of interface related activities [2-46](#)

- displaying description [2-314](#)

- displaying error-disabled state [2-318](#)

- displaying information when tunneling is enabled [2-366](#)

- displaying status [2-314](#)

- displaying traffic for a specific interface [2-306](#)

- entering interface configuration mode [2-111](#)

- executing a command on multiple ports in a range [2-114](#)
- selecting an interface to configure [2-111](#)
- setting a CoS value for Layer 2 packets [2-167](#)
- setting drop threshold for Layer 2 packets [2-168](#)
- setting the interface type [2-500](#)
- interface speed
 - configuring interface speed [2-489](#)
- interface transceiver
 - displaying diagnostic data [2-321](#)
- internal VLAN allocation
 - configuring [2-543](#)
 - default setting [2-543](#)
 - displaying allocation information [2-442](#)
- Internet Group Management Protocol
 - See IGMP
- IP ARP
 - applying ARP ACL to VLAN [2-117](#)
 - clearing inspection statistics [2-29](#)
 - clearing status of log buffer [2-28](#)
 - controlling packet logging [2-127](#)
 - enabling dynamic inspection [2-126](#)
 - limit rate of incoming requests [2-119](#)
 - set per-port config trust state [2-123](#)
 - showing status of dynamic ARP inspection [2-328](#)
 - showing status of log buffer [2-331](#)
- IPC
 - debugging IPC activities [2-54](#)
- IP DHCP Snooping
 - See DHCP snooping
- IP header validation
 - disabling [2-163](#)
 - enabling [2-163](#)
- IP interfaces
 - displaying usability status [2-350](#)
- IP multicast
 - displaying multicast routing table information [2-356](#)
- IP packets
 - enable DSCP rewrite [2-243](#)

- IP phone and standard desktop
 - enabling Cisco-recommended features [2-185](#)
- IP source binding
 - adding or deleting [2-160](#)
 - displaying bindingstagging [2-361](#)
- IP source guard
 - debugging messages [2-57](#)
 - displaying configuration and filters [2-362](#)
 - enabling on DHCP snooping [2-164](#)

J

- Jumbo frames
 - enabling jumbo frames [2-203](#)

L

- LACP
 - deselecting channeling protocol [2-18](#)
 - enabling LACP on an interface [2-18](#)
 - setting channeling protocol [2-18](#)
- Layer 2
 - displaying ACL configuration [2-372](#)
- Layer 2 interface type
 - specifying a nontrunking, nontagged single VLAN interface [2-500](#)
 - specifying a trunking VLAN interface [2-500](#)
- Layer 2 protocol ports
 - displaying [2-366](#)
- Layer 2 protocol tunneling error recovery [2-170](#)
- Layer 2 switching
 - enabling voice VLANs [2-495](#)
 - modifying switching characteristics [2-495](#)
- Layer 2 traceroute
 - IP addresses [2-521](#)
- Layer 3 switching
 - displaying information about an adjacency table [2-262](#)
 - displaying port status [2-319](#)
 - displaying status of native VLAN tagging [2-319](#)

log buffer

show status [2-331](#)

logging

controlling IP ARP packets [2-127](#)

M

MAC Access Control Lists

See MAC ACLs

MAC ACLs

defining extended MAC access list [2-174](#)

displaying MAC ACL information [2-439](#)

naming an ACL [2-174](#)

MAC address filtering

configuring [2-181](#)

disabling [2-181](#)

enabling [2-181](#)

MAC address table

adding static entries [2-191](#)

clearing dynamic entries [2-38](#)

configuring aging time [2-177](#)

displaying dynamic table entry information [2-377](#)

displaying entry count [2-376](#)

displaying information [2-373](#)

displaying interface-based information [2-379](#)

displaying multicast information [2-381](#)

displaying protocol-based information [2-383](#)

displaying static table entry information [2-385](#)

displaying the MAC address aging time [2-375](#)

displaying VLAN-based information [2-387](#)

learning in the protocol buckets [2-178](#)

removing static entries [2-191](#)

MAC address tables

adding static entries [2-181](#)

deleting secure or specific addresses [2-40](#)

disabling IGMP snooping on static MAC addresses [2-181](#)

removing static entries [2-181](#)

mac-address-table static [2-181](#)

MAC address unicast filtering

dropping unicast traffic [2-181](#)

macro keywords

help strings [2-2](#)

mapping secondary VLANs to MST instance [2-227](#)

mapping VLAN(s) to an MST instance [2-109](#)

match subcommand

accessing [2-20](#)

maximum transmission unit (MTU)

displaying the system MTU setting [2-431](#)

setting the maximum Layer 2 payload size [2-517](#)

MD5

verifying MD5 signature [2-533](#)

message digest 5

See MD5

MFIB

clearing ip mfib counters [2-35](#)

clearing ip mfib fastdrop [2-36](#)

displaying all active MFIB routes [2-353](#)

displaying MFIB fastdrop table entries [2-355](#)

enabling IP MFIB fastdrops [2-157](#)

modes

access-group [2-5](#)

show access-group interface [2-261](#)

switching between PVST+, MST, and Rapid PVST [2-467](#)

See also command modes

module password clearing [2-24](#)

module reset

resetting a module by toggling the power [2-106](#)

--More-- prompt

filter [1-6](#)

search [1-7](#)

MST

designating the primary and secondary root [2-475](#)

displaying MST protocol information [2-427](#)

displaying region configuration information [2-427](#)

displaying spanning tree information [2-427](#)

entering MST configuration submode [2-469](#)

- setting configuration revision number [2-254](#)
- setting path cost and port priority for instances [2-468](#)
- setting the forward delay timer for all instances [2-471](#)
- setting the hello-time delay timer for all instances [2-472](#)
- setting the max-age timer for all instances [2-473](#)
- setting the MST region name [2-204](#)
- specifying the maximum number of hops [2-474](#)
- switching between PVST+ and Rapid PVST [2-467](#)
- using the MST configuration submode revision command [2-254](#)
- using the submode name command [2-204](#)

MTU

- displaying global MTU settings [2-431](#)

multicast

- enabling storm control [2-494](#)

multicast/unicast packets

- prevent forwarding [2-499](#)

Multicast Forwarding Information Base

- See MFIB

multiple-character patterns [1-8](#)

multiple hosts on authorized port [2-88](#)

Multiple Spanning Tree

- See MST

N

native VLAN

- controlling tagging of traffic [2-513](#)
- displaying ports eligible for native tagging [2-441](#)
- displaying ports eligible for tagging [2-441](#)
- enabling tagging on 802.1Q trunk ports [2-541](#)
- specifying the tagging of traffic [2-514](#)

NetFlow

- enabling NetFlow statistics [2-158](#)
- including infer fields in routing statistics [2-158](#)

next-hop

- displaying CEF VLAN information [2-332](#)

no form of a command, using [1-6](#)

NVRAM

- debugging NVRAM activities [2-60](#)

O

output

- pattern searches [1-7](#)

P

packet forwarding

- prevent unknown packets [2-499](#)

packet memory failure

- direct switch action upon detection [2-82](#)

packet memory test

- bootup, displaying results [2-281](#)
- ongoing, displaying results [2-283](#)

PACL

- access-group mode [2-5](#)

paging prompt

- see --More-- prompt

PAgP

- clearing port channel information [2-39](#)
- debugging PAgP activity [2-61](#)
- deselecting channeling protocol [2-18](#)
- displaying port channel information [2-393](#)
- hot standby mode
 - returning to defaults [2-206](#)
 - selecting ports [2-206](#)
- input interface of incoming packets
 - learning [2-205](#)
 - returning to defaults [2-205](#)
- setting channeling protocol [2-18](#)

parentheses [1-10](#)

password

- clearing on an intelligent line module [2-24](#)
- establishing enhanced password security [2-532](#)
- setting username [2-532](#)

- PBR
 - displaying route maps [xvi](#)
 - redistributing route maps [xvi](#)
- PM activities
 - debugging [2-64](#)
 - disabling debugging [2-64](#)
- Policy Based Routing
 - See PBR
- port, dual-capable
 - selecting the connector [2-196](#)
- Port Aggregation Protocol
 - See PAgP
- port-based authentication
 - displaying debug messages [2-50](#)
 - displaying statistics and status [2-285](#)
 - enabling 802.1X [2-89](#)
 - manual control of authorization state [2-89](#)
 - multiple hosts on authorized port [2-88](#)
 - periodic re-authentication
 - enabling [2-92](#)
 - re-authenticating 802.1X-enabled ports [2-91](#)
 - switch-to-client frame-retransmission number [2-87](#)
- port channel
 - accessing [2-113](#)
 - creating [2-113](#)
 - displaying information [2-393](#)
 - load distribution method
 - resetting to defaults [2-211](#)
 - setting [2-211](#)
- port range
 - executing [2-114](#)
- port security
 - debugging ports security [2-65](#)
 - deleting secure or specific addresses [2-40](#)
 - displaying settings for an interface or switch [2-399](#)
 - enabling [2-502](#)
 - filter source IP and MAC addresses [2-164](#)
 - setting action upon security violation [2-502](#)
 - setting the rate limit for bad packets [2-502](#)
 - sticky port [2-502](#)
- Port Trust Device
 - displaying [2-409](#)
- power status
 - displaying inline power [2-402](#)
 - displaying power status [2-402](#)
- power supply
 - configuring combined and redundant power on the Catalyst 4507R [2-217](#)
 - configuring inline power [2-214](#)
 - configuring power consumption [2-216](#)
 - configuring power redundancy on the Catalyst 4507R [2-222](#)
 - displaying the SEEPROM [2-300](#)
 - setting inline power state [2-213](#)
- Private VLAN
 - See PVLANS
- privileged EXEC mode, summary [1-5](#)
- prompts
 - system [1-5](#)
- protocol tunneling
 - configuring encapsulation rate [2-170](#)
 - disabling [2-166](#)
 - displaying port information [2-366](#)
 - enabling [2-166](#)
 - setting a CoS value for Layer 2 packets [2-167](#)
 - setting a drop threshold for Layer 2 packets [2-168](#)
- PVLANS
 - configuring isolated, primary, and community PVLANS [2-223](#)
 - controlling tagging of native VLAN traffic [2-513](#)
 - disabling sticky-ARP [2-161](#)
 - displaying map information for VLAN SVIs [2-317](#)
 - displaying PVLAN information [2-444](#)
 - enabling interface configuration mode [2-500](#)
 - enabling sticky-ARP [2-161](#)
 - mapping VLANs to the same SVI [2-225](#)
 - specifying host ports [2-500](#)
 - specifying promiscuous ports [2-500](#)

PVST+

switching between PVST and MST [2-467](#)

Q

QoS

account Layer 2 encapsulation [2-230](#)
 attaching a policy-map to an interface [2-255](#)
 automatic configuration [2-12](#)
 clearing aggregate counters [2-41](#)
 configuring a QoS policy map [2-209](#)
 configuring auto [2-12](#)
 defining a named aggregate policer [2-232](#)
 defining default CoS value [2-235](#)
 defining ingress CoS-to-DSCP mapping [2-239](#)
 displaying aggregate policer information [2-407](#)
 displaying auto configuration [2-266](#)
 displaying class maps information [2-274](#)
 displaying configuration information [2-266](#)
 displaying configurations of policies [2-396](#)
 displaying policy map information [2-395, 2-398](#)
 displaying QoS information [2-406](#)
 displaying QoS map information [2-410](#)
 enabling global configuration mode [2-228](#)
 enabling per-VLAN QoS for a Layer 2 interface [2-246](#)
 enabling QoS on an interface [2-229](#)
 mapping DSCP values to transmit queues [2-240](#)
 mapping egress DSCP-to-CoS [2-240](#)
 mapping the DSCP-to-CoS value [2-240](#)
 setting the mapping of policed DSCP values [2-242](#)
 setting the trust state [2-244](#)
 specifying flow-based match criteria [2-193](#)

QoS CoS

configuring for tunneled Layer 2 protocol packets [2-167](#)
 defining default CoS value [2-235](#)

qos dbl [2-236](#)

question command [1-1](#)

queueing information

displaying [2-409](#)

R

Rapid PVST

switching between PVST and MST [2-467](#)

re-authenticating 802.1X-enabled ports [2-91](#)

re-authentication

periodic [2-92](#)

set the time [2-94](#)

reboots

restoring bindings across [2-132](#)

redundancy

accessing the main CPU [2-247](#)

changing from active to standby supervisor engine [2-248](#)

displaying information [2-412](#)

displaying redundancy facility information [2-412](#)

displaying RF client list [2-412](#)

displaying RF operational counters [2-412](#)

displaying RF states [2-412](#)

enabling automatic synchronization [2-15](#)

forcing switchover to standby supervisor engine [2-248](#)

set the mode [2-197](#)

synchronizing the route processor configurations [2-191](#)

related documentation [xv](#)

remote SPAN

See RSPAN

renew commands

ip dhcp snooping database [2-252](#)

resetting PVLAN trunk

setting switchport to trunk [2-500](#)

rj45 connector, selecting the connector [2-196](#)

ROM monitor mode

summary [1-6](#)

Route Processor Redundancy

See redundancy

RPR

set the redundancy mode [2-197](#)

RSPAN

- converting VLAN to RSPAN VLAN [2-251](#)
- displaying list [2-446](#)

S

- saving configuration changes [1-11](#)
- secure address, configuring [2-219](#)
- secure ports, limitations [2-503](#)
- set the redundancy mode [2-197](#)
- sfp connector, selecting the connector [2-196](#)
- show commands
 - filtering parameters [1-7](#)
 - searching and filtering [1-6](#)
 - show platform commands [1-11](#)
- Simple Network Management Protocol
 - See SNMP
- single-character patterns
 - special characters [1-7](#)
- slaveslot0
 - displaying information on the standby supervisor [2-419](#)
- slot0
 - displaying information about the system [2-421](#)
- SMF
 - debugging address insertions and deletions [2-67](#)
- SNMP
 - debugging spanning tree activities [2-68](#)
 - ifIndex persistence
 - clearing SNMP ifIndex commands [2-451](#)
 - compress SNMP ifIndex table format [2-456](#)
 - disabling globally [2-455](#)
 - disabling on an interface [2-452](#)
 - enabling globally [2-455](#)
 - enabling on an interface [2-452](#)
 - informs
 - disabling [2-453](#)
 - enabling [2-453](#)
 - traps
 - configuring to send when storm occurs [2-492](#)

- disabling [2-453](#)
 - enabling [2-453](#)
- software MAC filter
 - See SMF
- SPAN commands
 - configuring a SPAN session to monitor [2-199](#)
 - displaying SPAN session information [2-430, 2-493](#)
- SPAN enhancements
 - displaying status [2-391](#)
- Spanning Tree Protocol
 - See STP
- SPAN session
 - displaying session information [2-391](#)
 - filter ACLs [2-199](#)
 - specify encap type [2-199](#)
 - turn off host learning based on ingress packets [2-199](#)
- special characters
 - anchoring, table [1-10](#)
- SSO [2-197](#)
- standard desktop
 - enabling Cisco-recommended features [2-183](#)
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [2-185](#)
- sticky address, configuring [2-220](#)
- sticky-ARP
 - disabling on PVLANS [2-161](#)
 - enabling on PVLANS [2-161](#)
- sticky port
 - deleting [2-40](#)
 - enabling security [2-502](#)
- storm control
 - configuring for action when storm occurs [2-492](#)
 - disabling suppression mode [2-291](#)
 - displaying settings [2-429](#)
 - enabling [2-492](#)
 - enabling broadcast [2-492, 2-494](#)
 - enabling multicast [2-492, 2-494](#)
 - enabling suppression mode [2-291](#)
 - enabling timer to recover from error disable [2-100](#)

- enabling unicast [2-492, 2-494](#)
- multicast, enabling [2-494](#)
- setting high and low levels [2-492](#)
- setting suppression level [2-291](#)

STP

- configuring link type for a port [2-465](#)
- configuring tunneling encapsulation rate [2-170](#)
- debugging all activities [2-68](#)
- debugging spanning tree activities [2-68](#)
- debugging spanning tree BackboneFast events [2-69](#)
- debugging spanning tree UplinkFast [2-72](#)
- detecting misconfiguration [2-462](#)
- displaying active interfaces only [2-423](#)
- displaying BackboneFast status [2-423](#)
- displaying bridge status and configuration [2-423](#)
- displaying spanning tree debug messages [2-68](#)
- displaying summary of interface information [2-423](#)
- enabling BPDU filtering by default on all PortFast ports [2-480](#)
- enabling BPDU filtering on an interface [2-458](#)
- enabling BPDU guard by default on all PortFast ports [2-482](#)
- enabling BPDU guard on an interface [2-460](#)
- enabling extended system ID [2-463](#)
- enabling loop guard as a default on all ports [2-466](#)
- enabling PortFast by default on all access ports [2-483](#)
- enabling PortFast mode [2-478](#)
- enabling protocol tunneling for [2-166](#)
- enabling root guard [2-464](#)
- enabling spanning tree BackboneFast [2-457](#)
- enabling spanning tree on a per VLAN basis [2-487](#)
- enabling spanning tree UplinkFast [2-485](#)
- setting an interface priority [2-484](#)
- setting drop threshold for [2-168](#)
- setting pathcost [2-461](#)
- setting the default pathcost calculation method [2-477](#)

subinterface configuration mode, summary [1-6](#)

SVI

- creating a Layer 3 interface on a VLAN [2-116](#)

- switchport [2-514](#)
- switchport interfaces
 - displaying status of Layer 3 port [2-319](#)
 - displaying status of native VLAN tagging [2-319](#)
- switch shim
 - debugging [2-70](#)
 - disabling debugging [2-70](#)
- switch to router connection
 - enabling Cisco-recommended features [2-187](#)
- switch to switch connection
 - enabling Cisco-recommended features [2-189](#)
- switch virtual interface
 - See SVI
- sw-vlan [2-73](#)
- system prompts [1-5](#)

T

Tab key

- command completion [1-1](#)

tables

- characters with special meaning [1-7](#)
- mac access-list extended subcommands [2-174](#)
- match syntax description [2-21](#)
- multipliers [1-9](#)
- relationship between duplex and speed commands [2-490](#)
- show cdp neighbors detail field descriptions [2-273](#)
- show cdp neighbors field descriptions [2-272](#)
- show ip interface field descriptions [2-351](#)
- show vlan command output fields [2-445](#)
- show vtp command output fields [2-449](#)
- special characters [1-9](#)
- special characters used for anchoring [1-10](#)
- speed command options [2-193, 2-490](#)
- valid interface types [2-111](#)

TAC

- displaying information useful to TAC [2-432\](#)

TCAM

- debugging spanning tree activities [2-68](#)
- temperature readings
 - displaying information [2-288](#)
- timer information [2-292](#)
- traffic shaping
 - enable on an interface [2-259](#)
- traps, enabling [2-453](#)
- trunk encapsulation
 - setting format [2-514](#)
- trunk interfaces
 - displaying trunk interfaces information [2-326](#)
- trust state
 - setting [2-123](#)
- tunnel ports
 - displaying information about Layer 2 protocol [2-366](#)
- TX queues
 - allocating bandwidth [2-524](#)
 - returning to default values [2-524](#)
 - setting priority to high [2-524](#)
 - specifying burst size [2-524](#)
 - specifying traffic rate [2-524](#)

U

UDLD

- displaying administrative and operational status [2-434](#)
- enabling by default on all fiber interfaces [2-526](#)
- enabling on an individual interface [2-528](#)
- preventing a fiber interface from being enabled [2-528](#)
- resetting all shutdown ports [2-530](#)
- setting the message timer [2-526](#)
- Unidirectional Link Detection
 - See UDLD
- unknown multicast traffic, preventing [2-499](#)
- unknown unicast traffic, preventing [2-499](#)
- user EXEC mode, summary [1-5](#)
- username
 - setting password and privilege level [2-532](#)

V

VACLs

- access-group mode [2-5](#)
- applying VLAN access maps [2-542](#)
- displaying VLAN access map information [2-439](#)
- specifying an action in a VLAN access map [2-8](#)
- specifying the match clause for a VLAN access-map sequence [2-192](#)
- using a VLAN filter [2-542](#)

VLAN

- applying an ARP ACL [2-117](#)
- configuring [2-535](#)
- converting to RSPAN VLAN [2-251](#)
- displaying CEF information [2-332](#)
- displaying CEF next-hop information [2-332](#)
- displaying information on switch interfaces [2-342, 2-346](#)
- displaying information on VLAN switch interfaces [2-349](#)
- displaying information sorted by group IP address [2-342, 2-346](#)
- displaying IP address and version information [2-342, 2-346](#)
- displaying Layer 2 VLAN information [2-436](#)
- displaying statistical information [2-389](#)
- displaying VLAN information [2-438](#)
- enabling dynamic ARP inspection [2-126](#)
- enabling Explicit Host Tracking [2-151](#)
- enabling guest per-port [2-83](#)
- enabling guest VLAN supplicant [2-84](#)
- entering VLAN configuration mode [2-539](#)
- native frames
 - enabling tagging on all 802.1Q trunk ports [2-541](#)
- pruning the list for VTP [2-514](#)
- setting the list of allowed [2-514](#)

VLAN Access Control Lists

See VACLs

VLAN access map

See VACLs

- VLAN database
 - resetting [2-253](#)
- VLAN debugging
 - limiting output [2-49](#)
- VLAN manager
 - debugging [2-73](#)
 - disabling debugging [2-73](#)
 - IOS file system error tests
 - debugging [2-74](#)
 - disabling debugging [2-74](#)
- VLAN Query Protocol
 - See VQP
- VLAN query protocol (VQPC)
 - debugging [2-78](#)
- VLANs
 - clearing
 - counters [2-42](#)
 - clearing hardware logic [2-26](#)
 - configuring
 - internal allocation scheme [2-543](#)
 - displaying
 - internal VLAN allocation information [2-442](#)
 - RSPAN VLANs [2-446](#)
 - entering VLAN configuration mode [2-539](#)
- VMPS
 - configuring servers [2-547](#)
 - reconfirming dynamic VLAN assignments [2-545](#)
- voice VLANs
 - enabling [2-495](#)
- VoIP
 - configuring auto-QoS [2-12](#)
- VQP
 - per-server retry count [2-546](#)
 - reconfirming dynamic VLAN assignments [2-545](#)
- VTP
 - configuring the administrative domain name [2-551](#)
 - configuring the device in VTP client mode [2-550](#)
 - configuring the device in VTP server mode [2-554](#)
 - configuring the device in VTP transparent mode [2-555](#)
 - configuring tunnel encapsulation rate [2-170](#)
 - creating a VTP domain password [2-552](#)
 - displaying domain information [2-448](#)
 - displaying statistics information [2-448](#)
 - enabling protocol tunneling for [2-166](#)
 - enabling pruning in the VLAN database [2-553](#)
 - enabling VTP version 2 mode [2-556](#)
 - modifying the VTP configuration storage file name [2-549](#)
 - set drop threshold for [2-168](#)
- VTP protocol code
 - activating debug messages [2-76](#)
 - deactivating debug messages [2-76](#)

