

---

## Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-10](#)
- \* matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- \_ matches a comma (,), left brace ({}), left parenthesis [1-7](#)
- “ [1-10](#)

---

## Numerics

- 10-Gigabit Ethernet uplink
  - selecting [2-125](#)
  - showing the mode [2-352](#)
- 802.1Q trunk ports and native VLANs [2-638](#)
- 802.1Q tunnel ports
  - configuring [2-587](#)
- 802.1S Multiple Spanning Tree
  - see MST
- 802.1X
  - disabling port control [2-92](#)
  - enabling port control [2-92](#)
- 802.1X Critical Authentication
  - disabling on a port [2-93](#)
  - disabling on a VLAN [2-96](#)
- EAPOL
  - disabling send success packets [2-94](#)
  - enabling send success packets [2-94](#)
- enabling on a port [2-93](#)

- enabling on a VLAN [2-96](#)
- returning delay time to default setting [2-95](#)
- setting delay time on a port [2-95](#)
- 802.1X Port Based Authentication
  - allowing multiple hosts on a port [2-103](#)
  - debugging 802.1X Port Based Authentication [2-56](#)
  - displaying port based authentication [2-338](#)
  - enabling accounting for authentication sessions [2-3](#)
  - enabling authentication on the system [2-108](#)
  - enabling guest VLAN [2-97](#)
  - enabling guest VLAN supplicant [2-90, 2-98](#)
  - enabling manual control of auth state [2-104](#)
  - enabling periodic re-authentication of the client [2-107](#)
  - initializing re-authentication of dot1x ports [2-106](#)
  - initializing state machines [2-99](#)
  - receive session termination message upon reboot [2-4](#)
  - setting maximum number for EAP requests [2-102](#)
  - setting the reauthentication timer [2-109](#)

---

## A

- abbreviating commands
  - context-sensitive help [1-1](#)
- Access Gateway Module
  - connecting to a module [2-12](#)
  - connecting to a remote module [2-295](#)
  - connecting to a specific remote module [2-305](#)
- access-group
  - displaying mac interface [2-444](#)
  - show mode interface [2-309](#)
- access groups
  - IP [2-5](#)

- access lists
    - clearing an access template [2-28](#)
    - defining ARP [2-11](#)
    - displaying ARP information [2-312](#)
    - See also ACLs, MAC ACLs, and VACLs
  - access maps
    - applying with VLAN filter [2-639](#)
  - ACLs
    - access-group mode [2-5](#)
    - balancing hardware regions [2-8](#)
    - determining ACL hardware programming [2-6](#)
    - displaying mac access-group interface [2-444](#)
    - using ACL naming conventions for MAC ACLs [2-206](#)
  - action clause
    - specifying drop or forward action in a VACL [2-9](#)
  - addresses, configuring a maximum [2-263](#)
  - adjacency
    - debugging the adjacency table [2-50](#)
    - disabling the debug facility [2-50](#)
    - displaying information about the adjacency table [2-310](#)
    - displaying IPC table entries [2-50](#)
  - aggregate policer
    - displaying information [2-491](#)
  - aging time
    - displaying MAC address aging time [2-447](#)
    - MAC address table [2-209](#)
  - alarms
    - displaying operational status [2-341](#)
  - alternation
    - description [1-9](#)
  - anchoring
    - description [1-10](#)
  - ARP
    - access list, displaying detailed information [2-312](#)
    - defining access-lists [2-11](#)
  - ARP inspection
    - enforce certain types of checking [2-142](#)
  - ARP packet
    - deny based on DHCP bindings [2-86](#)
    - permit based on DHCP bindings [2-249](#)
  - authentication
    - setting username [2-629](#)
    - using an MD5-type encryption method [2-629](#)
    - verifying MD5 signature [2-630](#)
    - verifying the checksum for Flash memory [2-630](#)
  - auth fail VLAN
    - enable on a port [2-91](#)
    - set max number of attempts [2-90](#)
  - authorization state
    - enabling manual control [2-104](#)
  - authorization state of a controlled port [2-104](#)
  - automatic installation
    - displaying status [2-313](#)
  - automatic medium-dependent interface crossover
    - See Auto-MDIX
  - Auto-MDIX
    - disabling [2-234](#)
    - enabling [2-234](#)
  - auto-negotiate interface speed
    - example [2-578](#)
  - auto-QoS
    - configuring for VoIP [2-13](#)
    - displaying configuration [2-314](#)
- 
- B**
  - baby giants
    - displaying the system MTU setting [2-517](#)
    - setting the maximum Layer 2 payload size [2-612](#)
  - BackboneFast
    - displaying debugging messages [2-75](#)
    - displaying spanning tree status [2-507](#)
    - enabling debugging [2-75](#)
  - bindings
    - store for DHCP snooping [2-151](#)
  - BOOT environment variable
    - displaying information [2-318](#)

- bootflash
    - displaying information [2-316](#)
  - BPDUs
    - debugging spanning tree activities [2-74](#)
  - bridge protocol data units
    - See BPDUs
  - broadcast suppression level
    - configuring [2-579, 2-581](#)
    - enabling [2-579, 2-581](#)
- 
- C**
- cable diagnostics
    - TDR
      - displaying test results [2-319](#)
      - testing conditions of copper cables [2-613](#)
  - Catalyst 4507R [2-259](#)
    - power redundancy mode [2-264](#)
  - CDP
    - configuring tunneling encapsulation rate [2-196](#)
    - displaying
      - neighbor information [2-321](#)
    - enabling protocol tunneling for [2-193](#)
    - set drop threshold for [2-195](#)
  - CEF
    - displaying next-hop information [2-386](#)
    - displaying VLAN configuration information [2-386](#)
  - cisco-desktop
    - macro apply [2-217](#)
  - Cisco Express Forwarding
    - See CEF
  - cisco-phone
    - macro apply [2-219](#)
  - cisco-router
    - macro apply [2-221](#)
  - cisco-switch
    - macro apply [2-223](#)
  - clear commands
    - clearing Gigabit Ethernet interfaces [2-26](#)
    - clearing IGMP group cache entries [2-33](#)
    - clearing interface counters [2-23](#)
    - clearing IP access lists [2-28, 2-29](#)
    - clearing IP ARP inspection statistics VLAN [2-30](#)
    - clearing IP DHCP snooping database [2-31](#)
    - clearing IP DHCP snooping database statistics [2-32](#)
    - clearing MFIB counters and routes [2-36](#)
    - clearing MFIB fastdrop entries [2-37](#)
    - clearing PAgP channel information [2-42](#)
    - clearing QoS aggregate counters [2-45](#)
    - clearing VLAN interfaces [2-27](#)
  - CLI string search
    - anchoring [1-10](#)
    - expressions [1-7](#)
    - filtering [1-6](#)
    - multiple-character patterns [1-8](#)
    - multipliers [1-9](#)
    - parentheses for recall [1-10](#)
    - searching outputs [1-6](#)
    - single-character patterns [1-7](#)
    - using [1-6](#)
  - command modes
    - accessing privileged EXEC mode [1-4](#)
    - exiting [1-4](#)
    - understanding user EXEC and configuration modes [1-4](#)
  - condition interface
    - debugging interface-related activities [2-52](#)
  - condition vlan
    - debugging VLAN output [2-55](#)
  - configuration, saving [1-11](#)
  - configuring
    - root as secondary [2-562](#)
  - configuring a SPAN session to monitor
    - limit SPAN source traffic [2-238](#)
  - configuring forward delay [2-558](#)
  - configuring root as primary [2-562](#)

- CoPP
    - attaching
      - policy map to control plane [2-303](#)
    - displaying
      - policy-map class information [2-470](#)
    - entering configuration mode [2-48](#)
    - removing
      - service policy from control plane [2-303](#)
  - CoS
    - assigning to Layer 2 protocol packets [2-194](#)
  - CoS QoS default
    - defining value on an interface [2-279](#)
  - Cost of Service
    - See QoS CoS
  - counters
    - clearing interface counters [2-23](#)
- 
- D**
- DAI
    - clear statistics [2-30](#)
  - DBL
    - displaying qos dbl [2-492](#)
    - enabling DBL globally on the switch [2-280](#)
  - debug commands
    - debugging backup events [2-51](#)
    - debugging DHCP snooping events [2-61](#)
    - debugging DHCP snooping messages [2-62](#)
    - debugging EtherChannel/PAgP/shim [2-57](#)
    - debugging IPC activity [2-60](#)
    - debugging IP DHCP snooping security messages [2-63](#)
    - debugging NVRAM activities [2-66](#)
    - debugging PAgP activities [2-67](#)
    - debugging port manager activities [2-70](#)
    - debugging software MAC filter updates [2-73](#)
    - debugging spanning tree activities [2-74](#)
    - debugging spanning tree backbonefast [2-75](#)
    - debugging spanning tree UplinkFast [2-78](#)
    - debugging supervisor redundancy [2-72](#)
    - debugging VLAN manager activities [2-79](#)
    - displaying monitor activity [2-65](#)
    - displaying the adjacency table [2-50](#)
    - enabling debug dot1x [2-56](#)
    - enabling debugging messages for ISL VLAN IDs [2-81](#)
    - enabling debugging messages for VTP [2-82](#)
    - enabling debugging of UDLD activity [2-83](#)
    - enabling switch shim debugging [2-76](#)
    - enabling VLAN manager file system error tests [2-80](#)
    - limiting debugging output for VLANs [2-55](#)
    - limiting interface debugging output [2-52](#)
    - limiting output for debugging standby state changes [2-53](#)
    - shortcut to the debug condition interface [2-59](#)
  - debugging
    - activity monitoring [2-65](#)
    - DHCP snooping events [2-61](#)
    - DHCP snooping packets [2-62](#)
    - IPC activities [2-60](#)
    - IP DHCP snooping security packets [2-63](#)
    - NVRAM activities [2-66](#)
    - PAgP activities [2-67](#)
    - PAgP shim [2-57](#)
    - PM activities [2-70](#)
    - SMF address insertions and deletions [2-73](#)
    - spanning tree BackboneFast events [2-75](#)
    - spanning tree switch shim [2-76](#)
    - spanning tree UplinkFast events [2-78](#)
    - VLAN manager activities [2-79](#)
    - VLAN manager IOS file system error tests [2-80](#)
    - VTP protocol debug messages [2-82](#)
  - debug spanning tree switch [2-76](#)
  - debug sw-vlan vtp [2-82](#)
  - default CoS value [2-279](#)
  - default form of a command, using [1-6](#)
  - defining egress DSCP-to-CoS mapping [2-285](#)
  - DHCP
    - clearing database statistics [2-32](#)

- DHCP bindings
    - configuring bindings [2-150](#)
    - deny ARP packet based on matches [2-86](#)
    - permit ARP packet based on matches [2-249](#)
  - DHCP snooping
    - clearing database [2-31](#)
    - displaying binding table [2-388](#)
    - displaying configuration information [2-387](#)
    - displaying status of DHCP database [2-391](#)
    - displaying status of error detection [2-344](#)
    - enabling DHCP globally [2-149](#)
    - enabling IP source guard [2-182](#)
    - enabling on a VLAN [2-157](#)
    - enabling option 82 [2-153, 2-154](#)
    - enabling rate limiting on an interface [2-155](#)
    - enabling trust on an interface [2-156](#)
    - establishing binding configuration [2-150](#)
    - renew binding database [2-297](#)
    - store generated bindings [2-151](#)
  - diagnostic test
    - bootup packet memory [2-332](#)
    - displaying attributes [2-326](#)
    - display module-based results [2-328](#)
    - running [2-89](#)
    - show results for TDR [2-319](#)
    - testing conditions of copper cables [2-613](#)
  - displaying error disable recovery [2-345](#)
  - displaying inline power status [2-483](#)
  - displaying monitoring activity [2-65](#)
  - displaying SEEPROM information
    - GBIC [2-353](#)
  - displaying SPAN session information [2-516, 2-580](#)
  - document conventions [xviii](#)
  - document organization [xvii](#)
  - DoS
    - CoPP
      - attaching policy map to control plane [2-303](#)
      - displaying policy-map class information [2-470](#)
      - entering configuration mode [2-48](#)
      - removing service policy from control plane [2-303](#)
      - entering
        - CoPP configuration mode [2-48](#)
  - DOS attack
    - protecting system's resources [2-137](#)
  - drop threshold, Layer 2 protocol tunneling [2-195](#)
  - DSCP rewrite for IP packets
    - enable [2-288](#)
  - dual-capable port
    - selecting a connector [2-235](#)
  - duplex mode
    - configuring autonegotiation on an interface [2-111](#)
    - configuring full duplex on an interface [2-111](#)
    - configuring half duplex on an interface [2-111](#)
  - dynamic ARP inspection
    - preventing [2-137](#)
  - Dynamic Buffer Limiting
    - See DBL
  - Dynamic Host Configuration Protocol
    - See DHCP
- 
- ## E
- EAP
    - restarting authentication process [2-102](#)
  - EIGRP (Enhanced IGRP)
    - filters
      - routing updates, preventing [2-246](#)
  - enabling
    - debugging for UDLD [2-83](#)
    - voice VLANs [2-582](#)
  - environmental
    - alarms [2-341](#)
    - displaying information [2-341](#)
    - status [2-341](#)
    - temperature [2-341](#)
  - erase a file [2-113](#)
  - error disable detection
    - enabling error disable detection [2-116](#)

error-disabled state  
   displaying [2-372](#)

error disable recovery  
   configuring recovery mechanism variables [2-118](#)  
   displaying recovery timer information [2-345](#)  
   enabling ARP inspection timeout [2-118](#)  
   specifying recovery cause [2-118](#)

EtherChannel  
   assigning interfaces to EtherChannel groups [2-17](#)  
   debugging EtherChannel [2-57](#)  
   debugging PAgP shim [2-57](#)  
   debugging spanning tree activities [2-74](#)  
   displaying information for a channel [2-346](#)  
   removing interfaces from EtherChannel groups [2-17](#)

EtherChannel guard  
   detecting STP misconfiguration [2-549](#)

Explicit Host Tracking  
   clearing the database [2-35](#)  
   enabling per-VLAN [2-169](#)

expressions  
   matching multiple expression occurrences [1-9](#)  
   multiple-character patterns [1-8](#)  
   multiplying pattern occurrence [1-10](#)  
   single-character patterns [1-7](#)

Extensible Authentication Protocol  
   See EAP

---

## F

field replaceable unit (FRU)  
   displaying status information [2-341](#)

filters  
   EIGRP  
     routing updates, preventing [2-246](#)

Flash memory file system  
   displaying file system information [2-316](#)  
   verifying checksum [2-630](#)

flow control  
   configuring a gigabit interface for pause frames [2-121](#)  
   displaying per-interface statistics for flow control [2-350](#)

---

## G

GBIC  
   displaying SEEPROM information [2-353](#)

Gigabit Ethernet interface  
   clearing the hardware logic [2-26](#)

Gigabit Ethernet uplink  
   selecting [2-125](#)  
   showing the mode [2-352](#)

global configuration mode  
   using [1-5](#)

---

## H

hardware module  
   resetting a module by toggling the power [2-124](#)

hardware uplink  
   selecting the mode [2-125](#)  
   showing the mode [2-352](#)

helper addresses, IP [2-404](#)

hot standby protocol  
   debugging [2-53](#)  
   disabling debugging [2-53](#)  
   limiting output [2-53](#)

---

## I

IDPROMs  
   displaying SEEPROM information  
     chassis [2-353](#)  
     clock module [2-353](#)  
     fan trays [2-353](#)  
     module [2-353](#)  
     mux buffer [2-353](#)

- power supplies [2-353](#)
- supervisor engine [2-353](#)
- ifIndex persistence
  - clearing SNMP ifIndex commands [2-537](#)
  - compress SNMP ifIndex table format [2-542](#)
  - disabling globally [2-541](#)
  - disabling on an interface [2-538](#)
  - enabling globally [2-541](#)
  - enabling on an interface [2-538](#)
- IGMP
  - applying filters for host joining on Layer 2 interfaces [2-159](#)
  - clearing IGMP group cache entries [2-33](#)
  - configuring frequency for IGMP host-query messages [2-162](#)
  - creating an IGMP profile [2-161](#)
  - displaying IGMP interface configuration information [2-393](#)
  - displaying profiles [2-394](#)
  - setting maximum group numbers [2-160](#)
- IGMP profiles
  - displaying [2-394](#)
- IGMP snooping
  - clearing the EHT database [2-35](#)
  - configuring a Layer 2 interface as a group member [2-173](#)
  - configuring a Layer 2 interface as a multicast router [2-171](#)
  - configuring a static VLAN interface [2-173](#)
  - displaying multicast information [2-401](#)
  - displaying VLAN information [2-395, 2-399, 2-402](#)
  - enabling [2-164](#)
  - enabling immediate-leave processing [2-170](#)
  - enabling on a VLAN [2-168](#)
  - enabling per-VLAN Explicit Host Tracking [2-169](#)
- informs
  - enabling [2-539](#)
- inline power
  - displaying inline power status [2-483](#)
- In Service Software Upgrade
  - See ISSU
- inspection log
  - clearing log buffer [2-29](#)
- interface
  - displaying suppressed multicast bytes [2-366](#)
- interface capabilities
  - displaying [2-362](#)
- interface configuration mode
  - summary [1-5](#)
- interface link
  - display cable disconnect time [2-369](#)
- interfaces
  - configuring dot1q tunnel ports [2-587](#)
  - creating an interface-range macro [2-85](#)
  - debugging output of interface related activities [2-52](#)
  - displaying description [2-368](#)
  - displaying error-disabled state [2-372](#)
  - displaying information when tunneling is enabled [2-438](#)
  - displaying status [2-368](#)
  - displaying traffic for a specific interface [2-359](#)
  - entering interface configuration mode [2-129](#)
  - executing a command on multiple ports in a range [2-132](#)
  - selecting an interface to configure [2-129](#)
  - setting a CoS value for Layer 2 packets [2-194](#)
  - setting drop threshold for Layer 2 packets [2-195](#)
  - setting the interface type [2-587](#)
- interface speed
  - configuring interface speed [2-576](#)
- interface transceiver
  - displaying diagnostic data [2-375](#)
- internal VLAN allocation
  - configuring [2-640](#)
  - default setting [2-640](#)
  - displaying allocation information [2-528](#)
- Internet Group Management Protocol
  - See IGMP

## IP ARP

- applying ARP ACL to VLAN [2-135](#)
- clearing inspection statistics [2-30](#)
- clearing status of log buffer [2-29](#)
- controlling packet logging [2-145](#)
- enabling dynamic inspection [2-144](#)
- limit rate of incoming requests [2-137](#)
- set per-port config trust state [2-141](#)
- showing status of dynamic ARP inspection [2-382](#)
- showing status of log buffer [2-385](#)

## IPC

- debugging IPC activities [2-60](#)

## IP DHCP Snooping

- See DHCP snooping

## IP header validation

- disabling [2-181](#)
- enabling [2-181](#)

## IP interfaces

- displaying usability status [2-403](#)

## IP multicast

- displaying multicast routing table information [2-409](#)

## IP packets

- enable DSCP rewrite [2-288](#)

## IP phone and standard desktop

- enabling Cisco-recommended features [2-219](#)

## IP source binding

- adding or deleting [2-178](#)
- displaying bindingstaggging [2-414](#)

## IP source guard

- debugging messages [2-63](#)
- displaying configuration and filters [2-415](#)
- enabling on DHCP snooping [2-182](#)

## ISSU

- canceling process [2-184](#)
- configuring rollback timer [2-192](#)
- displaying capability [2-419](#)
- displaying client information [2-421](#)
- displaying compatibility matrix [2-423](#)
- displaying config-sync failure information [2-427](#)

- displaying endpoint information [2-429](#)
- displaying entities [2-430](#)
- displaying FSM session [2-431](#)
- displaying messages [2-432](#)
- displaying negotiated [2-433](#)
- displaying rollback-timer [2-434](#)
- displaying session information [2-435](#)
- displaying software version [2-436](#)
- displaying state [2-436](#)
- forcing switchover to standby supervisor engine [2-191](#)
- loading new image [2-187](#)
- mismatched command listing [2-188](#)
- starting process [2-190](#)
- stopping rollback timer [2-185](#)

---

**J**

## Jumbo frames

- enabling jumbo frames [2-242](#)

---

**L**

## LACP

- deselecting channeling protocol [2-19](#)
- enabling LACP on an interface [2-19](#)
- setting channeling protocol [2-19](#)

## Layer 2

- displaying ACL configuration [2-444](#)

## Layer 2 interface type

- specifying a nontrunking, nontagged single VLAN interface [2-587](#)
- specifying a trunking VLAN interface [2-587](#)

## Layer 2 protocol ports

- displaying [2-438](#)

Layer 2 protocol tunneling error recovery [2-196](#)

## Layer 2 switching

- enabling voice VLANs [2-582](#)
- modifying switching characteristics [2-582](#)



- Layer 2 traceroute
    - IP addresses [2-618](#)
  - Layer 3 switching
    - displaying information about an adjacency table [2-310](#)
    - displaying port status [2-373](#)
    - displaying status of native VLAN tagging [2-373](#)
  - link-status event messages
    - disabling
      - globally [2-200, 2-203](#)
      - on an interface [2-201, 2-204](#)
    - enabling
      - globally [2-200, 2-203](#)
      - on an interface [2-201, 2-204](#)
  - log buffer
    - show status [2-385](#)
  - logging
    - controlling IP ARP packets [2-145](#)
- 
- ## M
- MAC Access Control Lists
    - See MAC ACLs
  - MAC ACLs
    - defining extended MAC access list [2-206](#)
    - displaying MAC ACL information [2-525](#)
    - naming an ACL [2-206](#)
  - MAC address filtering
    - configuring [2-215](#)
    - disabling [2-215](#)
    - enabling [2-215](#)
  - MAC address table
    - adding static entries [2-228](#)
    - clearing dynamic entries [2-39, 2-41](#)
    - configuring aging time [2-209](#)
    - displaying dynamic table entry information [2-449](#)
    - displaying entry count [2-448](#)
    - displaying information [2-445](#)
    - displaying interface-based information [2-451](#)
    - displaying multicast information [2-453](#)
    - displaying notification information [2-455](#)
    - displaying protocol-based information [2-457](#)
    - displaying static table entry information [2-459](#)
    - displaying the MAC address aging time [2-447](#)
    - displaying VLAN-based information [2-461](#)
    - enabling authentication bypass [2-100](#)
    - enabling notifications [2-213](#)
    - learning in the protocol buckets [2-210](#)
    - removing static entries [2-228](#)
  - MAC address tables
    - adding static entries [2-215](#)
    - deleting secure or specific addresses [2-43](#)
    - disabling IGMP snooping on static MAC addresses [2-215](#)
    - removing static entries [2-215](#)
  - mac-address-table static [2-215](#)
  - MAC address unicast filtering
    - dropping unicast traffic [2-215](#)
  - macro
    - displaying descriptions [2-227](#)
  - macro keywords
    - help strings [2-2](#)
  - macros
    - adding a global description [2-227](#)
    - cisco global [2-225](#)
    - system-cpp [2-226](#)
  - mapping secondary VLANs to MST instance [2-271](#)
  - mapping VLAN(s) to an MST instance [2-127](#)
  - match subcommand
    - accessing [2-21](#)
  - maximum transmission unit (MTU)
    - displaying the system MTU setting [2-517](#)
    - setting the maximum Layer 2 payload size [2-612](#)
  - MD5
    - verifying MD5 signature [2-630](#)
  - message digest 5
    - See MD5

## MFIB

- clearing ip mfib counters [2-36](#)
- clearing ip mfib fastdrop [2-37](#)
- displaying all active MFIB routes [2-406](#)
- displaying MFIB fastdrop table entries [2-408](#)
- enabling IP MFIB fastdrops [2-175](#)

## modes

- access-group [2-5](#)
- show access-group interface [2-309](#)
- switching between PVST+, MST, and Rapid PVST [2-554](#)

See also command modes

module password clearing [2-25](#)

## module reset

- resetting a module by toggling the power [2-124](#)

## --More-- prompt

- filter [1-6](#)
- search [1-7](#)

## MST

- designating the primary and secondary root [2-562](#)
- displaying MST protocol information [2-512](#)
- displaying region configuration information [2-512](#)
- displaying spanning tree information [2-512](#)
- entering MST configuration submode [2-556](#)
- setting configuration revision number [2-299](#)
- setting path cost and port priority for instances [2-555](#)
- setting the forward delay timer for all instances [2-558](#)
- setting the hello-time delay timer for all instances [2-559](#)
- setting the max-age timer for all instances [2-560](#)
- setting the MST region name [2-243](#)
- specifying the maximum number of hops [2-561](#)
- switching between PVST+ and Rapid PVST [2-554](#)
- using the MST configuration submode revision command [2-299](#)
- using the submode name command [2-243](#)

## MTU

- displaying global MTU settings [2-517](#)

## multicast

- enabling storm control [2-581](#)

## multicast/unicast packets

- prevent forwarding [2-586](#)

## Multicast Forwarding Information Base

See MFIB

multiple-character patterns [1-8](#)

multiple hosts on authorized port [2-103](#)

## Multiple Spanning Tree

See MST

---

**N**

## native VLAN

- controlling tagging of traffic [2-607](#)
- displaying ports eligible for native tagging [2-527](#)
- displaying ports eligible for tagging [2-527](#)
- enabling tagging on 802.1Q trunk ports [2-638](#)
- specifying the tagging of traffic [2-608](#)

## NetFlow

- enabling NetFlow statistics [2-176](#)
- including infer fields in routing statistics [2-176](#)

## next-hop

- displaying CEF VLAN information [2-386](#)

no form of a command, using [1-6](#)

## NVRAM

- debugging NVRAM activities [2-66](#)

---

**O**

## output

- pattern searches [1-7](#)

---

**P**

## packet forwarding

- prevent unknown packets [2-586](#)

- packet memory failure
  - direct switch action upon detection [2-88](#)
- packet memory test
  - bootup, displaying results [2-332](#), [2-334](#)
  - ongoing, displaying results [2-336](#)
- PACL
  - access-group mode [2-5](#)
- paging prompt
  - see --More-- prompt
- PAgP
  - clearing port channel information [2-42](#)
  - debugging PAgP activity [2-67](#)
  - deselecting channeling protocol [2-19](#)
  - displaying port channel information [2-467](#)
  - hot standby mode
    - returning to defaults [2-245](#)
    - selecting ports [2-245](#)
  - input interface of incoming packets
    - learning [2-244](#)
    - returning to defaults [2-244](#)
  - setting channeling protocol [2-19](#)
- parentheses [1-10](#)
- password
  - clearing on an intelligent line module [2-25](#)
  - establishing enhanced password security [2-629](#)
  - setting username [2-629](#)
- PBR
  - displaying route maps [xviii](#)
  - redistributing route maps [xviii](#)
- PM activities
  - debugging [2-70](#)
  - disabling debugging [2-70](#)
- Policy Based Routing
  - See PBR
- port, dual-capable
  - selecting the connector [2-235](#)
- Port Aggregation Protocol
  - See PAgP
- port-based authentication
  - displaying debug messages [2-56](#)
  - displaying statistics and status [2-338](#)
  - enabling 802.1X [2-104](#)
  - manual control of authorization state [2-104](#)
  - multiple hosts on authorized port [2-103](#)
  - periodic re-authentication
    - enabling [2-107](#)
  - re-authenticating 802.1X-enabled ports [2-106](#)
  - switch-to-client frame-retransmission number [2-102](#)
- port channel
  - accessing [2-131](#)
  - creating [2-131](#)
  - displaying information [2-467](#)
  - load distribution method
    - resetting to defaults [2-253](#)
    - setting [2-253](#)
- port range
  - executing [2-132](#)
- port security
  - debugging ports security [2-71](#)
  - deleting secure or specific addresses [2-43](#)
  - displaying settings for an interface or switch [2-477](#)
  - enabling [2-592](#)
  - filter source IP and MAC addresses [2-182](#)
  - setting action upon security violation [2-592](#)
  - setting the rate limit for bad packets [2-592](#)
  - sticky port [2-592](#)
- Port Trust Device
  - displaying [2-493](#)
- power status
  - displaying inline power [2-483](#)
  - displaying power status [2-483](#)
- power supply
  - configuring combined and redundant power on the Catalyst 4507R [2-259](#)
  - configuring inline power [2-256](#)
  - configuring power consumption [2-258](#)

- configuring power redundancy on the Catalyst 4507R [2-264](#)
- displaying the SEEPROM [2-353](#)
- setting inline power state [2-255](#)
- Private VLAN
  - See PVLANS
- privileged EXEC mode, summary [1-5](#)
- prompts
  - system [1-5](#)
- protocol tunneling
  - configuring encapsulation rate [2-196](#)
  - disabling [2-193](#)
  - displaying port information [2-438](#)
  - enabling [2-193](#)
  - setting a CoS value for Layer 2 packets [2-194](#)
  - setting a drop threshold for Layer 2 packets [2-195](#)
- PVLANS
  - configuring isolated, primary, and community PVLANS [2-265](#)
  - controlling tagging of native VLAN traffic [2-607](#)
  - disabling sticky-ARP [2-179](#)
  - displaying map information for VLAN SVIs [2-371](#)
  - displaying PVLAN information [2-530](#)
  - enabling interface configuration mode [2-587](#)
  - enabling sticky-ARP [2-179](#)
  - mapping VLANs to the same SVI [2-269](#)
  - specifying host ports [2-587](#)
  - specifying promiscuous ports [2-587](#)
- PVST+
  - switching between PVST and MST [2-554](#)
- configuring auto [2-13](#)
- defining a named aggregate policer [2-276](#)
- defining default CoS value [2-279](#)
- defining ingress CoS-to-DSCP mapping [2-283](#)
- displaying aggregate policer information [2-491](#)
- displaying auto configuration [2-314](#)
- displaying class maps information [2-324](#)
- displaying configuration information [2-314](#)
- displaying configurations of policies [2-473](#)
- displaying policy map information [2-469, 2-476](#)
- displaying QoS information [2-490](#)
- displaying QoS map information [2-494](#)
- enabling global configuration mode [2-272](#)
- enabling per-VLAN QoS for a Layer 2 interface [2-291](#)
- enabling QoS on an interface [2-273](#)
- mapping DSCP values to transmit queues [2-285](#)
- mapping egress DSCP-to-CoS [2-285](#)
- mapping the DSCP-to-CoS value [2-285](#)
- setting the mapping of policed DSCP values [2-287](#)
- setting the trust state [2-289](#)
- specifying flow-based match criteria [2-230](#)
- QoS CoS
  - configuring for tunneled Layer 2 protocol packets [2-194](#)
  - defining default CoS value [2-279](#)
- qos dbl [2-280](#)
- question command [1-1](#)
- queueing information
  - displaying [2-493](#)

---

## Q

- QoS
  - account Layer 2 encapsulation [2-274](#)
  - attaching a policy-map to an interface [2-300](#)
  - automatic configuration [2-13](#)
  - clearing aggregate counters [2-45](#)
  - configuring a QoS policy map [2-251](#)

---

## R

- Rapid PVST
  - switching between PVST and MST [2-554](#)
- re-authenticating 802.1X-enabled ports [2-106](#)
- re-authentication
  - periodic [2-107](#)
  - set the time [2-109](#)
- reboots
  - restoring bindings across [2-150](#)

- redundancy
    - accessing the main CPU [2-292](#)
    - changing from active to standby supervisor engine [2-293](#)
    - displaying information [2-496](#)
    - displaying redundancy facility information [2-496](#)
    - displaying RF client list [2-496](#)
    - displaying RF operational counters [2-496](#)
    - displaying RF states [2-496](#)
    - enabling automatic synchronization [2-16](#)
    - forcing switchover to standby supervisor engine [2-293](#)
    - set the mode [2-236](#)
    - synchronizing the route processor configurations [2-228](#)
  - related documentation [xvii](#)
  - remote SPAN
    - See RSPAN
  - renew commands
    - ip dhcp snooping database [2-297](#)
  - resetting PVLAN trunk
    - setting switchport to trunk [2-587](#)
  - rj45 connector, selecting the connector [2-235](#)
  - ROM monitor mode
    - summary [1-6](#)
  - Route Processor Redundancy
    - See redundancy
  - RPR
    - set the redundancy mode [2-236](#)
  - RSPAN
    - converting VLAN to RSPAN VLAN [2-296](#)
    - displaying list [2-532](#)
- 
- S**
- saving configuration changes [1-11](#)
  - secure address, configuring [2-261](#)
  - secure ports, limitations [2-593](#)
  - set the redundancy mode [2-236](#)
  - sfp connector, selecting the connector [2-235](#)
  - show commands
    - filtering parameters [1-7](#)
    - searching and filtering [1-6](#)
    - show platform commands [1-11](#)
  - Simple Network Management Protocol
    - See SNMP
  - single-character patterns
    - special characters [1-7](#)
  - slaveslot0
    - displaying information on the standby supervisor [2-503](#)
  - slot0
    - displaying information about the system [2-505](#)
  - SMF
    - debugging address insertions and deletions [2-73](#)
  - SNMP
    - debugging spanning tree activities [2-74](#)
    - ifIndex persistence
      - clearing SNMP ifIndex commands [2-537](#)
      - compress SNMP ifIndex table format [2-542](#)
      - disabling globally [2-541](#)
      - disabling on an interface [2-538](#)
      - enabling globally [2-541](#)
      - enabling on an interface [2-538](#)
    - informs
      - disabling [2-539](#)
      - enabling [2-539](#)
    - traps
      - configuring to send when storm occurs [2-579](#)
      - disabling [2-539](#)
      - enabling [2-539](#)
      - mac-notification
        - adding [2-543](#)
        - removing [2-543](#)
  - software MAC filter
    - See SMF
  - SPAN commands
    - configuring a SPAN session to monitor [2-238](#)
    - displaying SPAN session information [2-516, 2-580](#)

- SPAN enhancements
  - displaying status [2-465](#)
- Spanning Tree Protocol
  - See STP
- SPAN session
  - displaying session information [2-465](#)
  - filter ACLs [2-238](#)
  - specify encap type [2-238](#)
  - turn off host learning based on ingress packets [2-238](#)
- special characters
  - anchoring, table [1-10](#)
- SSO [2-236](#)
- standard desktop
  - enabling Cisco-recommended features [2-217](#)
- standard desktop and Cisco IP phone
  - enabling Cisco-recommended features [2-219](#)
- sticky address, configuring [2-262](#)
- sticky-ARP
  - disabling on PVLANS [2-179](#)
  - enabling on PVLANS [2-179](#)
- sticky port
  - deleting [2-43](#)
  - enabling security [2-592](#)
- storm control
  - configuring for action when storm occurs [2-579](#)
  - disabling suppression mode [2-344](#)
  - displaying settings [2-515](#)
  - enabling [2-579](#)
  - enabling broadcast [2-579, 2-581](#)
  - enabling multicast [2-579, 2-581](#)
  - enabling suppression mode [2-344](#)
  - enabling timer to recover from error disable [2-118](#)
  - enabling unicast [2-579, 2-581](#)
  - multicast, enabling [2-581](#)
  - setting high and low levels [2-579](#)
  - setting suppression level [2-344](#)
- STP
  - configuring link type for a port [2-552](#)
  - configuring tunneling encapsulation rate [2-196](#)
  - debugging all activities [2-74](#)
  - debugging spanning tree activities [2-74](#)
  - debugging spanning tree BackboneFast events [2-75](#)
  - debugging spanning tree UplinkFast [2-78](#)
  - detecting misconfiguration [2-549](#)
  - displaying active interfaces only [2-507](#)
  - displaying BackboneFast status [2-507](#)
  - displaying bridge status and configuration [2-507](#)
  - displaying spanning tree debug messages [2-74](#)
  - displaying summary of interface information [2-507](#)
  - enabling BPDU filtering by default on all PortFast ports [2-567](#)
  - enabling BPDU filtering on an interface [2-545](#)
  - enabling BPDU guard by default on all PortFast ports [2-569](#)
  - enabling BPDU guard on an interface [2-547](#)
  - enabling extended system ID [2-550](#)
  - enabling loop guard as a default on all ports [2-553](#)
  - enabling PortFast by default on all access ports [2-570](#)
  - enabling PortFast mode [2-565](#)
  - enabling protocol tunneling for [2-193](#)
  - enabling root guard [2-551](#)
  - enabling spanning tree BackboneFast [2-544](#)
  - enabling spanning tree on a per VLAN basis [2-574](#)
  - enabling spanning tree UplinkFast [2-572](#)
  - setting an interface priority [2-571](#)
  - setting drop threshold for [2-195](#)
  - setting pathcost [2-548](#)
  - setting the default pathcost calculation method [2-564](#)
- subinterface configuration mode, summary [1-6](#)
- SVI
  - creating a Layer 3 interface on a VLAN [2-134](#)
- switchport [2-608](#)
- switchport interfaces
  - displaying status of Layer 3 port [2-373](#)
  - displaying status of native VLAN tagging [2-373](#)
- switch shim
  - debugging [2-76](#)
  - disabling debugging [2-76](#)

switch to router connection  
     enabling Cisco-recommended features [2-221](#)

switch to switch connection  
     enabling Cisco-recommended features [2-223](#)

switch virtual interface  
     See SVI

sw-vlan [2-79](#)

system prompts [1-5](#)

---

## T

Tab key  
     command completion [1-1](#)

tables  
     characters with special meaning [1-7](#)  
     mac access-list extended subcommands [2-206](#)  
     match syntax description [2-22](#)  
     multipliers [1-9](#)  
     relationship between duplex and speed  
         commands [2-577](#)  
     show cable-diagnostics tdr command output  
         fields [2-320](#)  
     show cdp neighbors detail field descriptions [2-323](#)  
     show cdp neighbors field descriptions [2-322](#)  
     show ip interface field descriptions [2-404](#)  
     show policy-map control-plane field descriptions [2-472](#)  
     show vlan command output fields [2-531](#)  
     show vtp command output fields [2-535](#)  
     special characters [1-9](#)  
     special characters used for anchoring [1-10](#)  
     speed command options [2-230, 2-576](#)  
     valid interface types [2-129](#)

TAC  
     displaying information useful to TAC [2-518](#)

TCAM  
     debugging spanning tree activities [2-74](#)

TDR  
     displaying cable diagnostic test results [2-319](#)  
     test condition of copper cables [2-613](#)

temperature readings  
     displaying information [2-341](#)

timer information [2-345](#)

traffic shaping  
     enable on an interface [2-307](#)

traps, enabling [2-539](#)

trunk encapsulation  
     setting format [2-608](#)

trunk interfaces  
     displaying trunk interfaces information [2-380](#)

trust state  
     setting [2-141](#)

tunnel ports  
     displaying information about Layer 2 protocol [2-438](#)

TX queues  
     allocating bandwidth [2-621](#)  
     returning to default values [2-621](#)  
     setting priority to high [2-621](#)  
     specifying burst size [2-621](#)  
     specifying traffic rate [2-621](#)

---

## U

UDLD  
     displaying administrative and operational status [2-520](#)  
     enabling by default on all fiber interfaces [2-623](#)  
     enabling on an individual interface [2-625](#)  
     preventing a fiber interface from being enabled [2-625](#)  
     resetting all shutdown ports [2-627](#)  
     setting the message timer [2-623](#)

Unidirectional Link Detection  
     See UDLD

unknown multicast traffic, preventing [2-586](#)

unknown unicast traffic, preventing [2-586](#)

user EXEC mode, summary [1-5](#)

username  
     setting password and privilege level [2-629](#)

## V

### VACLs

- access-group mode [2-5](#)
- applying VLAN access maps [2-639](#)
- displaying VLAN access map information [2-525](#)
- specifying an action in a VLAN access map [2-9](#)
- specifying the match clause for a VLAN access-map sequence [2-229](#)
- using a VLAN filter [2-639](#)

### VLAN

- applying an ARP ACL [2-135](#)
- configuring [2-632](#)
- converting to RSPAN VLAN [2-296](#)
- displaying CEF information [2-386](#)
- displaying CEF next-hop information [2-386](#)
- displaying information on switch interfaces [2-395, 2-399](#)
- displaying information on VLAN switch interfaces [2-402](#)
- displaying information sorted by group IP address [2-395, 2-399](#)
- displaying IP address and version information [2-395, 2-399](#)
- displaying Layer 2 VLAN information [2-521](#)
- displaying statistical information [2-463](#)
- displaying VLAN information [2-523](#)
- enabling dynamic ARP inspection [2-144](#)
- enabling Explicit Host Tracking [2-169](#)
- enabling guest per-port [2-97](#)
- enabling guest VLAN supplicant [2-90, 2-98](#)
- entering VLAN configuration mode [2-636](#)
- native frames
  - enabling tagging on all 802.1Q trunk ports [2-638](#)
- pruning the list for VTP [2-608](#)
- setting the list of allowed [2-608](#)

### VLAN Access Control Lists

See VACLs

### VLAN access map

See VACLs

### VLAN database

- resetting [2-298](#)

### VLAN debugging

- limiting output [2-55](#)

### VLAN manager

- debugging [2-79](#)
- disabling debugging [2-79](#)
- IOS file system error tests
  - debugging [2-80](#)
  - disabling debugging [2-80](#)

### VLAN Query Protocol

See VQP

### VLAN query protocol (VQPC)

- debugging [2-84](#)

### VLANs

- clearing
  - counters [2-46](#)
  - clearing hardware logic [2-27](#)
- configuring
  - internal allocation scheme [2-640](#)
- displaying
  - internal VLAN allocation information [2-528](#)
  - RSPAN VLANs [2-532](#)
- entering VLAN configuration mode [2-636](#)

### VMPS

- configuring servers [2-644](#)
- reconfirming dynamic VLAN assignments [2-642](#)

### voice VLANs

- enabling [2-582](#)

### VoIP

- configuring auto-QoS [2-13](#)

### VQP

- per-server retry count [2-643](#)
- reconfirming dynamic VLAN assignments [2-642](#)

### VTP

- configuring the administrative domain name [2-648](#)
- configuring the device in VTP client mode [2-647](#)
- configuring the device in VTP server mode [2-651](#)
- configuring the device in VTP transparent mode [2-652](#)



- configuring tunnel encapsulation rate [2-196](#)
  - creating a VTP domain password [2-649](#)
  - displaying domain information [2-534](#)
  - displaying statistics information [2-534](#)
  - enabling protocol tunneling for [2-193](#)
  - enabling pruning in the VLAN database [2-650](#)
  - enabling VTP version 2 mode [2-653](#)
  - modifying the VTP configuration storage file name [2-646](#)
  - set drop threshold for [2-195](#)
- VTP protocol code
- activating debug messages [2-82](#)
  - deactivating debug messages [2-82](#)

