

---

## Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- \* matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- \_ matches a comma (,), left brace ({), left parenthesis [1-7](#)
- “ [1-10](#)

---

## Numerics

- 10-Gigabit Ethernet uplink
  - selecting [2-151](#)
  - showing the mode [2-455, 2-456](#)
- 802.1Q trunk ports and native VLANs [2-778](#)
- 802.1Q tunnel ports
  - configuring [2-720](#)
- 802.1S Multiple Spanning Tree
  - see MST
- 802.1X
  - configuring for multiple hosts [2-119](#)
  - configuring for single host [2-119](#)
  - configuring multiple domains [2-119](#)
  - disabling port control [2-112](#)
  - enabling port control [2-112](#)
- 802.1X Critical Authentication
  - disabling on a port [2-113](#)
  - disabling on a VLAN [2-116](#)

## EAPOL

- disabling send success packets [2-114](#)
  - enabling send success packets [2-114](#)
- enabling on a port [2-113](#)
- enabling on a VLAN [2-116](#)
- returning delay time to default setting [2-115](#)
- setting delay time on a port [2-115](#)
- 802.1X Port Based Authentication
  - debugging 802.1X Port Based Authentication [2-74](#)
  - displaying port based authentication [2-439](#)
  - enabling accounting for authentication sessions [2-4](#)
  - enabling authentication on the system [2-130](#)
  - enabling guest VLAN [2-117](#)
  - enabling guest VLAN supplicant [2-110, 2-118](#)
  - enabling manual control of auth state [2-126](#)
  - enabling periodic re-authentication of the client [2-129](#)
  - initializing re-authentication of dot1x ports [2-128](#)
  - initializing state machines [2-121](#)
  - receive session termination message upon reboot [2-5](#)
  - setting maximum number for EAP requests [2-124](#)
  - setting the reauthentication timer [2-131](#)

---

## A

- abbreviating commands
  - context-sensitive help [1-1](#)
- Access Gateway Module
  - connecting to a module [2-17](#)
  - connecting to a remote module [2-380](#)
  - connecting to a specific remote module [2-392](#)

- access-group
  - displaying mac interface [2-560](#)
  - show mode interface [2-411](#)
- access groups
  - IP [2-6](#)
- access lists
  - clearing an access template [2-39](#)
  - defining ARP [2-16](#)
  - displaying ARP information [2-414](#)
  - See also ACLs, MAC ACLs, and VACLs
- access maps
  - applying with VLAN filter [2-780](#)
- ACLs
  - access-group mode [2-6](#)
  - balancing hardware regions [2-12](#)
  - capturing control packets [2-8](#)
  - determining ACL hardware programming [2-10](#)
  - disabling hardware statistics [2-146](#)
  - displaying mac access-group interface [2-560](#)
  - enabling hardware statistics [2-146](#)
  - using ACL naming conventions for MAC ACLs [2-258](#)
- action clause
  - specifying drop or forward action in a VACL [2-13](#)
- addresses, configuring a maximum [2-335](#)
- adjacency
  - debugging the adjacency table [2-67](#)
  - disabling the debug facility [2-67](#)
  - displaying information about the adjacency table [2-412](#)
  - displaying IPC table entries [2-67](#)
- aggregate policer
  - displaying information [2-612](#)
- aging time
  - displaying MAC address aging time [2-563](#)
  - MAC address table [2-261](#)
- alarms
  - displaying operational status [2-443](#)
- alternation
  - description [1-10](#)
- anchoring
  - description [1-10](#)
- ARP
  - access list, displaying detailed information [2-414](#)
  - defining access-lists [2-16](#)
- ARP inspection
  - enforce certain types of checking [2-168](#)
- ARP packet
  - deny based on DHCP bindings [2-106](#)
  - permit based on DHCP bindings [2-308](#)
- authentication
  - setting username [2-765](#)
  - using an MD5-type encryption method [2-765](#)
  - verifying MD5 signature [2-767](#)
  - verifying the checksum for Flash memory [2-767](#)
- auth fail VLAN
  - enable on a port [2-111](#)
  - set max number of attempts [2-110](#)
- authorization state
  - enabling manual control [2-126](#)
- authorization state of a controlled port [2-126](#)
- automatic installation
  - displaying status [2-415](#)
- automatic medium-dependent interface crossover
  - See Auto-MDIX
- Auto-MDIX
  - disabling [2-290](#)
  - enabling [2-290](#)
- auto-negotiate interface speed
  - example [2-709](#)
- auto-QoS
  - configuring for VoIP [2-18](#)
  - displaying configuration [2-416](#)

**B**

- baby giants
  - displaying the system MTU setting [2-643](#)
  - setting the maximum Layer 2 payload size [2-745](#)
- BackboneFast
  - displaying debugging messages [2-93](#)
  - displaying spanning tree status [2-633](#)
  - enabling debugging [2-93](#)
- bandwidth command [2-22](#)
- bindings
  - store for DHCP snooping [2-180](#)
- BOOT environment variable
  - displaying information [2-419](#)
- bootflash
  - displaying information [2-417](#)
- BPDUs
  - debugging spanning tree activities [2-91](#)
- bridge protocol data units
  - See BPDUs
- broadcast
  - counters [2-64](#)
- broadcast suppression level
  - configuring [2-710, 2-712](#)
  - enabling [2-710, 2-712](#)

**C**

- cable diagnostics
  - TDR
    - displaying test results [2-420](#)
    - testing conditions of copper cables [2-747](#)
- Catalyst 4507R [2-331](#)
- CDP
  - configuring tunneling encapsulation rate [2-248](#)
  - displaying
    - neighbor information [2-422](#)
  - enabling protocol tunneling for [2-243](#)
  - set drop threshold for [2-246](#)

- CEF
  - displaying next-hop information [2-492](#)
  - displaying VLAN configuration information [2-492](#)
- cisco-desktop
  - macro apply [2-268](#)
- Cisco Express Forwarding
  - See CEF
- cisco-phone
  - macro apply [2-270](#)
- cisco-router
  - macro apply [2-272](#)
- cisco-switch
  - macro apply [2-274](#)
- class maps
  - creating [2-32](#)
  - defining the match criteria [2-283](#)
- clear commands
  - clearing Gigabit Ethernet interfaces [2-37](#)
  - clearing IGMP group cache entries [2-46](#)
  - clearing interface counters [2-34](#)
  - clearing IP access lists [2-39, 2-40](#)
  - clearing IP ARP inspection statistics VLAN [2-41](#)
  - clearing IP DHCP snooping database statistics [2-45](#)
  - clearing MFIB counters and routes [2-49](#)
  - clearing MFIB fastdrop entries [2-50](#)
  - clearing PAgP channel information [2-55](#)
  - clearing QoS aggregate counters [2-58](#)
  - clearing VLAN interfaces [2-38](#)
- CLI string search
  - anchoring [1-10](#)
  - expressions [1-7](#)
  - filtering [1-6](#)
  - multiple-character patterns [1-8](#)
  - multipliers [1-9](#)
  - parentheses for recall [1-11](#)
  - searching outputs [1-6](#)
  - single-character patterns [1-7](#)
  - using [1-6](#)

## command modes

- accessing privileged EXEC mode [1-5](#)
- exiting [1-5](#)
- understanding user EXEC and configuration modes [1-5](#)

## condition interface

- debugging interface-related activities [2-69](#)

## condition vlan

- debugging VLAN output [2-72](#)

configuration, saving [1-11](#)

## configuring

- root as secondary [2-693](#)

## configuring a SPAN session to monitor

- limit SPAN source traffic [2-295](#)

configuring forward delay [2-689](#)configuring root as primary [2-693](#)

## CoPP

## attaching

- policy map to control plane [2-390](#)

## displaying

- policy-map class information [2-589](#)

entering configuration mode [2-62](#)

## removing

- service policy from control plane [2-390](#)

## CoS

- assigning to Layer 2 protocol packets [2-245](#)

## CoS QoS default

- defining value on an interface [2-356](#)

## Cost of Service

- See QoS CoS

## counters

- clearing interface counters [2-34](#)

**D**

## DAI

- clear statistics [2-41](#)

## DBL

- displaying qos dbl [2-613](#)
- enabling DBL globally on the switch [2-357](#)

## debug commands

- debugging backup events [2-68](#)
- debugging DHCP snooping events [2-79](#)
- debugging DHCP snooping messages [2-80](#)
- debugging EtherChannel/PAGP/shim [2-75](#)
- debugging IPC activity [2-78](#)
- debugging IP DHCP snooping security messages [2-81](#)
- debugging NVRAM activities [2-84](#)
- debugging PAGP activities [2-85](#)
- debugging port manager activities [2-88](#)
- debugging spanning tree activities [2-91](#)
- debugging spanning tree backbonefast [2-93](#)
- debugging spanning tree UplinkFast [2-96](#)
- debugging supervisor redundancy [2-90](#)
- debugging VLAN manager activities [2-97](#)
- displaying monitor activity [2-83](#)
- displaying the adjacency table [2-67](#)
- enabling debug dot1x [2-74](#)
- enabling debugging messages for ISL VLAN IDs [2-100](#)
- enabling debugging messages for VTP [2-101](#)
- enabling debugging of UDLD activity [2-102](#)
- enabling switch shim debugging [2-94](#)
- enabling VLAN manager file system error tests [2-98](#)
- limiting debugging output for VLANs [2-72](#)
- limiting interface debugging output [2-69](#)
- limiting output for debugging standby state changes [2-70](#)
- shortcut to the debug condition interface [2-77](#)

## debugging

- activity monitoring [2-83](#)
- DHCP snooping events [2-79](#)
- DHCP snooping packets [2-80](#)
- IPC activities [2-78](#)
- IP DHCP snooping security packets [2-81](#)
- NVRAM activities [2-84](#)

- PAgP activities [2-85](#)
- PAgP shim [2-75](#)
- PM activities [2-88](#)
- spanning tree BackboneFast events [2-93](#)
- spanning tree switch shim [2-94](#)
- spanning tree UplinkFast events [2-96](#)
- VLAN manager activities [2-97](#)
- VLAN manager IOS file system error tests [2-98](#)
- VTP protocol debug messages [2-101](#)
- debug spanning tree switch [2-94](#)
- debug sw-vlan vtp [2-101](#)
- default CoS value [2-356](#)
- default form of a command, using [1-6](#)
- defining egress DSCP-to-CoS mapping [2-363](#)
- DHCP
  - clearing database statistics [2-45](#)
- DHCP bindings
  - configuring bindings [2-178](#)
  - deny ARP packet based on matches [2-106](#)
  - permit ARP packet based on matches [2-308](#)
- DHCP snooping
  - clearing binding entries [2-42](#)
  - clearing database [2-44](#)
  - displaying binding table [2-495](#)
  - displaying configuration information [2-493](#)
  - displaying status of DHCP database [2-498](#)
  - displaying status of error detection [2-446](#)
  - enabling DHCP globally [2-177](#)
  - enabling IP source guard [2-217](#)
  - enabling on a VLAN [2-187](#)
  - enabling option 82 [2-182, 2-184](#)
  - enabling option-82 [2-189](#)
  - enabling rate limiting on an interface [2-185](#)
  - enabling trust on an interface [2-186](#)
  - establishing binding configuration [2-178](#)
  - renew binding database [2-382](#)
  - store generated bindings [2-180](#)
- diagnostic test
  - bootup packet memory [2-433](#)
  - displaying attributes [2-427](#)
  - display module-based results [2-429](#)
  - running [2-109](#)
  - show results for TDR [2-420](#)
  - testing conditions of copper cables [2-747](#)
- displaying error disable recovery [2-447](#)
- displaying inline power status [2-604](#)
- displaying monitoring activity [2-83](#)
- displaying SEEPROM information
  - GBIC [2-457](#)
- displaying SPAN session information [2-642, 2-711](#)
- document conventions [1-xviii](#)
- document organization [1-xvii](#)
- DoS
  - CoPP
    - attaching policy map to control plane [2-390](#)
    - displaying policy-map class information [2-589](#)
    - entering configuration mode [2-62](#)
    - removing service policy from control plane [2-390](#)
  - entering
    - CoPP configuration mode [2-62](#)
- DOS attack
  - protecting system's resources [2-163](#)
- drop threshold, Layer 2 protocol tunneling [2-246](#)
- DSCP rewrite for IP packets
  - enable [2-367](#)
- dual-capable port
  - selecting a connector [2-292](#)
- duplex mode
  - configuring autonegotiation on an interface [2-133](#)
  - configuring full duplex on an interface [2-133](#)
  - configuring half duplex on an interface [2-133](#)
- dynamic ARP inspection
  - preventing [2-163](#)
- Dynamic Buffer Limiting
  - See DBL

Dynamic Host Configuration Protocol

See DHCP

## E

EAP

restarting authentication process [2-124](#)

EIGRP (Enhanced IGRP)

filters

routing updates, preventing [2-305](#)

enabling

debugging for UDLD [2-102](#)

voice VLANs [2-713](#)

environmental

alarms [2-443](#)

displaying information [2-443](#)

status [2-443](#)

temperature [2-443](#)

erase a file [2-135](#)

error disable detection

enabling error disable detection [2-138](#)

error-disabled state

displaying [2-476](#)

error disable recovery

configuring recovery mechanism variables [2-140](#)

displaying recovery timer information [2-447](#)

enabling ARP inspection timeout [2-140](#)

specifying recovery cause [2-140](#)

EtherChannel

assigning interfaces to EtherChannel groups [2-25](#)

debugging EtherChannel [2-75](#)

debugging PAgP shim [2-75](#)

debugging spanning tree activities [2-91](#)

displaying information for a channel [2-449](#)

removing interfaces from EtherChannel groups [2-25](#)

EtherChannel guard

detecting STP misconfiguration [2-679](#)

Explicit Host Tracking

clearing the database [2-48](#)

enabling per-VLAN [2-201](#)

expressions

matching multiple expression occurrences [1-9](#)

multiple-character patterns [1-8](#)

multiplying pattern occurrence [1-11](#)

single-character patterns [1-7](#)

Extensible Authentication Protocol

See EAP

## F

field replaceable unit (FRU)

displaying status information [2-443](#)

filters

EIGRP

routing updates, preventing [2-305](#)

Flash memory file system

displaying file system information [2-417](#)

verifying checksum [2-767](#)

flow control

configuring a gigabit interface for pause frames [2-143](#)

displaying per-interface statistics for flow control [2-453](#)

## G

GBIC

displaying SEEPROM information [2-457](#)

Gigabit Ethernet interface

clearing the hardware logic [2-37](#)

Gigabit Ethernet uplink

selecting [2-151](#)

showing the mode [2-455, 2-456](#)

global configuration mode

using [1-5](#)

**H**

- hardware module
  - resetting a module by toggling the power [2-148](#)
- hardware statistics
  - disabling [2-146](#)
  - enabling [2-146](#)
- hardware uplink
  - changing the mode [2-149](#)
  - selecting the mode [2-151](#)
  - showing the mode [2-455, 2-456](#)
- helper addresses, IP [2-513](#)
- hot standby protocol
  - debugging [2-70](#)
  - disabling debugging [2-70](#)
  - limiting output [2-70](#)

**I**

- IDPROMs
  - displaying SEEPROM information
    - chassis [2-457](#)
    - clock module [2-457](#)
    - fan trays [2-457](#)
    - module [2-457](#)
    - mux buffer [2-457](#)
    - power supplies [2-457](#)
    - supervisor engine [2-457](#)
- ifIndex persistence
  - clearing SNMP ifIndex commands [2-665](#)
  - compress SNMP ifIndex table format [2-672](#)
  - disabling globally [2-671](#)
  - disabling on an interface [2-667](#)
  - enabling globally [2-671](#)
  - enabling on an interface [2-667](#)
- IGMP
  - applying filters for host joining on Layer 2 interfaces [2-191](#)
  - clearing IGMP group cache entries [2-46](#)
  - configuring frequency for IGMP host-query messages [2-194](#)
  - creating an IGMP profile [2-193](#)
  - displaying IGMP interface configuration information [2-500](#)
  - displaying profiles [2-502](#)
  - setting maximum group numbers [2-192](#)
- IGMP profiles
  - displaying [2-502](#)
- IGMP snooping
  - clearing the EHT database [2-48](#)
  - configuring a Layer 2 interface as a group member [2-207](#)
  - configuring a Layer 2 interface as a multicast router [2-205](#)
  - configuring a static VLAN interface [2-207](#)
  - displaying multicast information [2-509](#)
  - displaying VLAN information [2-503, 2-507, 2-510](#)
  - enabling [2-196](#)
  - enabling immediate-leave processing [2-203](#)
  - enabling on a VLAN [2-200](#)
  - enabling per-VLAN Explicit Host Tracking [2-201](#)
- informs
  - enabling [2-669](#)
- inline power
  - displaying inline power status [2-604](#)
- In Service Software Upgrade
  - See ISSU
- inspection log
  - clearing log buffer [2-40](#)
- interface
  - displaying suppressed multicast bytes [2-470](#)
- interface capabilities
  - displaying [2-466](#)
- interface configuration mode
  - summary [1-5](#)
- interface link
  - display cable disconnect time [2-473](#)

## interfaces

- configuring dot1q tunnel ports [2-720](#)
- creating an interface-range macro [2-105](#)
- debugging output of interface related activities [2-69](#)
- displaying description [2-472](#)
- displaying error-disabled state [2-476](#)
- displaying information when tunneling is enabled [2-554](#)
- displaying status [2-472](#)
- displaying traffic for a specific interface [2-463](#)
- entering interface configuration mode [2-155](#)
- executing a command on multiple ports in a range [2-158](#)
- selecting an interface to configure [2-155](#)
- setting a CoS value for Layer 2 packets [2-245](#)
- setting drop threshold for Layer 2 packets [2-246](#)
- setting the interface type [2-720](#)

## interface speed

- configuring interface speed [2-707](#)

## interface transceiver

- displaying diagnostic data [2-480](#)

## internal VLAN allocation

- configuring [2-781](#)
- default setting [2-781](#)
- displaying allocation information [2-655](#)

## Internet Group Management Protocol

See IGMP

## IP ARP

- applying ARP ACL to VLAN [2-161](#)
- clearing inspection statistics [2-41](#)
- clearing status of log buffer [2-40](#)
- controlling packet logging [2-172](#)
- enabling dynamic inspection [2-170](#)
- limit rate of incoming requests [2-163](#)
- set per-port config trust state [2-167](#)
- showing status of dynamic ARP inspection [2-487](#)
- showing status of log buffer [2-490](#)

## IPC

- debugging IPC activities [2-78](#)

## IP DHCP Snooping

See DHCP snooping

## IP header validation

- disabling [2-216](#)
- enabling [2-216](#)

## IP interfaces

displaying usability status [2-512](#)

## IP multicast

displaying multicast routing table information [2-518](#)

## IP packets

enable DSCP rewrite [2-367](#)

## IP phone and standard desktop

enabling Cisco-recommended features [2-270](#)

## IP Port Security

enabling [2-217](#)

## IP source binding

- adding or deleting [2-213](#)
- displaying bindingstaggering [2-523](#)

## IP source guard

- debugging messages [2-81](#)
- displaying configuration and filters [2-525](#)
- enabling on DHCP snooping [2-217](#)

## IPv6 MLD

- configuring queries [2-223, 2-225](#)
- configuring snooping
- last-listener-query-intervals [2-225](#)
- configuring snooping
- listener-message-suppression [2-227](#)
- configuring snooping robustness-variables [2-228](#)
- configuring tcn topology change notifications [2-230](#)
- counting snooping last-listener-queries [2-223](#)
- displaying information [2-530](#)
- displaying ports for a switch or VLAN [2-532](#)
- displaying querier information [2-533](#)
- enabling snooping [2-221](#)
- enabling snooping on a VLAN [2-231](#)



**ISSU**

- canceling process [2-233](#)
- configuring rollback timer [2-242](#)
- displaying capability [2-535](#)
- displaying client information [2-537](#)
- displaying compatibility matrix [2-539](#)
- displaying endpoint information [2-544](#)
- displaying entities [2-545](#)
- displaying FSM session [2-546](#)
- displaying messages [2-547](#)
- displaying negotiated [2-549](#)
- displaying rollback-timer [2-550](#)
- displaying session information [2-551](#)
- displaying software version [2-552](#)
- displaying state [2-552](#)
- forcing switchover to standby supervisor engine [2-241](#)
- loading new image [2-237](#)
- starting process [2-239](#)
- stopping rollback timer [2-235](#)

---

**J****Jumbo frames**

- enabling jumbo frames [2-301](#)

---

**L****LACP**

- deselecting channeling protocol [2-27](#)
- enabling LACP on an interface [2-27](#)
- setting channeling protocol [2-27](#)

**Layer 2**

- displaying ACL configuration [2-560](#)

**Layer 2 interface type**

- specifying a nontrunking, nontagged single VLAN interface [2-720](#)
- specifying a trunking VLAN interface [2-720](#)

**Layer 2 protocol ports**

- displaying [2-554](#)

**Layer 2 protocol tunneling error recovery** [2-248](#)**Layer 2 switching**

- enabling voice VLANs [2-713](#)
- modifying switching characteristics [2-713](#)

**Layer 2 traceroute**

- IP addresses [2-752](#)

**Layer 3 switching**

- displaying information about an adjacency table [2-412](#)
- displaying port status [2-478](#)
- displaying status of native VLAN tagging [2-478](#)

**link-status event messages****disabling**

- globally [2-252, 2-255](#)
- on an interface [2-253, 2-256](#)

**enabling**

- globally [2-252, 2-255](#)
- on an interface [2-253, 2-256](#)

**log buffer**

- show status [2-490](#)

**logging**

- controlling IP ARP packets [2-172](#)

---

**M****MAC Access Control Lists**

- See MAC ACLs

**MAC ACLs**

- defining extended MAC access list [2-258](#)
- displaying MAC ACL information [2-652](#)
- naming an ACL [2-258](#)

**MAC address filtering**

- configuring [2-267](#)
- disabling [2-267](#)
- enabling [2-267](#)

## MAC address table

- adding static entries [2-279](#)
- clearing dynamic entries [2-52, 2-54](#)
- configuring aging time [2-261](#)
- displaying dynamic table entry information [2-567](#)
- displaying entry count [2-565](#)
- displaying information [2-561](#)
- displaying interface-based information [2-569](#)
- displaying multicast information [2-571](#)
- displaying notification information [2-573](#)
- displaying protocol-based information [2-575](#)
- displaying static table entry information [2-577](#)
- displaying the MAC address aging time [2-563](#)
- displaying VLAN-based information [2-580](#)
- enabling authentication bypass [2-122](#)
- enabling notifications [2-265](#)
- learning in the protocol buckets [2-262](#)
- removing static entries [2-279](#)

## MAC address tables

- adding static entries [2-267](#)
- deleting secure or specific addresses [2-56](#)
- disabling IGMP snooping on static MAC addresses [2-267](#)
- removing static entries [2-267](#)

mac-address-table static [2-267](#)

## MAC address unicast filtering

- dropping unicast traffic [2-267](#)

## macro

- displaying descriptions [2-278](#)

## macro keywords

- help strings [2-2](#)

## macros

- adding a global description [2-278](#)
- cisco global [2-276](#)
- system-cpp [2-277](#)

mapping secondary VLANs to MST instance [2-346](#)mapping VLAN(s) to an MST instance [2-153](#)match (class-map configuration) command [2-283](#)

## maximum transmission unit (MTU)

- displaying the system MTU setting [2-643](#)
- setting the maximum Layer 2 payload size [2-745](#)

## MD5

- verifying MD5 signature [2-767](#)

## message digest 5

- See MD5

## MFIB

- clearing ip mfib counters [2-49](#)
- clearing ip mfib fastdrop [2-50](#)
- displaying all active MFIB routes [2-515](#)
- displaying MFIB fastdrop table entries [2-517](#)
- enabling IP MFIB fastdrops [2-210](#)

## MLD

- configuring snooping
  - last-listener-query-intervals [2-225](#)
- configuring snooping
  - listener-message-suppression [2-227](#)
- configuring snooping robustness-variables [2-228](#)
- configuring topology change notifications [2-230](#)
- counting snooping last-listener-queries [2-223](#)
- enabling snooping [2-221](#)
- enabling snooping on a VLAN [2-231](#)

## MLD snooping

- displaying [2-533](#)

## modes

- access-group [2-6](#)
- show access-group interface [2-411](#)
- switching between PVST+, MST, and Rapid PVST [2-684](#)
- See also command modes

module password clearing [2-36](#)

## module reset

- resetting a module by toggling the power [2-148](#)

## --More-- prompt

- filter [1-6](#)
- search [1-7](#)

**MST**

- designating the primary and secondary root [2-693](#)
- displaying MST protocol information [2-638](#)
- displaying region configuration information [2-638](#)
- displaying spanning tree information [2-638](#)
- entering MST configuration submode [2-687](#)
- setting configuration revision number [2-384](#)
- setting path cost and port priority for instances [2-685](#)
- setting the forward delay timer for all instances [2-689](#)
- setting the hello-time delay timer for all instances [2-690](#)
- setting the max-age timer for all instances [2-691](#)
- setting the MST region name [2-302](#)
- specifying the maximum number of hops [2-692](#)
- switching between PVST+ and Rapid PVST [2-684](#)
- using the MST configuration submode revision command [2-384](#)
- using the submode name command [2-302](#)

**MTU**

- displaying global MTU settings [2-643](#)

**Multicast Listener Discovery**

See MLD

**multicast**

- counters [2-64](#)
- enabling storm control [2-712](#)

**multicast/unicast packets**

- prevent forwarding [2-719](#)

**Multicast Forwarding Information Base**

See MFIB

**multiple-character patterns** [1-8](#)**Multiple Spanning Tree**

See MST

---

**N****native VLAN**

- controlling tagging of traffic [2-740](#)
- displaying ports eligible for native tagging [2-654](#)
- displaying ports eligible for tagging [2-654](#)

- enabling tagging on 802.1Q trunk ports [2-778](#)

- specifying the tagging of traffic [2-741](#)

**NetFlow**

- enabling NetFlow statistics [2-211](#)
- including infer fields in routing statistics [2-211](#)

**next-hop**

- displaying CEF VLAN information [2-492](#)

**no form of a command, using** [1-6](#)**NVRAM**

- debugging NVRAM activities [2-84](#)

---

**O****output**

- pattern searches [1-7](#)

---

**P****packet forwarding**

- prevent unknown packets [2-719](#)

**packet memory failure**

- direct switch action upon detection [2-108](#)

**packet memory test**

- bootup, displaying results [2-433](#), [2-435](#)
- ongoing, displaying results [2-437](#)

**PACL**

- access-group mode [2-6](#)

**paging prompt**

- see --More-- prompt

**PAGP**

- clearing port channel information [2-55](#)
- debugging PAGP activity [2-85](#)
- deselecting channeling protocol [2-27](#)
- displaying port channel information [2-586](#)
- hot standby mode
  - returning to defaults [2-304](#)
  - selecting ports [2-304](#)

- input interface of incoming packets
  - learning [2-303](#)
  - returning to defaults [2-303](#)
  - setting channeling protocol [2-27](#)
- parentheses [1-11](#)
- password
  - clearing on an intelligent line module [2-36](#)
  - establishing enhanced password security [2-765](#)
  - setting username [2-765](#)
- PBR
  - displaying route maps [1-xviii](#)
  - redistributing route maps [1-xviii](#)
- PM activities
  - debugging [2-88](#)
  - disabling debugging [2-88](#)
- police (percent) command [2-315](#)
- police (two rates) command [2-317](#), [2-319](#)
- police command [2-310](#)
- Policy Based Routing
  - See PBR
- policy maps
  - creating [2-323](#)
  - marking [2-394](#)
  - See also QoS, hierarchical policies
  - traffic classification
    - defining the class
    - defining trust states [2-755](#)
- port, dual-capable
  - selecting the connector [2-292](#)
- Port Aggregation Protocol
  - See PAgP
- port-based authentication
  - displaying debug messages [2-74](#)
  - displaying statistics and status [2-439](#)
  - enabling 802.1X [2-126](#)
  - host modes [2-119](#)
  - manual control of authorization state [2-126](#)
  - periodic re-authentication
    - enabling [2-129](#)
  - re-authenticating 802.1X-enabled ports [2-128](#)
  - switch-to-client frame-retransmission number [2-124](#)
- port channel
  - accessing [2-157](#)
  - creating [2-157](#)
  - displaying information [2-586](#)
  - load distribution method
    - resetting to defaults [2-325](#)
    - setting [2-325](#)
- port range
  - executing [2-158](#)
- port security
  - debugging ports security [2-89](#)
  - deleting secure or specific addresses [2-56](#)
  - displaying settings for an interface or switch [2-597](#)
  - enabling [2-725](#)
  - filter source IP and MAC addresses [2-217](#)
  - setting action upon security violation [2-725](#)
  - setting the rate limit for bad packets [2-725](#)
  - sticky port [2-725](#)
- Port Trust Device
  - displaying [2-614](#)
- power status
  - displaying inline power [2-604](#)
  - displaying power status [2-604](#)
- power supply
  - configuring combined and redundant power on the Catalyst 4507R [2-331](#)
  - configuring inline power [2-328](#)
  - configuring power consumption [2-330](#)
  - displaying the SEEPROM [2-457](#)
  - setting inline power state [2-327](#)
- priority command [2-337](#)
- priority-queue command [2-65](#)
- Private VLAN
  - See PVLANS
- privileged EXEC mode, summary [1-5](#)

- prompts
    - system [1-5](#)
  - protocol tunneling
    - configuring encapsulation rate [2-248](#)
    - disabling [2-243](#)
    - displaying port information [2-554](#)
    - enabling [2-243](#)
    - setting a CoS value for Layer 2 packets [2-245](#)
    - setting a drop threshold for Layer 2 packets [2-246](#)
  - PVLANs
    - configuring isolated, primary, and community PVLANs [2-339](#)
    - controlling tagging of native VLAN traffic [2-740](#)
    - disabling sticky-ARP [2-214](#)
    - displaying map information for VLAN SVIs [2-475](#)
    - displaying PVLAN information [2-657](#)
    - enabling interface configuration mode [2-720](#)
    - enabling sticky-ARP [2-214](#)
    - mapping VLANs to the same SVI [2-343](#)
    - specifying host ports [2-720](#)
    - specifying promiscuous ports [2-720](#)
  - PVST+
    - switching between PVST and MST [2-684](#)
- 
- Q**
- QoS
    - account Layer 2 encapsulation [2-349](#)
    - attaching a policy-map to an interface [2-385](#)
    - automatic configuration [2-18](#)
    - class maps
      - creating [2-32](#)
      - defining the match criteria [2-283](#)
    - clearing aggregate counters [2-58](#)
    - configuring auto [2-18](#)
    - defining a named aggregate policer [2-351](#)
    - defining default CoS value [2-356](#)
    - defining ingress CoS-to-DSCP mapping [2-361](#)
    - displaying aggregate policer information [2-612](#)
    - displaying auto configuration [2-416](#)
    - displaying class maps information [2-425](#)
    - displaying configuration information [2-416](#)
    - displaying configurations of policies [2-592](#)
    - displaying policy map information [2-588, 2-595](#)
    - displaying QoS information [2-611](#)
    - displaying QoS map information [2-616](#)
    - egress queue-sets
      - enabling the priority queue [2-65](#)
    - enabling global configuration mode [2-347](#)
    - enabling on control packets [2-354](#)
    - enabling per-VLAN QoS for a Layer 2 interface [2-370](#)
    - enabling QoS on an interface [2-348](#)
    - hierarchical policies
      - average-rate traffic shaping on a class [2-407](#)
      - bandwidth allocation for a class [2-22, 2-31](#)
      - creating a service policy [2-388](#)
      - marking [2-394](#)
      - strict priority queueing (LLQ) [2-337](#)
    - mapping DSCP values to transmit queues [2-363](#)
    - mapping egress DSCP-to-CoS [2-363](#)
    - mapping the DSCP-to-CoS value [2-363](#)
    - policy maps
      - creating [2-323](#)
      - marking [2-394](#)
      - traffic classifications
      - trust states [2-755](#)
    - setting the mapping of policed DSCP values [2-365](#)
    - setting the trust state [2-368](#)
    - specifying flow-based match criteria [2-286](#)
  - Supervisor Engine 6-E
    - setting CoS [2-396](#)
    - setting DSCP [2-399](#)
    - setting precedence values [2-402](#)
    - setting QoS group identifiers [2-405](#)

## QoS CoS

- configuring for tunneled Layer 2 protocol packets [2-245](#)
- defining default CoS value [2-356](#)

qos dbl [2-357](#)

## quality of service

See QoS

question command [1-1](#)

## queueing information

displaying [2-614](#)

## queue limiting

configuring packet limits [2-372](#)

---

**R**

## Rapid PVST

switching between PVST and MST [2-684](#)

re-authenticating 802.1X-enabled ports [2-128](#)

## re-authentication

- periodic [2-129](#)
- set the time [2-131](#)

## reboots

restoring bindings across [2-178](#)

## redundancy

- accessing the main CPU [2-374](#)
- changing from active to standby supervisor engine [2-378](#)
- displaying information [2-618](#)
- displaying ISSU config-sync failure information [2-622](#)
- displaying redundancy facility information [2-618](#)
- displaying RF client list [2-618](#)
- displaying RF operational counters [2-618](#)
- displaying RF states [2-618](#)
- enabling automatic synchronization [2-21](#)
- forcing switchover to standby supervisor engine [2-378](#)
- mismatched command listing [2-376](#)
- set the mode [2-293](#)

- synchronizing the route processor configurations [2-279](#)

related documentation [1-xvii](#)

## remote SPAN

See RSPAN

## renew commands

- ip dhcp snooping database [2-382](#)

## resetting PVLAN trunk

- setting switchport to trunk [2-720](#)

rj45 connector, selecting the connector [2-292](#)

## ROM monitor mode

- summary [1-6](#)

## Route Processor Redundancy

See redundancy

## RPF

- disabling IPv4 exists-only checks [2-219](#)
- enabling IPv4 exists-only checks [2-219](#)

## RPR

- set the redundancy mode [2-293](#)

## RSPAN

- converting VLAN to RSPAN VLAN [2-381](#)
- displaying list [2-659](#)

---

**S**

saving configuration changes [1-11](#)

secure address, configuring [2-333](#)

secure ports, limitations [2-726](#)

service-policy command (policy-map class) [2-388](#)

- set the redundancy mode [2-293](#)

sfp connector, selecting the connector [2-292](#)

shape command [2-407](#)

## show commands

- filtering parameters [1-7](#)
- searching and filtering [1-6](#)
- show platform commands [1-11](#)

## Simple Network Management Protocol

See SNMP

- single-character patterns
  - special characters [1-7](#)
- slaveslot0
  - displaying information on the standby supervisor [2-629](#)
- slot0
  - displaying information about the system [2-631](#)
- SNMP
  - debugging spanning tree activities [2-91](#)
  - ifIndex persistence
    - clearing SNMP ifIndex commands [2-665](#)
    - compress SNMP ifIndex table format [2-672](#)
    - disabling globally [2-671](#)
    - disabling on an interface [2-667](#)
    - enabling globally [2-671](#)
    - enabling on an interface [2-667](#)
  - informs
    - disabling [2-669](#)
    - enabling [2-669](#)
  - traps
    - configuring to send when storm occurs [2-710](#)
    - disabling [2-669](#)
    - enabling [2-669](#)
    - mac-notification
      - adding [2-673](#)
      - removing [2-673](#)
- SPAN commands
  - configuring a SPAN session to monitor [2-295](#)
  - displaying SPAN session information [2-642, 2-711](#)
- SPAN enhancements
  - displaying status [2-584](#)
- Spanning Tree Protocol
  - See STP
- SPAN session
  - displaying session information [2-584](#)
  - filter ACLs [2-295](#)
  - specify encap type [2-295](#)
  - turn off host learning based on ingress packets [2-295](#)
- special characters
  - anchoring, table [1-10](#)
- SSO [2-293](#)
- standard desktop
  - enabling Cisco-recommended features [2-268](#)
- standard desktop and Cisco IP phone
  - enabling Cisco-recommended features [2-270](#)
- sticky address, configuring [2-334](#)
- sticky-ARP
  - disabling on PVLANS [2-214](#)
  - enabling on PVLANS [2-214](#)
- sticky port
  - deleting [2-56](#)
  - enabling security [2-725](#)
- storm control
  - configuring for action when storm occurs [2-710](#)
  - disabling suppression mode [2-446](#)
  - displaying settings [2-641](#)
  - enabling [2-710](#)
  - enabling broadcast [2-710, 2-712](#)
  - enabling multicast [2-710, 2-712](#)
  - enabling suppression mode [2-446](#)
  - enabling timer to recover from error disable [2-140](#)
  - enabling unicast [2-710, 2-712](#)
  - multicast, enabling [2-712](#)
  - setting high and low levels [2-710](#)
  - setting suppression level [2-446](#)
- STP
  - configuring link type for a port [2-682](#)
  - configuring tunneling encapsulation rate [2-248](#)
  - debugging all activities [2-91](#)
  - debugging spanning tree activities [2-91](#)
  - debugging spanning tree BackboneFast events [2-93](#)
  - debugging spanning tree UplinkFast [2-96](#)
  - detecting misconfiguration [2-679](#)
  - displaying active interfaces only [2-633](#)
  - displaying BackboneFast status [2-633](#)
  - displaying bridge status and configuration [2-633](#)
  - displaying spanning tree debug messages [2-91](#)

- displaying summary of interface information [2-633](#)
- enabling BPDU filtering by default on all PortFast ports [2-698](#)
- enabling BPDU filtering on an interface [2-675](#)
- enabling BPDU guard by default on all PortFast ports [2-700](#)
- enabling BPDU guard on an interface [2-677](#)
- enabling extended system ID [2-680](#)
- enabling loop guard as a default on all ports [2-683](#)
- enabling PortFast by default on all access ports [2-701](#)
- enabling PortFast mode [2-696](#)
- enabling protocol tunneling for [2-243](#)
- enabling root guard [2-681](#)
- enabling spanning tree BackboneFast [2-674](#)
- enabling spanning tree on a per VLAN basis [2-705](#)
- enabling spanning tree UplinkFast [2-703](#)
- setting an interface priority [2-702](#)
- setting drop threshold for [2-246](#)
- setting pathcost [2-678](#)
- setting the default pathcost calculation method [2-695](#)
- subinterface configuration mode, summary [1-6](#)
- SVI
  - creating a Layer 3 interface on a VLAN [2-160](#)
- switching characteristics
  - excluding from link-up calculation [2-717](#)
  - modifying [2-717](#)
  - returning to interfaces
    - capture function [2-717](#)
- switchport [2-741](#)
- switchport interfaces
  - displaying status of Layer 3 port [2-478](#)
  - displaying status of native VLAN tagging [2-478](#)
- switch shim
  - debugging [2-94](#)
  - disabling debugging [2-94](#)
- switch to router connection
  - enabling Cisco-recommended features [2-272](#)

- switch to switch connection
  - enabling Cisco-recommended features [2-274](#)
- switch virtual interface
  - See SVI
- sw-vlan [2-97](#)
- system prompts [1-5](#)

---

## T

- Tab key
  - command completion [1-1](#)
- tables
  - characters with special meaning [1-7](#)
  - mac access-list extended subcommands [2-258](#)
  - multipliers [1-9](#)
  - relationship between duplex and speed commands [2-708](#)
  - show cable-diagnostics tdr command output fields [2-421](#)
  - show cdp neighbors detail field descriptions [2-424](#)
  - show cdp neighbors field descriptions [2-423](#)
  - show ip interface field descriptions [2-513](#)
  - show policy-map control-plane field descriptions [2-591](#)
  - show vlan command output fields [2-658](#)
  - show vtp command output fields [2-663](#)
  - special characters [1-9](#)
  - special characters used for anchoring [1-10](#)
  - speed command options [2-286, 2-708](#)
  - valid interface types [2-155](#)
- TAC
  - displaying information useful to TAC [2-644](#)
- TCAM
  - debugging spanning tree activities [2-91](#)
- TDR
  - displaying cable diagnostic test results [2-420](#)
  - test condition of copper cables [2-747](#)
- temperature readings
  - displaying information [2-443](#)



Ten-Gigabit Ethernet uplink

- blocking ports on redundant Supervisor Engine 6-E [2-149](#)

timer information [2-447](#)

traffic shaping

- enable on an interface [2-409](#)

traps, enabling [2-669](#)

trunk encapsulation

- setting format [2-741](#)

trunk interfaces

- displaying trunk interfaces information [2-485](#)

trust state

- setting [2-167](#)

tunnel ports

- displaying information about Layer 2 protocol [2-554](#)

TX queues

- allocating bandwidth [2-757](#)
- returning to default values [2-757](#)
- setting priority to high [2-757](#)
- specifying burst size [2-757](#)
- specifying traffic rate [2-757](#)

---

## U

### UDLD

- displaying administrative and operational status [2-646](#)
- enabling by default on all fiber interfaces [2-759](#)
- enabling on an individual interface [2-761](#)
- preventing a fiber interface from being enabled [2-761](#)
- resetting all shutdown ports [2-763](#)
- setting the message timer [2-759](#)

### unicast

- counters [2-64](#)

### Unidirectional Link Detection

See UDLD

unknown multicast traffic, preventing [2-719](#)

unknown unicast traffic, preventing [2-719](#)

user EXEC mode, summary [1-5](#)

### username

- setting password and privilege level [2-765](#)

---

## V

### VACLs

- access-group mode [2-6](#)
- applying VLAN access maps [2-780](#)
- displaying VLAN access map information [2-652](#)
- specifying an action in a VLAN access map [2-13](#)
- specifying the match clause for a VLAN access-map sequence [2-281](#)
- using a VLAN filter [2-780](#)

### VLAN

- applying an ARP ACL [2-161](#)
- configuring [2-769](#)
- configuring service policies [2-774](#)
- converting to RSPAN VLAN [2-381](#)
- displaying CEF information [2-492](#)
- displaying CEF next-hop information [2-492](#)
- displaying information on switch interfaces [2-503, 2-507](#)
- displaying information on VLAN switch interfaces [2-510](#)
- displaying information sorted by group IP address [2-503, 2-507](#)
- displaying IP address and version information [2-503, 2-507](#)
- displaying Layer 2 VLAN information [2-648](#)
- displaying statistical information [2-582](#)
- displaying VLAN information [2-650](#)
- enabling dynamic ARP inspection [2-170](#)
- enabling Explicit Host Tracking [2-201](#)
- enabling guest per-port [2-117](#)
- enabling guest VLAN supplicant [2-110, 2-118](#)
- entering VLAN configuration mode [2-774, 2-776](#)
- native frames
  - enabling tagging on all 802.1Q trunk ports [2-778](#)
- pruning the list for VTP [2-741](#)
- setting the list of allowed [2-741](#)

## VLAN Access Control Lists

- See VACLs

## VLAN access map

- See VACLs

## VLAN database

- resetting [2-383](#)

## VLAN debugging

- limiting output [2-72](#)

## VLAN link-up calculation

- excluding a switch port [2-717](#)

- including a switch port [2-717](#)

## VLAN manager

- debugging [2-97](#)

- disabling debugging [2-97](#)

- IOS file system error tests

- debugging [2-98](#)

- disabling debugging [2-98](#)

## VLAN Query Protocol

- See VQP

## VLAN query protocol (VQPC)

- debugging [2-104](#)

## VLANs

- clearing

- counters [2-60](#)

- clearing hardware logic [2-38](#)

- configuring

- internal allocation scheme [2-781](#)

- displaying

- internal VLAN allocation information [2-655](#)

- RSPAN VLANs [2-659](#)

- entering VLAN configuration mode [2-776](#)

## VMPS

- configuring servers [2-785](#)

- reconfirming dynamic VLAN assignments [2-104](#), [2-783](#)

## voice VLANs

- enabling [2-713](#)

## VoIP

- configuring auto-QoS [2-18](#)

## VQP

- per-server retry count [2-784](#)

- reconfirming dynamic VLAN assignments [2-104](#), [2-783](#)

## VTP

- configuring the administrative domain name [2-789](#)

- configuring the device in VTP client mode [2-788](#)

- configuring the device in VTP server mode [2-792](#)

- configuring the device in VTP transparent mode [2-793](#)

- configuring tunnel encapsulation rate [2-248](#)

- creating a VTP domain password [2-790](#)

- displaying domain information [2-662](#)

- displaying statistics information [2-662](#)

- enabling protocol tunneling for [2-243](#)

- enabling pruning in the VLAN database [2-791](#)

- enabling VTP version 2 mode [2-794](#)

- modifying the VTP configuration storage file name [2-787](#)

- set drop threshold for [2-246](#)

## VTP protocol code

- activating debug messages [2-101](#)

- deactivating debug messages [2-101](#)