



## Preface

---

This preface describes the organization and conventions of the *Cisco UCS Server Configuration Utility, Release 1.0*. It also provides information on how to obtain related documentation and submit a service request.

## Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in server, storage, and network administration and network security.

## Organization

This guide is organized as follows:

Chapter	Title	Description
Chapter 1	<a href="#">Introduction to Cisco UCS-Server Configuration Utility</a>	Provides an introduction to the utility and the features it provides.
Chapter 2	<a href="#">Getting Started with UCS-Server Configuration Utility</a>	Contains information on getting started with the utility.
Chapter 3	<a href="#">Using UCS-Server Configuration Utility</a>	Contains detailed instructions on using the utility.

## Related Documentation

The documentation set for the Cisco Unified Computing System (UCS) C-Series rack-mount servers is described in the roadmap document at the following link:

[Cisco UCS C-Series Documentation Roadmap](#)

***Send document comments to [ucs-docfeedback@cisco.com](mailto:ucs-docfeedback@cisco.com)***

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.