



ACS Group-of-Objects Configuration Mode Commands

The ACS Group-of-Objects Configuration Mode is used to configure groups of Active Charging Service (ACS) objects.



Important This configuration mode is available only in 10.2 and later releases.

Command Modes

Exec > ACS Configuration > ACS Group-of-Objects Configuration

active-charging service *service_name* > **group-of-objects** *object_name* [**type string**]

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-acs-group-of-objects) #
```



Important The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [end, on page 1](#)
- [exit, on page 2](#)
- [member-object, on page 2](#)

end

Exits the current configuration mode and returns to the Exec mode.

Product All

Privilege Security Administrator, Administrator

Syntax Description **end**

Usage Guidelines Use this command to return to the Exec mode.

exit

Exits the current mode and returns to the parent configuration mode.

Product	All
Privilege	Security Administrator, Administrator
Syntax Description	exit
Usage Guidelines	Use this command to return to the parent configuration mode.

member-object

This command allows you to add or remove objects from the current group-of-objects.



Important A maximum of 128 objects can be added to a group-of-objects.

Product	ACS
Privilege	Security Administrator, Administrator
Command Modes	Exec > ACS Configuration > ACS Group-of-Objects Configuration active-charging service <i>service_name</i> > group-of-objects <i>object_name</i> [type string] Entering the above command sequence results in the following prompt: <pre>[local]host_name(config-acs-group-of-objects)#</pre>
Syntax Description	[no] member-object <i>object</i> no If previously added, removes the specified member object from the current group-of-objects. object Specifies the member object to add to or remove from the current group-of-objects. <i>object</i> must be an alpha and/or numeric string of 1 through 63 characters.
Usage Guidelines	Use this command to add or remove member objects from a group-of-objects.

Example

The following command adds the object *test* to the current group-of-objects:

```
member-object test
```