



Gateway Selection Profile Configuration Mode Commands

Command Modes Exec > Global Configuration > Gateway Selection Profile Configuration

configure > **gateway-selection-profile** *profile_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(gw-profile-profile_name)#
```



Important Available commands or keywords/variables vary based on platform type, product version, and installed license(s).

- [description, on page 1](#)
- [do show, on page 2](#)
- [end, on page 2](#)
- [exit, on page 3](#)
- [zone, on page 3](#)

description

Product ePDG

Privilege Security Administrator, Administrator

Command Modes Exec > Global Configuration > Gateway Selection Profile Configuration

configure > **gateway-selection-profile** *profile_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(gw-profile-profile_name)#
```

Syntax Description **description** *descriptive_string*

remove description

remove

descriptive_string

descriptive_string must be an alphanumeric string from 1 to 100 characters.

Usage Guidelines

Use this command to

Example

Use the following command to

do show

Executes all **show** commands while in Configuration mode.

Product

All

Privilege

Security Administrator, Administrator

Syntax Description

do show

Usage Guidelines

Use this command to run all Exec mode **show** commands while in Configuration mode. It is not necessary to exit the Config mode to run a **show** command.

The pipe character | is only available if the command is valid in the Exec mode.



Caution

There are some Exec mode **show** commands which are too resource intensive to run from Config mode. These include: **do show support collection**, **do show support details**, **do show support record** and **do show support summary**. If there is a restriction on a specific **show** command, the following error message is displayed:

```
Failure: Cannot execute 'do show support' command from Config mode.
```

end

Exits the current configuration mode and returns to the Exec mode.

Product

All

Privilege

Security Administrator, Administrator

Syntax Description

end

Usage Guidelines

Use this command to return to the Exec mode.

exit

Exits the current mode and returns to the parent configuration mode.

Product	All
Privilege	Security Administrator, Administrator
Syntax Description	exit
Usage Guidelines	Use this command to return to the parent configuration mode.

zone

Product	ePDG
Privilege	Security Administrator, Administrator
Command Modes	Exec > Global Configuration > Gateway Selection Profile Configuration configure > gateway-selection-profile <i>profile_name</i> Entering the above command sequence results in the following prompt: <pre>[local]host_name(gw-profile-profile_name)#</pre>
Syntax Description	zone <i>zone_fqdn</i> action { ignore mandatory } remove zone <i>zone_fqdn</i> remove zone_fqdn <i>zone_fqdn</i> must be an alphanumeric string from 1 to 255 characters. action { ignore mandatory }
Usage Guidelines	Use this command to

Example

Use the following command to

zone