



## FIPS Certification

---

- [FIPS Certification, on page 1](#)
- [Enable or Disable FIPS Mode using CLI, on page 1](#)
- [Verify FIPS Mode using CLI, on page 1](#)

## FIPS Certification

The Federal Information Processing Standard (FIPS) mode ensures that the SSH and GUI functionalities are in compliance with FIPS140-3 security standards from NIST. When FIPS is enabled, the AP ensures that the configuration is compliant with FIPS requirements.



---

**Note** FIPS certification does not support SNMP.

---

## Enable or Disable FIPS Mode using CLI

---

**Step 1** Device#configure fips {enable|disable}  
**Step 2** Device#write  
**Step 3** Device#reload

---

## Verify FIPS Mode using CLI

Use this command to verify FIPS mode on the AP.

```
Device#show fips  
FIPS: enabled
```

