



## Data Source

---

- [Configuring Location Data Source, on page 1](#)

## Configuring Location Data Source

### Configuring Location Data Source

You can configure any of the following as a source for location data:

- Cisco Spaces Connector Configuration. Refer to [Cisco DNA Spaces Connector Configuration Guide](#)
- Cisco AireOS Wireless Controller configuration: You can configure the Detect and Locate using wireless controller as data source. For more information, see [Configuring Cisco Wireless Controllers and Cisco Catalyst 9800 Series Controllers for Cisco DNA Spaces](#)
- Cisco CMX tethering: With the Cisco CMX as a data source, location computation for wireless devices is calculated using Cisco CMX. Cisco Spaces: Detect and Locate displays wireless clients and tags.

