

# Resolución de problemas de hardware para cablemódems serie Cisco uBR9xx de Cisco

## Contenido

[Introducción](#)

[Prerequisites](#)

[Requirements](#)

[Componentes Utilizados](#)

[Convenciones](#)

[Diagrama de flujo de resolución de problemas](#)

[Información Relacionada](#)

## [Introducción](#)

Este documento proporciona información de troubleshooting para fallas de hardware comunes con cablemódems de la serie Cisco uBR9xx, y proporciona maneras de resolver esos errores. El diagrama de flujo enumera los síntomas más comunes encontrados por los cablemódems de la serie uBR9xx de Cisco.

## [Prerequisites](#)

## [Requirements](#)

No hay requisitos específicos para este documento.

## [Componentes Utilizados](#)

Este documento no tiene restricciones específicas en cuanto a versiones de software y de hardware.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

## [Convenciones](#)

Consulte [Convenciones de Consejos Técnicos Cisco para obtener más información sobre las convenciones del documento.](#)

## [Diagrama de flujo de resolución de problemas](#)

