

零接触调配实施和故障排除提示

目录

[简介](#)

[背景信息](#)

[Linux服务器配置](#)

[DHCP 配置](#)

[HTTP服务器要求](#)

[故障排除提示](#)

[使路由器能通过DHCP获取IP地址](#)

[验证HTTP服务器是否正常工作](#)

[如何启动ZTP?](#)

[手动启动ZTP](#)

[使用iPXE启动路由器](#)

[安装后自动化](#)

[相关信息](#)

简介

本文档介绍首次部署零接触调配(ZTP)的故障排除提示。

ZTP的引入是为了在提供XR设备时减少人与人之间的交互。ZTP使用预引导执行环境(iPXE)的实现。

背景信息

ZTP可以执行：

- 自动配置更新：映像安装后下载并应用XR配置
- 脚本执行：下载并执行用户定义的脚本文件。各种方法/功能可作为脚本执行的一部分实现：多个包更新SMU安装验证eXR根据文件中第一行的内容确定要执行的操作 如果文件以`!!IOS XR`表示配置文件并执行`apply_config`。同样，以`#`开头的文件！`/bin/bash`或`#!/bin/sh`或`#!/usr/bin/python`表示脚本文件，并执行脚本执行。eXR 6.2.2引入了对python的支持eXR iPXE支持简单文件传输协议(TFTP)、文件传输协议(FTP)和超文本传输协议(HTTP)。不支持超文本传输协议安全(HTTPS)，因为它无法预测要验证的签名。

Linux服务器配置

iPXE是PXE上的一项增强功能，需要TFTP/FTP/HTTP才能下载映像/配置，并使用动态主机配置协议(DHCP)获取/提供映像和配置信息。

DHCP 配置

在后面的示例中，将回顾数据包捕获，以确认DHCP操作。

HTTP服务器要求

必须能从管理以太网接口访问HTTP服务器。

故障排除提示

设置Linux服务器后，请执行DHCP/HTTP服务器可达性和功能检查。

在此设置中，单个Linux服务器用作DHCP/HTTP服务器。如果这些功能有单独的服务器，请根据需要在所有服务器上验证这些步骤。

```
[root@xxxxxxxxxx]# service dhcpd status
Redirecting to /bin/systemctl status dhcpd.service
dhcpd.service - DHCPv4 Server Daemon
   Loaded: loaded (/usr/lib/systemd/system/dhcpd.service; disabled; vendor preset: disabled)
   Active: active (running) since Mon 2017-05-29 10:30:59 PDT; 15h ago
     Docs: man:dhcpd(8)
           man:dhcpd.conf(5)
    Main PID: 26913 (dhcpd)
   Status: "Dispatching packets..."
    CGroup: /system.slice/dhcpd.service
           26913 /usr/sbin/dhcpd -f -cf /etc/dhcp/dhcpd.conf -user dhcpd -group dhcpd --no-pid
<SNIP>
```

提示：有些线是椭圆的，使用 — | 全显示。

```
[root@xxxxxxxxxx]# service httpd status
Redirecting to /bin/systemctl status httpd.service
httpd.service - The Apache HTTP Server
   Loaded: loaded (/usr/lib/systemd/system/httpd.service; disabled; vendor preset: disabled)
   Active: active (running) since Fri 2017-05-26 05:50:30 PDT; 3 days ago
     Docs: man:httpd(8)
           man:apachectl(8)
  Process: 28088 ExecStop=/bin/kill -WINCH ${MAINPID} (code=exited, status=0/SUCCESS)
  Process: 11036 ExecReload=/usr/sbin/httpd $OPTIONS -k graceful (code=exited, status=0/SUCCESS)
    Main PID: 28095 (httpd)
   Status: "Total requests: 0; Current requests/sec: 0; Current traffic: 0 B/sec"
    CGroup: /system.slice/httpd.service
           11037 /usr/sbin/httpd -DFOREGROUND
           11038 /usr/sbin/httpd -DFOREGROUND
           11039 /usr/sbin/httpd -DFOREGROUND
           11040 /usr/sbin/httpd -DFOREGROUND
           11041 /usr/sbin/httpd -DFOREGROUND
           26998 /usr/sbin/httpd -DFOREGROUND
           27426 /usr/sbin/httpd -DFOREGROUND
           27427 /usr/sbin/httpd -DFOREGROUND
           27428 /usr/sbin/httpd -DFOREGROUND
           27889 /usr/sbin/httpd -DFOREGROUND
           28095 /usr/sbin/httpd -DFOREGROUND

May 26 05:50:30 xxxxxx systemd[1]: Starting The Apache HTTP Server...
May 26 05:50:30 xxxxxx systemd[1]: Started The Apache HTTP Server.
May 27 03:16:01 xxxxxx systemd[1]: Reloaded The Apache HTTP Server.
May 28 03:37:01 xxxxxx systemd[1]: Reloaded The Apache HTTP Server.
```

使路由器能通过DHCP获取IP地址

```
Interface MgmtEth 0/RP0/CPU0/0
Ipv4 address dhcp
Shut/no shut
```

验证HTTP服务器是否正常工作

- 测试<http://<ip-servername>>是否有效。
- 打开指向IP地址/服务器名称的浏览器。

如果DHCP或HTTP无法工作，则可能存在防火墙问题或可达性问题。

要检查服务器上的防火墙属性，请执行以下命令或添加特定协议：

使用IP表命令验证防火墙规则：

```
Iptables -L -n
Chain IN_public_allow (1 references)
target      prot opt source                destination           udp dpt:67 ctstate NEW
ACCEPT      udp  --  0.0.0.0/0              0.0.0.0/0            tcp dpt:80 ctstate NEW
ACCEPT      tcp  --  0.0.0.0/0              0.0.0.0/0            tcp dpt:22 ctstate NEW
```

使用此firewall命令列出允许的条目：

```
[root@xxxxxxxxxx ~]# firewall-cmd --list-all
public (active)
  target: default
  icmp-block-inversion: no
  interfaces: enp2s0f0
  sources:
  services: dhcp dhcpv6-client http ssh
  ports:
  protocols:
  masquerade: no
  forward-ports:
  sourceports:
  icmp-blocks:
  rich rules:
```

使用命令永久允许端口：

```
firewall-cmd --permanent --add-service=http
firewall-cmd --permanent --add-service=dhcp
```

在DHCP服务器上启用数据包捕获：

```
tcpdump -i <interface id> port (bootpc & bootps & port http) -s 0(buffer size) -w <dest. File name>
```

```
ex: tcpdump -i enp2s0f0 port 67 or port 68 or port 80 -s 0 -w iPXboot.pcap
```

如何启动ZTP?

手动启动ZTP

使用ZTP `initiate exec` CLI命令调用ZTP。默认情况下，用于ZTP的接口为MGMTeth。要在其他接

口上启动此进程，请使用以下选项：

```
ZTP initiate interface <type> <number> <cr>
```

或者

```
Ztp initiate <cr>
```

使用iPXE启动路由器

1.从卡尔瓦多斯启动reload CLI命令：

此命令导致路由器重新加载，从而启动iPXE引导。

注意：由于Wireshark中存在Bug，用户类信息被解释为格式错误的选项。

2.路由器启动DHCP发现，注意用户类已填充iPXE选项：

```
43 2017-05-26 04:55:24.207214 172.16.58.212 172.16.58.212 DHCP 342 DHCP Offer - Transaction ID 0xf2e1f250
44 2017-05-26 04:55:24.208101 172.16.58.212 172.16.58.212 DHCP 342 DHCP ACK - Transaction ID 0xf2e1f250
45 2017-05-26 04:56:09.890179 0.0.0.0 255.255.255.255 DHCP 449 DHCP Discover - Transaction ID 0x97c7ee55
  Instance of User Class: [0]
    User Class Length: 105
    [Expert Info (Error/Protocol): User Class Information: malformed option]
      [User Class Information: malformed option]
      [Severity level: Error]
      [Group: Protocol]
  Option: (55) Parameter Request List
    Length: 22
    Parameter Request List Item: (1) Subnet Mask
    Parameter Request List Item: (3) Router
    Parameter Request List Item: (6) Domain Name Server
    Parameter Request List Item: (7) Log Server
    Parameter Request List Item: (12) Host Name
    Parameter Request List Item: (15) Domain Name
    Parameter Request List Item: (17) Root Path
    Parameter Request List Item: (43) Vendor-Specific Information
    Parameter Request List Item: (60) Vendor class identifier
    Parameter Request List Item: (66) TFTP Server Name
    Parameter Request List Item: (67) Bootfile name
    Parameter Request List Item: (119) Domain Search
    Parameter Request List Item: (128) DOCSIS full security server IP [T0D0]
00e0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00f0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0100 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0110 00 00 00 00 00 00 63 82 53 63 35 01 01 39 02 05 .....C. Sc5..9..
0120 c0 5d 02 00 09 5e 03 01 03 0a 4d 04 69 50 58 45 .]...^...M.iPXE
0130 37 16 01 03 06 07 0c 0f 11 2b 3c 42 43 77 80 81 7.....+<BCw..
0140 82 83 84 85 86 87 af cb af 24 b1 05 01 80 86 15 .....$......
0150 21 eb 03 01 00 00 17 01 01 24 01 01 13 01 01 2a !.....$.....*
0160 01 01 27 01 01 20 01 01 15 01 01 26 01 01 3d 0b .....&..=.
0170 46 4f 43 32 30 32 36 52 33 38 5a 3c 30 50 58 45 FOC2026R 38Z<0PXE
0180 43 6c 69 65 6e 74 3a 41 72 63 68 3a 30 30 30 30 Client:A rch:0000
0190 39 3a 55 4e 44 49 3a 30 30 33 30 31 30 3a 50 49 9:UNDI:0 03010:PI
01a0 44 3a 4e 43 53 2d 35 35 30 32 2d 53 45 61 11 00 D:NCS-55 02-SEa..
01b0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
01c0 ff
```

3.服务器的DHCP提供包括选项67中的启动文件名：

No.	Time	Source	Destination	Protocol	Length	Info
46	2017-05-26 04:56:09.890388	172.16.58.115	172.16.58.110	DHCP	342	DHCP Offer - Transaction ID 0x97c7ee55
47	2017-05-26 04:56:10.889556	0.0.0.0	255.255.255...	DHCP	449	DHCP Discover - Transaction ID 0x97c7ee55
48	2017-05-26 04:56:10.889765	172.16.58.115	172.16.58.110	DHCP	342	DHCP Offer - Transaction ID 0x97c7ee55

```

Hardware type: Ethernet (0x01)
Hardware address length: 6
Hops: 0
Transaction ID: 0x97c7ee55
Seconds elapsed: 4
▶ Bootp flags: 0x0000 (Unicast)
Client IP address: 0.0.0.0
Your (client) IP address: 172.16.58.110
Next server IP address: 0.0.0.0
Relay agent IP address: 0.0.0.0
Client MAC address: Cisco_1c:a5:1a (00:62:ec:1c:a5:1a)
Client hardware address padding: 00000000000000000000
Server host name not given
Boot file name: http://172.16.58.115/images/ncs5500-mini-x.iso-6.1.2
Magic cookie: DHCP
▶ Option: (53) DHCP Message Type (Offer)
▶ Option: (54) DHCP Server Identifier
▶ Option: (51) IP Address Lease Time
▶ Option: (1) Subnet Mask
▶ Option: (3) Router
▶ Option: (6) Domain Name Server

```

```

0000 00 62 ec 1c a5 1a cc 46 d6 f8 8f 86 08 00 45 10 .b.....F.....E.
0010 01 48 00 00 00 00 80 11 6c 93 ac 10 3a 73 ac 10 .H.....l...:s..
0020 3a 6e 00 43 00 44 01 34 5d 97 02 01 06 00 97 c7 :n.C.D.4 }.....
0030 ee 55 00 04 00 00 00 00 00 00 ac 10 3a 6e 00 00 .U.....:n..
0040 00 00 00 00 00 00 00 62 ec 1c a5 1a 00 00 00 00 .....b.....
0050 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0060 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0070 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0080 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0090 00 00 00 00 00 00 68 74 74 70 3a 2f 2f 31 37 32 .....ht tp://172
00a0 2e 31 36 2e 35 38 2e 31 31 35 2f 69 6d 61 67 65 .16.58.1 15/image
00b0 73 2f 6e 63 73 35 35 30 30 2d 6d 69 6e 69 2d 78 s/ncs550 0-mini-x
00c0 2e 69 73 6f 2d 36 2e 31 2e 32 00 00 00 00 00 .iso-6.1 .2.....
00d0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00e0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....

```

DHCP Server -> NCS5K

Server responds with Boot file information

4. 路由器启动映像下载：

No.	Time	Source	Destination	Protocol	Length	Info
46	2017-05-26 04:56:09.890388	172.16.58.115	172.16.58.110	DHCP	342	DHCP Offer - Transaction ID 0x97c7ee55
47	2017-05-26 04:56:10.889556	0.0.0.0	255.255.255...	DHCP	449	DHCP Discover - Transaction ID 0x97c7ee55
48	2017-05-26 04:56:10.889765	172.16.58.115	172.16.58.110	DHCP	342	DHCP Offer - Transaction ID 0x97c7ee55
49	2017-05-26 04:56:12.888299	0.0.0.0	255.255.255...	DHCP	461	DHCP Request - Transaction ID 0x97c7ee55
50	2017-05-26 04:56:12.888506	172.16.58.115	172.16.58.110	DHCP	342	DHCP ACK - Transaction ID 0x97c7ee55
51	2017-05-26 04:56:25.659940	172.16.58.110	172.16.58.115	TCP	74	36332 -> 80 [SYN] Seq=0 Win=65532 Len=0 TSval=36...
52	2017-05-26 04:56:25.660031	172.16.58.115	172.16.58.110	TCP	74	80 -> 36332 [SYN, ACK] Seq=0 Ack=1 Win=28960 Len...
53	2017-05-26 04:56:25.660153	172.16.58.110	172.16.58.115	HTTP	168	GET /images/ncs5500-mini-x.iso-6.1.2 HTTP/1.1
54	2017-05-26 04:56:25.660206	172.16.58.115	172.16.58.110	TCP	66	80 -> 36332 [ACK] Seq=1 Ack=103 Win=29056 Len=0 ...
55	2017-05-26 04:56:25.661660	172.16.58.115	172.16.58.110	TCP	14546	[TCP segment of a reassembled PDU]
56	2017-05-26 04:56:25.661864	172.16.58.110	172.16.58.115	TCP	66	36332 -> 80 [ACK] Seq=103 Ack=4345 Win=262144 Le...
57	2017-05-26 04:56:25.661918	172.16.58.115	172.16.58.110	TCP	8754	[TCP segment of a reassembled PDU]

```

▶ Frame 53: 168 bytes on wire (1344 bits), 168 bytes captured (1344 bits)
▶ Ethernet II, Src: Cisco_1c:a5:1a (00:62:ec:1c:a5:1a), Dst: Cisco_f8:8f:86 (cc:46:d6:f8:8f:86)
▶ Internet Protocol Version 4, Src: 172.16.58.110, Dst: 172.16.58.115
▼ Transmission Control Protocol, Src Port: 36332, Dst Port: 80, Seq: 1, Ack: 1, Len: 102
  Source Port: 36332
  Destination Port: 80
  [Stream index: 0]
  [TCP Segment Len: 102]
  Sequence number: 1 (relative sequence number)
  [Next sequence number: 103 (relative sequence number)]
  Acknowledgment number: 1 (relative ack number)
  Header Length: 32 bytes
  Flags: 0x018 (PSH, ACK)

```

```

0000 cc 46 d6 f8 8f 86 00 62 ec 1c a5 1a 08 00 45 00 .F.....b.....E.
0010 00 9a 09 b3 00 00 40 06 a3 a9 ac 10 3a 6e ac 10 .....@.....:n..
0020 3a 73 8d ec 00 50 30 83 ab 5e 7a d3 a4 16 80 18 :s...P0. ^z.....
0030 02 00 25 b4 00 00 01 01 08 0a 02 25 c3 af 94 c7 %.....%.....
0040 56 00 47 45 54 20 2f 69 6d 61 67 65 73 2f 6e 63 %.GET /i mages/nc
0050 73 35 35 30 30 2d 6d 69 6e 69 2d 78 2e 69 73 6f s5500-mi ni-x.iso
0060 2d 36 2e 31 2e 32 20 48 54 54 50 2f 31 2e 31 0d -6.1.2 H TTP/1.1.
0070 0a 55 73 65 72 2d 41 67 65 6e 74 3a 20 69 50 58 .User-Ag ent: iPX
0080 45 2f 31 2e 30 2e 30 2b 20 28 65 32 39 31 29 0d E/1.0.0+ (e291).
0090 0a 48 6f 73 74 3a 20 31 37 32 2e 31 36 2e 35 38 .Host: 1 72.16.58
00a0 2e 31 31 35 0d 0a 0d 0a .115...

```

NCS5K initiates download of ISO image

5. 成功下载映像后，便开始在设备上安装映像。

6. 路由器成功启动下载的映像后，会启动另一个DHCP请求：

No.	Time	Source	Destination	Protocol	Length	Info
418654	2017-05-26 05:04:12.051436	172.16.58.115	172.16.58.212	DHCP	342	DHCP Offer - Transaction ID 0xd...
418655	2017-05-26 05:04:12.052378	172.16.58.115	172.16.58.212	DHCP	342	DHCP ACK - Transaction ID 0xd...
418656	2017-05-26 05:06:52.778102	0.0.0.0	255.255.255...	DHCP	367	DHCP Discover - Transaction ID 0x5...
418657	2017-05-26 05:06:52.778327	172.16.58.115	172.16.58.110	DHCP	342	DHCP Offer - Transaction ID 0x5...
418658	2017-05-26 05:06:52.778626	0.0.0.0	255.255.255...	DHCP	379	DHCP Request - Transaction ID 0x5...

```

Your (client) IP address: 0.0.0.0
Next server IP address: 0.0.0.0
Relay agent IP address: 0.0.0.0
Client MAC address: Cisco_1c:a5:1a (00:62:ec:1c:a5:1a)
Client hardware address padding: 00000000000000000000
Server host name not given
Boot file name not given
Magic cookie: DHCP
  > Option: (53) DHCP Message Type (Discover)
  > Option: (55) Parameter Request List
  > Option: (60) Vendor class identifier
      Length: 45
      Vendor class identifier: PXEClient:Arch:00009:UNDI:003010:PID:NCS-5500
  > Option: (61) Client identifier
  > Option: (77) User Class Information
      Length: 10
      > Instance of User Class: [0]
  > Option: (255) End
      Option End: 255
  
```

```

0080 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0090 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00a0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00b0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00c0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00d0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00e0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00f0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0100 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0110 00 00 00 00 00 00 63 82 53 63 35 01 01 37 07 01 .....c. Sc5..7..
0120 1c 02 03 0f 06 0c 3c 2d 50 58 45 43 6c 69 65 6e .....<- PXEClie
0130 74 3a 41 72 63 68 3a 30 30 30 30 39 3a 55 4e 44 .....t:Arch:0 0009:UND
0140 49 3a 30 30 33 30 31 30 3a 50 49 44 3a 4e 43 53 .....I:003010 :PID:NCS
0150 2d 35 35 30 30 3d 0b 46 4f 43 32 30 32 36 52 33 .....-5500=.F 0C2026R3
0160 38 5a 4d 0a 65 78 72 2d 63 6f 6e 66 69 67 ff 82M.exr- config.
  
```

NCS5K-> DHCP Server

NCS user-class has info on "exr-config"

在此发现中，请注意用户类信息包括*.exr-config。因为DHCP配置为返回配置文件或脚本(即etc/dhcp/dhcpd.conf中的else语句)。

7. DHCP服务器返回选项67中所需的文件信息：

No.	Time	Source	Destination	Protocol	Length	Info
418654	2017-05-26 05:04:12.051436	172.16.58.115	172.16.58.212	DHCP	342	DHCP Offer - Transaction ID 0xd...
418655	2017-05-26 05:04:12.052378	172.16.58.115	172.16.58.212	DHCP	342	DHCP ACK - Transaction ID 0xd...
418656	2017-05-26 05:06:52.778102	0.0.0.0	255.255.255...	DHCP	367	DHCP Discover - Transaction ID 0x5...
418657	2017-05-26 05:06:52.778327	172.16.58.115	172.16.58.110	DHCP	342	DHCP Offer - Transaction ID 0x5...
418658	2017-05-26 05:06:52.778626	0.0.0.0	255.255.255...	DHCP	379	DHCP Request - Transaction ID 0x5...

```

Seconds elapsed: 36
  > Bootp flags: 0x0000 (Unicast)
  Client IP address: 0.0.0.0
  Your (client) IP address: 172.16.58.110
  Next server IP address: 0.0.0.0
  Relay agent IP address: 0.0.0.0
  Client MAC address: Cisco_1c:a5:1a (00:62:ec:1c:a5:1a)
  Client hardware address padding: 00000000000000000000
  Server host name not given
  Boot file name: http://172.16.58.115/images/NCS-5502-A.cfg
  Magic cookie: DHCP
  > Option: (53) DHCP Message Type (Offer)
      Length: 1
      DHCP: Offer (2)
  > Option: (54) DHCP Server Identifier
      Length: 4
      DHCP Server Identifier: 172.16.58.115
  > Option: (51) IP Address Lease Time
      Length: 4
      IP Address Lease Time: (600e) 10 minutes
  
```

```

0070 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0080 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0090 00 00 00 00 00 00 68 74 74 70 3a 2f 2f 31 37 32 .....ht tp://172
00a0 2e 31 36 2e 35 38 2e 31 31 35 2f 69 6d 61 67 65 .....16.58.1 15/image
00b0 73 2f 4e 43 53 2d 35 35 30 32 2d 41 2e 63 66 67 .....s/NCS-55 02-A.cfg
00c0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00d0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00e0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00f0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0100 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0110 00 00 00 00 00 00 63 82 53 63 35 01 02 36 04 ac .....c. Sc5..6..
0120 10 3a 73 33 04 00 00 02 58 01 04 ff ff ff 00 1c .....:s3... X...
0130 04 ac 10 3a ff 03 04 ac 10 3a 01 0f 09 63 69 73 .....:...:..cis
0140 63 6f 2e 63 6f 6d 06 04 ab 46 a8 b7 ff 00 00 00 .....co.com...F....
0150 00 00 00 00 00 00 .....
  
```

DHCP Server -> NCS5K

Server responds with config info

8. 路由器下载配置：

No.	Time	Source	Destination	Protocol	Length	Info
418660	2017-05-26 05:06:56.981542	172.16.58.110	172.16.58.115	TCP	74	36775 → 80 [SYN] Seq=0 Win=42746 L...
418661	2017-05-26 05:06:56.981642	172.16.58.115	172.16.58.110	TCP	74	80 → 36775 [SYN, ACK] Seq=0 Ack=1 ...
418662	2017-05-26 05:06:56.981779	172.16.58.110	172.16.58.115	TCP	66	36775 → 80 [ACK] Seq=1 Ack=1 Win=4...
418663	2017-05-26 05:06:56.981852	172.16.58.110	172.16.58.115	HTTP	268	HEAD /images/NCS-5502-A.cfg HTTP/1...
418664	2017-05-26 05:06:56.981900	172.16.58.115	172.16.58.110	TCP	66	80 → 36775 [ACK] Seq=1 Ack=203 Win...

[Stream index: 1]
[TCP Segment Len: 202]
Sequence number: 1 (relative sequence number)
[Next sequence number: 203 (relative sequence number)]
Acknowledgment number: 1 (relative ack number)
Header Length: 32 bytes
Flags: 0x018 (PSH, ACK)
Window size value: 21
[Calculated window size: 43008]
[Window size scaling factor: 2048]
Checksum: 0x0502 [unverified]
[Checksum Status: Unverified]
Urgent pointer: 0
Options: (12 bytes), No-Operation (NOP), No-Operation (NOP), Timestamps
▶ No-Operation (NOP)
▶ No-Operation (NOP)
▶ Timestamps: TSval 4294963862, TSecr 2496722970
▶ [SEQ/ACK analysis]

Hypertext Transfer Protocol
Hypertext Transfer Protocol
0020 3a 73 8f a7 00 50 a9 0f 07 af 8d 06 14 b1 80 18 :S...P.. ..
0030 00 15 05 02 00 00 01 01 08 0a ff ff f2 96 94 d0
0040 f8 1a 48 45 41 44 20 2f 69 6d 61 67 65 73 2f 4e ..HEAD / images/N
0050 43 53 2d 35 35 30 32 2d 41 2e 63 66 67 20 48 54 CS-5502- A.cfg HT
0060 54 50 2f 31 2e 31 0d 0a 55 73 65 72 2d 41 67 65 TP/1.1.. User-Age
0070 6e 74 3a 20 63 75 72 6c 2f 37 2e 33 37 2e 31 0d nt: curl /7.37.1.
0080 0a 48 6f 73 74 3a 20 31 37 32 2e 31 36 2e 35 38 .Host: 1 72.16.58
0090 2e 31 31 35 0d 0a 41 63 63 65 70 74 3a 20 2a 2f .115..Ac cept: /*
00a0 2a 0d 0a 58 2d 63 69 73 63 6f 2d 61 72 63 68 3a *.X-cis co-arch:
00b0 78 38 36 5f 36 34 0d 0a 58 2d 63 69 73 63 6f 2d x86_64.. X-cisco-
00c0 6f 70 65 72 3a 65 78 72 2d 63 6f 6e 66 69 67 0d oper:exr -config.
00d0 0a 58 2d 63 69 73 63 6f 2d 70 6c 61 74 66 6f 72 .X-cisco -platfor
00e0 6d 3a 46 72 65 74 74 61 0d 0a 20 58 2d 63 69 73 m:Fretta .. X-cis
00f0 63 6f 2d 73 65 72 69 61 6c 3a 22 46 4f 43 32 30 co-seria l:"FOC20
0100 32 36 52 33 38 5a 22 20 0d 0a 0d 0a 26R38Z"

脚本可以作为来自DHCP服务器的响应包含，并让脚本复制映像/配置。这也用作安装后脚本，如以下示例中所示。

安装后自动化

在eXR软件安装后可执行各种自动化。

在本示例中，此脚本安装所有必需的包并应用配置。这是稍微修改的ztp_helper.sh版本。此脚本从xr-linux-shell调用：

```
RP/0/RP0/CPU0:NCS-5502-A#more disk0:/ztp/ztp_helper_file.sh
Wed May 31 00:55:54.529 UTC
#!/bin/bash
#####
# Install config and additional packages
#####

source /disk0:/ztp/ztp_helper.sh

export HTTP_SERVER=http://10.10.10.10
export RPM_PATH=images
export CONFIG_PATH=images
#Config
export INITIAL_CONFIG=NCS-5502-A.cfg
export FINAL_CONFIG=NCS-5502-A.cfg

#Packages
K9SEC_RPM=ncs5500-k9sec-2.2.0.0-r612.x86_64.rpm
```

```
MCAST_RPM=ncs5500-mcast-2.0.0.0-r612.x86_64.rpm
ISIS_RPM=ncs5500-isis-1.1.0.0-r612.x86_64.rpm
OSPF_RPM=ncs5500-ospf-1.1.0.0-r612.x86_64.rpm
MGBL_RPM=ncs5500-mgbl-3.0.0.0-r612.x86_64.rpm
MPLS_RPM=ncs5500-mpls-2.1.0.0-r612.x86_64.rpm
MPLSTE_RPM=ncs5500-mpls-te-rsvp-2.2.0.0-r612.x86_64.rpm
```

```
function download_config(){
    ip netns exec tpnns /usr/bin/wget ${HTTP_SERVER}/${CONFIG_PATH}/${FINAL_CONFIG} -O
/harddisk:/new-config 2>&1
    if [[ "$?" != 0 ]]; then
        printf "### Error downloading system configuration ###"
    else
        printf "### Downloading system configuration complete ###";
    fi
}
```

```
function apply_config(){
    # Applies initial configuration
    printf "### Applying initial system configuration ###";
    xrapply_with_reason "Initial ZTP configuration" /harddisk:/new-config 2>&1;
    printf "### Checking for errors ###";
    local config_status=$(xrcmd "show configuration failed");
    if [[ $config_status ]]; then
        echo $config_status
        printf "!!! Error encounter applying configuration file, review the log !!!!";
    fi
    printf "### Applying system configuration complete ###";
}
```

```
function install_pkg(){
    #Download packages
    printf "Downloading Packages"
    ip netns exec tpnns /usr/bin/wget ${HTTP_SERVER}/${RPM_PATH}/${K9SEC_RPM} -O
/harddisk:/${K9SEC_RPM} 2>&1
    if [[ "$?" != 0 ]]; then
        printf "### Error downloading $K9SEC_RPM ###"
    else
        printf "### Downloading $K9SEC_PKG complete ###";
    fi

    printf "Downloading Packages"
    ip netns exec tpnns /usr/bin/wget ${HTTP_SERVER}/${RPM_PATH}/${MCAST_RPM} -O
/harddisk:/${MCAST_RPM} 2>&1
    if [[ "$?" != 0 ]]; then
        printf "### Error downloading $MCAST_RPM ###"
    else
        printf "### Downloading $MCAST_RPM complete ###";
    fi

    printf "Downloading Packages"
    ip netns exec tpnns /usr/bin/wget ${HTTP_SERVER}/${RPM_PATH}/${ISIS_RPM} -O
/harddisk:/${ISIS_RPM} 2>&1
    if [[ "$?" != 0 ]]; then
        printf "### Error downloading $ISIS_RPM ###"
    else
        printf "### Downloading $ISIS_RPM complete ###";
    fi

    printf "Downloading Packages"
    ip netns exec tpnns /usr/bin/wget ${HTTP_SERVER}/${RPM_PATH}/${OSPF_RPM} -O
/harddisk:/${OSPF_RPM} 2>&1
    if [[ "$?" != 0 ]]; then
        printf "### Error downloading $OSPF_RPM ###"
    fi
}
```



```

else
    printf "### Downloading $OSPF_RPM complete ###";
fi
printf "Downloading Packages"
ip netns exec tpnns /usr/bin/wget ${HTTP_SERVER}/${RPM_PATH}/${MGBL_RPM} -O
/harddisk:/$MGBL_RPM 2>&1
if [[ "$?" != 0 ]]; then
    printf "### Error downloading $MGBL_RPM ###"
else
    printf "### Downloading $MGBL_RPM complete ###";
fi

printf "Downloading Packages"
ip netns exec tpnns /usr/bin/wget ${HTTP_SERVER}/${RPM_PATH}/${MPLS_RPM} -O
/harddisk:/$MPLS_RPM 2>&1
if [[ "$?" != 0 ]]; then
    printf "### Error downloading $MPLS_RPM ###"
else
    printf "### Downloading $MPLS_RPM complete ###";
fi

printf "Downloading Packages"
ip netns exec tpnns /usr/bin/wget ${HTTP_SERVER}/${RPM_PATH}/${MPLSTE_RPM} -O
/harddisk:/$MPLSTE_RPM 2>&1
if [[ "$?" != 0 ]]; then
    printf "### Error downloading $MPLSTE_RPM ###"
else
    printf "### Downloading $MPLSTE_RPM complete ###";
fi

xrcmd "install update source /harddisk:/ $K9SEC_RPM $MCAST_RPM $ISIS_RPM $OSPF_RPM $MGBL_RPM
$MPLS_RPM $MPLSTE_RPM" 2>&1
local complete=0
while [ "$complete" = 0 ]; do
    complete=`xrcmd "show install active" | grep k9sec | head -n1 | wc -l`
    printf "Waiting for k9sec package to be activated"
    sleep 5
done
rm -f /harddisk:/$K9SEC_RPM /harddisk:/$MCAST_RPM /harddisk:/$MCAST_RPM /harddisk:/$ISIS_RPM
/harddisk:/$OSPF_RPM /harddisk:/$MGBL_RPM /harddisk:/$MPLSTE_RPM /harddisk:/$MPLS_RPM
printf "### XR PACKAGE INSTALL COMPLETE ###"
}

printf "Start Auto provision"
install_pkg;
download_config;
apply_config;

```

相关信息

- <https://xrdocs.github.io/software-management/tutorials/2016-08-26-working-with-ztp/>
- <https://xrdocs.github.io/software-management/tutorials/2016-07-27-ipxe-deep-dive/>
- <https://xrdocs.github.io/software-management/blogs/2016-10-14-ios-xr-packages-and-security/>