IEEE 802.1x Authentication with Catalyst 6500/6000 Running Cisco IOS Software Configuration Example

Document ID: 42665

Contents

Introduction **Prerequisites** Requirements **Components Used** Conventions **Background Information** Configure Network Diagram Configure the Catalyst Switch for 802.1x Authentication Configure the RADIUS Server Configure the PC Clients to Use 802.1x Authentication Verifv PC Clients Catalyst 6500 Troubleshoot **Related Information** Introduction

This document explains how to configure IEEE 802.1x on a Catalyst 6500/6000 that runs in native mode (a single Cisco IOS® Software image for the Supervisor Engine and MSFC) and a Remote Authentication Dial–In User Service (RADIUS) server for authentication and VLAN assignment.

Prerequisites

Requirements

Readers of this document should have knowledge of these topics:

- Installation Guide for Cisco Secure ACS for Windows 4.1
- User Guide for Cisco Secure Access Control Server 4.1
- How Does RADIUS Work?
- Catalyst Switching and ACS Deployment Guide

Components Used

The information in this document is based on these software and hardware versions:

• Catalyst 6500 that runs Cisco IOS Software Release 12.2(18)SXF on Supervisor Engine

Note: You need Cisco IOS Software Release 12.1(13)E or later to support 802.1x port–based authentication.

• This example uses Cisco Secure Access Control Server (ACS) 4.1 as the RADIUS server.

Note: A RADIUS server must be specified before you enable 802.1x on the switch.

• PC clients that supports 802.1x authentication

Note: This example uses Microsoft Windows XP clients.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

Refer to the Cisco Technical Tips Conventions for more information on document conventions.

Background Information

The IEEE 802.1x standard defines a client–server–based access control and authentication protocol that restricts unauthorized devices from connecting to a LAN through publicly accessible ports. 802.1x controls network access by creating two distinct virtual access points at each port. One access point is an uncontrolled port; the other is a controlled port. All traffic through the single port is available to both access points. 802.1x authenticates each user device that is connected to a switch port and assigns the port to a VLAN before it makes available any services that are offered by the switch or the LAN. Until the device is authenticated, 802.1x access control allows only Extensible Authentication Protocol over LAN (EAPOL) traffic through the port to which the device is connected. After authentication is successful, normal traffic can pass through the port.

Note: If the switch receives EAPOL packets from the port that is not configured for 802.1x authentication or if the switch does not support 802.1x authentication, then the EAPOL packets are dropped and are not forwarded to any upstream devices.

Configure

In this section, you are presented with the information to configure the 802.1x feature described in this document.

This configuration requires these steps:

- Configure the Catalyst switch for 802.1x authentication.
- Configure the RADIUS server.
- Configure the PC clients to use 802.1x authentication.

Network Diagram

This document uses this network setup:



- RADIUS server Performs the actual authentication of the client. The RADIUS server validates the identity of the client and notifies the switch whether or not the client is authorized to access the LAN and switch services. Here, the RADIUS server is configured for authentication and VLAN assignment.
- Switch Controls the physical access to the network based on the authentication status of the client. The switch acts as an intermediary (proxy) between the client and the RADIUS server. It requests identity information from the client, verifies that information with the RADIUS server, and relays a response to the client. Here, the Catalyst 6500 switch is also configured as a DHCP server. The 802.1x authentication support for the Dynamic Host Configuration Protocol (DHCP) allows the DHCP server to assign the IP addresses to the different classes of end users by adding the authenticated user identity into the DHCP discovery process.
- Clients The devices (workstations) that requests access to the LAN and switch services and responds to requests from the switch. Here, PCs 1 to 4 are the clients that request an authenticated network access. PCs 1 and 2 use the same logon credential that is in VLAN 2. Similarly, PCs 3 and 4 use a logon credential for VLAN 3. PC clients are configured to attain the IP address from a DHCP server.

Configure the Catalyst Switch for 802.1x Authentication

This sample switch configuration includes:

- How to enable 802.1x authentication on FastEthernet ports.
- How to connect a RADIUS server to VLAN 10 behind FastEthernet port 3/1.
- A DHCP server configuration for two IP pools, one for clients in VLAN 2 and the other for clients in VLAN 3.
- Inter-VLAN routing to have connectivity between clients after authentication.

Refer to 802.1x Port–Based Authentication Guidelines and Restrictions for the guidelines on how to configure 802.1x authentication.

Note: Make sure that the RADIUS server always connects behind an authorized port.

Catalyst 6500

```
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config) #hostname Cat6K
!--- Sets the hostname for the switch.
Cat6K(config)#vlan 2
Cat6K(config-vlan)#name VLAN2
Cat6K(config-vlan)#vlan 3
Cat6K(config-vlan)#name VLAN3
!--- VLAN should be existing in the switch for a successful authentication.
Cat6K(config-vlan)#vlan 10
Cat6K(config-vlan)#name RADIUS_SERVER
!--- This is a dedicated VLAN for the RADIUS server.
Cat6K(config-vlan)#exit
Cat6K(config-if)#interface fastEthernet3/1
Cat6K(config-if)#switchport
Cat6K(config-if)#switchport mode access
Cat6K(config-if)#switchport access vlan 10
Cat6K(config-if)#no shut
!--- Assigns the port connected to the RADIUS server to VLAN 10.
!--- Note:- All the active access ports are in VLAN 1 by default.
Cat6K(config-if)#exit
Cat6K(config)#dot1x system-auth-control
!--- Globally enables 802.1x.
Cat6K(config)#interface range fastEthernet3/2-48
Cat6K(config-if-range)#switchport
Cat6K(config-if-range)#switchport mode access
Cat6K(config-if-range)#dot1x port-control auto
Cat6K(config-if-range)#no shut
!--- Enables 802.1x on all the FastEthernet interfaces.
Cat6K(config-if-range)#exit
Cat6K(config)#aaa new-model
!--- Enables AAA.
Cat6K(config)#aaa authentication dot1x default group radius
!--- Method list should be default. Otherwise dot1x does not work.
Cat6K(config)#aaa authorization network default group radius
!--- You need authorization for dynamic VLAN assignment to work with RADIUS.
Cat6K(config)#radius-server host 172.16.1.1
!--- Sets the IP address of the RADIUS server.
Cat6K(config)#radius-server key cisco
!--- The key must match the key used on the RADIUS server.
Cat6K(config)#interface vlan 10
Cat6K(config-if)#ip address 172.16.1.2 255.255.255.0
Cat6K(config-if) #no shut
```

```
!--- This is used as the gateway address in RADIUS server
!--- and also as the client identifier in the RADIUS server.
Cat6K(config-if)#interface vlan 2
Cat6K(config-if)#ip address 172.16.2.1 255.255.255.0
Cat6K(config-if)#no shut
!--- This is the gateway address for clients in VLAN 2.
Cat6K(config-if)#interface vlan 3
Cat6K(config-if)#ip address 172.16.3.1 255.255.255.0
Cat6K(config-if)#no shut
!--- This is the gateway address for clients in VLAN 3.
Cat6K(config-if)#exit
Cat6K(config)#ip dhcp pool vlan2_clients
Cat6K(dhcp-config)#network 172.16.2.0 255.255.255.0
Cat6K(dhcp-config)#default-router 172.16.2.1
!--- This pool assigns ip address for clients in VLAN 2.
Cat6K(dhcp-config)#ip dhcp pool vlan3_clients
Cat6K(dhcp-config)#network 172.16.3.0 255.255.255.0
Cat6K(dhcp-config)#default-router 172.16.3.1
!--- This pool assigns ip address for clients in VLAN 3.
Cat6K(dhcp-config)#exit
Cat6K(config)#ip dhcp excluded-address 172.16.2.1
Cat6K(config)#ip dhcp excluded-address 172.16.3.1
Cat6K(config-if)#end
Cat6K#show vlan
VLAN Name
                                   Status Ports
____ _____
                                             Fa3/2, Fa3/3, Fa3/4, Fa3/5
1 default
                                    active
                                             Fa3/6, Fa3/7, Fa3/8, Fa3/9
                                             Fa3/10, Fa3/11, Fa3/12, Fa3/13
                                             Fa3/14, Fa3/15, Fa3/16, Fa3/17
                                             Fa3/18, Fa3/19, Fa3/20, Fa3/21
                                             Fa3/22, Fa3/23, Fa3/24, Fa3/25
                                             Fa3/26, Fa3/27, Fa3/28, Fa3/29
                                             Fa3/30, Fa3/31, Fa3/32, Fa3/33
                                             Fa3/34, Fa3/35, Fa3/36, Fa3/37
                                             Fa3/38, Fa3/39, Fa3/40, Fa3/41
                                             Fa3/42, Fa3/43, Fa3/44, Fa3/45
                                             Fa3/46, Fa3/47, Fa3/48
  VLAN2
2
                                   active
    VLAN3
3
                                   active
10 RADIUS SERVER
                                   active
                                            Fa3/1
1002 fddi-default
                                   act/unsup
1003 token-ring-default
                                   act/unsup
1004 fddinet-default
                                   act/unsup
1005 trnet-default
                                   act/unsup
!--- Output suppressed.
!--- All active ports are in VLAN 1 (except 3/1) before authentication.
```

Note: Use the Command Lookup Tool (registered customers only) to obtain more information on the commands used in this section.

Configure the RADIUS Server

The RADIUS server is configured with a static IP address of 172.16.1.1/24. Complete these steps in order to configure the RADIUS server for an AAA client:

- 1. Click **Network Configuration** on the ACS administration window in order to configure an AAA client.
- 2. Click **Add Entry** under the AAA clients section.

	CISCO SYSTEMS	Network Configuration		
addinaaddinaa		Select		
	User Setup			
	Group Setup	% Q	AAA Clients	?
	68 SharedProfile Components	AAA Client Hostname	AAA Client IP Address	Authenticate Using
	Network	None Defined		
	System Configuration		Add Entry Search	

- 3. Configure the AAA client hostname, IP address, shared secret key and authentication type as:
 - ♦ AAA client hostname = Switch Hostname (**Cat6K**).
 - ♦ AAA client IP address = Management interface IP address of the switch (172.16.1.2).
 - Shared Secret = RADIUS Key configured on the switch (cisco).
 - Authenticate Using = **RADIUS IETF**.

Note: For correct operation, the shared secret key must be identical on the AAA client and ACS. Keys are case sensitive.

4. Click **Submit + Apply** to make these changes effective, as this example shows:

CISCO SYSTEMS	Network Configuration		
tillintillin	Add AAA Client		
User Setup			
Group Setup	AAA Client Hostname Cat6K		
Shared Profile Components	AAA Client IP Address		
Network Configuration	Shared Secret cisco		
System Configuration	RADIUS Key Wrap		
Configuration	Key Encryption Key		
Administration Control	Message Authenticator Code Key		
Databases			
Fosture Validation	Authenticate Using RADIUS (IETF)		
Network Access	□ Single Connect TACACS+ AAA Client (Record stop in accounting on failure)		
Reports and	Log Update/Watchdog Packets from this AAA Client		
Activity	Log RADIUS Tunneling Packets from this AAA Client		
Documentation	Replace RADIUS Port info with Username from this AAA Client		
	Match Framed-IP-Address with user IP address for accounting packets from this AAA Client		
	Submit Submit + Apply Cancel		

Complete these steps in order to configure the RADIUS server for authentication, VLAN and IP address assignment.

Two user names have to be created separately for clients that connect to VLAN 2 as well as for VLAN 3. Here, a user **user_vlan2** for clients that connect to VLAN 2 and another user **user_vlan3** for clients that connect to VLAN 3 are created for this purpose.

Note: Here, the user configuration is shown for clients that connect to VLAN 2 only. For users that connect to VLAN 3, follow the same procedure.

1. In order to add and configure users, click **User Setup** and define the user name and password.

CISCO SYSTEMS	User Setup	
	Select	
User Setup		
Group Setup		User: user_vlan2
Shared Profile Components		Find Add/Edit
Network Configuration		List users beginning with letter/number:
System Configuration		<u>A B C D E F G H I J K L M</u> <u>N O P Q R S T U V W X Y Z</u>
Configuration		
Administration Control		
External User Databases		Remove Dynamic Users
Construction Validation		0
Network Access Profiles		Back to Help

CISCO SYSTEMS	User Setup
• مىنا التىسىنا التى	Edit
User Setup	User: user_vlan2 (New User)
Setup	Account Disabled
Network Configuration	Supplementary User Info 💡
Sustem Configuration	Real Name user_vlan2
Configuration	Description Client in VLAN 2
Administration Control	
Databases	User Setup ?
Posture Validation	Password Authentication:
Network Access Profiles	CiscoSecure PAP (Also used for CHAP/MS-CHAP/ARAP, if the Separate field is not checked.)
Reports and Activity	Password •••••
Online Documentation	Confirm Password

2. Define the client IP address assignment as **Assigned by AAA client pool**. Enter the name of the IP address pool configured on the switch for VLAN 2 clients.

CISCO SYSTEMS	User Setup
- سناألنيسييناألنيد	Password
User Setup Group Setup	When a token server is used for authentication, supplying a separate CHAP password for a token card user allows CHAP authentication. This is especially useful when token caching is enabled.
Shared Profile	Group to which the user is assigned:
Network	Default Group
System Configuration	Callback
Interface Configuration	O Use group setting
Administration Control	Callback using this number
12 External User	O Dialup client specifies callback number
Stell Databases	O Use Windows Database callback settings
Validation	Client IP Address Assignment
I Pepertrand	O Use group settings
Activity	O No IP address assignment
Online Documentation	O Assigned by dialup client
	O Assign static IP address
	Assigned by AAA client pool vlan2_clients

Note: Select this option and type the AAA client IP pool name in the box, only if this user is to have the IP address assigned by an IP address pool configured on the AAA client.

3. Define the Internet Engineering Task Force (IETF) attributes 64 and 65.

Make sure that the Tags of the Values are set to **1**, as this example shows. Catalyst ignores any tag other than 1. In order to assign a user to a specific VLAN, you must also define attribute **81** with a VLAN *name* or VLAN *number* that corresponds.

Note: If you use the VLAN name, it should be exactly same as the one configured in the switch.



Note: For more information on these IETF attributes, refer to RFC 2868: RADIUS Attributes for Tunnel Protocol Support \Box .

Note: In the initial configuration of the ACS server, IETF RADIUS attributes can fail to display in User Setup. In order to enable IETF attributes in user configuration screens, choose Interface configuration > RADIUS (IETF). Then, check attributes 64, 65, and 81 in the User and Group columns.

Note: If you do not define IETF attribute **81** and the port is a switch port in access mode, the client has assignment to the access VLAN of the port. If you have defined the attribute **81** for dynamic VLAN assignment and the port is a switch port in access mode, you need to issue the command **aaa authorization network default group radius** on the switch. This command assigns the port to the VLAN that the RADIUS server provides. Otherwise, 802.1x moves the port to the AUTHORIZED state after authentication of the user; but the port is still in the default VLAN of the port, and connectivity can fail. If you have defined the attribute **81**, but you have configured the port as a routed port, access denial occurs. This error message displays:

%DOT1X-SP-5-ERR_VLAN_NOT_ASSIGNABLE: RADIUS attempted to assign a VLAN to Dot1x port FastEthernet3/4 whose VLAN cannot be assigned.

Configure the PC Clients to Use 802.1x Authentication

This example is specific to the Microsoft Windows XP Extensible Authentication Protocol (EAP) over LAN (EAPOL) client:

- 1. Choose Start > Control Panel > Network Connections, then right-click on your Local Area Connection and choose Properties.
- 2. Check Show icon in notification area when connected under the General tab.

- 3. Under the Authentication tab, check Enable IEEE 802.1x authentication for this network.
- 4. Set the EAP type to **MD5–Challenge**, as this example shows:

Local Area Connection Properties					
General Authentication Advanced					
Select this option to provide authenticated network access for Ethernet networks.					
Enable IEEE 802.1x authentication for this network					
EAP type: MD5-Challenge					
Properties					
Authenticate as computer when computer information is available					
Authenticate as guest when user or computer information is unavailable					
OK Cancel					

Complete these steps to configure the clients to obtain the IP address from a DHCP server.

- 1. Choose Start > Control Panel > Network Connections, then right-click on your Local Area Connection and choose Properties.
- 2. Under the General tab, click Internet Protocol (TCP/IP) and then Properties.
- 3. Choose Obtain an IP address automatically.

Internet Protocol (TCP/IP) Propertie	es ?×
General	
You can get IP settings assigned autor this capability. Otherwise, you need to the appropriate IP settings.	matically if your network supports ask your network administrator for
Obtain an IP address automatica	ally
$\square \bigcirc \bigcirc$ Use the following IP address: —	
[P address:	· · · ·
S <u>u</u> bnet mask:	
Default gateway:	· · · · ·
 Obtain DNS server address auto Use the following DNS server address 	matically Idresses:
Preferred DNS server:	
Alternate DNS server:	
	Ad <u>v</u> anced
	OK Cancel

Verify

PC Clients

If you have correctly completed the configuration, the PC clients displays a popup prompt to enter a user name and password.

1. Click on the prompt, which this example shows:



A user name and password entry window displays.

2. Enter the user name and password.

Local Area Connection
User name: user_vlan2
Password:
Logon domain:
OK Cancel

Note: In PC 1 and 2, enter VLAN 2 user credentials and in PC 3 and 4 enter VLAN 3 user credentials.

3. If no error messages appear, verify connectivity with the usual methods, such as through access of the network resources and with **ping**. This output is from PC 1, and shows a successful **ping** to PC 4:



If this error appears, verify that the user name and password are correct:



Catalyst 6500

If the password and user name appear to be correct, verify the 802.1x port state on the switch.

1. Look for a port status that indicates AUTHORIZED.

ReAuthPeriod = 3600 Seconds

```
Cat6K#show dot1x
Sysauthcontrol= EnabledDot1x Protocol Version= 1
Dot1x Oper Controlled Directions = Both
Dot1x Admin Controlled Directions = Both
Cat6K#show dot1x interface fastEthernet 3/2
AuthSM State = AUTHENTICATED
Authom State= Authom FieldBendSM State= IDLEPortStatus= AUTHORIZEDMaxReq= 2MultiHosts= EnabledPort Control= AutoQuietPeriod= 60 Seconds
Re-authentication = Disabled
ReAuthPeriod = 3600 Seconds
ServerTimeout = 30 Seconds
SuppTimeout = 30 Seconds
Typeriod = 20 Seconds
TxPeriod
                       = 30 Seconds
Cat6K#show dot1x interface fastEthernet 3/4
AuthSM State = AUTHENTICATED
BendSM State = IDLE

PortStatus = AUTHORIZED

MaxReg = 2
                       = 2
MaxReq
MaxReq = 2
MultiHosts = Enabled
Port Control = Auto
QuietPeriod = 60 Seconds
Re-authentication = Disabled
ReAuthPeriod = 3600 Seconds
ServerTimeout
                       = 30 Seconds
SuppTimeout = 30 Seconds
TxPeriod = 30 Seconds
Cat6K#show dot1x interface fastEthernet 3/1
Default Dot1x Configuration Exists for this interface FastEthernet3/1
AuthSM State = FORCE AUTHORIZED
Internet PointPointPointBendSM State= IDLEPortStatus= AUTHORIZEDMaxReq= 2MultiHosts= DisabledPortControl= Force AuthorizedQuietPeriod= 60 Seconds
Re-authentication = Disabled
```

ServerTimeout	=	30	Seconds
SuppTimeout	=	30	Seconds
TxPeriod	=	30	Seconds

Verify the VLAN status after successful authentication.

Cat6K#**show vlan**

VLAN	Name	Status	Ports
1	default	active	Fa3/6, Fa3/7, Fa3/8, Fa3/9, Fa3/10, Fa3/11, Fa3/12, Fa3/13, Fa3/14, Fa3/15, Fa3/16, Fa3/17, Fa3/18, Fa3/19, Fa3/20, Fa3/21, Fa3/22, Fa3/23, Fa3/24, Fa3/25, Fa3/26, Fa3/27, Fa3/28, Fa3/29, Fa3/30, Fa3/31, Fa3/32, Fa3/33, Fa3/34, Fa3/35, Fa3/36, Fa3/37, Fa3/38, Fa3/39, Fa3/40, Fa3/41, Fa3/42, Fa3/43, Fa3/44, Fa3/45, Fa3/46, Fa3/47, Fa3/48
2	VLAN2	active	Fa3/2, Fa3/3
3	VLAN3	active	Fa3/4, Fa3/5
10	RADIUS_SERVER	active	Fa3/1
1002	fddi-default	act/unsup	
1003	token-ring-default	act/unsup	
1004	fddinet-default	act/unsup	
1005	trnet-default	act/unsup	
!	Output suppressed.		

2. Verify the DHCP binding status from the after successful authentication.

Router# show	ip dhcp binding		
IP address	Hardware address	Lease expiration	Туре
172.16.2.2	0100.1636.3333.9c	Mar 04 2007 06:35 AM	Automatic
172.16.2.3	0100.166F.3CA3.42	Mar 04 2007 06:43 AM	Automatic
172.16.3.2	0100.145e.945f.99	Mar 04 2007 06:50 AM	Automatic
172.16.3.3	0100.1185.8D9A.F9	Mar 04 2007 06:57 AM	Automatic

The Output Interpreter Tool (registered customers only) (OIT) supports certain **show** commands. Use the OIT to view an analysis of **show** command output.

Troubleshoot

Collect the output of these **debug** commands in order to troubleshoot:

Note: Refer to Important Information on Debug Commands before you use debug commands.

• debug dot1x events Enables debugging of print statements guarded by the dot1x events flag.

```
Cat6K#debug dot1x events
Dot1x events debugging is on
Cat6K#

!--- Debug output for PC 1 connected to Fa3/2.
00:13:36: dot1x-ev:Got a Request from SP to send it to Radius with id 14
00:13:36: dot1x-ev:Couldn't Find a process thats already handling
   the request for this id 3
00:13:36: dot1x-ev:Inserted the request on to list of pending requests.
   Total requests = 1
```

```
00:13:36: dot1x-ev:Found a free slot at slot: 0
00:13:36: dot1x-ev:AAA Client process spawned at slot: 0
00:13:36: dot1x-ev:AAA Client-process processing Request
                    Interface= Fa3/2,
                    Request-Id = 14,
                    Length = 15
00:13:36: dot1x-ev:The Interface on which we got this AAA Request
   is FastEthernet3/2
00:13:36: dot1x-ev:MAC Address is 0016.3633.339c
00:13:36: dot1x-ev:Dot1x Authentication Status:AAA_AUTHEN_STATUS_GETDATA
00:13:36: dot1x-ev:going to send to backend on SP, length = 6
00:13:36: dot1x-ev:Sent to Bend
00:13:36: dot1x-ev:Got a Request from SP to send it to Radius with id 15
00:13:36: dot1x-ev:Found a process thats already handling therequest for
    this id 12
00:13:36: dot1x-ev:Username is user_vlan2; eap packet length = 6
00:13:36: dot1x-ev:Dot1x Authentication Status:AAA_AUTHEN_STATUS_GETDATA
00:13:36: dot1x-ev:going to send to backend on SP, length = 31
00:13:36: dot1x-ev:Sent to Bend
00:13:36: dot1x-ev:Got a Request from SP to send it to Radius with id 16
00:13:36: dot1x-ev:Found a process thats already handling therequest for
   this id 13
00:13:36: dot1x-ev:Username is user_vlan2; eap packet length = 32
00:13:36: dot1x-ev:Dot1x Authentication Status:AAA AUTHEN STATUS PASS
00:13:36: dot1x-ev:Vlan name = VLAN2
00:13:37: dot1x-ev:Sending Radius SUCCESS to Backend SM -
   id 16 EAP pkt len = 4
00:13:37: dot1x-ev:The process finished processing the request
   will pick up any pending requests from the queue
Cat6K#
Cat6K#
!--- Debug output for PC 3 connected to Fa3/4.
00:19:58: dot1x-ev:Got a Request from SP to send it to Radius with id 8
00:19:58: dot1x-ev:Couldn't Find a process thats already handling
   the request for this id 1
00:19:58: dot1x-ev:Inserted the request on to list of pending requests.
   Total requests = 1
00:19:58: dot1x-ev:Found a free slot at slot: 0
00:19:58: dot1x-ev:AAA Client process spawned at slot: 0
00:19:58: dot1x-ev:AAA Client-process processing Request
                    Interface= Fa3/4,
                    Request-Id = 8,
                    Length = 15
00:19:58: dot1x-ev:The Interface on which we got this AAA
   Request is FastEthernet3/4
00:19:58: dot1x-ev:MAC Address is 0014.5e94.5f99
00:19:58: dot1x-ev:Dot1x Authentication Status:AAA_AUTHEN_STATUS_GETDATA
00:19:58: dot1x-ev:going to send to backend on SP, length = 6
00:19:58: dot1x-ev:Sent to Bend
00:19:58: dot1x-ev:Got a Request from SP to send it to Radius with id 9
00:19:58: dot1x-ev:Found a process thats already handling therequest
   for this id 10
00:19:58: dot1x-ev:Username is user_vlan3; eap packet length = 6
00:19:58: dot1x-ev:Dot1x Authentication Status: AAA AUTHEN STATUS GETDATA
00:19:58: dot1x-ev:going to send to backend on SP, length = 31
00:19:58: dot1x-ev:Sent to Bend
00:19:58: dot1x-ev:Got a Request from SP to send it to Radius with id 10
00:19:58: dot1x-ev:Found a process thats already handling therequest
   for this id 11
00:19:58: dot1x-ev:Username is user_vlan3; eap packet length = 32
00:19:58: dot1x-ev:Dot1x Authentication Status:AAA_AUTHEN_STATUS_PASS
00:19:58: dot1x-ev:Vlan name = 3
00:19:58: dot1x-ev:Sending Radius SUCCESS to Backend SM - id 10 EAP pkt len = 4
00:19:58: dot1x-ev:The process finished processing the request
```

will pick up any pending requests from the queue Cat6K#debug radius Displays information associated with RADIUS.

> Cat6K#debug radius Radius protocol debugging is on Cat6K# !--- Debug output for PC 1 connected to Fa3/2. 00:13:36: RADIUS: ustruct sharecount=1 00:13:36: RADIUS: Unexpected interface type in nas_port_format_a 00:13:36: RADIUS: EAP-login: length of radius packet = 85 code = 1 00:13:36: RADIUS: Initial Transmit FastEthernet3/2 id 17 172.16.1.1:1812, Access-Request, len 85 00:13:36: Attribute 4 6 AC100201 Attribute 61 6 0000000 Attribute 1 12 75736572 00:13:36: 00:13:36: 00:13:36:Attribute 12 6 000003E800:13:36:Attribute 79 17 0201000F00:13:36:Attribute 80 18 CCEE4889 00:13:36: RADIUS: Received from id 17 172.16.1.1:1812, Access-Challenge, len 79 00:13:36: Attribute 79 8 010D0006 Attribute 24 33 43495343 00:13:36: Attribute 80 18 C883376B 00:13:36: 00:13:36: RADIUS: EAP-login: length of eap packet = 6 00:13:36: RADIUS: EAP-login: got challenge from radius 00:13:36: RADIUS: ustruct sharecount=1 00:13:36: RADIUS: Unexpected interface type in nas_port_format_a 00:13:36: RADIUS: EAP-login: length of radius packet = 109 code = 1 00:13:36: RADIUS: Initial Transmit FastEthernet3/2 id 18 172.16.1.1:1812, Access-Request, len 109 00:13:36: Attribute 4 6 AC100201 Attribute 61 6 0000000 Attribute 1 12 75736572 Attribute 12 6 000003E8 Attribute 24 33 43495343 00:13:36: 00:13:36: 00:13:36: 00:13:36: 00:13:36:Attribute 79 8 020D000600:13:36:Attribute 80 18 15582484 00:13:36: RADIUS: Received from id 18 172.16.1.1:1812, Access-Challenge, len 104 Attribute 79 33 010E001F 00:13:36: 00:13:36: Attribute 24 33 43495343 00:13:36: Attribute 80 18 0643D234 00:13:36: RADIUS: EAP-login: length of eap packet = 31 00:13:36: RADIUS: EAP-login: got challenge from radius 00:13:36: RADIUS: ustruct sharecount=1 00:13:36: RADIUS: Unexpected interface type in nas_port_format_a 00:13:36: RADIUS: EAP-login: length of radius packet = 135 code = 1 00:13:36: RADIUS: Initial Transmit FastEthernet3/2 id 19 172.16.1.1:1812, Access-Request, len 135 00:13:36: Attribute 4 6 AC100201 00:13:36: Attribute 61 6 0000000 00:13:36: Attribute 1 12 75736572 00:13:36: Attribute 12 6 000003E8 00:13:36: Attribute 24 33 43495343 Attribute 79 34 020E0020 Attribute 80 18 E8A61751 00:13:36: 00:13:36: 00:13:36: RADIUS: Received from id 19 172.16.1.1:1812, Access-Accept, len 124 Attribute 64 6 0100000D 00:13:36: Attribute 65 6 01000006 00:13:36: Attribute 81 8 01564C41 Attribute 88 15 766C616E Attribute 8 6 FFFFFFE 00:13:36: 00:13:36: 00:13:36:

```
00:13:36:
00:13:36:
00:13:36:
                             Attribute 79 6 030E0004
                          Attribute 25 39 43495343
                            Attribute 80 18 11A7DD44
00:13:36: RADIUS: EAP-login: length of eap packet = 4
Cat6K#
Cat6K#
!--- Debug output for PC 3 connected to Fa3/4.
00:19:58: RADIUS: ustruct sharecount=1
00:19:58: RADIUS: Unexpected interface type in nas_port_format_a
00:19:58: RADIUS: EAP-login: length of radius packet = 85 code = 1
00:19:58: RADIUS: Initial Transmit FastEthernet3/4 id 11 172.16.1.1:1812,
                           Access-Request, len 85

      00:19:58:
      Attribute 4 6 AC100201

      00:19:58:
      Attribute 61 6 0000000

      00:19:58:
      Attribute 1 12 75736572

      00:19:58:
      Attribute 12 6 00003E8

      00:19:58:
      Attribute 79 17 0201000F

      00:19:58:
      Attribute 80 18 0001AC52

00:19:58: RADIUS: Received from id 11 172.16.1.1:1812, Access-Challenge,
                            len 79
                             Attribute 79 8 010B0006
00:19:58:
00:19:58:Attribute 24 33 4349534300:19:58:Attribute 80 18 23B9C9E7
00:19:58: RADIUS: EAP-login: length of eap packet = 6
00:19:58: RADIUS: EAP-login: got challenge from radius
00:19:58: RADIUS: ustruct sharecount=1
00:19:58: RADIUS: Unexpected interface type in nas_port_format_a
00:19:58: RADIUS: EAP-login: length of radius packet = 109 code = 1
00:19:58: RADIUS: Initial Transmit FastEthernet3/4 id 12 172.16.1.1:1812,
                          Access-Request, len 109
                          Attribute 4 6 AC100201
00:19:58:

      00:19:58:
      Attribute 4 0 Acto201

      00:19:58:
      Attribute 61 6 0000000

      00:19:58:
      Attribute 1 12 75736572

      00:19:58:
      Attribute 12 6 00003E8

      00:19:58:
      Attribute 24 33 43495343

      00:19:58:
      Attribute 79 8 020B0006

      00:19:58:
      Attribute 80 18 F4C8832E

00:19:58: RADIUS: Received from id 12 172.16.1.1:1812,
                   Access-Challenge, len 104
                          Attribute 79 33 010C001F
Attribute 24 33 43495343
00:19:58:
00:19:58:
00:19:58:
                             Attribute 80 18 45472A93
00:19:58: RADIUS: EAP-login: length of eap packet = 31
00:19:58: RADIUS: EAP-login: got challenge from radius
00:19:58: RADIUS: ustruct sharecount=1
00:19:58: RADIUS: Unexpected interface type in nas_port_format_a
00:19:58: RADIUS: EAP-login: length of radius packet = 135 code = 1
00:19:58: RADIUS: Initial Transmit FastEthernet3/4 id 13 172.16.1.1:1812,
                         Access-Request, len 135

      00:19:58:
      Attribute 4 6 AC100201

      00:19:58:
      Attribute 61 6 0000000

      00:19:58:
      Attribute 1 12 75736572

      00:19:58:
      Attribute 12 6 00003E8

      00:19:58:
      Attribute 24 33 43495343

      00:19:58:
      Attribute 79 34 020C0020

      00:19:58:
      Attribute 80 18 37011E8F

00:19:58: RADIUS: Received from id 13 172.16.1.1:1812, Access-Accept,
                            len 120
00:19:58:Attribute 64 6 0100000D00:19:58:Attribute 65 6 0100000600:19:58:Attribute 81 4 0133580F00:19:58:Attribute 88 15 766C616E00:19:58:Attribute 8 6 FFFFFFE00:19:58:Attribute 79 6 030C0004
```

```
00:19:58: Attribute 25 39 43495343
00:19:58: Attribute 80 18 F5520A95
00:19:58: RADIUS: EAP-login: length of eap packet = 4
Cat6K#
```

Related Information

- IEEE 802.1x Authentication with Catalyst 6500/6000 Running CatOS Software Configuration Example
- Guidelines for the Deployment of Cisco Secure ACS for Windows NT/2000 Servers in a Cisco Catalyst Switch Environment
- RFC 2868: RADIUS Attributes for Tunnel Protocol Support
- Configuring IEEE 802.1X Port-Based Authentication
- LAN Product Support
- LAN Switching Technology Support
- Technical Support & Documentation Cisco Systems

Contacts & Feedback | Help | Site Map

© 2013 – 2014 Cisco Systems, Inc. All rights reserved. Terms & Conditions | Privacy Statement | Cookie Policy | Trademarks of Cisco Systems, Inc.

Updated: Mar 27, 2007

Document ID: 42665