

# 如何在快取引擎上配置TACACS+支援

## 目錄

[簡介](#)

[必要條件](#)

[需求](#)

[採用元件](#)

[慣例](#)

[設定](#)

[網路圖表](#)

[為TACACS+支援配置快取引擎](#)

[驗證](#)

[疑難排解指令](#)

[相關資訊](#)

## 簡介

本文說明如何設定終端存取控制器存取控制系統Plus(TACACS+)支援，以便存取思科快取引擎。通過telnet到快取引擎時，本文檔中的說明允許您對遠端TACACS+伺服器/資料庫進行驗證。如果伺服器不包含使用者ID的條目，則它在本地檢查是否有有效的訪問資訊。

## 必要條件

### 需求

本文件沒有特定需求。

### 採用元件

本文中的資訊係根據以下軟體和硬體版本：

- 實驗環境下的思科快取引擎505，已清除設定
- 思科快取引擎軟體版本2.3.1
- CiscoSecure for UNIX

本文中的資訊是根據特定實驗室環境內的裝置所建立。文中使用到的所有裝置皆從已清除（預設）的組態來啟動。如果您的網路正在作用，請確保您已瞭解任何指令可能造成的影響。

### 慣例

請參閱[思科技術提示慣例](#)以瞭解有關檔案慣例的資訊。


## 設定

本節提供用於設定本文中所述功能的資訊。

註：使用[Command Lookup Tool](#)(僅供已註冊客戶使用)可獲取本節中使用的命令的詳細資訊。

## 網路圖表

本檔案會使用以下網路設定：



## 為TACACS+支援配置快取引擎

完成以下步驟，設定快取引擎以提供TACACS+支援：

1. 為各自版本的Web Cache Communication Protocol(WCCP)配置快取引擎。
2. 使用以下命令進行預設配置：

```
authentication login local enable
```

```
authentication configuration local enable
```

3. 配置TACACS+伺服器IP地址。如果多個伺服器指定哪個地址為主地址，則輔助伺服器將保留為空白選項。
4. 將TACACS+伺服器的身份驗證配置為主身份驗證。如果伺服器不可用，則預設值為本地指定的身份驗證。
5. 必要時配置TACACS+金鑰資訊的身份驗證。

**注意：**您必須在思科快取引擎上啟用TACACS+，因為與不需要PPP的路由器不同，思科快取引擎使用PPP來向TACACS伺服器進行身份驗證。要在Cisco快取引擎上啟用TACACS+，請開啟Cisco Secure ACS 2.6，按一下**Group Setup**頁籤，然後選中TACACS+設定區域中的PPP IP覈取方塊。

您的命令列應類似於以下輸出：

```
cepro(config)#tacacs server 172.18.124.114
cepro(config)#authentication login tacacs ena primary
cepro(config)#authen configuration tacacs enab
```

## 驗證

使用本節內容，確認您的組態是否正常運作。

[輸出直譯器工具](#)(僅供已註冊客戶使用)(OIT)支援某些show命令。使用OIT檢視show命令輸出的分析

o

- **show version** — 顯示運行在快取引擎上的軟體，以及一些其他元件，如系統正常運行時間（如代碼上次引導的位置和編譯的日期）。

```
cepro#show version
Cisco Cache Engine
Copyright (c) 1986-2001 by Cisco Systems, Inc.
Software Release: CE ver 2.31 (Build: FCS 02/16/01)
Compiled: 11:20:14 Feb 22 2001 by bbalagot
Image text-base 0x108000, data_base 0x437534
```

```
System restarted by Reload
The system has been up for 20 hours, 42 minutes, 59 seconds.
System booted from "flash"
```

- **show hardware** — 顯示與show version命令以及快取引擎的硬體元件相同的資訊。

```
cepro#show hardware
Cisco Cache Engine
Copyright (c) 1986-2001 by Cisco Systems, Inc.
Software Release: CE ver 2.31 (Build: FCS 02/16/01)
Compiled: 11:20:14 Feb 22 2001 by bbalagot
Image text-base 0x108000, data_base 0x437534
```

```
System restarted by Reload
The system has been up for 21 hours, 15 minutes, 16 seconds.
System booted from "flash"
```

```
Cisco Cache Engine CE505 with CPU AMD-K6 (model 8) (rev. 12) AuthenticAMD
2 Ethernet/IEEE 802.3 interfaces
1 Console interface.
134213632 bytes of Physical Memory
131072 bytes of ROM memory.
8388608 bytes of flash memory.
```

List of disk drives:

/c0t0d0 (scsi bus 0, unit 0, lun 0)

- **show running-config** — 顯示快取引擎上的運行配置。

```
cepro#show running-config
```

```
Building configuration...
```

```
Current configuration:
```

```
!  
!  
!  
user add admin uid 0 password 1 "eeSdy9dcy" capability admin-access  
user add chbanks uid 5001 password 1 "eeSdy9dcy" capability admin-access  
!  
!  
!  
hostname cepro  
!  
interface ethernet 0  
 ip address 10.27.2.2 255.255.255.0  
 ip broadcast-address 10.27.2.255  
exit  
!  
!  
interface ethernet 1  
exit  
!  
ip default-gateway 10.27.2.1  
ip route 0.0.0.0 0.0.0.0 10.27.2.1  
cron file /local/etc/crontab  
!  
wccp router-list 1 10.27.2.1  
wccp web-cache router-list-num 1  
!  
authentication login tacacs enable primary  
authentication login local enable !--- on by default ---!  
authentication configuration tacacs enable  
authentication configuration local enable !---- on by default ---!  
tacacs server 172.18.124.114 primary  
rule no-cache url-regex .*cgi-bin.*  
rule no-cache url-regex .*aw-cgi.*  
!  
!  
end  
cepro#
```

- **show tacacs** — 顯示TACACS+伺服器的設定。

```
cepro#show tacacs
```

```
Login Authentication for Console/Telnet Session: enabled (primary)
```

```
Configuration Authentication for Console/Telnet Session: enabled
```

```
TACACS Configuration:
```

```
-----
```

```
Key          =  
Timeout     = 5 seconds  
Retransmit  = 2 times
```

Server	Status
-----	-----
172.18.124.114	primary

- **show statistics tacacs** — 顯示TACACS+統計資訊。

```
cepro#show statistics tacacs
```

```
TACACS+ Statistics
-----
Number of access requests: 13
Number of access deny responses: 7
Number of access allow responses: 0
```

- **show authentication** — 顯示當前TACACS+當前身份驗證和授權配置。

```
cepro#show authentication
Login Authentication:      Console/Telnet Session
-----
local                      enabled
tacacs                     enabled (primary)

Configuration Authentication: Console/Telnet Session
-----
local                      enabled
tacacs                     enabled

cepro#
```

## 疑難排解指令

本節提供的資訊可用於對組態進行疑難排解。

[輸出直譯器工具](#)(僅供[已註冊](#)客戶使用)(OIT)支援某些**show**命令。使用OIT檢視**show**命令輸出的分析。

**附註：**使用 **debug** 指令之前，請先參閱[有關 Debug 指令的重要資訊](#)。

- **show debug** — 顯示已啟用的debug命令。

```
cepro#show debug
Authentication debugging is on
Tacacs debugging is on
```

- **terminal monitor** — 在螢幕上顯示調試輸出。此輸出顯示**debug authentication**和**debug tacacs**命令的結果。

```
cepro#terminal monitor
cepro#authenticateUser(): Begin
setRemoteIPAddress(): pRemoteAddress 172.18.124.193
bAuthentication(): Begin
bAuthenticationIntersection(): Begin
bAuthenticationIntersection(): telnet_access 1
setAuthenticatedService(): nServiceToAuthenticate 6
getAuthenticatedService(): Begin
getAuthenticatedService(): nServiceToAuthenticate = 6
bAuthenticationIntersection() getAuthenticatedService 6
setErrorDisplayed(): Begin bStatus 0
getLocalLoginAuthEnable(): Begin
getLocalLoginAuthEnable(): uiState = 1
getTacacsLoginAuthEnable(): Begin
getTacacsLoginAuthEnable(): uiState = 1
getTacacsLoginAuthPrimary(): Begin
getTacacsLoginAuthPrimary(): uiState = 1
IncrementTacacsStatRequest(): Begin
tacacs_plus_login() Begin
isConsole() Begin
getAuthenticatedService(): Begin
getAuthenticatedService(): nServiceToAuthenticate = 6
isConsole() nReturn 0 telnet
```

```

tacacs_plus_login() sWhatService() tty = telnet
getRemoteIPAddress(): Begin
getRemoteIPAddress(): pRemoteAddress = 172.18.124.193
tacacs_plus_login() getRemoteIPAddress sHostIp 172.18.124.193
tacacs_malloc() Begin 164
tacacs_malloc() PSkmalloc ptr
getUserStruct() malloc_named ustr
tacacs_plus_login() allocated memory for ustruct
aaa_update_user() Begin
debug_authen_svc() Begin

aaa_update_user(): user='admin' ruser='system' port='telnet'
    rem_addr='172.18.124.193' authen_type=1
tacacs_plus_login() updated user
getNumTacacsLoginAttempts(): Begin
getNumTacacsLoginAttempts(): ulRetransmit = 2
##### tacacs_plus_login() num_tries 1
aaa_start_login() Begin
debug_start_login() Begin

debug_start_login()/AUTHEN/START (0): port='telnet' list='(null)'
    action=LOGIN service=LOGIN
aaa_randomize_id() Begin
tacacs_plus_start_login() Begin
tacacs_parse_server() Begin user_str admin
getTacacsDirectRequestEnable(): Begin
getTacacsDirectRequestEnable(): cDirectRequestEnable = 0
printIpAddr() Begin
printIpAddr() 0.0.0.0
tacacs_plus_start_login() server.ip_addr 0.0.0.0          server.type
    0 server.length 0
choose_version() Begin
create_authen_start() Begin
create_authen_start() len 45
tacacs_malloc() Begin 45
tacacs_malloc() PSkmalloc ptr
create_authen_start() malloc_named tac_pak
fill_tacacs_plus_hdr() Begin encrypt 1
fill_tacacs_plus_hdr() len 33, tac_pak->length 33
#### fill_tacacs_plus_hdr() tac_pak->encrypted 1
#### fill_tacacs_plus_hdr() TEST nTestLen 33
create_authen_start() len 33, tac_pak->length 33
create_authen_start() u->priv_lvl 15 start->priv_lvl 15
create_authen_start() start->action 1
create_authen_start() start->authen_type 1
create_authen_start() start->service 1
create_authen_start() user_len 5
create_authen_start() port_len 6
create_authen_start() addr_len 14
create_authen_start() out_len 33
tacacs_plus_start_login() TACACS+: send AUTHEN/START packet ver=192
    id=1541646967
tacacs_plus_start_login() login to TACACS+ server:
printIpAddr() Begin
printIpAddr() 0.0.0.0
tacacs_plus_get_conn() Begin server(0)
printIpAddr() Begin
printIpAddr() 0.0.0.0
tacacs_plus_get_conn() **pSocketHandleIndex 89434348
tacacs_plus_get_conn() Look at server in the TACACS+ server list
tacacs_plus_get_conn() TACACS+: This is a loop through server list
tacacs_plus_openconn() Begin
printIpAddr() Begin
printIpAddr() 172.18.124.114

```

```
open_handle() Begin
tacacs_plus_socket() Begin
tacacs_plus_socket Socket: return nSocket 784 nSockFdTbl[28] = 784
printIpAddress() Begin
printIpAddress() 172.18.124.114
open_handle() TACACS+: Opening TCP/IP connection to 172.18.124.114
open_handle() nSockFdTbl[28]= 784
setCurrentServer() Begin SaveCurrentServer->ip_addr 172.18.124.114
IncrementTacacsStatPerServerRequest(): Begin
##### IncrementTacacsStatPerServerRequest Server->ip_addr 1920733868
    tacacs_root.ulTacacsServerAddr
open_handle() socket(28) 784
tacacs_plus_connect() Begin
tacacs_plus_connect() socket(28) 784
tacacs_plus_connect() End
open_handle() is connected
open_handle() *connection_handle 28
open_handle() **pSocketHandleIndex 28
tacacs_plus_openconn() **pSocketHandleIndex 28
get_server() Begin
tacacs_plus_openconn() server->opens++
tacacs_plus_get_conn() **pSocketHandleIndex 28
tacacs_plus_get_conn() oldServerCount: 0, count:0
    tacacs_plus_start_login() **pHandleIndex 28
tacacs_plus_send_receive() Begin
tacacs_plus_proc_send_receive() Begin
tacacs_plus_proc_send_receive() length 33
copy_tac_plus_packet() Begin
tacacs_malloc() Begin 45
tacacs_malloc() PSkmalloc ptr
copy_tac_plus_packet() malloc_named copy
tacacs_plus_encrypt() Begin
getTacacsKey(): Begin
getTacacsKey(): sKey =
tacacs_plus_encrypt() key
tacacs_plus_encrypt() sizeof(tacacs_plus_pkt_hdr) 12
tacacs_plus_encrypt() sizeof(uchar) 1
tacacs_plus_encrypt() tac_pak->encrypted 1
tacacs_plus_encrypt() tac_pak->encrypted = TAC_PLUS_CLEAR && key is empty
tacacs_plus_proc_send_receive() out_pak->encrypted 1
tacacs_plus_proc_send_receive() out_pak->encrypted 1
tacacs_plus_proc_send_receive() PSkfree dump_pak
tacacs_plus_proc_send_receive() ntohl(out_pak->length) 33
dump_start_session() Begin ntohl(out_pak->length) 33
getTacacsKey(): Begin
getTacacsKey(): sKey =
0xc0 0x1 0x1 0x1 0x77 0xaa 0xe3 0x5b 0x0 0x0 0x0 0x21 0x1 0xf 0x1 0x1 0x5
    0x6 0xe 0x0 0x61 0x64 0x6d
encrypt_md5_xor() Begin
encrypt_md5_xor() no key
dump_summarise_incoming_packet_type() Begin
Read AUTHEN/START size=45
dump_nas_pak() Begin
dump_header() Begin
PACKET: key=
version 192 (0xc0), type 1, seq no 1, encrypted 1
session_id 2007688027 (0x77aae35b), Data length 33 (0x21)
End header
type=AUTHEN/START, priv_lvl = 15action=login
authen_type=ascii
service=login
user_len=5 port_len=6 (0x6), rem_addr_len=14 (0xe)
data_len=0
User: port: rem_addr: data:
```

```
End packet
dump_start_session() PSkfree test
getTacacsTimeout(): Begin
getTacacsTimeout(): ulTimeout = 5
tacacs_plus_sockwrite() Begin
tacacs_plus_proc_send_receive() PSkfree out_pak
getTacacsTimeout(): Begin
getTacacsTimeout(): ulTimeout = 5
sockread() Begin
tacacs_plus_proc_send_receive() read
tacacs_malloc() Begin 18
tacacs_malloc() PSkmalloc ptr
tacacs_plus_proc_send_receive() malloc_named *in
tacacs_plus_proc_send_receive() allocated memory
getTacacsTimeout(): Begin
getTacacsTimeout(): ulTimeout = 5
sockread() Begin
tacacs_plus_proc_send_receive() OK
tacacs_plus_decrypt() Begin
getTacacsKey(): Begin
getTacacsKey(): sKey =
tacacs_plus_decrypt() key
tacacs_plus_decrypt() tac_pak->encrypted = TAC_PLUS_CLEAR && key is empty
authen_resp_sanity_check() Begin
tacacs_plus_hdr_sanity_check() Begin
authen_debug_response() Begin
authen_debug_response() TACACS+: ver=192 id=1541646967 received AUTHEN
    status = FAIL
tacacs_plus_start_login() PSkfree out_tac_pak
unload_authen_resp() Begin
tacacs_plus_start_login() PSkfree in_tac_pak
debug_authen_status() Begin

TACACS+/AUTHEN (2007688027): status = FAIL

tacacs_plus_login() Authentication failed.
tacacs_plus_login() label1
aaa_cleanup_login() Begin
aaa_close_connection() Begin
tacacs_plus_closeconn() Begin
get_server() Begin
close_handle() Begin
close_handle() nHandleIndex 28 nSockFdTbl[**handle] 784
aaa_set_password() Begin
aaa_free_user() Begin
debug_authen_svc() Begin
aaa_close_connection() Begin

TACACS+/AUTHEN: free user admin system telnet 172.18.124.193
    authen_type=ASCII service=LOGIN priv_lv
aaa_free_user() PSkfree ustr
##### tacacs_plus_login() num_tries 2
aaa_start_login() Begin
debug_start_login() Begin

debug_start_login()/AUTHEN/START (0): port='unknown' list='(null)'
    action=LOGIN service=LOGIN

TACACS+/AUTHEN/START aaa_start_login() (0): ERROR (no ustruct)
    tacacs_plus_login() TACACS+: aaa_start
aaa_free_user() Begin
tacacs_plus_login() try_local_login AUTHENTICATION_INTERNAL_ERROR
IncrementTacacsStatDenyAccess(): Begin
localAuthentication(): Begin
```

```
localAuthentication() usrName admin
localAuthentication() passwd system
localAuthentication() pUid 89435294
localAuthentication() telnet_access
localAuthentication() rc == TRUE
AuthenticationIntersection(): bTacacsLogin 0
IncrementLocalLoginStat(): Begin
getLocalConfigAuthEnable(): Begin
getLocalConfigAuthEnable(): uiState = 1
getTacacsConfigAuthEnable(): Begin
getTacacsConfigAuthEnable(): uiState = 1
getTacacsConfigAuthPrimary(): Begin
getTacacsConfigAuthPrimary(): uiState = 0
localAuthentication(): Begin
localAuthentication() usrName admin
localAuthentication() passwd system
localAuthentication() pUid 89435294
localAuthentication() telnet_access
localAuthentication() rc == TRUE
AuthenticationIntersection(): bTacacsConfig 0
AuthenticationIntersection():== Local Database Authentication ==
IncrementLocalConfigStat(): Begin
AuthenticationIntersection(): user has been found
AuthenticationIntersection(): bTacacsLogin pUid 89435294
AuthenticationIntersection(): GOT ACCESS capab 0 Admin 0 Ftp 0 Http 0
    Telnet 0

authenticateUser() AUTHENTICATION IS OK
authenticateUser() AUTHENTICATION #2
```

## [相關資訊](#)

- [Cisco 500系列快取引擎產品與服務](#)