

Configure and Verify Port-Channel on Firepower Appliances

Contents

[Introduction](#)

[Prerequisites](#)

[Requirements](#)

[Components Used](#)

[Background Information](#)

[Configure](#)

[Port-Channel on FPR4100/FPR9300](#)

[Configure a Port-Channel from FXOS User Interface \(FPR4100/FPR9300\)](#)

[Switch Configuration](#)

[Configure a Port-Channel from FXOS CLI \(FPR4100/FPR9300\)](#)

[Port-Channel on FPR21xx/FPR1xxx](#)

[EDM Configuration](#)

[Verify](#)

[Verify Port-Channel on FPR4100/FPR9300](#)

[Verify Port-Channel on FPR21xx/FPR1xxx](#)

[Troubleshoot](#)

[LACP Overview](#)

[Troubleshoot Port-Channel on FPR4100/FPR9300](#)

[Troubleshoot Port-Channel on FPR21xx/FPR1xxx](#)

[Additional Troubleshoot \(Common in all Platforms\)](#)

[Common Issues](#)

[Case 1. EtherChannel Mode Mismatch](#)

[Case 2. Wrong Port-Channel Design](#)

[Case 3. FXOS Port-Channel Unassigned](#)

[Case 4. Health Alerts About Port-Channel Do Not Receive Any Packets](#)

[Case 5. Health Alert on FMC: Port-Channel Disassociated or Interface Added](#)

[Port-Channel Considerations](#)

[Design Considerations](#)

[Case 1. FTD/ASA Blade in HA](#)

[Related Information](#)

[Case 2. FTD/ASA in Cluster](#)

[Case 3. Port-ChannelTerminated on FXOS](#)

[Case 4. Port-Channel Through FXOS](#)

[Additional Considerations](#)

[Frequently Asked Questions \(FAQ\)](#)

[Related Information](#)

Introduction


This document describes how to configure, verify, and troubleshoot the Port-Channel on Firepower Appliances.

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

- Firepower Management Center (FMC)
 - Firepower Chassis Manager (FCM)
 - Firepower eXtensible Operating System (FXOS)
 - Firepower Threat Defense (FTD)
 - EtherChannel (EC)
-



Note: In this document, the terms EtherChannel and Port-Channel (PC) are used interchangeably.

Components Used

The information in this document is based on these software and hardware versions:

- 2 x FPR4120 on FXOS 2.2(2.17), FTD 6.2.0.2.51
- 1 x FPR4110 on FXOS 2.1(0.159), FTD 6.1.0.330
- 1 x FPR2110 on FTD 6.2.1 (build 341)
- 1 x FPR1150 on FTD 6.5.0
- WS-C3750X-24 on 15.2(4)E5

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, ensure that you understand the potential impact of any command.


Background Information

This document describes the configuration, verification and troubleshoot of a Port-Channel on Firepower Appliances (FPR1xxx, FPR21xx, FPR41xx, FPR93xx). The document configuration examples are based on Firepower Threat Defense (FTD), but many concepts (for example, the verification and troubleshoot) are fully applicable to Adaptive Security Appliance (ASA) as well.

Configure

Port-Channel on FPR4100/FPR9300

Network Diagram



Configure a Port-Channel from FXOS User Interface (FPR4100/FPR9300)

FTD Port-Channel on Firepower Appliances is managed by the FXOS code. On FPR4100/FPR9300 the configuration is done from the Firepower Chassis Manager:

| Interface | Type | Admin Speed | Operational Speed | Application | Admin Duplex | Auto Negotiation | Operation State | Admin State |
|----------------|------------|-------------|-------------------|-------------|--------------|------------------|-----------------|-------------------------------------|
| MGMT | Management | | | | | | | <input checked="" type="checkbox"/> |
| Port-channel15 | data | 1gbps | 1gbps | FTD | Full Duplex | no | up | <input checked="" type="checkbox"/> |
| Ethernet1/2 | | | | | | | up | |
| Ethernet1/3 | | | | | | | up | |
| Port-channel48 | cluster | 10gbps | indeterminate | | Full Duplex | no | admin-down | <input type="checkbox"/> |
| Ethernet1/1 | mgmt | 1gbps | 1gbps | FTD | Full Duplex | no | up | <input checked="" type="checkbox"/> |
| Ethernet1/4 | data | 10gbps | 10gbps | | Full Duplex | no | failed | <input type="checkbox"/> |

Edit Port Channel - Port-channel15

Port Channel ID: 15 Enable

Type: Data

Admin Speed: 1gbps

Admin Duplex: Full Duplex

Auto Negotiation: Yes No

Interfaces

Available Interface

- Ethernet1/4
- Ethernet1/5
- Ethernet1/6
- Ethernet1/7
- Ethernet1/8
- Ethernet3/1
- Ethernet3/2
- Ethernet3/3
- Ethernet3/4
- Ethernet3/5
- Ethernet3/6

Member ID

- Ethernet1/2
- Ethernet1/3

Add Interface

OK Cancel


The Port-Channel is down (failed state) until it is assigned to a logical device:

Overview **Interfaces** Logical Devices Security Engine Platform Settings

All Interfaces Hardware Bypass Add Port Channel

| Interface | Type | Admin Speed | Operational Speed | Application | Admin Duplex | Auto Negotiation | Operation State | Admin State |
|----------------|------------|-------------|-------------------|-------------|--------------|------------------|-----------------|-------------------------------------|
| MGMT | Management | | | | | | | <input checked="" type="checkbox"/> |
| Port-channel15 | data | 1gbps | 1gbps | | Full Duplex | no | failed | <input checked="" type="checkbox"/> |
| Ethernet1/2 | data | 1gbps | | | Full Duplex | no | down | <input checked="" type="checkbox"/> |
| Ethernet1/3 | data | 1gbps | | | Full Duplex | no | down | <input checked="" type="checkbox"/> |
| Port-channel48 | cluster | 10gbps | indeterminate | | Full Duplex | no | admin-down | <input type="checkbox"/> |
| Ethernet1/1 | mgmt | 1gbps | 1gbps | FTD | Full Duplex | no | up | <input checked="" type="checkbox"/> |
| Ethernet1/4 | data | 10gbps | 10gbps | | Full Duplex | no | failed | <input type="checkbox"/> |
| Ethernet1/5 | data | 10gbps | 10gbps | | Full Duplex | no | sfp-not-present | <input type="checkbox"/> |
| Ethernet1/6 | data | 10gbps | 10gbps | FTD | Full Duplex | no | sfp-not-present | <input type="checkbox"/> |
| Ethernet1/7 | data | 10gbps | 10gbps | | Full Duplex | no | sfp-not-present | <input type="checkbox"/> |
| Ethernet1/8 | data | 10gbps | 10gbps | | Full Duplex | no | sfp-not-present | <input type="checkbox"/> |
| Ethernet3/1 | data | 10gbps | 10gbps | | Full Duplex | no | admin-down | <input type="checkbox"/> |
| Ethernet3/2 | data | 10gbps | 10gbps | | Full Duplex | no | admin-down | <input type="checkbox"/> |
| Ethernet3/3 | data | 10gbps | 10gbps | | Full Duplex | no | admin-down | <input type="checkbox"/> |
| Ethernet3/4 | data | 10gbps | 10gbps | | Full Duplex | no | admin-down | <input type="checkbox"/> |
| Ethernet3/5 | data | 10gbps | 10gbps | | Full Duplex | no | admin-down | <input type="checkbox"/> |
| Ethernet3/6 | data | 10gbps | 10gbps | | Full Duplex | no | admin-down | <input type="checkbox"/> |

To assign the Port-Channel to the logical device:



The result:

Overview **Interfaces** Logical Devices Security Engine Platform Settings

| Interface | Type | Admin Speed | Operational Speed | Application | Admin Duplex | Auto Negotiation | Operation State | Admin State |
|----------------|------------|-------------|-------------------|-------------|--------------|------------------|-----------------|-------------------------------------|
| MGMT | Management | | | | | | | <input checked="" type="checkbox"/> |
| Port-channel15 | data | 1gbps | 1gbps | FTD | Full Duplex | no | up | <input checked="" type="checkbox"/> |
| Ethernet1/2 | | | | | | | up | |
| Ethernet1/3 | | | | | | | up | |
| Port-channel48 | cluster | 10gbps | indeterminate | | Full Duplex | no | admin-down | <input type="checkbox"/> |
| Ethernet1/1 | mgmt | 1gbps | 1gbps | FTD | Full Duplex | no | up | <input checked="" type="checkbox"/> |

Main points

- Before FXOS 2.4.x release, the FPR4100/FPR9300 supports only LACP (no mode ON or PAGP). Since FXOS 2.4.1.101 mode ON is supported for data and data-sharing Etherchannels.
- Please ensure that the interface(s) which are to be added in the Port-Channel are not added already to the logical device. If they are, they do not show up in the interface when the Port-Channel is added.
- You cannot enable/disable individual Port-Channel members, but only the Port-Channel itself.
- You cannot delete a Port-Channel that is used by a Logical Device (for example, ASA or FTD). You must disassociate it first.
- The Port-Channel does not come up until you assign it to a logical device. If the EtherChannel is removed from the logical device or the logical device is deleted, the Port-Channel reverts to a Suspended state.
- Set the switch ports that connect to Active mode for the best compatibility.

Switch Configuration

When you configure the switch, in order to avoid Port-Channel instabilities it is recommended to:

- Use the interface range command.
- Shutdown the Port-Channel interface members before you make changes that affect the Port-Channel operation (for example, if the Port-Channel mode is changed).

Example

```
<#root>
```

```
Switch(config)#
```

```
interface range g1/0/2 - 3
```

```
Switch(config-if-range)#
```


```
shutdown
```

```
Switch(config-if-range)#
```

```
switchport trunk encapsulation dot1q
```

```
Switch(config-if-range)#
```

```
switchport mode trunk
Switch(config-if-range)#
channel-group 5 mode active
Switch(config-if-range)#
no shutdown
```



Note: Always refer to the switch model Configuration Guide section for additional details.

Configure a Port-Channel from FXOS CLI (FPR4100/FPR9300)

Step 1. Verify the interfaces that are already assigned to the FTD logical device.

```
<#root>
FP4110-7-A#
```

```
scope ssa
```

```
FP4110-7-A /ssa #
```

```
show logical-device
```

```
Logical Device:
```

| Name | Description | Slot ID | Mode | Oper State | Template Name |
|--------------|-------------|---------|------|---------------|---------------|
| mzafeiro_FTD | | | 1 | Standalone Ok | ftd |

```
FP4110-7-A /ssa #
```

```
scope logical-device mzafeiro_FTD
```

```
FP4110-7-A /ssa/logical-device #
```

```
show external-port-link
```

```
External-Port Link:
```

| Name | Port or Port Channel Name | App Name | Description |
|----------------|---------------------------|----------|-------------|
| Ethernet11_ftd | Ethernet1/1 | ftd | |
| Ethernet16_ftd | Ethernet1/6 | ftd | |

Step 2. Verify the chassis interfaces.

```
<#root>
```

```
FP4110-7-A#
```

```
scope eth-uplink
```

```
FP4110-7-A /eth-uplink #
```

```
scope fabric a
```

```
FP4110-7-A /eth-uplink/fabric #
```

```
show interface
```

```
Interface:
```

| Port Name | Port Type | Admin State | Oper State | State Reason |
|-------------|-----------|-------------|-----------------|-----------------------|
| Ethernet1/1 | Mgmt | Enabled | Up | |
| Ethernet1/2 | Data | Disabled | Admin Down | Administratively down |
| Ethernet1/3 | Data | Disabled | Admin Down | Administratively down |
| Ethernet1/4 | Data | Disabled | Failed | SFP checksum error |
| Ethernet1/5 | Data | Disabled | Sfp Not Present | Unknown |
| Ethernet1/6 | Data | Disabled | Sfp Not Present | Unknown |
| Ethernet1/7 | Data | Disabled | Sfp Not Present | Unknown |
| Ethernet1/8 | Data | Disabled | Sfp Not Present | Unknown |
| Ethernet3/1 | Data | Disabled | Admin Down | Administratively down |
| Ethernet3/2 | Data | Disabled | Admin Down | Administratively down |
| Ethernet3/3 | Data | Disabled | Admin Down | Administratively down |
| Ethernet3/4 | Data | Disabled | Admin Down | Administratively down |
| Ethernet3/5 | Data | Disabled | Admin Down | Administratively down |
| Ethernet3/6 | Data | Disabled | Admin Down | Administratively down |

FP4110-7-A /eth-uplink/fabric #

show port-channel

Port Channel:

| Port Channel Id | Name | Port Type | Admin State | Oper State | State Reason |
|-----------------|----------------|-----------|-------------|------------|-----------------------|
| 48 | Port-channel48 | Cluster | Disabled | Admin Down | Administratively down |

Step 3. Create the Port-Channel.

<#root>

bsns-4110-2-A#

scope eth-uplink

bsns-4110-2-A /eth-uplink #

scope fabric a

bsns-4110-2-A /eth-uplink/fabric #

create port-channel 15

bsns-4110-2-A /eth-uplink/fabric/port-channel* #

create member-port Ethernet1/5

bsns-4110-2-A /eth-uplink/fabric/port-channel/member-port* #

exit

bsns-4110-2-A /eth-uplink/fabric/port-channel* #

create member-port Ethernet1/6

bsns-4110-2-A /eth-uplink/fabric/port-channel/member-port* #

exit

bsns-4110-2-A /eth-uplink/fabric/port-channel* #

set port-type data

bsns-4110-2-A /eth-uplink/fabric/port-channel* #

set speed 1gbps

bsns-4110-2-A /eth-uplink/fabric/port-channel* #

enable

bsns-4110-2-A /eth-uplink/fabric/port-channel* #

commit-buffer

Step 4. Assign the interface to the FTD logical device:

<#root>

```

FP4110-7-A#
  scope ssa
FP4110-7-A /ssa #
  scope logical-device mzafeiro_FTD
FP4110-7-A /ssa/logical-device #
  create external-port-link PC15_ftd Port-channel15 ftd
FP4110-7-A /ssa/logical-device/external-port-link* #
  commit-buffer
FP4110-7-A /ssa/logical-device/external-port-link #

```

Verification

<#root>

```

FP4110-7-A#
  scope ssa
FP4110-7-A /ssa #
  scope logical-device mzafeiro_FTD
FP4110-7-A /ssa/logical-device #
  show external-port-link

```

External-Port Link:

| Name | Port or Port Channel | Name | App Name | Description |
|----------------|----------------------|------|----------|-------------|
| Ethernet11_ftd | Ethernet1/1 | | ftd | |
| Ethernet16_ftd | Ethernet1/6 | | ftd | |
| PC15_ftd | Port-channel15 | | ftd | |

<#root>

```

FP4110-7-A#
  scope eth-uplink
FP4110-7-A /eth-uplink #
  scope fabric a
FP4110-7-A /eth-uplink/fabric #
  show port-channel

```

Port Channel:

| Port Channel | Id | Name | Port Type | Admin State | Oper State | State Reason |
|--------------|----|----------------|-----------|-------------|------------|--------------|
| 15 | | Port-channel15 | Data | Enabled | Up | |

```
<#root>
```

```
FP4110-7-A /eth-uplink/fabric #
```

```
enter port-channel 15
```

```
FP4110-7-A /eth-uplink/fabric/port-channel #
```

```
show member-port
```

```
Member Port:
```

| Port Name | Membership | Oper State | State Reason |
|-------------|------------|------------|--------------|
| Ethernet1/2 | Up | Up | |
| Ethernet1/3 | Up | Up | |

Delete the Port-Channel from FXOS CLI (FPR4100/FPR9300).

```
<#root>
```

```
FP4110-7-A#
```

```
scope eth-uplink
```

```
FP4110-7-A /eth-uplink #
```

```
scope fabric a
```

```
FP4110-7-A /eth-uplink/fabric #
```


```
delete port-channel 15
```

```
FP4110-7-A /eth-uplink/fabric* #
```


```
commit-buffer
```

Port-Channel on FPR21xx/FPR1xxx

Network Diagram



The FTD Port-Channel on FPR21xx/FPR1xxx appliances is managed by the FXOS code, but the configuration is done from the FMC since the FTD and FXOS code is integrated in one software bundle:



Add Ether Channel Interface

Name: Enabled Management Only

Security Zone:

Description:

General | IPv4 | IPv6 | Advanced | Hardware Configuration

MTU: (64 - 9198)

Ether Channel ID *: (1 - 48)

Available Interfaces

- Ethernet1/13
- Ethernet1/14
- Ethernet1/15
- Ethernet1/16
- Ethernet1/2
- Ethernet1/3

Add

Selected Interfaces

- Ethernet1/1
- Ethernet1/2

OK Cancel

Mode (LACP Active or ON) are configured from the Advanced tab:

Add Ether Channel Interface

Name: Enabled Management Only

Security Zone:

Description:

General | IPv4 | IPv6 | **Advanced** | Hardware Configuration

Information | ARP and MAC | Security Configuration

LACP Mode:

Active Mac Address:

Standby Mac Address:

DNS Lookup:

Duplex and Speed settings are configured from the Hardware Configuration tab:

Add Ether Channel Interface

Name: Enabled Management Only

Security Zone:

Description:

General

IPv4

IPv6


Advanced

Hardware Configuration

Duplex:

Speed:

Auto-negotiation:



Note: On FPR2100, you cannot create a Port-Channel from FXOS CLI unless you use an ASA as a logical device. After ASA 9.13.x, this is the case only in Platform Mode. In Appliance Mode (11xx/21xx), there is not FCM and all interface configuration is performed directly in the ASA CLI.

```
<#root>
```

```
Fp2110 /eth-uplink/fabric* #
```

```
create port-channel 16
```

```
Fp2110 /eth-uplink/fabric/port-channel* #
```

```
create member-port Ethernet1/10
```

```
Fp2110 /eth-uplink/fabric/port-channel/member-port* #
```

```
exit
```

```
Fp2110 /eth-uplink/fabric/port-channel* #
```

```
create member-port Ethernet1/11
```

```
Fp2110 /eth-uplink/fabric/port-channel/member-port* #
```

```
exit
```

```
Fp2110 /eth-uplink/fabric/port-channel* #
```

```
commit-buffer
```

```
Error: Changes not allowed. use: 'connect ftd' to make changes.
```

In case a physical interface is down and you want to enable it do this:

```
<#root>
```

```
firepower-2110#
```

```
scope eth-uplink
```

```
firepower-2110 /eth-uplink #
```

```
scope fabric a
```

```
firepower-2110 /eth-uplink/fabric #
```

```
show interface
```

```
Interface:
```

| Port Name | Port Type | Admin State | Oper State | State Reason |
|--------------|-----------|-------------|------------|--------------|
| Ethernet1/3 | Data | Enabled | Up | Up |
| Ethernet1/4 | Data | Disabled | Link Down | Down |
| Ethernet1/5 | Data | Disabled | Link Down | Down |
| Ethernet1/6 | Data | Disabled | Link Down | Down |
| Ethernet1/7 | Data | Disabled | Link Down | Down |
| Ethernet1/8 | Data | Disabled | Link Down | Down |
| Ethernet1/9 | Data | Disabled | Link Down | Down |
| Ethernet1/10 | Data | Disabled | Link Down | Down |

```

Ethernet1/11 Data Disabled Link Down Down
Ethernet1/12 Data Disabled Link Down Down
Ethernet1/13 Data Disabled Link Down Down
Ethernet1/14 Data Disabled Link Down Down
Ethernet1/15 Data Disabled Link Down Down
Ethernet1/16 Data Disabled Link Down Down
firepower-2110 /eth-uplink/fabric #

```

```

enter interface Ethernet1/4

```

```

firepower-2110 /eth-uplink/fabric/interface #

```

```

show

```

```

Interface:

```

| Port Name | Port Type | Admin State | Oper State | State Reason |
|-------------|-----------|-------------|------------|--------------|
| Ethernet1/4 | Data | Disabled | Link Down | Down |

```

firepower-2110 /eth-uplink/fabric/interface #

```

```

enable

```

```

firepower-2110 /eth-uplink/fabric/interface* #

```

```

commit-buffer

```

```

firepower-2110 /eth-uplink/fabric/interface #

```

```

show

```

```

Interface:

```

| Port Name | Port Type | Admin State | Oper State | State Reason |
|-------------|-----------|-------------|------------|--------------|
| Ethernet1/4 | Data | Enabled | Link Down | Down |


```

firepower-2110 /eth-uplink/fabric/interface #

```

FDM Configuration

Consider this topology:



You can configure EtherChannel interfaces that use FDM as from 6.5 software release. Navigate to Device > Interfaces > EtherChannels and add an EtherChannel. Since in this case the EtherChannel is a trunk specify the EtherChannel ID, enable it (Status), and add the members. The EtherChannel supports LACP Active and mode On (no LACP). In this case, LACP Active mode is configured.

Add EtherChannel Interface



Name

Mode

Routed ▾

EtherChannel ID

1

Status

Most features work with named interfaces only, although some require unnamed interfaces.

1 - 48

Description

EtherChannel Specific

IPv4 Address

IPv6 Address

Advanced

Link Aggregation Control Protocol

Active ▾

EtherChannel Members



- unnamed (Ethernet1/3)
- unnamed (Ethernet1/2)

Add the Subinterfaces:

Add EtherChannel Subinterface



Parent Interface

unnamed (Port-channel1)

Subinterface Name

inside1

Mode

Routed

Status



Most features work with named interfaces only, although some require unnamed interfaces.

Description

VLAN ID

201

1 - 4094

Subinterface ID

201

IPv4 Address

IPv6 Address

Advanced

Type

Static

IP Address and Subnet Mask

192.168.201.112 / 24

e.g. 192.168.5.15/17 or 192.168.5.15/255.255.128.0

The result:


| NAME | LOGICAL NAME | TYPE | STATE | MODE | IP ADDRESS | MONITOR FOR HA | ACTIONS |
|---|--------------|--------------------|-------------------------------------|--------|---------------------------------------|----------------|---------|
| Port-channel1 | | EtherChannel | <input checked="" type="checkbox"/> | Routed | | Enabled | |
| ETHERCHANNEL MEMBERS | | | | | | | |
| <input checked="" type="checkbox"/> Ethernet1/2 | | Physical Interface | | | | | |
| <input checked="" type="checkbox"/> Ethernet1/3 | | Physical Interface | | | | | |
| SUBINTERFACES | | | | | | | |
| <input checked="" type="checkbox"/> Port-channel1.201 | inside1 | Subinterface | <input checked="" type="checkbox"/> | | 192.168.201.112 <small>Static</small> | Enabled | |
| <input checked="" type="checkbox"/> Port-channel1.202 | inside202 | Subinterface | <input checked="" type="checkbox"/> | | 192.168.202.112 <small>Static</small> | Enabled | |

Deploy the expected changes.

Verify

Verify Port-Channel on FPR4100/FPR9300

Network Diagram



The FTD (or ASA) is not aware of the Port-Channel individual members. Logical interfaces (subinterfaces) are configured on FMC:

```
<#root>
```

```
>
```

```
system support diagnostic-cli
```

```
firepower#
```

```
show interface ip brief
```

| Interface | IP-Address | OK? | Method | Status | Protocol |
|------------------|-------------|-----|--------|--------|----------|
| Internal-Data0/0 | unassigned | YES | unset | up | up |
| Internal-Data0/1 | unassigned | YES | unset | up | up |
| Internal-Data0/2 | 169.254.1.1 | YES | unset | up | up |
| Port-channel15 | unassigned | YES | unset | up | up |

```
firepower# show nameif
```

| Interface | Name | Security |
|-----------|------|----------|
|-----------|------|----------|

```

Port-channel15      INSIDE      0
Ethernet1/1        diagnostic  0

```

```
<#root>
```

```
firepower#
```

```
show interface Port-channel15 detail
```

```

Interface Port-channel15 "INSIDE", is up, line protocol is up
  Hardware is EtherSVI, BW 20000 Mbps, DLY 1000 usec
    MAC address 2c33.118e.07de, MTU 1500
    IP address unassigned
  Traffic Statistics for "INSIDE":
    6767 packets input, 566328 bytes
    0 packets output, 0 bytes
    6736 packets dropped
    1 minute input rate 4 pkts/sec, 375 bytes/sec
    1 minute output rate 0 pkts/sec, 0 bytes/sec
    1 minute drop rate, 4 pkts/sec
    5 minute input rate 4 pkts/sec, 401 bytes/sec
    5 minute output rate 0 pkts/sec, 0 bytes/sec
    5 minute drop rate, 4 pkts/sec
  Control Point Interface States:
    Interface number is 6
    Interface config status is active
    Interface state is active

```

To check the status of the Port-Channel and its members, navigate to **FXOS** mode:

```
<#root>
```

```
FP4110-7-A#
```

```
connect fxos
```

```
FP4110-7-A(fxos)#
```

```
show port-channel summary
```

```

Flags: D - Down          P - Up in port-channel (members)
       I - Individual    H - Hot-standby (LACP only)
       s - Suspended     r - Module-removed
       S - Switched      R - Routed
       U - Up (port-channel)
       M - Not in use. Min-links not met

```

```

-----
Group Port-      Type      Protocol  Member Ports
Channel
-----
15   Po15(SU)    Eth       LACP      Eth1/2(P)  Eth1/3(P)
48   Po48(SD)    Eth       NONE      --

```

To see the state of the Port-Channels along with last state history:

```
<#root>
```

FP4110-7-A(fxos)#

show port-channel database

port-channel15

Last membership update is successful
2 ports in total, 2 ports up
First operational port is Ethernet1/3
Age of the port-channel is 0d:00h:35m:00s
Time since last bundle is 0d:00h:34m:56s
Last bundled member is Ethernet1/3
Ports: Ethernet1/2 [active] [up]
Ethernet1/3 [active] [up] *

port-channel148

Last membership update is successful
0 ports in total, 0 ports up
Age of the port-channel is 5d:06h:35m:27s

To check traffic distribution among Port-Channel interface members:

<#root>

FP4110-7-A(fxos)#

show port-channel traffic

Table with 8 columns: ChanId, Port, Rx-Ucst, Tx-Ucst, Rx-Mcst, Tx-Mcst, Rx-Bcst, Tx-Bcst. It shows traffic distribution for two channels (15) across two ports (Eth1/2 and Eth1/3).

LACP neighbor verification

<#root>

FP4110-7-A(fxos)#

show lacp neighbor

Flags: S - Device is sending Slow LACPDUs F - Device is sending Fast LACPDUs
A - Device is in Active mode P - Device is in Passive mode

port-channel15 neighbors

Partner's information

Table showing LACP neighbor information for port Eth1/2, including Partner System ID, Port Number, Age, and Flags.

Partner's information

Table showing LACP neighbor information for port Eth1/3, including Partner System ID, Port Number, Age, and Flags.

| | | |
|---------------|----------|------------|
| Port Priority | Oper Key | Port State |
| 32768 | 0x5 | 0x3f |

Partner Oper Key 0x5 = The switch is configured with Port-Channel ID 5.

On the switch:

<#root>

Switch#


show lacp neighbor

Flags: S - Device is requesting Slow LACPDUs
F - Device is requesting Fast LACPDUs
A - Device is in Active mode P - Device is in Passive mode

Channel group 5 neighbors

Partner's information:

| Port | Flags | LACP port Priority | Dev ID | Age | Admin key | Oper Key | Port Number | Port State |
|---------|-------|-----------------------|----------------|-----|--------------|-------------|----------------|---------------|
| Gi1/0/2 | FA | 32768 | 2c33.118e.07b3 | 0s | 0x0 | 0xE | 0x42 | 0x3F |
| Gi1/0/3 | FA | 32768 | 2c33.118e.07b3 | 0s | 0x0 | 0xE | 0x43 | 0x3F |



Note: On the adjacent Switch, the Partner Oper Key is shown as 0xE (14) although FXOS is configured with Port-Channel ID 15.

LACP packet capture in Wireshark:

LACP switch capture - SLOW - FXOS FAST.pcapng

File Edit View Go Capture Analyze Statistics Telephony Wireless Tools Help

lACP

| No. | Time | Source | Destination | Protocol | Length | Source Port |
|-----|----------------------------|----------------|----------------|----------|--------|-------------|
| 480 | 2017-10-12 11:25:34.759928 | Cisco_ec:59:8f | Slow-Protocols | LACP | 124 | |
| 481 | 2017-10-12 11:25:34.903681 | Cisco_8e:02:a3 | Slow-Protocols | LACP | 124 | |
| 483 | 2017-10-12 11:25:35.723075 | Cisco_ec:59:8f | Slow-Protocols | LACP | 124 | |
| 484 | 2017-10-12 11:25:35.903752 | Cisco_8e:02:a3 | Slow-Protocols | LACP | 124 | |

Partner State: 0x3f LACP Activity, LACP Timeout, Aggregation, Synchronization, Collecting, Distributing

-1 = LACP Activity: Active
-1. = LACP Timeout: Short Timeout
-1.. = Aggregation: Aggregatable
- 1... = Synchronization: In Sync
- ...1 = Collecting: Enabled
- ..1. = Distributing: Enabled
- .0.. = Defaulted: No
- 0... = Expired: No

[Partner State Flags: **DCSGSA]

Reserved: 000000

Collector Information: 0x03

Collector Information Length: 0x10

Collector Max Delay: 32768


Reserved: 00000000000000000000000000000000

| Partner State | | | | | | | | |
|---------------|---------|-----------|-------------|-----------|-----------------|-------------|--------------|---------------|
| State | Expired | Defaulted | Distributed | Collected | Synchronization | Aggregation | LACP Timeout | LACP Activity |
| Value | 0 | 0 | 1 | 1 | 1 | 1 | 1 | 1 |
| Hex | 3 | | | | f | | | |

Verify Port-Channel on FPR21xx/FPR1xxx

Network Diagram

FPR2100



E1/1 Po11 E1/2

G1/0/13 Po22 G1/0/14



Catalyst 3750-X

Port-Channel basic verification

```
<#root>
```

```
>
```

```
connect fxos
```

```
FP2110-2#
```

```
connect local-mgmt
```

```
FP2110-2(local-mgmt)#
```

```
show portchannel summary
```

```
Flags: D - Down P - Up in port-channel (members)
```

```
I - Individual H - Hot-standby (LACP only)
```

```
s - Suspended r - Module-removed
```

```
S - Switched R - Routed
```

```
U - Up (port-channel)
```

```
M - Not in use. Min-links not met
```

```
-----  
Group Port-      Type      Protocol  Member Ports  
Channel  
-----  
11   Po11(U)    Eth      LACP      Eth1/1(P)  Eth1/2(P)
```

Additional verification:

```
<#root>
```

```
FP2110-2#
```

```
scope eth-uplink
```

```
FP2110-2 /eth-uplink #
```

```
scope fabric a
```

```
FP2110-2 /eth-uplink/fabric #
```

```
show port-channel
```

```
Port Channel:
```

| Port Channel Id | Name | Port Type | Admin State | Oper State | State Reason |
|-----------------|----------------|-----------|-------------|------------|--------------|
| 11 | Port-channel11 | Data | Enabled | Up | Up |

Verify the Port-Channel details:

```
<#root>
```

```
FP2110-2 /eth-uplink/fabric #
```

```
show port-channel detail
```

```
Port Channel:
```

```
Port Channel Id: 11
Name: Port-channel11
Port Type: Data
Description:
Admin State: Enabled
Oper State: Up
Auto negotiation: Yes
Speed: 1 Gbps
Duplex: Full Duplex
Oper Speed: 1 Gbps
Band Width (Gbps): 2
State Reason: Up
flow control policy: default
LACP policy name: default
oper LACP policy name: org-root/lacp-default
Lacp Mode: Active
Inline Pair Admin State: Enabled
Inline Pair Peer Port Name:
```

Verify the Port-Channel member details:

```
<#root>
```

```
FP2110-2#
```

```
scope eth-uplink
```

```
FP2110-2 /eth-uplink #
```

```
scope fabric a
```

```
FP2110-2 /eth-uplink/fabric #
```

```
scope port-channel 11
```

```
FP2110-2 /eth-uplink/fabric/port-channel #
```

```
show member-port
```

```
Member Port:
```

| Port Name | Membership | Oper State | State Reason |
|-------------|------------|------------|--------------|
| Ethernet1/1 | Up | Up | Up |
| Ethernet1/2 | Up | Up | Up |

```
Member port details:
```

```
<#root>
```

```
FP2110-2 /eth-uplink/fabric/port-channel #
```

```
show member-port detail
```

```
Member Port:
```

```
Port Name: Ethernet1/1  
Membership: Up  
Oper State: Up  
State Reason: Up  
Ethernet Link Profile name: default  
Oper Ethernet Link Profile name: fabric/lan/eth-link-prof-default  
Udld Oper State: Unknown  
Current Task:
```

```
Port Name: Ethernet1/2  
Membership: Up  
Oper State: Up  
State Reason: Up  
Ethernet Link Profile name: default  
Oper Ethernet Link Profile name: fabric/lan/eth-link-prof-default  
Udld Oper State: Unknown  
Current Task:
```

```
LACP verification
```

```
<#root>
```

```
FP2110-2(local-mgmt)#
```

```
show lacp neighbor
```

Flags: S - Device is requesting Slow LACPDUs
 F - Device is requesting Fast LACPDUs
 A - Device is in Active mode P - Device is in Passive mode

Channel group: 11

Partner (internal) information:

| | | | | |
|--------|----------------------|------------------------|------|---|
| Port | Partner System ID | Partner Port Number | Age | Partner Flags |
| Eth1/1 | 32768,286f.7fec.5980 | 0x10e | 13 s | FA <-- the peer is requesting Fast Rate |

| | | |
|-------------------------------|---------------------|-----------------------|
| LACP Partner Port Priority | Partner Oper Key | Partner Port State |
| 32768 | 0x16 | 0x3f |

Port State Flags Decode:

| | | | |
|-----------|----------|--------------|------------------|
| Activity: | Timeout: | Aggregation: | Synchronization: |
| Active | Long | Yes | Yes |

| | | | |
|------------|---------------|------------|----------|
| Collected: | Distributing: | Defaulted: | Expired: |
| Yes | Yes | No | No |

| | | | | |
|--------|----------------------|------------------------|-----|---|
| Port | Partner System ID | Partner Port Number | Age | Partner Flags |
| Eth1/2 | 32768,286f.7fec.5980 | 0x10f | 5 s | FA <-- the peer is requesting Fast Rate |

| | | |
|-------------------------------|---------------------|-----------------------|
| LACP Partner Port Priority | Partner Oper Key | Partner Port State |
| 32768 | 0x16 | 0x3f |

Port State Flags Decode:

| | | | |
|-----------|----------|--------------|------------------|
| Activity: | Timeout: | Aggregation: | Synchronization: |
| Active | Long | Yes | Yes |

| | | | |
|------------|---------------|------------|----------|
| Collected: | Distributing: | Defaulted: | Expired: |
| Yes | Yes | No | No |

Note: On FPR21xx/FPR1xxx, the default LACP rate is Slow and cannot be changed.

LACP counters

<#root>

FP2110-2(local-mgmt)#

show lacp counters

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|-------------------|---------|------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| ----- | | | | | | | | |
| Channel group: 11 | | | | | | | | |
| Eth1/1 | 4435 | 3532 | 0 | 0 | 0 | 0 | 0 | 0 |
| Eth1/2 | 4566 | 3532 | 0 | 0 | 0 | 0 | 0 | 0 |

FP2110-2(local-mgmt)#

show lacp counters

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|-------------------|---------|------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| ----- | | | | | | | | |
| Channel group: 11 | | | | | | | | |
| Eth1/1 | 4436 | 3532 | 0 | 0 | 0 | 0 | 0 | 0 |
| Eth1/2 | 4567 | 3532 | 0 | 0 | 0 | 0 | 0 | 0 |

FPR2100 interface verification

How the physical interfaces map to the FPR2100 internal Switch:

| Interface | Internal Switch on FPR2110/FPR2120 | Internal Switch on FPR2130/FPR2140 |
|-----------|---------------------------------------|---------------------------------------|
| E1/1 | 1 | 1 |
| E1/2 | 0 | 0 |
| E1/3 | 3 | 3 |
| E1/4 | 2 | 2 |
| E1/5 | 5 | 5 |
| E1/6 | 4 | 4 |
| E1/7 | 7 | 7 |
| E1/8 | 6 | 6 |
| E1/9 | 9 | 49 |
| E1/10 | 8 | 48 |
| E1/11 | 11 | 51 |
| E1/12 | 10 | 50 |
| E1/13 | 12 | 59 |

| | | |
|-------|----|----|
| E1/14 | 13 | 58 |
| E1/15 | 14 | 57 |
| E1/16 | 15 | 56 |
| E2/1 | - | 70 |
| E2/2 | - | 71 |
| E2/3 | - | 69 |
| E2/4 | - | 68 |
| E2/5 | - | 66 |
| E2/6 | - | 67 |
| E2/7 | - | 65 |
| E2/8 | - | 64 |

Verify the physical interface status:

```
<#root>
```

```
FP2110-2(local-mgmt)#
```

```
show portmanager port-info ethernet 1 1
```

```
port_info:
```

```

  if_index:    0x1081000
  type:        PORTMGR_IPC_MSG_PORT_TYPE_PHYSICAL
  mac_address: 70:df:2f:18:d8:04
  flowctl:    PORTMGR_IPC_MSG_FLOWCTL_NONE
  role:        PORTMGR_IPC_MSG_PORT_ROLE_NPU
  admin_state: PORTMGR_IPC_MSG_PORT_STATE_ENABLED
  oper_state:  PORTMGR_IPC_MSG_PORT_STATE_UP
  admin_speed: PORTMGR_IPC_MSG_SPEED_AUTO
  oper_speed:  PORTMGR_IPC_MSG_SPEED_1GB
  admin_mtu:   9216
  admin_duplex: PORTMGR_IPC_MSG_PORT_DUPLEX_FULL
  oper_duplex: PORTMGR_IPC_MSG_PORT_DUPLEX_FULL
  pc_if_index: 0x200000b
  pc_membership_status: PORTMGR_IPC_MSG_MMBR_UP
  pc_protocol: PORTMGR_IPC_MSG_PORT_CHANNEL_PRTCL_LACP_ACTIVE
  native_vlan: 1011

```



```
num_allowed_vlan: 1
allowed_vlan[0]: 1011
```

Physical interface counters:

<#root>

FP2110-2(local-mgmt)#

show portmanager counters ethernet 1 1

| | |
|-------------------------------|-----------|
| Good Octets Received | : 2692986 |
| Bad Octets Received | : 0 |
| MAC Transmit Error | : 0 |
| Good Packets Received | : 37038 |
| Bad Packets Received | : 0 |
| BRDC Packets Received | : 22290 |
| MC Packets Received | : 12538 |
| Size 64 | : 34193 |
| Size 65 to 127 | : 1531 |
| Size 128 to 255 | : 1515 |
| Size 256 to 511 | : 374 |
| Size 512 to 1023 | : 95 |
| Size 1024 to Max | : 0 |
| Good Octets Sent | : 87296 |
| Good Packets Sent | : 682 |
| Excessive Collision | : 0 |
| MC Packets Sent | : 682 |
| BRDC Packets Sent | : 0 |
| Unrecognized MAC Received | : 0 |
| FC Sent | : 0 |
| Good FC Received | : 0 |
| Drop Events | : 0 |
| Undersize Packets | : 0 |
| Fragments Packets | : 0 |
| Oversize Packets | : 0 |
| Jabber Packets | : 0 |
| MAC RX Error Packets Received | : 0 |
| Bad CRC | : 0 |
| Collisions | : 0 |

FPR2100 internal switch MAC table.

Note: 01:80:C2:00:00:02 = LACP

<#root>

FP2110-2(local-mgmt)#

show portmanager switch mac-filters

| port | ix | MAC | mask | action | packets | bytes |
|------|-----|-------------------|-------------------|---------|---------|---------|
| 00 | 03e | 70:DF:2F:18:D8:05 | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 043 | 01:80:C2:00:00:02 | FF:FF:FF:FF:FF:FF | FORWARD | 687 | 87936 |
| | 044 | 70:DF:2F:18:D8:2D | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 045 | FF:FF:FF:FF:FF:FF | FF:FF:FF:FF:FF:FF | FORWARD | 5501 | 385360 |
| | 3d0 | 00:00:00:00:00:00 | 01:00:00:00:00:00 | DROP | 2101 | 141426 |
| | 3e8 | 01:00:00:00:00:00 | 01:00:00:00:00:00 | DROP | 7946 | 1524820 |
| 01 | 03f | 70:DF:2F:18:D8:04 | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 040 | 01:80:C2:00:00:02 | FF:FF:FF:FF:FF:FF | FORWARD | 687 | 87936 |
| | 041 | 70:DF:2F:18:D8:2D | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 042 | FF:FF:FF:FF:FF:FF | FF:FF:FF:FF:FF:FF | FORWARD | 22351 | 1451504 |
| | 3d1 | 00:00:00:00:00:00 | 01:00:00:00:00:00 | DROP | 2215 | 154542 |
| | 3e9 | 01:00:00:00:00:00 | 01:00:00:00:00:00 | DROP | 11886 | 1006067 |

```

02  03c  70:DF:2F:18:D8:07  FF:FF:FF:FF:FF:FF  FORWARD
049  01:80:C2:00:00:02  FF:FF:FF:FF:FF:FF  FORWARD
04a  70:DF:2F:18:D8:6D  FF:FF:FF:FF:FF:FF  FORWARD
04b  FF:FF:FF:FF:FF:FF  FF:FF:FF:FF:FF:FF  FORWARD
3d2  00:00:00:00:00:00  01:00:00:00:00:00  DROP
3ea  01:00:00:00:00:00  01:00:00:00:00:00  DROP

```

Ports e1/1 and e1/2 correspond to 0/0 and 0/1 on the internal switch:

```
<#root>
```

```
FP2110-2(local-mgmt)#
```

```
show portmanager switch status
```

| Dev/Port | Mode | Link | Speed | Duplex | Loopback Mode |
|----------|--------|------|-------|--------|---------------|
| 0/0 | QSGMII | Up | 1G | Full | None |
| 0/1 | QSGMII | Up | 1G | Full | None |
| 0/2 | QSGMII | Down | 1G | Half | None |
| 0/3 | QSGMII | Down | 1G | Half | None |
| 0/4 | QSGMII | Down | 1G | Half | None |
| 0/5 | QSGMII | Down | 1G | Half | None |
| 0/6 | QSGMII | Down | 1G | Half | None |
| 0/7 | QSGMII | Down | 1G | Half | None |
| 0/8 | QSGMII | Down | 1G | Half | None |
| 0/9 | QSGMII | Down | 1G | Half | None |
| 0/10 | QSGMII | Down | 1G | Half | None |
| 0/11 | QSGMII | Down | 1G | Half | None |
| 0/12 | QSGMII | Down | 10 | Half | None |
| 0/13 | QSGMII | Down | 10 | Half | None |
| 0/14 | QSGMII | Down | 10 | Half | None |
| 0/15 | QSGMII | Down | 10 | Half | None |
| 0/16 | n/a | Down | n/a | Full | N/A |
| 0/17 | n/a | Down | n/a | Full | N/A |
| 0/18 | n/a | Down | n/a | Full | N/A |
| 0/19 | n/a | Down | n/a | Full | N/A |
| 0/20 | n/a | Down | n/a | Full | N/A |
| 0/21 | n/a | Down | n/a | Full | N/A |
| 0/22 | n/a | Down | n/a | Full | N/A |
| 0/23 | n/a | Down | n/a | Full | N/A |
| 0/24 | KR | Up | 10G | Full | None |
| 0/25 | KR | Up | 10G | Full | None |
| 0/26 | KR | Down | 10G | Full | None |
| 0/27 | KR | Up | 10G | Full | None |

Troubleshoot

LACP Overview


LACP Facts:

- IEEE standard (802.3ad) Link Aggregation Control Protocol (LACP) is a L2 protocol used for Port-Channel negotiation.
- LACP uses destination MAC 0180.c200.0002 and Ethernet Type 0x8809.
- LACP and Mode On (no LACP) are the only modes supported on Firepower appliances (Mode On was added on FP4100/FP9300 in 2.4.x FXOS release).
- LACP can be configured in one of the 2 modes (Active or Passive). FXOS always uses an Active mode.
- The main goal of LACP is to protect from Port-Channel misconfigurations.
- In order for an LACP PC to come UP, there is a need to have the same Speed/Duplex settings in Port-Channel interface members. On FXOS you set the speed at the Port-Channel level.
- LACP Actor = the local device
- LACP Partner = the remote device
- Each device has an LACP System ID which usually is the chassis' MAC. The LACP System ID is sent within each LACP packet.
- Each LACP packet has ~110 Bytes of size.
- LACP can work in Fast Rate or Slow (Normal) Rate. For FXOS the default is Fast Rate (except 1xxx/21xx where it is always Slow), but it can also be configured as Slow. The LACP mode on the switch side depends on the switch model and SW used. For example, a Cat3750 supports both Slow and Fast as from 15.2(4)E. Check the switch confirmation guide for more details.
- In the LACP detection period, LACPs are sent every 1 sec no matter what is the LACP rate. The LACP rate affects only the LACP Keepalive interval once the interface is UP.

Benefits of LACP Keepalive

The LACP keepalive is helpful in scenarios when the remote interface is not functional anymore, but still UP (no direct failure was detected). This could be the case of driver/L2 problem or if there is some device in the path (for example, IPS) which does not allow the detection of remote link failures. LACP Keepalive has a timeout of peer rate x 3. For example, if the remote peer sends every 1 sec then the local device declares the remote peer down if no LACP packet is received within 3 sec. In the case of Slow Rate, this is after 90 sec.

All the fields of an LACP packet as they are shown in Wireshark:



Note: When a port-channel is terminated on the FTD, the FXOS capture does not show LACP packets (ingress or egress).

LACP Fast Rate vs Slow Rate

In general, the recommendation is to use Fast Rate on both sides (FXOS on 4100/9300 uses Fast Rate by default, on FPR2100 the default LACP Send Rate is Slow). The LACP rate fast can increase the Port-Channel bundling speed.

| | FXOS Configured Slow | FXOS Configured Fast |
|------------------------|---|---|
| Switch Configured Slow | Switch requests Slow FXOS Requests Slow Switch sends 1 LACP/30sec | Switch requests Slow FXOS Requests Fast Switch sends 1 LACP/sec |

| | | |
|------------------------|--|--|
| | FXOS sends 1 LACP/30sec | FXOS sends 1 LACP/30sec |
| Switch Configured Fast | Switch requests Fast FXOS Requests Slow Switch sends 1 LACP/30sec FXOS sends 1 LACP/sec | Switch requests Fast FXOS Requests Fast Switch sends 1 LACP/sec FXOS sends 1 LACP/sec |


To configure the LACP mode on FXOS (41xx/93xx):

```
<#root>
KSEC-FPR4100-1#
scope org
KSEC-FPR4100-1 /org #
show lacppolicy

LACP policy:
  Name      LACP rate
  -----  -
  default   Fast
KSEC-FPR4100-1 /org # scope lacppolicy default
KSEC-FPR4100-1 /org/lacppolicy # set lacp-rate
  fast     lacp rate fast
  normal   lacp rate normal
```

Troubleshoot Port-Channel on FPR4100/FPR9300

Network Diagram



The FPR4100 and FPR9300 chassis contain an internal switch where the Port-Channel is terminated. Since the internal switch is similar to a Nexus 5K and FXOS supports only LACP the troubleshoot approach is similar to a Nexus 5K.

Check 1 – Verify the Port-Channel status.

```
<#root>
```

```
FP4110-7-A(fxos)#
```

```
show port-channel summary
```

```
Flags: D - Down          P - Up in port-channel (members)
       I - Individual    H - Hot-standby (LACP only)
       s - Suspended     r - Module-removed
       S - Switched      R - Routed
       U - Up (port-channel)
       M - Not in use. Min-links not met
```

| Group | Port-Channel | Type | Protocol | Member Ports |
|-------|--------------|------|----------|---------------------|
| 15 | Po15(SU) | Eth | LACP | Eth1/2(P) Eth1/3(P) |

Verify the FXOS interface status:

```
<#root>
```

```
FP4110-7-A(fxos)#
```


show interface brief

| Ethernet Interface | VLAN | Type | Mode | Status | Reason | Speed | Port Ch # |
|--------------------|------|------|--------|--------|-----------------------|---------|-----------|
| Eth1/1 | 1 | eth | 1qtun1 | up | none | 1000(D) | -- |
| Eth1/2 | 1 | eth | 1qtun1 | up | none | 1000(D) | 15 |
| Eth1/3 | 1 | eth | 1qtun1 | up | none | 1000(D) | 15 |
| Eth1/4 | 1 | eth | 1qtun1 | down | SFP not inserted | 10G(D) | -- |
| Eth1/5 | 1 | eth | 1qtun1 | down | Administratively down | 1000(D) | -- |
| Eth1/6 | 1 | eth | 1qtun1 | down | Administratively down | 1000(D) | -- |
| Eth1/7 | 1 | eth | 1qtun1 | down | Administratively down | 10G(D) | -- |
| Eth1/8 | 1 | eth | 1qtun1 | down | SFP not inserted | 10G(D) | -- |
| Eth1/9 | 1 | eth | vntag | up | none | 40G(D) | -- |
| Eth1/10 | 1 | eth | access | down | Administratively down | 40G(D) | -- |
| Eth1/11 | 1 | eth | access | down | Administratively down | 1000(D) | -- |
| Eth1/12 | 1 | eth | access | down | Administratively down | 1000(D) | -- |

Check 2 – Verify that the FXOS sends and receives LACPs (run the command a few times).

<#root>

FP4110-7-A(fxos)#

show lacp counters interface port-channel 15

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|----------------|---------|--------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| port-channel15 | | | | | | | | |
| Ethernet1/2 | 223019 | 207280 | 0 | 0 | 0 | 0 | 0 | 0 |
| Ethernet1/3 | 296532 | 207744 | 0 | 0 | 0 | 0 | 0 | 0 |

Verify the same on the switch:

<#root>

Switch#

show lacp 5 counters

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|------------------|---------|------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| Channel group: 5 | | | | | | | | |
| Gi1/0/2 | 627 | 596 | 0 | 0 | 0 | 0 | 0 | 0 |
| Gi1/0/3 | 623 | 593 | 0 | 0 | 0 | 0 | 0 | 0 |

Verify the LACP details of an individual FXOS interface:

<#root>

```
FP4110-7-A(fxos)#
```

```
show lacp interface ethernet 1/2
```

```
Interface Ethernet1/2 is up
  Channel group is 15 port channel is Po15
  PDUs sent: 222828
  PDUs rcvd: 207074
  Markers sent: 0
  Markers rcvd: 0
  Marker response sent: 0
  Marker response rcvd: 0
  Unknown packets rcvd: 0
  Illegal packets rcvd: 0
Lag Id: [ [(8000, 28-6f-7f-ec-59-80, 5, 8000, 103), (8000, 2c-33-11-8e-7-b3, e,
8000, 42)] ]
Operational as aggregated link since Tue Oct 31 19:14:57 2017
```

```
Local Port: Eth1/2   MAC Address= 2c-33-11-8e-7-b3
  System Identifier=0x8000,2c-33-11-8e-7-b3
  Port Identifier=0x8000,0x42
  Operational key=14
  LACP_Activity=active
  LACP_Timeout=Short Timeout (1s)
  Synchronization=IN_SYNC
  Collected=true
  Distributing=true
```

Check 3 - Verify the LACP IDs of the local and remote device.

```
<#root>
```

```
FP4110-7-A(fxos)#
```

```
show lacp port-channel interface port-channel 15

port-channel15
  System Mac=2c-33-11-8e-7-b3
  Local System Identifier=0x8000,2c-33-11-8e-7-b3
  Admin key=0xe
  Operational key=0xe
  Partner System Identifier=0x8000,28-6f-7f-ec-59-80
  Operational key=0x5
  Max delay=0
  Aggregate or individual=1
  Member Port List=
```

Check 4 (optional) - Collect this output (can be used by Cisco TAC).

```
<#root>
```

```
FP4110-7-A(fxos)#
```

```
show lacp internal event-history errors
```

```
1) Event:E_DEBUG, length:74, at 574387 usecs after Tue Oct 31 19:14:57 2017
  [102] lacp_proto_set_ntt(1780): Restarting periodic tx timer in 0x210 msecs
```

```
2) Event:E_DEBUG, length:467, at 544757 usecs after Tue Oct 31 19:14:57 2017
   [102] lacp_ac_init_port_channel_member(1660): TYPE1 UPDATE lacp_ac_init_port
   _channel_member port-channel port-channel15(0x1600000e) lacp_mcec_type1_upd_sent
   ...
```

Check 5 - Check the LACP FSM transition for the specific port that has the problem. The messages are shown with the oldest at the top of the output.

```
<#root>
```

```
FP4110-7-A(fxos)#
```

```
show lacp internal event-history interface ethernet 1/2
```

```
>>>>FSM: <Ethernet1/2> has 975 logged transitions<<<<<
```

```
1) FSM:<Ethernet1/2> Transition at 257150 usecs after Sun Oct 29 12:35:16 2017
   Previous state: [LACP_ST_WAIT_FOR_HW_TO_PROGRAM_RECEIVE_PATH]
   Triggered event: [LACP_EV_PORT_RECEIVE_PATH_ENABLED_AS_CHANNEL_MEMBER_MESSAGE]
   Next state: [LACP_ST_PORT_MEMBER_RECEIVE_ENABLED]
```

```
...
```

```
4) FSM:<Ethernet1/2> Transition at 966987 usecs after Sun Oct 29 12:35:19 2017
   Previous state: [LACP_ST_PORT_MEMBER_COLLECTING_AND_DISTRIBUTING_ENABLED]
   Triggered event: [LACP_EV_PARTNER_PDU_IN_SYNC] <--- Good (Received LACP with 'Synchronization')
   Next state: [LACP_ST_PORT_IS_DOWN_OR_LACP_IS_DISABLED]
```

```
...
```

```
207) FSM:<Ethernet1/4> Transition at 482767 usecs after Sun Oct 29 13:18:40 2017
   Previous state: [LACP_ST_ATTACHED_TO_AGGREGATOR]
   Triggered event: [LACP_EV_PARTNER_PDU_OUT_OF_SYNC]
   Next state: [FSM_ST_NO_CHANGE]
```

```
208) FSM:<Ethernet1/4> Transition at 363720 usecs after Sun Oct 29 13:18:41 2017
   Previous state: [LACP_ST_ATTACHED_TO_AGGREGATOR]
   Triggered event: [LACP_EV_PARTNER_PDU_OUT_OF_SYNC] <--- Bad (Received LACP with 'Synchronization')
   Next state: [FSM_ST_NO_CHANGE]
```

Check 6 - Collect the Port-Channel event history (can be used by Cisco TAC).

```
<#root>
```


```
FP4110-7-A(fxos)#
```

```
show port-channel internal event-history all
```

```
Low Priority Pending queue: len(0), max len(1) [Tue Oct 31 19:37:03 2017] High Priority Pending queue: 1
```

Troubleshoot Port-Channel on FPR21xx/FPR1xxx

Network Diagram



Check 1. In case LACP is used, verify the LACP counters.

You see both sides (switch and FXOS) send and receive:

```
<#root>
```

```
FP2110-2(local-mgmt)#
```

```
show lacp counters
```

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|-------------------|---------|------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| ----- | | | | | | | | |
| Channel group: 11 | | | | | | | | |
| Eth1/1 | 4435 | 3532 | 0 | 0 | 0 | 0 | 0 | 0 |
| Eth1/2 | 4566 | 3532 | 0 | 0 | 0 | 0 | 0 | 0 |

Another way to verify the same:

```
<#root>
```

```
FP2110-2(local-mgmt)#
```

show pktmgr counters

| Ports | Tx Packets | Tx Drops | Tx Bytes | Rx Packets | Rx Drops | Rx Bytes | Rx Forwards | |
|---------|---------------|-------------|-------------|---------------|-------------|-------------|----------------|-----------------------------|
| Eth1/1 | 4575 | 0 | 567300 | 3537 | 0 | 452736 | 3537 | < LACP PDUs forwarded inter |
| Eth1/2 | 4706 | 0 | 583544 | 3537 | 0 | 452736 | 3537 | < LACP PDUs forwarded inter |
| Eth1/3 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/4 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/5 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/6 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/7 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/8 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/9 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/10 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/11 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/12 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/13 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/14 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/15 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/16 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| Misc. | 0 | 0 | 0 | 0 | 0 | 0 | n/a | |

Check 2. Verify the upstream switch status.

<#root>

FP2110-2(local-mgmt)#

show lacp neighbor

Flags: S - Device is requesting Slow LACPDUs
F - Device is requesting Fast LACPDUs
A - Device is in Active mode P - Device is in Passive mode

Channel group: 11

Partner (internal) information:

| Port | Partner System ID | Partner Port Number | Age | Partner Flags |
|--------|----------------------|------------------------|-----|------------------|
| Eth1/1 | 32768,286f.7fec.5980 | 0x10e | 9 s | FA |

| LACP Partner Port Priority | Partner Oper Key | Partner Port State |
|-------------------------------|---------------------|-----------------------|
| 32768 | 0x16 | 0x3f |

Port State Flags Decode:

| Activity: | Timeout: | Aggregation: | Synchronization: |
|-----------|----------|--------------|------------------|
| Active | Long | Yes | Yes |

| Collected: | Distributing: | Defaulted: | Expired: |
|------------|---------------|------------|----------|
| Yes | Yes | No | No |


| Port | Partner System ID | Partner Port Number | Age | Partner Flags |
|--------|----------------------|------------------------|------|------------------|
| Eth1/2 | 32768,286f.7fec.5980 | 0x10f | 24 s | FA |

| | | |
|---------------|----------|------------|
| LACP Partner | Partner | Partner |
| Port Priority | Oper Key | Port State |
| 32768 | 0x16 | 0x3f |

Port State Flags Decode:

| | | | |
|-----------|----------|--------------|------------------|
| Activity: | Timeout: | Aggregation: | Synchronization: |
| Active | Long | Yes | Yes |

| | | | |
|------------|--------------|------------|----------|
| Collected: | Distributed: | Defaulted: | Expired: |
| Yes | Yes | No | No |



Note: If Collected and Distributed are not Yes and Defaulted is No then LACP is not converged.

Check 3. Verify that the local LACP system-ID is not 0.

<#root>

FP2110-2(local-mgmt)#

```
show lacp sys-id
```

```
32768, 70df.2f18.d813
```

Additional Troubleshoot (Common in all Platforms)

Check 1

Ensure that both sides (Firewall and switch) have matched settings (for example, Speed is the same, Port-Channel mode is the same).

Check 2

Check for FXOS faults. You can do this check from the chassis User Interface (UI) or from the CLI that uses this command:

```
<#root>
```

```
FPR4100#
```

```
show fault
```

| Severity | Code | Last Transition Time | ID | Description |
|----------|-------|-------------------------|--------|--|
| Major | F0479 | 2020-03-19T11:50:44.322 | 543322 | Virtual interface 781 link state is down |
| Major | F0373 | 2020-03-19T10:55:13.778 | 34178 | Fan 1 in Fan Module 1-5 under chassis 1 operability |
| Minor | F0480 | 2020-03-19T10:55:13.777 | 34177 | Fan module 1-5 in chassis 1 operability: degraded |
| Major | F1767 | 2020-03-19T10:54:04.162 | 531228 | The password encryption key has not been set. |
| Major | F0727 | 2020-03-19T09:50:02.891 | 522921 | lan Member 1/5 of Port-Channel 10 on fabric interconnect |
| Major | F0282 | 2020-03-19T09:49:31.462 | 522922 | lan port-channel 10 on fabric interconnect A oper state |
| Major | F0277 | 2020-03-19T09:49:31.437 | 522929 | ether port 1/5 on fabric interconnect A oper state |
| Info | F0279 | 2020-01-17T11:06:45.472 | 300958 | ether port 1/7 on fabric interconnect A oper state |
| Info | F0279 | 2020-01-17T11:06:37.941 | 300903 | ether port 1/6 on fabric interconnect A oper state |
| Minor | F1437 | 2020-01-16T10:11:39.675 | 291723 | Config backup may be outdated |


The faults are shown in chronological order. The Severity reflects the importance of the fault, while the description provides a brief overview. The focus is mainly on the severity, the timestamp, and the description. The fault severity order from most severe to least severe is:

- Critical
- Major
- Minor
- Warning
- Info/Condition
- Cleared

For details about each fault check the FXOS Faults and Error Messages guide: [FXOS Error and System Messages](#)

Error and System Messages

View Documents by Topic

Choose a Topic 

Cisco Firepower 9300 FXOS Faults and Error Messages

[Cisco Firepower 4100/9300 FXOS Faults and Error Messages, 2.7\(1\)](#) 25/Sep/2019

[Cisco Firepower 4100/9300 FXOS Faults and Error Messages, 2.6\(1\)](#) 13/Mar/2019

[Cisco Firepower 4100/9300 FXOS Faults and Error Messages, 2.4\(1\)](#) 25/Oct/2018

[Cisco FXOS Faults and Error Messages, 2.3\(1\)](#) 29/Nov/2017

[Cisco FXOS Faults and Error Messages, 2.2\(2\)](#) 28/Aug/2017

Check 3

If you did some recent changes related to Port-Channel configuration on FMC, ensure that the policy was deployed from FMC to FTD.

Check 4

If the Port-Channel is in Failed state, and the device belongs to a Cluster, then ensure that the Cluster is enabled on the device. A device that is kicked off the cluster is normal to have the Port-Channel in a failed state.

Check 5

If the configuration is correct, but the interface does not come UP check and replace the cable and/or Small Form-Factor Pluggable (SFP) transceiver.

Check 6

Check the firepower Release Notes for known issues related to Port-Channel. For example, if you run FXOS version 2.6.1.169 and FTD 6.4.0.6 check these sections:

Cisco Firepower 4100/9300 FXOS Release Notes, 2.6(1)

Contents

[Cisco Firepower 4100/9300 FXOS Release Notes, 2.6\(1\)](#)

[Introduction](#)

[What's New](#)

[Software Download](#)

[Important Notes](#)

[Adapter Bootloader Upgrade](#)

[System Requirements](#)

[Upgrade Instructions](#)

[Open and Resolved Bugs](#)

[Open Bugs](#)

[Resolved Bugs in FXOS 2.6.1.192](#)

[Resolved Bugs in FXOS 2.6.1.187](#)

[Resolved Bugs in FXOS 2.6.1.174](#)

[Resolved Bugs in FXOS 2.6.1.169](#)

[Resolved Bugs in FXOS 2.6.1.166](#)

[Resolved Bugs in FXOS 2.6.1.157](#)

[Resolved Bugs in FXOS 2.6.1.131](#)

Additionally, check the related FMC/FTD Release Notes. Since in this example the FTD runs 6.4.0.5 there is need to check the 6.4.x Release Notes:

Cisco Firepower Release Notes, Version 6.4.0.1, 6.4.0.2, 6.4.0.3, 6.4.0.4, 6.4.0.5, 6.4.0.7, and 6.4.0.8

Book Contents

Find Matches in This Book

Download Print

Chapter: Resolved Issues

Updated: February 26, 2020

> Chapter Contents

Bugs listed for a patch were verified as resolved when that patch was initially released.



Note

For your convenience, this document provides lists of resolved bugs for each patch. These lists are auto-generated once and are not subsequently updated. Depending on how and when a particular resolved issue was categorized or updated in our system, it may not appear in the release notes. You should regard the Cisco Bug Search Tool as the 'source of truth.'

- [Searching for Resolved Issues](#)
- [Resolved Issues in New Builds](#)
- [Version 6.4.0.8 Resolved Issues](#)
- [Version 6.4.0.7 Resolved Issues](#)
- [Version 6.4.0.6 Resolved Issues](#)
- [Version 6.4.0.5 Resolved Issues](#)

Was this Document Helpful?

Yes

No

Feedback


Viewers of This Document Also Viewed

- [Upgrade to Version 6.4.0.x](#)
- [Known Issues](#)
- [Available Hotfixes](#)

Common Issues

Case 1. EtherChannel Mode Mismatch

Consider this topology:



The Problem Symptoms

On Firepower the Port-Channel is Down and the Negotiation protocol is LACP:

```
<#root>
```

```
FP2110-2(local-mgmt)#
```

```
show portchannel summary
```

```
Flags: D - Down          P - Up in port-channel (members)
I - Individual          H - Hot-standby (LACP only)
s - Suspended          r - Module-removed
S - Switched           R - Routed
U - Up (port-channel)
M - Not in use. Min-links not met
```

| Group | Port-Channel | Type | Protocol | Member Ports |
|-------|--------------|------|----------|---------------------|
| 11 | Po11(D) | Eth | LACP | Eth1/1(D) Eth1/2(D) |

On FXOS the LACP Sent counters increment every 30 sec, but the Receive counters do not:

```
<#root>
```

```
FP2110-2(local-mgmt)#
```

```
show lacp counters
```

```
-----  
Port          LACPDUs      Marker      Marker Response  LACPDUs  
              Sent   Recv      Sent   Recv      Sent   Recv      Pkts Err  
-----  
Channel group: 11  
Eth1/1        11356  3762      0      0          0      0          0  
Eth1/2        11393  3761      0      0          0      0          0  
FP2110-2(local-mgmt)#
```

```
show lacp counters
```

```
-----  
Port          LACPDUs      Marker      Marker Response  LACPDUs  
              Sent   Recv      Sent   Recv      Sent   Recv      Pkts Err  
-----  
Channel group: 11  
Eth1/1        11357  3762      0      0          0      0          0  
Eth1/2        11394  3761      0      0          0      0          0
```

The Root Cause

The Port-Channel on the switch is UP, but notice the absence of Negotiation protocol:

```
<#root>
```

```
Switch#
```

```
show etherchannel 22 summary
```

```
...  
Number of channel-groups in use: 15  
Number of aggregators:          15
```

```
Group Port-channel Protocol Ports  
-----+-----+-----+-----  
22    Po22(SU)         -      Gi1/0/13(P) Gi1/0/14(P)
```

The switch port configuration confirms this:

```
<#root>
```

```
Switch#
```

```
show run int g1/0/13
```

```
interface GigabitEthernet1/0/13  
  lacp rate fast  
  channel-group 22 mode on  
end
```

```
Switch#
```

```
show run int g1/0/14
```

```
interface GigabitEthernet1/0/14
 lacp rate fast
 channel-group 22 mode on
end
```

Solution

Since this is an FPR21xx appliance, there are 2 possible solutions:

1. Change the Port-Channel mode on the switch side from ON to LACP (Active or Passive).
2. Change the Port-Channel mode on the FTD side from LACP to ON.

In this scenario, the second solution was chosen (set FTD Port-Channel to mode ON):

```
<#root>
```

```
FP2110-2(local-mgmt)#
```

```
show portchannel summary
```

```
Flags: D - Down          P - Up in port-channel (members)
I - Individual          H - Hot-standby (LACP only)
s - Suspended          r - Module-removed
S - Switched           R - Routed
U - Up (port-channel)
M - Not in use. Min-links not met
```

```
-----
Group Port-      Type      Protocol  Member Ports
  Channel
-----
11   Po11(U)     Eth       ON        Eth1/1(P)  Eth1/2(P)
```

The LACP counters are not shown any more:

```
<#root>
```

```
FP2110-2(local-mgmt)#
```

```
show lacp counters
```

```
FP2110-2(local-mgmt)#
```

Case 2. Wrong Port-Channel Design

The Problem Symptoms

```
<#root>
```

```
FP4110-7-A(fxos)#
```

```
show port-channel summary
```

Flags: D - Down P - Up in port-channel (members)
 I - Individual H - Hot-standby (LACP only)
 s - Suspended r - Module-removed
 S - Switched R - Routed
 U - Up (port-channel)
 M - Not in use. Min-links not met

```
-----
```

| Group | Port-Channel | Type | Protocol | Member Ports |
|-------|--------------|------|----------|---------------------|
| 15 | Po15(SD) | Eth | LACP | Eth1/2(P) Eth1/3(s) |
| 48 | Po48(SD) | Eth | NONE | -- |

```
-----
```

FXOS LACP counters increase in both directions:

<#root>

FP4110-7-A(fxos)#

show lacp counters

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|----------------|---------|--------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| ----- | | | | | | | | |
| port-channel15 | | | | | | | | |
| Ethernet1/2 | 419219 | 451268 | 0 | 0 | 0 | 0 | 0 | 0 |
| Ethernet1/3 | 419215 | 446806 | 0 | 0 | 0 | 0 | 0 | 0 |

FP4110-7-A(fxos)# show lacp counters

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|----------------|---------|--------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| ----- | | | | | | | | |
| port-channel15 | | | | | | | | |
| Ethernet1/2 | 419219 | 451269 | 0 | 0 | 0 | 0 | 0 | 0 |
| Ethernet1/3 | 419216 | 446807 | 0 | 0 | 0 | 0 | 0 | 0 |

The Root Cause

The output of show lacp neighbor shows different Partner System ID on each port:

<#root>

FP4110-7-A(fxos)#

show lacp neighbor

Flags: S - Device is sending Slow LACPDUs F - Device is sending Fast LACPDUs
 A - Device is in Active mode P - Device is in Passive mode

port-channel15 neighbors


Partner's information

| Port | Partner System ID | Partner Port Number | Age | Partner Flags |
|--------|------------------------------|---------------------|--------|---------------|
| Eth1/2 | 32768,28-6f-7f-ec-59-800x103 | | 419611 | FA |
| | LACP Partner | Partner | | Partner |
| | Port Priority | Oper Key | | Port State |
| | 32768 | 0x5 | | 0x3d |

Partner's information

| | | | | |
|---------------|-----------------------|-------------|---------|------------|
| Partner | Partner | Partner | Partner | |
| Port | System ID | Port Number | Age | Flags |
| Eth1/3 | 32768,4-62-73-d2-65-0 | 0x12f | 419610 | SA |
| LACP Partner | Partner | Partner | Partner | |
| Port Priority | 32768 | Oper Key | 0x16 | Port State |
| | | | | 0xd |

This can be visualized as:




Solution

- In the case of 2960, you need to configure stacking (FlexStack).
- In the case of 3750-X/3850 and so on, you need to configure stacking (StackWise Plus).
- In the case of 4500, 6500, 6800, you need to use Virtual Switching System (VSS).
- In the case of Nexus 5K, 7K or 9K, you need to use Virtual Port-Channel (vPC).
- In a different case, you need to connect the FXOS to the same physical switch.

Case 3. FXOS Port-Channel Unassigned

Network Diagram



The Problem Symptoms

On FXOS side the Port-Channel members are Suspended:

```
<#root>
```

```
FP4110-7-A(fxos)#
```

```
show port-channel summary
```

```
Flags: D - Down          P - Up in port-channel (members)
       I - Individual    H - Hot-standby (LACP only)
       s - Suspended     r - Module-removed
       S - Switched      R - Routed
       U - Up (port-channel)
       M - Not in use. Min-links not met
```

```
-----
```

| Group | Port-Channel | Type | Protocol | Member Ports |
|-------|--------------|------|----------|---------------------|
| 15 | Po15(SD) | Eth | LACP | Eth1/2(s) Eth1/3(s) |
| 48 | Po48(SD) | Eth | NONE | -- |

```
-----
```

The same on the switch side:

```
<#root>
```

```
Switch#
```

```
show etherchannel 5 summary
```



```

...
Group Port-channel Protocol Ports
-----+-----+-----+-----
5 Po5(SD) LACP Gi1/0/2(s) Gi1/0/3(s)

```

FXOS LACP counters shows packets that are sent and received:

```
<#root>
```

```
FP4110-7-A(fxos)#
```

```
show lacp counters
```

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|----------------|---------|--------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| ----- | | | | | | | | |
| port-channel15 | | | | | | | | |
| Ethernet1/2 | 420839 | 452531 | 0 | 0 | 0 | 0 | 0 | 0 |
| Ethernet1/3 | 420793 | 447409 | 0 | 0 | 0 | 0 | 0 | 0 |

```
FP4110-7-A(fxos)#
```

```
show lacp counters
```

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|----------------|---------|--------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| ----- | | | | | | | | |
| port-channel15 | | | | | | | | |
| Ethernet1/2 | 421026 | 452537 | 0 | 0 | 0 | 0 | 0 | 0 |
| Ethernet1/3 | 420981 | 447416 | 0 | 0 | 0 | 0 | 0 | 0 |

On the switch side, the LACP counters also show packets that are sent, but not received:

```
<#root>
```

```
Switch#
```

```
show lacp 5 counters
```

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|------------------|---------|--------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| ----- | | | | | | | | |
| Channel group: 5 | | | | | | | | |
| Gi1/0/2 | 452539 | 420223 | 0 | 0 | 0 | 0 | 0 | 0 |
| Gi1/0/3 | 447232 | 415274 | 0 | 0 | 0 | 0 | 0 | 0 |


```
Switch#
```

```
show lacp 5 counters
```

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|------------------|---------|--------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| ----- | | | | | | | | |
| Channel group: 5 | | | | | | | | |
| Gi1/0/2 | 452540 | 420223 | 0 | 0 | 0 | 0 | 0 | 0 |
| Gi1/0/3 | 447233 | 415274 | 0 | 0 | 0 | 0 | 0 | 0 |

The Root Cause

The problem, in this case, is that the FXOS Port-Channel is not assigned to the logical device (FTD application):



The screenshot shows the FXOS configuration interface. At the top, there are tabs for Overview, Interfaces, Logical Devices, Security Engine, and Platform Settings. Below the tabs, there is a diagram of the network hardware including Network Module 1, Network Module 2 (Empty), and Network Module 3. Below the diagram, there is a table of interfaces. The table has columns for Interface, Type, Admin Speed, Operational Speed, Application, Admin Duplex, Auto Negotiation, Operation State, and Admin State. The 'Port-channel15' interface is highlighted with an orange box, and its 'Application' and 'Operation State' cells are also highlighted with orange boxes. The 'Operation State' for 'Port-channel15' is 'failed', and for 'Ethernet1/2' and 'Ethernet1/3' it is 'suspended'.


| Interface | Type | Admin Speed | Operational Speed | Application | Admin Duplex | Auto Negotiation | Operation State | Admin State |
|----------------|------------|-------------|-------------------|-------------|--------------|------------------|-----------------|-------------------------------------|
| MGMT | Management | | | | | | | <input checked="" type="checkbox"/> |
| Port-channel15 | data | 1gbps | 1gbps | | Full Duplex | no | failed | <input checked="" type="checkbox"/> |
| Ethernet1/2 | data | 1gbps | | | Full Duplex | no | suspended | |
| Ethernet1/3 | data | 1gbps | | | Full Duplex | no | suspended | |

Solution

Assign the Port-Channel to the logical device.

Case 4. Health Alerts About Port-Channel Do Not Receive Any Packets

The device (FTD) sends every 5 minutes info about the interface traffic received on each interface that has a name configured and is UP. If there are no packets received in the last interval messages like this appear on FMC UI:



The screenshot shows the FMC UI with tabs for Deployments, Health, and Tasks. The Health tab is active, showing a summary of 12 total alerts, 1 warning, 11 critical, and 0 errors. Below the summary, there is a red banner with an exclamation mark icon and the text 'Interface Status'. The banner contains two lines of text: 'Interface 'Port-channel4.50' is not receiving any packets' and 'Interface 'Port-channel10.14' is not receiving any packets'.

Recommended Action

From the FTD CLI, check the show traffic output and focus on the 5-minute input rate. For example,

```
Interface Port-channel10.14
INSIDE:
    received (in 237938.740 secs):
        2 packets      84 bytes
        0 pkts/sec    0 bytes/sec
    transmitted (in 237938.740 secs):
        5 packets     140 bytes
        0 pkts/sec    0 bytes/sec
    1 minute input rate 0 pkts/sec,  0 bytes/sec
    1 minute output rate 0 pkts/sec,  0 bytes/sec
    1 minute drop rate, 0 pkts/sec
    5 minute input rate 0 pkts/sec,  0 bytes/sec
```

5 minute output rate 0 pkts/sec, 0 bytes/sec
5 minute drop rate, 0 pkts/sec

Case 5. Health Alert on FMC: Port-Channel Disassociated or Interface Added

The Health alert states: "Interface with physical-name: "Port-Channel" disassociated." or "Interface with physical-name: \"name_if\" added."

Recommended Action


This is a known, cosmetic issue tracked by Cisco bug ID [CSCvb15074](#)

Port-Channel Considerations

Design Considerations

Case 1. FTD/ASA Blade in HA


This setup is unsupported. The reason is the Port-Channel configuration on the switch side is incorrect and leads to traffic block on the standby device. Such design is only supported when you configure ASA or FTD in Cluster Spanned mode.





Warning: This scenario is incorrect in failover (high-availability).

This is the proper Port-Channel design for High Availability:




Related Information

- [Connecting to an EtherChannel on Another Device](#)
- [EtherChannels for Inter-Chassis Clustering](#)


Case 2. FTD/ASA in Cluster

Each firewall data interface Port-Channel uses Spanned mode (this is the only mode supported on Firepower platforms). From a design point of view, on the switch side, the switchports for a single data interface belong to one port-channel.


For example, in the case of FP9300 (2 chassis, 6 blades) the data ports can be configured like this:




On the other hand, the Cluster Control Link (CCL) uses Individual port-channel mode and per best practices, the bandwidth must match the maximum capacity of each member. Additionally, in the case of Nexus, each port-channel belongs to a different vPC.



Similarly, in case of FP41xx:




And the CCL:





Case 3. Port-Channel Terminated on FXOS

Port-Channel terminated on FXOS chassis. Here is an example of this design:



Case 4. Port-Channel Through FXOS

The Port-Channel goes through the FXOS chassis. Here is an example of this design:



Note: In the second scenario, there is no Port-Channel configured on the Firepower appliance.

Port-Channel terminated on FXOS vs Port-Channel through FXOS

| Feature | Comments |
|---------|----------|
| | |

| | |
|---|---|
| Port-Channel terminated on FXOS chassis (MIO) | Works as from FXOS 2.1.1 |
| Port-Channel goes through FXOS chassis (MIO) | <ul style="list-style-type: none"> • Works before FXOS 2.1.1.58 • Does not work on FXOS \geq 2.1.1.58 and $<$ 2.3.1.3 (due to Cisco bug ID CSCva00405) • Works after FXOS 2.3.1.3 |

Additional Considerations

LACP Graceful Convergence

In case of a Cluster setup (ASA or FTD), the recommendation is for LACP Graceful Convergence to be enabled on Nexus.

Frequently Asked Questions (FAQ)

Q. Is SSP port-channel hash distribution fixed or adaptive?

FXOS uses resilient hash distribution. This seems to be equivalent to the fixed hash-distribution mode described in Nexus 7000/9k documentation online. In resilient hashing, if a link fails, the flows assigned to the failed link are redistributed uniformly among the active links. The current flows through the active links are not reshaped and their packets are not delivered out of order. When a link is added to the port-channel or ECMP group, some of the flows hashed to the current links are reshaped to the new link, but not across all current links.

Q. What happens if the switchports connected to the Port-Channel go down? Does FTD monitor the physical link, or the port-channel?

If all the port-channel interface members go down, the port-channel does down as well. The Port Channel Operation State is shown as failed. From the FTD point of view, the port-channel is shown as down. On the other hand, in this rule, there is an exception: When the switches use stacking. With LACP, the system ID uses the stack MAC address from the active switch, and if the active switch changes, the LACP system ID can change. If the LACP system ID changes, the entire EtherChannel flaps, and there is STP re-convergence. Use the stack-mac persistent timer command to control whether or not the stack MAC address changes after an active switch failover.

Q. Would like to use the command "port-channel min-bundle 2" so that if one link in the port-channel goes down then the port-channel goes down and the firewall does a failover.

This option is not possible on FXOS chassis. As a workaround and whenever possible, configure the lacp min-links command on the peer switches.

Q. How to Capture LACP packets?

Case 1. Port-Channel terminated on the logical appliance (FTD/ASA)

- The Port-Channel is actually terminated at the chassis level (FXOS).
- You cannot capture LACP packets (ingress or egress) at neither chassis level (FXOS) nor application level (FTD/ASA).

Case 2. Port-Channel through the FTD – FTD interface deployed as inline-set:

```
inline-set set1
  snort fail-open down
  interface-pair INSIDE OUTSIDE
!
interface Ethernet1/2
  nameif INSIDE
  cts manual
  propagate sgt preserve-untag
  policy static sgt disabled trusted
!
interface Ethernet1/3
  nameif OUTSIDE
  cts manual
  propagate sgt preserve-untag
  policy static sgt disabled trusted
```

LACP Ethertype is 0x8809 (dec 34825):

```
firepower# capture CAP interface INSIDE ethernet-type 34825
```

```
firepower# show capture CAP
```

```
1: 21:15:00.403131      2894.0f57.271d 0180.c200.0002 0x8809 Length: 124 <-- LACP packet

      0101 0114 8000 0017 dfd6 ec00 0016 8000
      0223 3d00 0000 0214 8000 0017 dfd6 ec00
      0015 8000 0222 3d00 0000 0310 8000 0000
      0000 0000 0000 0000 0000 0000 0000 0000
      0000 0000 0000 0000 0000 0000 0000 0000
      0000 0000 0000 0000 0000 0000 0000 0000
      0000 0000 0000 0000 0000 0000 0000
```

Case 3. Port-Channel through the FTD – FTD interface deployed as bridge-group mode:

```
interface Ethernet1/2
  bridge-group 1
  nameif INSIDE
  cts manual
  propagate sgt preserve-untag
  policy static sgt disabled trusted
  security-level 0
!
interface Ethernet1/3
  bridge-group 1
  nameif OUTSIDE
  cts manual
  propagate sgt preserve-untag
  policy static sgt disabled trusted
  security-level 0
!
interface BVI1
  ip address 192.168.201.134 255.255.255.0
```

```
firepower# capture CAP interface INSIDE ethernet-type 34825
```

```
firepower# show capture CAP
```

1 packet captured

1: 21:21:29.731987 2894.0f57.271c 0180.c200.0002 0x8809 Length: 124 <-- LACP packet

```
0101 0114 8000 0017 dfd6 ec00 0015 8000
0222 7d00 0000 0214 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0310 8000 0000
0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000
0000 0000 0000 0000 0000 0000 0000 0000
```

1 packet shown

Q. How to migrate from a single port to a Port-Channel?

This change requires a Maintenance Window (MW) and is intrusive. Once you migrate from a single interface to Port-Channel all configuration related to the single interface is disassociated from it. Once you create the Port-Channel there is a need to re-associate the same configuration with the newly configured Port-Channel, for example, NAT, Routing, VPN, and so on. For FTD there is a note in this document:

[Configure an EtherChannel](#)

For an ASA device the procedure is described in this document:

[Converting In-Use Interfaces to a Redundant or EtherChannel Interface](#)

Q. How to change FTD high availability (HA) link to Port-Channel?

This change requires a Maintenance Window (MW) and is intrusive. You must break the HA and reconfigure it. In the new HA pair specify as an HA link the Port-Channel. Related document:

[Configure FTD High Availability on Firepower Appliances](#)

Q. Firepower with ASA shows port-channel Up, physical interface status down

This is related to Cisco bug ID [CSCvp03354](#)

Q. Does it matter what to choose for the Port-Channel ID on the FMC? Does it have to match anything on the switch side?

No, it does not matter. You can use whatever Port-Channel ID you want.

Q. Under the Port-Channel Advanced tab, is there a need to do anything for the active/standby MAC?

If you plan to use the Port-Channel in Access Mode (no trunk) and you use High Availability (HA) setup, then Active/Standby MAC is highly recommended to be configured. This recommendation is not Port-Channel-specific but is applicable to any HA setup.

Q. Is it possible to configure descriptions for interface members of a Port-Channel?

Currently (FXOS 2.13.x), it is not supported. Check the latest FXOS configuration guide for additional details.

Q. It is possible to change the FXOS port-channel load-balancing algorithm?

Currently (FXOS 2.13.x), it is not supported. Check the latest FXOS configuration guide for additional details.

Q. Is it possible to configure the minimum number (min-links) of member interfaces in a port-channel in order to transition the port-channel into the bundled state?

Currently (FXOS 2.13.x), it is not supported. Check the latest FXOS configuration guide for additional details.

Related Information

- [FXOS Configuration Guides](#)
- [FMC/FTD Configuration Guides](#)