



# Connections

---

This chapter has details about the connections of the Cisco Nexus Dashboard Data Broker.

Beginning with Release 3.10.1, Cisco Nexus Data Broker (NDB) has been renamed to Cisco Nexus Dashboard Data Broker. However, some instances of NDB are present in this document, to correspond with the GUI, and installation folder structure. References of NDB/ Nexus Data Broker/ Nexus Dashboard Data Broker can be used interchangeably.

- [Connections, on page 1](#)
- [User Connections, on page 1](#)
- [Default Connections, on page 11](#)

## Connections

The **Connections** tab has the following subtabs:


- **User Connections**—user-defined connections to manage traffic between an input port and monitoring tool port. See [User Connections](#) for more details.
- **Default Connections**—by default, ingress traffic on the input ports is denied, until a user-defined connection is defined. See [Default Connections](#) for more details.

## User Connections

The **User Connections** tab displays details of all the user-defined connections between input port(s) (with or without filters) and monitoring tool port(s).

A table with the following details is displayed:

Table 1: User Connections

Column Name	Description
<b>Connection Name</b>	<p>The name of the connection.</p> <p>This field is a hyperlink. Click the name of the connection. A new pane is displayed on the right which has more information about the connection. You can view the topology of the connection in either <b>Deployment View</b> or <b>Network View</b>.</p> <p>Additional actions that can be performed here:</p> <ul style="list-style-type: none"> <li>• <b>Edit Connection</b>—Select this action to edit a connection. See <a href="#">Editing or Cloning a Connection</a> for details.</li> <li>• <b>Clone Connection</b>—Select this action to clone a connection. See <a href="#">Editing or Cloning a Connection</a> for details. Cloning a connection is similar to editing a connection.</li> </ul> <p>Click the <b>Details</b> icon (  ) to get additional details of the connection. A new window displays the following details for the selected connection:</p> <ul style="list-style-type: none"> <li>• General</li> <li>• Deployment View</li> <li>• Network View</li> <li>• Flow Statistics</li> <li>• Port Statistics</li> </ul>
<b>Type</b>	<p>Type of connection. The options are:</p> <ul style="list-style-type: none"> <li>• Normal— here, the connection applies filters on the input ports and redirects traffic to the monitoring tool.</li> <li>• Auto Priority— here, the connection redirects the traffic to the monitoring tool based on the set auto-priority number. For more details, see <a href="#">Auto Priority, on page 10</a>.</li> </ul>
<b>Applied Filters</b>	<p>The number of <b>Allow</b> and <b>Drop</b> filters applied to the connection. Matching traffic is either dropped or allowed based on the selection.</p> <p>This field is a hyperlink. Click the displayed number and a new pane opens on the right. A list of all the filters applied to the connection is displayed.</p>

Column Name	Description
<b>Input Port/ Input Port Groups</b>	The number of input ports and/or input port groups of the connection.  This field is a hyperlink. Click the displayed number and a new pane opens on the right. A list of sources (production devices from which traffic reaches the Nexus Dashboard Data Broker controller) and ports applicable to the connection is displayed.
<b>Monitoring Tools/ Monitoring Tools Group</b>	The number of monitoring tools and/or monitoring tool groups of the connection.  This field is a hyperlink. Click the displayed number and a new pane opens on the right. A list of monitoring tools applicable to the connection is displayed.
<b>Description</b>	Description of the connection.
<b>Created By</b>	User who created the connection.
<b>Last Modified By</b>	User who last modified the connection.

A color coded circle and a lock are displayed at the beginning of each row. The factors impacting the status of a connection are— operational and administration state of the source ports, operational state and administration state of the monitoring tools and the sessions involved in the connection.

- A green circle indicates that the connection is successful.
- A red circle indicates that the connection has failed.
- A yellow circle indicates the connection is partially successful; one or more input port(s) and monitoring tools have errors.
- A gray circle indicates that the connection is not operational; check the state of all the input ports and monitoring tools.

The lock symbol indicates that the connection is locked and unauthorized modification of the connection parameters is not allowed. Only the user (or administrator) who has created the connection or the user who has locked the connection can make required changes. You can lock a connection while adding a connection.

The following actions can be performed from the **User Connections** tab:

- **Add Connection**—Select this action to add a new connection. See [Adding a Connection](#) for details about this task.
- **Delete Connection**—Select the required connection(s) by checking the check box which is at the beginning of the row. Click the **Actions** button and, select **Delete Connection**. The selected connection(s) are deleted. If you choose the delete action without selecting a check box, an error is displayed. You will be prompted to select a connection.
- **Toggle Install**—Select the required connection(s) by checking the check box which is at the beginning of the row. Click the **Actions** button, select **Toggle Install** to install a connection. **Toggle Install** will install/ uninstall connection(s) on the NDB devices but the connection configuration will not be deleted from the Nexus Dashboard Data Broker controller.

If you choose the toggle install action without selecting a check box, an error is displayed. You will be prompted to select a connection.

You can disable deny ACL on all the ISL interfaces by setting the **configure.global.acls** parameter to false in the **config.ini** file. Ensure that you restart Nexus Dashboard Data Broker after making changes in the configuration file.

You can disable Global deny ACL or ISL deny ACL during the CLI upgrade or configuration upload by using the CLI upgrade command and setting the **configure.global.acls** parameter to false in the **config.ini** file. For example:

```
configure.global.acls=false
```

## Adding a Connection

Use this procedure to add a connection. A connection establishes a link between the input ports (with filters) of a device to the monitoring tool ports of the device.

### Before you begin

Complete these tasks:

- Define a filter for the connection
- Configure a monitoring tool (recommended)
- Configure an edge port (recommended)
- Use [Dry Run](#) (recommended)

Follow these restrictions and usage guidelines for creating a connection:

- Configure QinQ VLAN to add a new connection with auto priority across devices (with multiple hops).
- You can configure only one connection with auto priority for each input port/port group.

- 
- Step 1** Navigate to **Connections > User Connections**.
- Step 2** From the **Actions** drop-down list, select **Add Connection**.
- Step 3** In the **Add Connection** dialog box, enter the following details:

*Table 2: Add Connection*

Field	Description
Connection Name	Enter the connection name.
Description	Enter a description for the connection.

Field	Description
<b>Priority</b>	<p>Enter the priority you want to set for the connection. By default, priority level is 100. Range is from 2 to 10000. Higher the number, greater the priority. For example, 200 indicates higher priority when compared to 100.</p> <p>Incoming traffic from the ports is matched based on priority. If two connections have the same inputs ports and same filters, traffic takes the connection with the higher priority.</p> <p><b>Note</b> By default, Edit is enabled for the Cisco NDB administrator role.</p>
<b>Lock Connection</b>	<p>Click the gray button to lock the connection. The gray button turns blue and moves to the right indicating that locking is enabled.</p> <p>Locking a connection prevents unauthorized changes to a connection.</p>
<b>AutoPriority</b>	<p>Click the gray button to enable auto priority. The gray button turns blue and moves to the right indicating that AutoPriority is enabled.</p> <p>When <b>AutoPriority</b> is enabled, the <b>Priority</b> field is disabled. NDB automatically assigns a priority for a connection based on certain criteria (monitoring tools and filters).</p> <p>Auto priority provides flexibility to map filters to multiple monitoring tools in a connection. For more details, see <a href="#">Auto Priority, on page 10</a>.</p>
<b>Connection Topology</b>	<p>Here, you can define <b>Input Port(s), Filter(s) and Monitoring Tools(s)</b> for a connection.</p>

Field	Description
<b>Input Port</b>	<p>Select an input port for the connection.</p> <p>Click <b>Select Input Port(s)/ Group</b>. Select either <b>Input Port</b> or <b>Input Port Group</b>.</p> <p>If you select <b>Input Port</b>, a list of devices is displayed.</p> <ol style="list-style-type: none"> <li>To select a device, check the corresponding check box. Based on the selected device, the available ports of the device are displayed.</li> <li>To select a port, check the corresponding check box. Details of the selected port(s) are displayed on the right. The current status of the port is displayed by a color-coded circle.</li> </ol> <p><b>Note</b> Click <b>Add Input Port</b> to add an input port for the selected device. For the detailed procedure, see <a href="#">Adding an Input Port</a>.</p> <ol style="list-style-type: none"> <li>Click <b>Select</b> to include the selected source port(s) as part of the connection.</li> </ol> <p>If you select <b>Input Port Group</b>, a list of port groups is displayed.</p> <ol style="list-style-type: none"> <li>To select a port group, check the corresponding check box. Details of the selected port group(s) are displayed on the right. The current status of the port group is indicated by a color-coded circle.</li> </ol> <p><b>Note</b> Click <b>Add Input Port Group</b> to add an input port group. For the detailed procedure, see <a href="#">Adding an Input Port Group</a>.</p> <ol style="list-style-type: none"> <li>Click <b>Select</b> to include the selected source port group(s) as part of the connection.</li> </ol>
<b>Filter</b>	<p>Click <b>Select Filter(s)</b>.</p> <ol style="list-style-type: none"> <li>To select a filter, check the corresponding check box. Details of the selected filter(s) are displayed on the right. More than one filter can be selected. You can either choose to use the <b>Allow</b> or <b>Deny</b> behavior for a filter. Allow enables the traffic from the input ports to pass through; deny drops the traffic from the input ports.</li> </ol> <p><b>Note</b> Click <b>Add Filter</b> to add a filter. For the detailed procedure, see <a href="#">Adding a Filter</a>.</p> <ol style="list-style-type: none"> <li>Click <b>Select</b> to include the selected filter(s) as part of the connection.</li> </ol> <p><b>Note</b> This field is disabled if <b>AutoPriority</b> is enabled.</p>

Field	Description
Monitoring Tools	<p>The <b>Select Monitoring Tool(s)/ Group</b> option is displayed if AutoPriority is not enabled.</p> <p>Click <b>Select Monitoring Tool(s)/ Group</b> . Select either <b>Monitoring Tool</b> or <b>Tool Group</b>.</p> <p>If you select <b>Monitoring Tool</b>, a list of monitoring tools is displayed.</p> <ol style="list-style-type: none"> <li>To select a monitoring tool, check the corresponding check box. The details of the monitoring tool are displayed on the right, with the current status of the monitoring tool. The status is indicated by color coded circles.</li> </ol> <p><b>Note</b> Click <b>Add Monitoring Tool</b> to add a monitoring tool. For the detailed procedure, see <a href="#">Adding a Monitoring Tool</a>.</p> <ol style="list-style-type: none"> <li>Click <b>Select</b> to include the monitoring tool(s) as part of the connection.</li> </ol> <p>If you select <b>Tool Group</b>, a list of monitoring tool groups is displayed.</p> <ol style="list-style-type: none"> <li>To select a tool group, check the corresponding check box. Details of the selected tool group(s) are displayed on the right. The current status of the tool group is indicated by a color coded circle.</li> </ol> <p><b>Note</b> Click <b>Add Monitoring Tool Group</b> to add a monitoring tool group. For the detailed procedure, see <a href="#">Adding a Monitoring Tool Group</a>.</p> <ol style="list-style-type: none"> <li>Click <b>Select</b> to include the selected tool group(s) as part of the connection.</li> </ol> <p>The <b>Select Monitoring Tool and Filter Pair</b> option is displayed if AutoPriority is enabled.</p> <ol style="list-style-type: none"> <li>Select one or more monitoring tool(s) and filter(s).</li> <li>Click <b>Select</b>.</li> </ol>

**Step 4** Click **Add Connection** to add the connection or **Install Connection** to add and deploy the connection on the NDB device.

## Editing or Cloning a Connection

Use this procedure to edit or clone a connection.

Editing a connection means changing the parameters of an existing connection.

Cloning a connection means creating a new connection with identical parameters of an existing connection, and then, changing the required parameters. Ensure to change the name of the connection before saving it.

**Before you begin**

Create one or more connections.

**Step 1** Navigate to **Connections > User Connections**.

**Step 2** In the displayed table, click a **Connection Name**.

A new pane is displayed on the right.

**Step 3** Click **Actions** and select **Edit Connection**.

To clone a connection, select **Clone Connection**.

**Step 4** In the **Edit Connection** or **Clone Connection** dialog box, the current connection information is displayed. Modify these fields, as required:

**Table 3: Edit Connection/ Clone Connection**

Field	Description
<b>Connection Name</b>	Connection name.
<b>Description</b>	Description of the connection.
<b>Priority</b>	The current priority of the connection.
<b>Lock Connection</b>	Click the gray button to lock the connection. The gray button turns blue and moves to the right indicating that locking is enabled. Locking a connection prevents unauthorized changes to a connection.
<b>Auto Priority</b>	If <b>Auto Priority</b> was not enabled while adding a connection, then this field is disabled.
<b>Connection Topology</b>	Here, you can define <b>Input Port(s)</b> , <b>Filter(s)</b> and <b>Monitoring Tools(s)</b> for a connection.



Field	Description
<b>Input Port</b>	<p>The current input port(s) included in the connection are displayed. Click the cross mark adjacent to an input port to delete the port from the connection. To edit the input ports, click <b>Select Input Port(s)/ Group</b>. Select either <b>Input Port</b> or <b>Input Port Group</b>.</p> <p>If you select <b>Input Port</b>, a list of devices is displayed.</p> <ol style="list-style-type: none"> <li>a. To select a device, check the corresponding check box. Based on the selected device, the available ports of the device are displayed.</li> <li>b. To select a port, check the corresponding check box. Details of the selected port(s) are displayed on the right.</li> <li>c. Click <b>Select</b> to include the selected source port(s) as part of the connection.</li> </ol> <p>If you select <b>Input Port Group</b>, a list of port groups is displayed.</p> <ol style="list-style-type: none"> <li>a. To select a port group, check the corresponding check box. Details of the selected port group(s) are displayed on the right.</li> <li>b. Click <b>Select</b> to include the selected source port group(s) as part of the connection.</li> </ol>
<b>Filter</b>	<p>The current filter(s) included in the connection are displayed. Click the cross mark adjacent to a filter to delete the filter from the connection. To edit filters, click <b>Select Filter(s)</b>.</p> <ol style="list-style-type: none"> <li>a. To select a filter, check the corresponding check box. Details of the selected filter(s) are displayed on the right. More than one filter can be selected.</li> <li>b. Click <b>Select</b> to include the selected filter(s) as part of the connection.</li> </ol>

Field	Description
<b>Monitoring Tools</b>	<p>The current monitoring tool(s) or tool group(s) included in the connection are displayed. Click the cross mark adjacent to a monitoring tool or tool group to delete it from the connection. To edit any of these, click <b>Select Monitoring Tool(s)/ Group</b> . Select either <b>Monitoring Tool</b> or <b>Tool Group</b>.</p> <p>If you select <b>Monitoring Tool</b>, a list of monitoring tools is displayed.</p> <ol style="list-style-type: none"> <li>a. To select a monitoring tool, check the corresponding check box. The details of the monitoring tool are displayed on the right, with the current status of the monitoring tool. The status is indicated by color coded circles.</li> <li>b. Click <b>Select</b> to include the monitoring tool(s) as part of the connection.</li> </ol> <p>If you select <b>Tool Group</b>, a list of monitoring tool groups is displayed.</p> <ol style="list-style-type: none"> <li>a. To select a tool group, check the corresponding check box. Details of the selected tool group(s) are displayed on the right. The current status of the tool group is indicated by a color coded circle.</li> <li>b. Click <b>Select</b> to include the selected tool group(s) as part of the connection.</li> </ol>

**Step 5** Click **Edit Connection** or **Clone Connection**.

## Auto Priority

Auto priority provides flexibility to map filters to multiple destination devices in a connection. The priority of a connection with Auto-Priority is set to the value configured in the `config.ini` file. You can configure the `connection.autopriority.priorityValue` attribute in the `config.ini` file with a priority value to be used for all the new connections with auto-priority. The connection information lists the allowed filters along with the destination devices.

## Dry Run

You can estimate the amount of traffic generated for a new connection using the Dry Run feature. This feature samples the traffic for 30 seconds for the new connection and estimates the approximate traffic generated for the connection. You can use the Dry Run feature before adding a new connection. You can manage the Dry Run feature using the `mm.dryrun.timer` parameter in the `config.ini` file. To enable the Dry Run feature, set the `mm.dryrun.timer` parameter to a value greater than zero. If the `mm.dryrun.timer` parameter is set to zero, the Dry Run feature is disabled.

The Dry Run feature shows the topology for the new connection with information about the estimated traffic. The feature samples the traffic for few (`mm.dryrun.timer` value in `config.ini` file) seconds for the new connection and estimates the approximate traffic generated for the connection. Use the Dry Run feature before adding a new connection.

# Default Connections

The **Default Connections** tab displays details of the default Nexus Dashboard Data Broker connections. Default deny rules are system-configured on the input ports, monitoring tools and packet truncation ports. This means, by default, traffic received on the input ports is denied, until a user defined connection is configured.

By default, deny ACL is enabled on all the Inter Switch Links (ISL) interfaces causing all the traffic in the ISL interfaces to be dropped if there is no connection installed. The following connections are installed on the ISL interfaces:

- Default-Deny-ISL-*device\_name* connection with Default-Deny-All, Default-Deny-MPLS, and Default-Deny-ARP filters. This connection is supported on all the types of switches in NXAPI mode.
- Default-Deny-ISL-ICMP-*device\_name* connection with Default-Deny-ICMP and Default-Deny-ICMP-All filters. This connection is supported on Nexus 9200, 9300EX, 9300FX, 9500EX, and 9500FX switches in NXAPI mode.
- You can manage this feature using the `mm.addDefaultISLDenyRules` attribute in `config.ini` file. By default, the `mm.addDefaultISLDenyRules` attribute is not present in `config.in` file. To disable this feature, you need to add the `mm.addDefaultISLDenyRules` attribute to `config.ini` file and set it to `false` and restart the device. For example:

```
mm.addDefaultISLDenyRules = false
```

A table is displayed with the following details:

**Table 4: Default Connections**

Column Name	Description
<b>Connection Name</b>	<p>The default connection name.</p> <p>This field is a hyperlink. Click the name of the connection. A new pane is displayed on the right which has more information about the connection.</p> <p>The following actions can be performed here:</p> <ul style="list-style-type: none"> <li>• <b>Clone Connection</b>—Select this action to clone a connection. See <a href="#">Editing or Cloning a Connection</a> for details. Cloning a connection is similar to editing a connection.</li> </ul> <p><b>Note</b> Default connections cannot be edited.</p>
<b>Drop Filters</b>	<p>The number of drop filters for the connection.</p> <p>Drop filters on NDB drop the matching traffic.</p>
<b>Input / Monitoring Ports</b>	<p>The number of input or monitoring ports.</p>
<b>Description</b>	<p>Description of the connection.</p>

