



## **SNMP Command Reference, Cisco IOS XE Release 3SE (Catalyst 3850 Switches)**

**First Published:** 2013-01-11

**Last Modified:** 2013-01-11

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2013 Cisco Systems, Inc. All rights reserved.



## CONTENTS

---

### CHAPTER 1

#### **sample (event trigger) through snmp mib event sample 1**

- show snmp chassis 2
- show snmp community 3
- show snmp contact 5
- show snmp engineID 6
- show snmp group 8
- show snmp host 10
- show snmp location 12
- show snmp user 13
- show snmp view 16

---

### CHAPTER 2

#### **snmp mib event trigger owner through snmp-server enable informs 19**

- snmp-server chassis-id 20
- snmp-server community 22
- snmp-server contact 26

---

### CHAPTER 3

#### **snmp-server enable traps ospf cisco-specific state-change through snmp-server enable traps voice**

- poor-qov 27**
- snmp-server enable traps 28

---

### CHAPTER 4

#### **snmp-server engineID local through snmp trap link-status 37**

- snmp-server engineID local 38
- snmp-server group 40
- snmp-server host 45
- snmp-server inform 59
- snmp-server location 61
- snmp-server packetsize 62
- snmp-server system-shutdown 63

snmp-server tftp-server-list 64  
snmp-server trap-source 66  
snmp-server user 68  
snmp-server view 73

---

**CHAPTER 5****startup (test boolean) through write mib-data 77**

startup (test boolean) 78  
startup (test existence) 79  
startup (test threshold) 80  
test (event trigger) 82  
type (test existence) 84  
url (bulk statistics) 86  
value (test boolean) 88  
value type 89  
wildcard (expression) 91  
write mib-data 92



## sample (event trigger) through snmp mib event sample

---

- [show snmp chassis, page 2](#)
- [show snmp community, page 3](#)
- [show snmp contact, page 5](#)
- [show snmp engineID, page 6](#)
- [show snmp group, page 8](#)
- [show snmp host, page 10](#)
- [show snmp location, page 12](#)
- [show snmp user, page 13](#)
- [show snmp view, page 16](#)

# show snmp chassis

To display the Simple Network Management Protocol (SNMP) server serial number, use the **show snmp chassis** command in privileged EXEC mode.

**show snmp chassis**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The system serial number will be displayed.

**Command Modes** Privileged EXEC (#)

## Command History

Release	Modification
12.4(12)T	This command was introduced.
12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.2SX	This command was integrated into Cisco IOS Release 12.2SX.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

**Usage Guidelines** To configure a message line identifying the SNMP server chassis ID, use the **snmp-server chassis-id** command.

**Examples** The following is sample output from the **show snmp chassis** command. The output is self-explanatory.

```
Router# show snmp chassis
01506199
```

## Related Commands

Command	Description
<b>show snmp</b>	Displays SNMP communication details.
<b>snmp-server chassis-id</b>	Configures a message line identifying the SNMP server serial number.

## show snmp community

To display Simple Network Management Protocol (SNMP) community access strings, use the **show snmp community** command in privileged EXEC mode.

**show snmp community**

**Syntax Description** This command has no arguments or keywords.

**Command Default** All community access strings configured to enable access to SNMP entities are displayed.

**Command Modes** Privileged EXEC (#)

Release	Modification
12.4(12)T	This command was introduced.
12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.2SX	This command was integrated into Cisco IOS Release 12.2SX.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

**Usage Guidelines** Community string consists of 1 to 32 alphanumeric characters and functions like a password enabling access to the SNMP entities.

To set up the community access string to permit access to the SNMP, use the **snmp-server community** command.

**Examples** The following is sample output from the **show snmp community** command. The output displays the community access strings configured for enabling access to an SNMP entity.

```
Router# show snmp community
Community name: ILMI
Community Index: ILMI
Community SecurityName: ILMI
storage-type: read-only active
Community name: private
Community Index: private
Community SecurityName: private
storage-type: nonvolatile active
Community name: private@1
Community Index: private@1
Community SecurityName: private
storage-type: read-only active
```

```
Community name: public
Community Index: public
Community SecurityName: public
storage-type: nonvolatile      active
```

The table below describes the significant fields shown in the display.

**Table 1: show snmp community Field Descriptions**

Field	Description
Community name	Displays the community name.
Community Index	Displays the community index.
Community SecurityName	Displays the security name of the community string.
storage-type	Displays the access type stored for the community string.

#### Related Commands

Command	Description
<b>snmp-server community</b>	Sets up the community string to permit access to SNMP entities.



## show snmp contact

To display Simple Network Management Protocol (SNMP) system contact information, use the **show snmp contact** command in privileged EXEC mode.

**show snmp contact**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The SNMP system contact information is displayed.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	12.4(12)T	This command was introduced.
	12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB2.
	12.2SX	This command was integrated into Cisco IOS Release 12.2SX.
	Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
	Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

**Usage Guidelines** To set the system contact information, use the **snmp-server contact** command.

**Examples** The following is sample output from the **show snmp contact** command. The output is self-explanatory.

```
Router# show snmp contact
snmp-server contact '{"phone": "123-456-7899", "name": "Bob"}'
```

### Related Commands

Command	Description
<b>snmp-server contact</b>	Sets the system contact information.

# show snmp engineID

To display the identification of the local Simple Network Management Protocol (SNMP) engine and all remote engines that have been configured on the router, use the **show snmp engineID** command in EXEC mode.

## show snmp engineID

### Syntax Description

This command has no arguments or keywords.

### Command Modes

EXEC

### Command History

Release	Modification
12.0(3)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

An SNMP engine is a copy of SNMP that can reside on a local or remote device.

### Examples

The following example specifies 0000000902000000C025808 as the local engineID and 123456789ABCDEF000000000 as the remote engine ID, 172.16.37.61 as the IP address of the remote engine (copy of SNMP) and 162 as the port from which the remote device is connected to the local device:

```
Router# show snmp engineID
Local SNMP engineID: 0000000902000000C025808
Remote Engine ID      IP-addr      Port
123456789ABCDEF000000000  172.16.37.61  162
```

The table below describes the fields shown in the display.

**Table 2: show snmp engineID Field Descriptions**

Field	Definition
Local SNMP engine ID	A string that identifies the copy of SNMP on the local device.

Field	Definition
Remote Engine ID	A string that identifies the copy of SNMP on the remote device.
IP-addr	The IP address of the remote device.
Port	The port number on the local device to which the remote device is connected.

**Related Commands**

Command	Description
<b>snmp-server engineID local</b>	Configures a name for either the local or remote SNMP engine on the router.

# show snmp group

To display the names of configured SNMP groups, the security model being used, the status of the different views, and the storage type of each group, use the **show snmp group** command in privileged EXEC mode.

## show snmp group

### Syntax Description

This command has no arguments or keywords.

### Command Modes

Privileged EXEC

### Command History

Release	Modification
12.0(3)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

SNMP groups are configured using the `snmp-server group` command.

SNMP groups and users are used in the context of the View-based Access Control Model (VACM) for SNMP (for further information, see the “VACM for SNMP” IETF internet draft document).

### Examples

The following example specifies the group name as `public`, the security model as `v1`, the read view name as `v1default`, the notify view name as `*tv.FFFFFFFF`, and the storage type as `volatile`:

```
Router# show snmp group
groupname: V1                      security model:v1
readview : v1default                writeview: <no writeview specified>
notifyview: <no notifyview specified>
row status: active
groupname: ILMI                     security model:v1
readview : *ilmi                    writeview: *ilmi
notifyview: <no notifyview specified>
row status: active
groupname: ILMI                     security model:v2c
readview : *ilmi                    writeview: *ilmi
notifyview: <no notifyview specified>
row status: active
groupname: group1                   security model:v1
readview : v1default                writeview: <no writeview specified>
```

```
notifyview: <no notifyview specified>
row status: active
```

The table below describes the fields shown in the example.

**Table 3: show snmp group Field Descriptions**

Field	Definition
groupname	The name of the SNMP group, or collection of users that have a common access policy.
security model	The security model used by the group, either v1, v2c, or v3.
readview	A string identifying the read view of the group. <ul style="list-style-type: none"> <li>• For further information on the SNMP views, use the <b>show snmp view</b> command.</li> </ul>
writeview	A string identifying the write view of the group.
notifyview	A string identifying the notify view of the group. The notify view indicates the group for SNMP notifications, and corresponds to the setting of the <b>snmp-server group</b> <i>group-name version</i> <b>notify</b> <i>notify-view</i> command.

#### Related Commands

Command	Description
<b>snmp-server group</b>	Configures a new SNMP group or a table that maps SNMP users to SNMP views.
<b>show snmp user</b>	Displays the configured characteristics for SNMP users.
<b>show snmp view</b>	Displays a list of configured SNMP views.

# show snmp host

To display the recipient details for Simple Network Management Protocol (SNMP) notification operations, use the **show snmp host** command in privileged EXEC mode.

**show snmp host**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The information configured for SNMP notification operation is displayed.

**Command Modes** Privileged EXEC (#)

Release	Modification
12.4(12)T	This command was introduced.
12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.2SX	This command was integrated into Cisco IOS Release 12.2SX.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

**Usage Guidelines** The **show snmp host** command displays details such as IP address of the Network Management System (NMS), notification type, SNMP version, and the port number of the NMS.

To configure these details, use the **snmp-server host** command.

**Examples** The following is sample output from the **show snmp host** command.

```
Router# show snmp host
Notification host: 10.2.28.6 udp-port: 162   type: inform
user: public   security model: v2c
traps: 00001000.00000000.00000000
The table below describes the significant fields shown in the display.
```

**Table 4: show snmp host Field Descriptions**

Field	Description
Notification host	Displays the IP address of the host for which the notification is generated.

Field	Description
udp-port	Displays the port number.
type	Displays the type of notification.
user	Displays the access type of the user for which the notification is generated.
security model	Displays the SNMP version used to send notifications.
traps	Displays details of the notification generated.

**Related Commands**

Command	Description
<b>snmp-server host</b>	Configures the recipient details for SNMP notification operations.

# show snmp location

To display the Simple Network Management Protocol (SNMP) system location string, use the **show snmp location** command in privileged EXEC mode.

**show snmp location**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The SNMP system location information is displayed.

**Command Modes** Privileged EXEC (#)

## Command History

Release	Modification
12.4(12)T	This command was introduced.
12.2(31)SB	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.2SX	This command was integrated into Cisco IOS Release 12.2SX.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

**Usage Guidelines** To configure system location details, use the **snmp-server location** command.

**Examples** The following is sample output from the **show snmp location** command. The output is self-explanatory.

```
Router# show snmp location
building 3/Room 214
```

## Related Commands

Command	Description
<b>snmp-server location</b>	Configures SNMP system location details.



## show snmp user

To display information about the configured characteristics of Simple Network Management Protocol (SNMP) users, use the **show snmp user** command in privileged EXEC mode.

```
show snmp user [ username ]
```

### Syntax Description

<i>username</i>	(Optional) Name of a specific user or users about which to display SNMP information.
-----------------	--

### Command Modes

Privileged EXEC (#)

### Command History

Release	Modification
12.0(3)T	This command was introduced.
12.3(2)T	The <i>username</i> argument was added. The output for this command was enhanced to show the authentication protocol (MD5 or SHA) and group name.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

An SNMP user must be part of an SNMP group, as configured using the **snmp-server user *username group-name*** command.

When the *username* argument is not entered, the **show snmp user** command displays information about all configured users. If you specify the *username* argument, if one or more users of that name exists, the information pertaining to those users is displayed. Because this command displays users configured with the SNMP engine ID of the local agent and other engine IDs, there can be multiple users with the same username.

When configuring SNMP, you may see the logging message “Configuring snmpv3 USM user.” USM stands for the User-based Security Model for version 3 of the Simple Network Management Protocol (SNMPv3). For further information on the USM, see RFC 2574.

## Examples

The following is sample output from the **show snmp user** command. The output indicates the username as authuser, the engine ID string as 00000009020000000C025808, and the storage type as nonvolatile:

```
Router# show snmp user
  authuser
User name: authuser
Engine ID: 00000009020000000C025808
storage-type: nonvolatile      active access-list: 10
Rowstatus: active
Authentication Protocol: MD5
Privacy protocol: DES
Group name: VacmGroupName
```

The table below describes the significant fields shown in the display.

**Table 5: show snmp user Field Descriptions**

Field	Description
User name	A string identifying the name of the SNMP user.
Engine ID	A string identifying the name of the copy of SNMP on the device.
storage-type	Indicates whether the settings have been set in volatile or temporary memory on the device, or in nonvolatile or persistent memory where settings will remain after the device has been turned off and on again.
active access-list	Standard IP access list associated with the SNMP user.
Rowstatus	Indicates whether Rowstatus is active or inactive.
Authentication Protocol	Identifies which authentication protocol is used. Options are message digest algorithm 5 (MD5), Secure Hash Algorithm (SHA) packet authentication, or None. <ul style="list-style-type: none"> <li>• If authentication is not supported in your software image, this field will not be displayed.</li> </ul>
Privacy protocol	Indicates whether Data Encryption Standard (DES) packet encryption is enabled. <ul style="list-style-type: none"> <li>• If DES is not supported in your software image, this field will not be displayed.</li> </ul>

Field	Description
Group name	Indicates the SNMP group the user is a part of. <ul style="list-style-type: none"><li>• SNMP groups are defined in the context of a View-based Access Control Model (VACM).</li></ul>

# show snmp view

To display the family name, storage type, and status of a Simple Network Management Protocol (SNMP) configuration and associated MIB, use the **show snmp view** command in privileged EXEC mode.

**show snmp view**

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	12.4(2)T	This command was introduced.
	12.0(31)S	This command was integrated into Cisco IOS Release 12.0(31)S.
	Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
	Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

**Usage Guidelines** Use this command to display the SNMP view configuration.

**Examples** The following is sample output from the **show snmp view** command.

```
Router# show snmp view
View Family Name/View Family Subtree/View Family Mask/View Family Type/storage/status
myview          mib-2          -          included      nonvolatile active
myview          cisco          -          included      nonvolatile active
myview          atEntry        -          excluded      nonvolatile active
vldefault       iso            -          included      permanent active
vldefault       internet       -          included      volatile active
vldefault       internet.6.3.15 -          excluded      volatile active
vldefault       internet.6.3.16 -          excluded      volatile active
vldefault       internet.6.3.18 -          excluded      volatile active
```

The table below describes the significant fields shown in the display.

**Table 6: show snmp view Field Descriptions**

Field	Description
View Family Name	Family name.
View Family Subtree	MIB name.

<b>Field</b>	<b>Description</b>
View Family Mask	Family mask. A hyphen (-) appears in this column when no mask is associated.
View Family Type	Type of family, either included or excluded.
storage	Type of memory storage, for example, volatile.
status	Status of the configuration, either active or nonactive.





## **snmp mib event trigger owner through snmp-server enable informs**

---

- [snmp-server chassis-id, page 20](#)
- [snmp-server community, page 22](#)
- [snmp-server contact, page 26](#)

## snmp-server chassis-id

To provide a message line identifying the Simple Network Management Protocol (SNMP) server serial number, use the **snmp-server chassis-id** command in global configuration mode. To restore the default value, if any, use the **no** form of this command.

**snmp-server chassis-id** *text*

**no snmp-server chassis-id**

### Syntax Description

<i>text</i>	Message that identifies the chassis serial number.
-------------	--

### Command Default

On hardware platforms where the serial number can be machine read, the default is the serial number. For example, a Cisco 7000 router has a default chassis-id value of its serial number.

### Command Modes

Global configuration

### Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

The Cisco MIB provides a chassis MIB variable that enables the SNMP manager to gather data on system card descriptions, chassis type, chassis hardware version, chassis ID string, software version of ROM monitor, software version of system image in ROM, bytes of processor RAM installed, bytes of NVRAM installed, bytes of NVRAM in use, current configuration register setting, and the value of the configuration register at the next reload. The following installed card information is provided: type of card, serial number, hardware version, software version, and chassis slot number.

The chassis ID message can be seen with the **show snmp** command.



**Examples**

In the following example, the chassis serial number specified is 1234456:

```
Router(config)# snmp-server chassis-id 1234456
```

**Related Commands**

Command	Description
<b>show snmp</b>	Checks the status of SNMP communications.
show snmp chassis	Displays the SNMP server serial number.

## snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP), use the **snmp-server community** command in global configuration mode. To remove the specified community string, use the **no** form of this command.

**snmp-server community** *string* [**view** *view-name*] [**ro** | **rw**] [**ipv6** *nacl*] [*access-list-number* | *extended-access-list-number*] *access-list-name*]

**no snmp-server community** *string*

### Syntax Description

<i>string</i>	Community string that consists of 1 to 32 alphanumeric characters and functions much like a password, permitting access to SNMP. Blank spaces are not permitted in the community string.  <b>Note</b> The @ symbol is used for delimiting the context information. Avoid using the @ symbol as part of the SNMP community string when configuring this command.
<b>view</b>	(Optional) Specifies a previously defined view. The view defines the objects available to the SNMP community.
<i>view-name</i>	(Optional) Name of a previously defined view.
<b>ro</b>	(Optional) Specifies read-only access. Authorized management stations can retrieve only MIB objects.
<b>rw</b>	(Optional) Specifies read-write access. Authorized management stations can both retrieve and modify MIB objects.
<b>ipv6</b>	(Optional) Specifies an IPv6 named access list.
<i>nacl</i>	(Optional) IPv6 named access list.
<i>access-list-number</i>	(Optional) Integer from 1 to 99 that specifies a standard access list of IP addresses or a string (not to exceed 64 characters) that is the name of a standard access list of IP addresses allowed access to the SNMP agent.  Alternatively, an integer from 1300 to 1999 that specifies a list of IP addresses in the expanded range of standard access list numbers that are allowed to use the community string to gain access to the SNMP agent.

**Command Default** An SNMP community string permits read-only access to all objects.

**Command Modes** Global configuration (config)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	10.0	This command was introduced.
	12.0(14)ST	This command was integrated into Cisco IOS Release 12.0(14)ST.
	12.0(17)S	This command was integrated into Cisco IOS Release 12.0(17)S.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.
	12.3(2)T	The access list values were enhanced to support the expanded range of standard access list values and to support named standard access lists.
	12.0(27)S	The <b>ipv6 nacl</b> keyword and argument pair was added to support assignment of IPv6 named access lists. This keyword and argument pair is not supported in Cisco IOS 12.2S releases.
	12.3(14)T	The <b>ipv6 nacl</b> keyword and argument pair was integrated into Cisco IOS Release 12.3(14)T to support assignment of IPv6 named access lists. This keyword and argument pair is not supported in Cisco IOS 12.2S releases.
	12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.4(11)T	This command was integrated into Cisco IOS Release 12.4(11)T.
	12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
	12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
	Cisco IOS XE Release 2.1	This command was introduced on Cisco ASR 1000 Aggregation Series Routers.
	12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
	12.2(33)SRE	This command was modified. The automatic insertion of the <b>snmp-server community</b> command into the configuration, along with the community string specified in the <b>snmp-server host</b> command, is changed. The <b>snmp-server community</b> command has to be manually configured.

Release	Modification
15.1(0)M	This command was modified. The automatic insertion of the <b>snmp-server community</b> command into the configuration, along with the community string specified in the <b>snmp-server host</b> command, is changed. The <b>snmp-server community</b> command has to be manually configured.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

The **no snmp-server** command disables all versions of SNMP (SNMPv1, SNMPv2C, SNMPv3).

The first **snmp-server** command that you enter enables all versions of SNMP.

To configure SNMP community strings for the MPLS LDP MIB, use the **snmp-server community** command on the host network management station (NMS).



#### Note

In Cisco IOS Release 12.0(3) to 12.2(33)SRD, if a community string was not defined using the **snmp-server community** command prior to using the **snmp-server host** command, the default form of the **snmp-server community** command was automatically inserted into the configuration. The password (community string) used for this automatic configuration of the **snmp-server community** was same as specified in the **snmp-server host** command. However, in Cisco IOS Release 12.2(33)SRE and later releases, you have to manually configure the **snmp-server community** command.

The **snmp-server community** command can be used to specify only an IPv6 named access list, only an IPv4 access list, or both. For you to configure both IPv4 and IPv6 access lists, the IPv6 access list must appear first in the command statement.



#### Note

The @ symbol is used as a delimiter between the community string and the context in which it is used. For example, specific VLAN information in BRIDGE-MIB may be polled using `community@VLAN_ID` (for example, `public@100`) where 100 is the VLAN number. Avoid using the @ symbol as part of the SNMP community string when configuring this command.

### Examples

The following example shows how to set the read/write community string to newstring:

```
Router(config)# snmp-server community newstring rw
```

The following example shows how to allow read-only access for all objects to members of the standard named access list lmnop that specify the comaccess community string. No other SNMP managers have access to any objects.

```
Router(config)# snmp-server community comaccess ro lmnop
```

The following example shows how to assign the string comaccess to SNMP, allow read-only access, and specify that IP access list 4 can use the community string:

```
Router(config)# snmp-server community comaccess ro 4
```

The following example shows how to assign the string manager to SNMP and allow read-write access to the objects in the restricted view:

```
Router(config)# snmp-server community manager view restricted rw
```

The following example shows how to remove the community comaccess:

```
Router(config)# no snmp-server community comaccess
```

The following example shows how to disable all versions of SNMP:

```
Router(config)# no snmp-server
```

The following example shows how to configure an IPv6 access list named list1 and links an SNMP community string with this access list:

```
Router(config)# ipv6 access-list list1
Router(config-ipv6-acl)# permit ipv6 2001:DB8:0:12::/64 any
Router(config-ipv6-acl)# exit
Router(config)# snmp-server community comaccess rw ipv6 list1
```

## Related Commands

Command	Description
<b>access-list</b>	Configures the access list mechanism for filtering frames by protocol type or vendor code.
show snmp community	Displays SNMP community access strings.
<b>snmp-server enable traps</b>	Enables the router to send SNMP notification messages to a designated network management workstation.
<b>snmp-server host</b>	Specifies the targeted recipient of an SNMP notification operation.
<b>snmp-server view</b>	Creates or updates a view entry.

## snmp-server contact

To set the system contact (sysContact) string, use the **snmp-server contact** command in global configuration mode. To remove the system contact information, use the **no** form of this command.

**snmp-server contact** *text*

**no snmp-server contact**

### Syntax Description

<i>text</i>	String that describes the system contact information.
-------------	---

### Command Default

No system contact string is set.

### Command Modes

Global configuration

### Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Examples

The following is an example of a system contact string:

```
Router(config)#snmp-server contact '{"phone": "123-456-7899", "name": "Bob"}'
```

### Related Commands

Command	Description
show snmp contact	Displays SNMP system contact information.
<b>snmp-server location</b>	Sets the system location string.



## **snmp-server enable traps ospf cisco-specific state-change through snmp-server enable traps voice poor-qov**

---

- [snmp-server enable traps, page 28](#)

## snmp-server enable traps

To enable all Simple Network Management Protocol (SNMP) notification types that are available on your system, use the **snmp-server enable traps** command in global configuration mode. To disable all available SNMP notifications, use the **no** form of this command.

**snmp-server enable traps** [ *notification-type* ] [ *vrrp* ]

**no snmp-server enable traps** [ *notification-type* ] [ *vrrp* ]

### Syntax Description

<i>notification-type</i>	<p>(Optional) Type of notification (trap or inform) to enable or disable. If no type is specified, all notifications available on your device are enabled or disabled (if the <b>no</b> form is used). The notification type can be one of the following keywords:</p> <p><b>alarms</b> --Enables alarm filtering to limit the number of syslog messages generated. Alarms are generated for the severity configured as well as for the higher severity values.</p> <ul style="list-style-type: none"> <li>• The <i>severity</i> argument is an integer or string value that identifies the severity of an alarm. Integer values are from 1 to 4. String values are critical, major, minor, and informational. The default is 4 (informational). Severity levels are defined as follows: <ul style="list-style-type: none"> <li>• 1--Critical. The condition affects service.</li> <li>• 2--Major. Immediate action is needed.</li> <li>• 3--Minor. Minor warning conditions.</li> <li>• 4--Informational. No action is required. This is the default.</li> </ul> </li> </ul>
	<ul style="list-style-type: none"> <li>• <b>auth-framework [sec-violation]</b>--Enables the SNMP CISCO-AUTH-FRAMEWORK-MIB traps. The optional <b>sec-violation</b> keyword enables the SNMP camSecurityViolationNotif notification. 1</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>config</b> --Controls configuration notifications, as defined in the CISCO-CONFIG-MAN-MIB (enterprise 1.3.6.1.4.1.9.9.43.2). The notification type is (1) ciscoConfigManEvent.</li> </ul>



	<ul style="list-style-type: none"> <li>• <b>dot1x</b> --Enables IEEE 802.1X traps. This notification type is defined in the CISCO PAE MIB.</li> </ul> <p><b>Catalyst 6500 Series Switches</b> The following keywords are available under the <b>dot1x</b> keyword:</p> <ul style="list-style-type: none"> <li>• <b>auth-fail-vlan</b> --Enables the SNMP cpaeAuthFailVlanNotif notification.</li> <li>• <b>no-auth-fail-vlan</b> --Enables the SNMP cpaeNoAuthFailVlanNotif notification.</li> <li>• <b>guest-vlan</b> --Enables the SNMP cpaeGuestVlanNotif notification.</li> <li>• <b>no-guest-vlan</b> --Enables the SNMP cpaeNoGuestVlanNotif notification.</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>ds0-busyout</b> --Sends notification when the busyout of a DS0 interface changes state (Cisco AS5300 platform only). This notification is defined in the CISCO-POP-MGMT-MIB (enterprise 1.3.6.1.4.1.9.10.19.2), and the notification type is (1) cpmDS0BusyoutNotification.</li> <li>• <b>ds1-loopback</b> --Sends notification when the DS1 interface goes into loopback mode (Cisco AS5300 platform only). This notification type is defined in the CISCO-POP-MGMT-MIB (enterprise 1.3.6.1.4.1.9.10.19.2) as (2) cpmDS1LoopbackNotification.</li> <li>• <b>dsp</b> --Enables SNMP digital signal processing (DSP) traps. This notification type is defined in the CISCO-DSP-MGMT-MIB.</li> <li>• <b>dsp oper-state</b> --Sends a DSP notification made up of both a DSP ID that indicates which DSP is affected and an operational state that indicates whether the DSP has failed or recovered.</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>l2tc</b> --Enable the SNMP Layer 2 tunnel configuration traps. This notification type is defined in CISCO-L2-TUNNEL-CONFIG-MIB.<sup>1</sup></li> </ul>

	<ul style="list-style-type: none"> <li>• <b>entity</b> --Controls Entity MIB modification notifications. This notification type is defined in the ENTITY-MIB (enterprise 1.3.6.1.2.1.47.2) as (1) entConfigChange.</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>entity-diag type</b> -- Enables the SNMP CISCO-ENTITY-DIAG-MIB traps. The valid <i>type</i> values are as follows: 1 <ul style="list-style-type: none"> <li>• <b>boot-up-fail</b>--(Optional) Enables the SNMP ceDiagBootUpFailedNotif traps. 1</li> <li>• <b>hm-test-recover</b>--(Optional) Enables the SNMP ceDiagHMTTestRecoverNotif traps. 1</li> <li>• <b>hm-thresh-reached</b>--(Optional) Enables the SNMP ceDiagHMThresholdReachedNotif traps. 1</li> <li>• <b>scheduled-fail</b>--(Optional) Enables the SNMP ceDiagScheduledJobFailedNotif traps. 1</li> </ul> </li> </ul>
	<ul style="list-style-type: none"> <li>• <b>flowmon</b> --Controls flow monitoring notifications.</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>hsrp</b> --Controls Hot Standby Routing Protocol (HSRP) notifications, as defined in the CISCO-HSRP-MIB (enterprise 1.3.6.1.4.1.9.9.106.2). The notification type is (1) cHsrpStateChange.</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>ipmulticast</b> --Controls IP multicast notifications.</li> </ul>

	<ul style="list-style-type: none"> <li>• <b>license</b> --Enables licensing notifications as traps or informs. The notifications are grouped into categories that can be individually controlled by combining the keywords with the <b>license</b> keyword, or as a group by using the <b>license</b> keyword by itself. <ul style="list-style-type: none"> <li>• <b>deploy</b>--Controls notifications generated as a result of install, clear, or revoke license events.</li> <li>• <b>error</b>--Controls notifications generated as a result of a problem with the license or with the usage of the license.</li> <li>• <b>imagelevel</b>--Controls notifications related to the image level of the license.</li> <li>• <b>usage</b>--Controls usage notifications related to the license.</li> </ul> </li> </ul>
	<ul style="list-style-type: none"> <li>• <b>modem-health</b> --Controls modem-health notifications.</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>module-auto-shutdown [status]</b>--Enables the SNMP CISCO-MODULE-AUTO-SHUTDOWN-MIB traps. The optional <b>status</b> keyword enables the SNMP Module Auto Shutdown status change traps. 1</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>rsvp</b> --Controls Resource Reservation Protocol (RSVP) flow change notifications.</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>sys-threshold</b> --(Optional) Enables the SNMP cltcTunnelSysDropThresholdExceeded notification. This notification type is an enhancement to the CISCO-L2-TUNNEL-CONFIG-MIB. 1</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>tty</b> --Controls TCP connection notifications.</li> </ul>

	<ul style="list-style-type: none"> <li>• <b>xgcp</b> --Sends External Media Gateway Control Protocol (XGCP) notifications. This notification is from the XGCP-MIB-V1SMI.my, and the notification is enterprise 1.3.6.1.3.90.2 (1) xgcpUpDownNotification.</li> </ul> <p><b>Note</b> For additional notification types, see the Related Commands table.</p>
<b>vrrp</b>	(Optional) Specifies the Virtual Router Redundancy Protocol (VRRP).

<sup>1</sup> Supported on the Catalyst 6500 series switches.

**Command Default** No notifications controlled by this command are sent.

**Command Modes** Global configuration (config)

#### Command History

Release	Modification
10.3	This command was introduced.
12.0(2)T	The <b>rsvp</b> notification type was added in Cisco IOS Release 12.0(2)T.
12.0(3)T	The <b>hsrp</b> notification type was added in Cisco IOS Release 12.0(3)T.
12.0(24)S	This command was integrated into Cisco IOS Release 12.0(24)S.
12.2(14)SX	Support for this command was implemented on the Supervisor Engine 720.
12.2(18)S	This command was integrated into Cisco IOS Release 12.2(18)S.
12.2(17d)SXB	Support for this command on the Supervisor Engine 2 was integrated into Cisco IOS Release 12.2(17d)SXB.
12.3(11)T	The <b>vrrp</b> notification type was added in Cisco IOS Release 12.3(11)T.
12.4(4)T	Support for the <b>alarms</b> notification type and <i>severity</i> argument was added in Cisco IOS Release 12.4(4)T. Support for the <b>dsp</b> and <b>dsp oper-staten</b> notification types was added in Cisco IOS Release 12.4(4)T.
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

Release	Modification
12.4(11)T	The <b>dot1x</b> notification type was added in Cisco IOS Release 12.4(11)T.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
12.4(20)T	The <b>licensenotification</b> type keyword was added.
12.2(33)SXH	The <b>l2tc</b> keyword was added and supported on the Catalyst 6500 series switch.
12.2(33)SXI	The following keywords were added and supported on the Catalyst 6500 series switch: <ul style="list-style-type: none"> <li>• <b>auth-fail-vlan</b></li> <li>• <b>entity-diag</b></li> <li>• <b>guest-vlan</b></li> <li>• <b>module-auto-shutdown</b></li> <li>• <b>no-auth-fail-vlan</b></li> <li>• <b>no-guest-vlan</b></li> <li>• <b>sys-threshold</b></li> </ul>
Cisco IOS XE Release 2.6	This command was integrated into Cisco IOS XE Release 2.6.
15.0(1)S	This command was modified. The <b>flowmon</b> notification type was added in Cisco IOS Release 15.0(1)S.
Cisco IOS XE 3.1.0SG	This command was modified. Licensing SNMP traps are enabled by default on Catalyst 4500 series switches.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

For additional notification types, see the Related Commands table for this command.

SNMP notifications can be sent as traps or inform requests. This command enables both traps and inform requests for the specified notification types. To specify whether the notifications should be sent as traps or informs, use the **snmp-server host [traps | informs]** command.

To configure the router to send these SNMP notifications, you must enter at least one **snmp-server enable traps** command. If you enter the command with no keywords, all notification types are enabled. If you enter the command with a keyword, only the notification type related to that keyword is enabled. To enable multiple

types of notifications, you must issue a separate **snmp-server enable traps** command for each notification type and notification option.

Most notification types are disabled by default but some cannot be controlled with the **snmp-server enable traps** command.

The **snmp-server enable traps** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. To send notifications, you must configure at least one **snmp-server host** command.

### Catalyst 6500 Series Switches

The following MIBs were enhanced or supported in Cisco IOS Release 12.2(33)SXI and later releases on the Catalyst 6500 series switch:

- CISCO-L2-TUNNEL-CONFIG-MIB-LLDP--Enhancement. The CISCO-L2-TUNNEL-CONFIG-MIB provides SNMP access to the Layer 2 tunneling-related configurations.
- CISCO-PAE-MIB--Enhancement for critical condition and includes traps when the port goes into the Guest Vlan or AuthFail VLAN.
- CISCO-MODULE-AUTO-SHUTDOWN-MIB--Supported. The CISCO-MODULE-AUTO-SHUTDOWN-MIB provides SNMP access to the Catalyst 6500 series switch Module Automatic Shutdown component.
- CISCO-AUTH-FRAMEWORK-MIB--Supported. The CISCO-AUTH-FRAMEWORK-MIB provides SNMP access to the Authentication Manager component.
- CISCO-ENTITY-DIAG-MIB--The CISCO-ENTITY-DIAG-MIB provides SNMP traps for generic online diagnostics (GOLD) notification enhancements.

### Examples

The following example shows how to enable the router to send all traps to the host specified by the name myhost.cisco.com, using the community string defined as public:

```
Router(config)# snmp-server enable traps
Router(config)# snmp-server host myhost.cisco.com public
```

The following example shows how to configure an alarm severity threshold of 3:

```
Router# snmp-server enable traps alarms 3
```

The following example shows how to enable the generation of a DSP operational state notification from from the command-line interface (CLI):

```
Router(config)# snmp-server enable traps dsp oper-state
```

The following example shows how to enable the generation of a DSP operational state notification from a network management device:

```
setany -v2c 1.4.198.75 test cdspEnableOperStateNotification.0 -i 1
cdspEnableOperStateNotification.0=true(1)
```

The following example shows how to send no traps to any host. The Border Gateway Protocol (BGP) traps are enabled for all hosts, but the only traps enabled to be sent to a host are ISDN traps (which are not enabled in this example).

```
Router(config)# snmp-server enable traps bgp
Router(config)# snmp-server host user1 public isdn
```

The following example shows how to enable the router to send all inform requests to the host at the address myhost.cisco.com, using the community string defined as public:

```
Router(config)# snmp-server enable traps
```

```
Router(config)# snmp-server host myhost.cisco.com informs version 2c public
```

The following example shows how to send HSRP MIB traps to the host myhost.cisco.com using the community string public:

```
Router(config)# snmp-server enable traps hsrp
```

```
Router(config)# snmp-server host myhost.cisco.com traps version 2c public hsrp
```

The following example shows that VRRP will be used as the protocol to enable the traps:

```
Router(config)# snmp-server enable traps vrrp
```

```
Router(config)# snmp-server host myhost.cisco.com traps version 2c vrrp
```

The following example shows how to send IEEE 802.1X MIB traps to the host "myhost.example.com" using the community string defined as public:

```
Router(config)# snmp-server enable traps dot1x
```

```
Router(config)# snmp-server host myhost.example.com traps public
```

## Related Commands

Command	Description
<b>snmp-server enable traps atm pvc</b>	Enables ATM PVC SNMP notifications.
<b>snmp-server enable traps atm pvc extension</b>	Enables extended ATM PVC SNMP notifications.
<b>snmp-server enable traps bgp</b>	Enables BGP server state change SNMP notifications.
<b>snmp-server enable traps calltracker</b>	Enables Call Tracker callSetup and callTerminate SNMP notifications.
<b>snmp-server enable traps envmon</b>	Enables environmental monitor SNMP notifications.
<b>snmp-server enable traps frame-relay</b>	Enables Frame Relay DLCI link status change SNMP notifications.
<b>snmp-server enable traps ipsec</b>	Enables IPsec SNMP notifications.
<b>snmp-server enable traps isakmp</b>	Enables IPsec ISAKMP SNMP notifications.
<b>snmp-server enable traps isdn</b>	Enables ISDN SNMP notifications.
<b>snmp-server enable traps memory</b>	Enables memory pool and buffer pool SNMP notifications.
<b>snmp-server enable traps mpls ldp</b>	Enables MPLS LDP SNMP notifications.
<b>snmp-server enable traps mpls traffic-eng</b>	Enables MPLS TE tunnel state-change SNMP notifications.

Command	Description
<b>snmp-server enable traps mpls vpn</b>	Enables MPLS VPN specific SNMP notifications.
<b>snmp-server enable traps repeater</b>	Enables RFC 1516 hub notifications.
<b>snmp-server enable traps snmp</b>	Enables RFC 1157 SNMP notifications.
<b>snmp-server enable traps syslog</b>	Enables the sending of system logging messages via SNMP.
<b>snmp-server host</b>	Specifies whether you want the SNMP notifications sent as traps or informs, the version of SNMP to use, the security level of the notifications (for SNMPv3), and the destination host (recipient) for the notifications.
<b>snmp-server informs</b>	Specifies inform request options.
<b>snmp-server trap-source</b>	Specifies the interface (and the corresponding IP address) from which an SNMP trap should originate.
<b>snmp trap illegal-address</b>	Issues an SNMP trap when a MAC address violation is detected on an Ethernet hub port of a Cisco 2505, Cisco 2507, or Cisco 2516 router.
<b>vrrp shutdown</b>	Disables a VRRP group.





## snmp-server engineID local through snmp trap link-status

---

- [snmp-server engineID local, page 38](#)
- [snmp-server group, page 40](#)
- [snmp-server host, page 45](#)
- [snmp-server inform, page 59](#)
- [snmp-server location, page 61](#)
- [snmp-server packetsize, page 62](#)
- [snmp-server system-shutdown, page 63](#)
- [snmp-server tftp-server-list, page 64](#)
- [snmp-server trap-source, page 66](#)
- [snmp-server user, page 68](#)
- [snmp-server view, page 73](#)

## snmp-server engineID local

To specify the Simple Network Management Protocol (SNMP) engine ID on the local device, use the **snmp-server engineID local** command in global configuration mode. To remove the configured engine ID, use the **no** form of this command.

**snmp-server engineID local** *engineid-string*

**no snmp-server engineID local** *engineid-string*

### Syntax Description

<i>engineid-string</i>	String of a maximum of 24 characters that identifies the engine ID.
------------------------	---

### Command Default

An SNMP engine ID is generated automatically but is not displayed or stored in the running configuration. You can display the default or configured engine ID by using the **show snmp engineID** command.

### Command Modes

Global configuration (config)

### Command History

Release	Modification
12.0(3)T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

The SNMP engine ID is a unique string used to identify the device for administrative purposes. You do not need to specify an engine ID for the device; a default string is generated using Cisco's enterprise number (1.3.6.1.4.1.9) and the MAC address of the first interface on the device. For further details on the SNMP engine ID, see RFC 2571.

If you specify your own ID, note that the entire 24-character engine ID is not needed if it contains trailing zeros. Specify only the portion of the engine ID up until the point where only zeros remain in the value. For example, to configure an engine ID of 123400000000000000000000, you can specify **snmp-server engineID local 1234**.

The value for the engine ID is displayed in hexadecimal value pairs. If the length of the input is an odd number, the last digit will be prepended with a zero ("0"). For example, if the engine ID is 12345, the ID is treated as 12:34:05 internally. Hence, the engine ID is displayed as 123405 in the **show running configuration** command output.

Changing the value of the SNMP engine ID has significant effects. A user's password (entered on the command line) is converted to a message digest5 algorithm (MD5) or Secure Hash Algorithm (SHA) security digest. This digest is based on both the password and the local engine ID. The command line password is then destroyed, as required by RFC 2274. Because of this deletion, if the local value of the engineID changes, the security digests of SNMPv3 users will become invalid, and the users will have to be reconfigured.

Similar restrictions require the reconfiguration of community strings when the engine ID changes. A remote engine ID is required when an SNMPv3 inform is configured. The remote engine ID is used to compute the security digest for authenticating and encrypting packets sent to a user on the remote host.

### Examples

The following example specifies the local SNMP engine ID:

```
Router(config)# snmp-server engineID local
```

### Related Commands

Command	Description
<b>show snmp engineID</b>	Displays the identification of the local SNMP engine and all remote engines that have been configured on the router.
<b>snmp-server host</b>	Specifies the recipient (SNMP manager) of an SNMP trap notification.

## snmp-server group

To configure a new Simple Network Management Protocol (SNMP) group, use the **snmp-server group** command in global configuration mode. To remove a specified SNMP group, use the **no** form of this command.

**snmp-server group** *group-name* {**v1**|**v2c**|**v3** {**auth**|**noauth**|**priv**}} [**context** *context-name*] [**read** *read-view*] [**write** *write-view*] [**notify** *notify-view*] [**access** [**ipv6** *named-access-list*] [*acl-number*|*acl-name*]]

**no snmp-server group** *group-name* {**v1**|**v2c**|**v3** {**auth**|**noauth**|**priv**}} [**context** *context-name*]

### Syntax Description

<i>group-name</i>	Name of the group.
<b>v1</b>	Specifies that the group is using the SNMPv1 security model. SNMPv1 is the least secure of the possible SNMP security models.
<b>v2c</b>	Specifies that the group is using the SNMPv2c security model.  The SNMPv2c security model allows informs to be transmitted and supports 64-character strings.
<b>v3</b>	Specifies that the group is using the SNMPv3 security model.  SMNPv3 is the most secure of the supported security models. It allows you to explicitly configure authentication characteristics.
<b>auth</b>	Specifies authentication of a packet without encrypting it.
<b>noauth</b>	Specifies no authentication of a packet.
<b>priv</b>	Specifies authentication of a packet with encryption.
<b>context</b>	(Optional) Specifies the SNMP context to associate with this SNMP group and its views.
<i>context-name</i>	(Optional) Context name.
<b>read</b>	(Optional) Specifies a read view for the SNMP group. This view enables you to view only the contents of the agent.

<i>read-view</i>	<p>(Optional) String of a maximum of 64 characters that is the name of the view.</p> <p>The default is that the read-view is assumed to be every object belonging to the Internet object identifier (OID) space (1.3.6.1), unless the <b>read</b> option is used to override this state.</p>
<b>write</b>	(Optional) Specifies a write view for the SNMP group. This view enables you to enter data and configure the contents of the agent.
<i>write-view</i>	<p>(Optional) String of a maximum of 64 characters that is the name of the view.</p> <p>The default is that nothing is defined for the write view (that is, the null OID). You must configure write access.</p>
<b>notify</b>	(Optional) Specifies a notify view for the SNMP group. This view enables you to specify a notify, inform, or trap.
<i>notify-view</i>	<p>(Optional) String of a maximum of 64 characters that is the name of the view.</p> <p>By default, nothing is defined for the notify view (that is, the null OID) until the <b>snmp-server host</b> command is configured. If a view is specified in the <b>snmp-server group</b> command, any notifications in that view that are generated will be sent to all users associated with the group (provided a SNMP server host configuration exists for the user).</p> <p>Cisco recommends that you let the software autogenerate the notify view. See the “Configuring Notify Views” section in this document.</p>
<b>access</b>	(Optional) Specifies a standard access control list (ACL) to associate with the group.
<b>ipv6</b>	(Optional) Specifies an IPv6 named access list. If both IPv6 and IPv4 access lists are indicated, the IPv6 named access list must appear first in the list.
<i>named-access-list</i>	(Optional) Name of the IPv6 access list.
<i>acl-number</i>	(Optional) The <i>acl-number</i> argument is an integer from 1 to 99 that identifies a previously configured standard access list.

<i>acl-name</i>	(Optional) The <i>acl-name</i> argument is a string of a maximum of 64 characters that is the name of a previously configured standard access list.
-----------------	---

**Command Default** No SNMP server groups are configured.

**Command Modes** Global configuration (config)

### Command History

Release	Modification
11.(3)T	This command was introduced.
12.0(23)S	The <b>context</b> <i>context-name</i> keyword and argument pair was added.
12.3(2)T	The <b>context</b> <i>context-name</i> keyword and argument pair was integrated into Cisco IOS Release 12.3(2)T, and support for standard named access lists ( <i>acl-name</i> ) was added.
12.0(27)S	The <b>ipv6</b> <i>named-access-list</i> keyword and argument pair was added.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.3(14)T	The <b>ipv6</b> <i>named-access-list</i> keyword and argument pair was integrated into Cisco IOS Release 12.3(14)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(31)SB2	This command was integrated into Cisco IOS Release 12.2(31)SB2.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
Cisco IOS XE Release 2.1	This command was introduced on Cisco ASR 1000 Series Routers.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

When a community string is configured internally, two groups with the name public are autogenerated, one for the v1 security model and the other for the v2c security model. Similarly, deleting a community string will delete a v1 group with the name public and a v2c group with the name public.

No default values exist for authentication or privacy algorithms when you configure the **snmp-server group** command. Also, no default passwords exist. For information about specifying a Message Digest 5 (MD5) password, see the documentation of the **snmp-server user** command.

### Configuring Notify Views

The notify-view option is available for two reasons:

- If a group has a notify view that is set using SNMP, you may need to change the notify view.
- The **snmp-server host** command may have been configured before the **snmp-server group** command. In this case, you must either reconfigure the **snmp-server host** command, or specify the appropriate notify view.

Specifying a notify view when configuring an SNMP group is not recommended, for the following reasons:

- The **snmp-server host** command autogenerates a notify view for the user, and then adds it to the group associated with that user.
- Modifying the group's notify view will affect all users associated with that group.

Instead of specifying the notify view for a group as part of the **snmp-server group** command, use the following commands in the order specified:

- 1 **snmp-server user** --Configures an SNMP user.
- 2 **snmp-server group** --Configures an SNMP group, without adding a notify view .
- 3 **snmp-server host** --Autogenerates the notify view by specifying the recipient of a trap operation.

### SNMP Contexts

SNMP contexts provide VPN users with a secure way of accessing MIB data. When a VPN is associated with a context, that VPN's specific MIB data exists in that context. Associating a VPN with a context enables service providers to manage networks with multiple VPNs. Creating and associating a context with a VPN enables a provider to prevent the users of one VPN from accessing information about users of other VPNs on the same networking device.

Use this command with the **context** *context-name* keyword and argument to associate a read, write, or notify SNMP view with an SNMP context.

### Examples

#### Examples

The following example shows how to create the SNMP server group "public," allowing read-only access for all objects to members of the standard named access list "lmnop":

```
Router(config)# snmp-server group public v2c access lmnop
```

#### Examples

The following example shows how to remove the SNMP server group "public" from the configuration:

```
Router(config)# no snmp-server group public v2c
```

**Examples**

The following example shows SNMP context “A” associated with the views in SNMPv2c group “GROUP1”:

```
Router(config)# snmp-server context A
Router(config)# snmp mib community commA
Router(config)# snmp mib community-map commA context A target-list commAVpn
Router(config)# snmp-server group GROUP1 v2c context A read viewA write viewA notify viewB
```

**Related Commands**

Command	Description
<b>show snmp group</b>	Displays the names of groups on the router and the security model, the status of the different views, and the storage type of each group.
<b>snmp mib community-map</b>	Associates a SNMP community with an SNMP context, engine ID, security name, or VPN target list.
<b>snmp-server host</b>	Specifies the recipient of a SNMP notification operation.
<b>snmp-server user</b>	Configures a new user to a SNMP group.



## snmp-server host

To specify the recipient of a Simple Network Management Protocol (SNMP) notification operation, use the **snmp-server host** command in global configuration mode. To remove the specified host from the configuration, use the **no** form of this command.

```
snmp-server host {hostname| ip-address} [vrf vrf-name] informs| traps| version {1| 2c| 3} [auth| noauth|
priv]]] community-string [udp-port port [ notification-type ]] notification-type
```

```
no snmp-server host {hostname| ip-address} [vrf vrf-name] informs| traps| version {1| 2c| 3} [auth| noauth|
priv]]] community-string [udp-port port [ notification-type ]] notification-type
```

### Command Syntax on Cisco ME 3400, ME 3400E, and Catalyst 3750 Metro Switches

```
snmp-server host ip-address {community-string| informs| traps} {community-string| version {1| 2c| 3} {auth|
noauth}}] {community-string| vrf vrf-name {informs| traps}} [notification-type]
```

```
no snmp-server host ip-address {community-string| informs| traps} {community-string| version {1| 2c| 3}
{auth| noauth}}] {community-string| vrf vrf-name {informs| traps}} [notification-type]
```

### Command Syntax on Cisco 7600 Series Router

```
snmp-server host ip-address {community-string| {informs| traps} {community-string| version {1| 2c| 3}
{auth| noauth| priv}}} community-string| version {1| 2c| 3} {auth| noauth| priv}}} community-string| vrf
vrf-name {informs| traps} {community-string| version {1| 2c| 3} {auth| noauth| priv}}} community-string}}]
[ notification-type ]
```

```
no snmp-server host ip-address {community-string| {informs| traps} {community-string| version {1| 2c| 3}
{auth| noauth| priv}}} community-string| version {1| 2c| 3} {auth| noauth| priv}}} community-string| vrf
vrf-name {informs| traps} {community-string| version {1| 2c| 3} {auth| noauth| priv}}} community-string}}]
[ notification-type ]
```

### Syntax Description

<i>hostname</i>	Name of the host. The SNMP notification host is typically a network management station (NMS) or SNMP manager. This host is the recipient of the SNMP traps or informs.
<i>ip-address</i>	IPv4 address or IPv6 address of the SNMP notification host.
<b>vrf</b>	(Optional) Specifies that a VPN routing and forwarding (VRF) instance should be used to send SNMP notifications. <ul style="list-style-type: none"> <li>In Cisco IOS Release 12.2(54)SE, the <b>vrf</b> keyword is required.</li> </ul>

<i>vrf-name</i>	<p>(Optional) VPN VRF instance used to send SNMP notifications.</p> <ul style="list-style-type: none"> <li>• In Cisco IOS Release 12.2(54)SE, the <i>vrf-name</i> argument is required.</li> </ul>
<b>informs</b>	<p>(Optional) Specifies that notifications should be sent as informs.</p> <ul style="list-style-type: none"> <li>• In Cisco IOS Release 12.2(54)SE, the <b>informs</b> keyword is required.</li> </ul>
<b>traps</b>	<p>(Optional) Specifies that notifications should be sent as traps. This is the default.</p> <ul style="list-style-type: none"> <li>• In Cisco IOS Release 12.2(54)SE, the <b>traps</b> keyword is required.</li> </ul>
<b>version</b>	<p>(Optional) Specifies the version of the SNMP that is used to send the traps or informs. The default is 1.</p> <ul style="list-style-type: none"> <li>• In Cisco IOS Release 12.2(54)SE, the <b>version</b> keyword is required and the <b>priv</b> keyword is not supported.</li> </ul> <p>If you use the <b>version</b> keyword, one of the following keywords must be specified:</p> <ul style="list-style-type: none"> <li>• <b>1</b> --SNMPv1.</li> <li>• <b>2c</b> --SNMPv2C.</li> <li>• <b>3</b> --SNMPv3. The most secure model because it allows packet encryption with the <b>priv</b> keyword. The default is <b>noauth</b>.</li> </ul> <p>One of the following three optional security level keywords can follow the <b>3</b> keyword:</p> <ul style="list-style-type: none"> <li>• <b>auth</b> --Enables message digest algorithm 5 (MD5) and Secure Hash Algorithm (SHA) packet authentication.</li> <li>• <b>noauth</b> --Specifies that the noAuthNoPriv security level applies to this host. This is the default security level for SNMPv3.</li> <li>• <b>priv</b> --Enables Data Encryption Standard (DES) packet encryption (also called “privacy”).</li> </ul>

<i>community-string</i>	<p>Password-like community string sent with the notification operation.</p> <p><b>Note</b> You can set this string using the <b>snmp-server host</b> command by itself, but Cisco recommends that you define the string using the <b>snmp-server community</b> command prior to using the <b>snmp-server host</b> command.</p> <p><b>Note</b> The “at” sign (@) is used for delimiting the context information.</p>
<b>udp-port</b>	<p>(Optional) Specifies that SNMP traps or informs are to be sent to a network management system (NMS) host.</p> <ul style="list-style-type: none"> <li>In Cisco IOS Release 12.2(54)SE, the <b>udp-port</b> keyword is not supported.</li> </ul>
<i>port</i>	<p>(Optional) User Datagram Protocol (UDP) port number of the NMS host. The default is 162.</p> <ul style="list-style-type: none"> <li>In Cisco IOS Release 12.2(54)SE, the <i>port</i> argument is not supported.</li> </ul>
<i>notification-type</i>	<p>(Optional) Type of notification to be sent to the host. If no type is specified, all available notifications are sent. See the “Usage Guidelines” section for more information about the keywords available.</p>

**Command Default**

This command behavior is disabled by default. A recipient is not specified to receive notifications.

**Command Modes**

Global configuration (config)

**Command History**

Release	Modification
10.0	This command was introduced.
12.0(3)T	<p>This command was modified.</p> <ul style="list-style-type: none"> <li>The <b>version 3 [auth   noauth   priv]</b> syntax was added as part of the SNMPv3 Support feature.</li> <li>The <b>hsrp</b> notification-type keyword was added.</li> <li>The <b>voice</b> notification-type keyword was added.</li> </ul>

Release	Modification
12.1(3)T	This command was modified. The <b>calltracker</b> notification-type keyword was added for the Cisco AS5300 and AS5800 platforms.
12.2(2)T	This command was modified. <ul style="list-style-type: none"> <li>• The <b>vrf</b> <i>vrf-name</i> keyword-argument pair was added.</li> <li>• The <b>ipmobile</b> notification-type keyword was added.</li> <li>• Support for the <b>vsimaster</b> notification-type keyword was added for the Cisco 7200 and Cisco 7500 series routers.</li> </ul>
12.2(4)T	This command was modified. <ul style="list-style-type: none"> <li>• The <b>pim</b> notification-type keyword was added.</li> <li>• The <b>ipsec</b> notification-type keyword was added.</li> </ul>
12.2(8)T	This command was modified. <ul style="list-style-type: none"> <li>• The <b>mpls-traffic-eng</b> notification-type keyword was added.</li> <li>• The <b>director</b> notification-type keyword was added.</li> </ul>
12.2(13)T	This command was modified. <ul style="list-style-type: none"> <li>• The <b>srp</b> notification-type keyword was added.</li> <li>• The <b>mpls-ldp</b> notification-type keyword was added.</li> </ul>
12.3(2)T	This command was modified. <ul style="list-style-type: none"> <li>• The <b>flash</b> notification-type keyword was added.</li> <li>• The <b>l2tun-session</b> notification-type keyword was added.</li> </ul>
12.3(4)T	This command was modified. <ul style="list-style-type: none"> <li>• The <b>cpu</b> notification-type keyword was added.</li> <li>• The <b>memory</b> notification-type keyword was added.</li> <li>• The <b>ospf notification-type</b> keyword was added.</li> </ul>
12.3(8)T	This command was modified. The <b>iplocalpool notification-type</b> keyword was added for the Cisco 7200 and 7301 series routers.
12.3(11)T	This command was modified. The <b>vrrp</b> keyword was added.

Release	Modification
12.3(14)T	This command was modified. <ul style="list-style-type: none"> <li>Support for SNMP over IPv6 transport was integrated into Cisco IOS Release 12.3(14)T. Either an IP or IPv6 Internet address can be specified as the <i>hostname</i> argument.</li> <li>The <b>igrp</b> notification-type keyword was added.</li> </ul>
12.4(20)T	This command was modified. The <b>license</b> notification-type keyword was added.
15.0(1)M	This command was modified. <ul style="list-style-type: none"> <li>The <b>nhrp</b> notification-type keyword was added.</li> <li>The automatic insertion of the <b>snmp-server community</b> command into the configuration, along with the community string specified in the <b>snmp-server host</b> command, was changed. The <b>snmp-server community</b> command must be manually configured.</li> </ul>
12.0(17)ST	This command was modified. The <b>mpls-traffic-eng</b> notification-type keyword was added.
12.0(21)ST	This command was modified. The <b>mpls-ldp notification-type</b> keyword was added.
12.0(22)S	This command was modified. <ul style="list-style-type: none"> <li>All features in Cisco IOS Release 12.0ST were integrated into Cisco IOS Release 12.0(22)S.</li> <li>The <b>mpls-vpn</b> notification-type keyword was added.</li> </ul>
12.0(23)S	This command was modified. The <b>l2tun-session</b> notification-type keyword was added.
12.0(26)S	This command was modified. The <b>memory</b> notification-type keyword was added.
12.0(27)S	This command was modified. <ul style="list-style-type: none"> <li>Support for SNMP over IPv6 transport was added. Either an IP or IPv6 Internet address can be specified as the <i>hostname</i> argument.</li> <li>The <b>vrf vrf-name</b> keyword and argument combination was added to support multiple Lightweight Directory Protocol (LDP) contexts for VPNs.</li> </ul>
12.0(31)S	This command was modified. The <b>l2tun-pseudowire-status</b> notification-type keyword was added.
12.2(18)S	This command was integrated into Cisco IOS Release 12.2(18)S.

Release	Modification
12.2(25)S	This command was modified. <ul style="list-style-type: none"> <li>• The <b>cpu</b> notification-type keyword was added.</li> <li>• The <b>memory</b> notification-type keyword was added.</li> </ul>
12.2(28)SB	This command was integrated into Cisco IOS Release 12.2(28)SB.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(31)SB2	The <b>cef</b> notification-type keyword was added.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
12.2(33)SXI5	This command was modified. <ul style="list-style-type: none"> <li>• The <b>dhcp-snooping</b> notification-type keyword was added.</li> <li>• The <b>errdisable</b> notification-type keyword was added.</li> </ul>
12.2(54)SE	This command was modified. See the <a href="#">snmp-server host</a> , on page 45 for the command syntax for these switches.
12.2(33)SXJ	This command was integrated into Cisco IOS Release 12.2(33)SXJ. The <b>public storm-control</b> notification-type keyword was added.
15.0(1)S	This command was modified. The <b>flowmon notification-type</b> keyword was added.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.
15.2(1)S	This command was modified. The <b>p2mp-traffic-eng</b> notification-type keyword was added.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

If you enter this command with no optional keywords, the default is to send all notification-type traps to the host. No informs will be sent to the host.

The **no snmp-server host** command with no keywords disables traps, but not informs, to the host. To disable informs, use the **no snmp-server host informs** command.

**Note**

If a community string is not defined using the **snmp-server community** command prior to using this command, the default form of the **snmp-server community** command will automatically be inserted into the configuration. The password (community string) used for this automatic configuration of the **snmp-server community** command will be the same as that specified in the **snmp-server host** command. This automatic command insertion and use of passwords is the default behavior for Cisco IOS Release 12.0(3) and later releases. However, in Cisco IOS Release 12.2(33)SRE and later releases, you must manually configure the **snmp-server community** command. That is, the **snmp-server community** command will not be seen in the configuration.

SNMP notifications can be sent as traps or inform requests. Traps are unreliable because the receiver does not send acknowledgments when it receives traps. The sender cannot determine if the traps were received. However, an SNMP entity that receives an inform request acknowledges the message with an SNMP response protocol data unit (PDU). If the sender never receives the response, the inform request can be sent again. Thus, informs are more likely to reach their intended destination than traps.

Compared to traps, informs consume more resources in the agent and in the network. Unlike a trap, which is discarded as soon as it is sent, an inform request must be held in memory until a response is received or the request times out. Also, traps are sent only once; an inform may be tried several times. The retries increase traffic and contribute to a higher overhead on the network.

If you do not enter an **snmp-server host** command, no notifications are sent. To configure the router to send SNMP notifications, you must enter at least one **snmp-server host** command. If you enter the command with no optional keywords, all trap types are enabled for the host.

To enable multiple hosts, you must issue a separate **snmp-server host** command for each host. You can specify multiple notification types in the command for each host.

When multiple **snmp-server host** commands are given for the same host and kind of notification (trap or inform), each succeeding command overwrites the previous command. Only the last **snmp-server host** command will be in effect. For example, if you enter an **snmp-server host inform** command for a host and then enter another **snmp-server host inform** command for the same host, the second command will replace the first.

The **snmp-server host** command is used in conjunction with the **snmp-server enable** command. Use the **snmp-server enable** command to specify which SNMP notifications are sent globally. For a host to receive most notifications, at least one **snmp-server enable** command and the **snmp-server host** command for that host must be enabled.

Some notification types cannot be controlled with the **snmp-server enable** command. Some notification types are always enabled, and others are enabled by a different command. For example, the **linkUpDown** notifications are controlled by the **snmp trap link-status** command. These notification types do not require an **snmp-server enable** command.

The availability of notification-type options depends on the router type and the Cisco IOS software features supported on the router. For example, the **envmon** notification type is available only if the environmental monitor is part of the system. To see what notification types are available on your system, use the command **help ?** at the end of the **snmp-server host** command.

The **vrf** keyword allows you to specify the notifications being sent to a specified IP address over a specific VRF VPN. The VRF defines a VPN membership of a user so that data is stored using the VPN.

In the case of the NMS sending the query having a correct SNMP community but not having a read or a write view, the SNMP agent returns the following error values:

- For a get or a getnext query, returns GEN\_ERROR for SNMPv1 and AUTHORIZATION\_ERROR for SNMPv2C.
- For a set query, returns NO\_ACCESS\_ERROR.

### Notification-Type Keywords

The notification type can be one or more of the following keywords.



#### Note

The available notification types differ based on the platform and Cisco IOS release. For a complete list of available notification types, use the question mark (?) online help function.

- **aaa server** --Sends SNMP authentication, authorization, and accounting (AAA) traps.
- **adsl** --Sends Asymmetric Digital Subscriber Line (ADSL) LINE-MIB traps.
- **atm** --Sends ATM notifications.
- **authenticate-fail** --Sends an SNMP 802.11 Authentication Fail trap.
- **auth-framework** --Sends SNMP CISCO-AUTH-FRAMEWORK-MIB notifications.
- **bgp** --Sends Border Gateway Protocol (BGP) state change notifications.
- **bridge** --Sends SNMP STP Bridge MIB notifications.
- **bstun** --Sends Block Serial Tunneling (BSTUN) event notifications.
- **bulkstat** --Sends Data-Collection-MIB notifications.
- **c6kxbar** --Sends SNMP crossbar notifications.
- **callhome** --Sends Call Home MIB notifications.
- **calltracker** -- Sends Call Tracker call-start/call-end notifications.
- **casa** --Sends Cisco Appliances Services Architecture (CASA) event notifications.
- **ccme** --Sends SNMP Cisco netManager Event (CCME) traps.
- **cef** --Sends notifications related to Cisco Express Forwarding.
- **chassis** --Sends SNMP chassis notifications.
- **cnpd** --Sends Cisco Network-based Application Recognition (NBAR) Protocol Discovery (CNPD) traps.
- **config** --Sends configuration change notifications.
- **config-copy** --Sends SNMP config-copy notifications.
- **config-ctid** --Sends SNMP config-ctid notifications.
- **cpu** --Sends CPU-related notifications.
- **csg** --Sends SNMP Content Services Gateway (CSG) notifications.
- **deauthenticate** --Sends an SNMP 802.11 Deauthentication trap.
- **dhcp-snooping** --Sends DHCP snooping MIB notifications.



- **director** --Sends notifications related to DistributedDirector.
- **disassociate** --Sends an SNMP 802.11 Disassociation trap.
- **dls** --Sends data-link switching (DLSW) notifications.
- **dnis** --Sends SNMP Dialed Number Identification Service (DNIS) traps.
- **dot1x** --Sends 802.1X notifications.
- **dot11-mibs** --Sends dot11 traps.
- **dot11-qos** --Sends SNMP 802.11 QoS Change trap.
- **ds1** --Sends SNMP digital signaling 1 (DS1) notifications.
- **ds1-loopback** --Sends ds1-loopback traps.
- **dspu** --Sends downstream physical unit (DSPU) notifications.
- **eigrp** --Sends Enhanced Interior Gateway Routing Protocol (EIGRP) stuck-in-active (SIA) and neighbor authentication failure notifications.
- **energywise** --Sends SNMP energywise notifications.
- **entity** --Sends Entity MIB modification notifications.
- **entity-diag** --Sends SNMP entity diagnostic MIB notifications.
- **envmon** --Sends Cisco enterprise-specific environmental monitor notifications when an environmental threshold is exceeded.
- **errdisable** --Sends error disable notifications.
- **ethernet-cfm** --Sends SNMP Ethernet Connectivity Fault Management (CFM) notifications.
- **event-manager** --Sends SNMP Embedded Event Manager notifications.
- **firewall** --Sends SNMP Firewall traps.
- **flash** --Sends flash media insertion and removal notifications.
- **flexlinks** --Sends FLEX links notifications.
- **flowmon** --Sends flow monitoring notifications.
- **frame-relay** --Sends Frame Relay notifications.
- **fru-ctrl** --Sends entity field-replaceable unit (FRU) control notifications.
- **hsrp** --Sends Hot Standby Routing Protocol (HSRP) notifications.
- **icsudsu** --Sends SNMP ICSUDSU traps.
- **iplocalpool** --Sends IP local pool notifications.
- **ipmobile** --Sends Mobile IP notifications.
- **ipmulticast** --Sends IP multicast notifications.
- **ipsec** --Sends IP Security (IPsec) notifications.
- **isakmp** --Sends SNMP ISAKMP notifications.
- **isdn** --Sends ISDN notifications.

- **l2tc** --Sends SNMP L2 tunnel configuration notifications.
- **l2tun-pseudowire-status** --Sends pseudowire state change notifications.
- **l2tun-session** --Sends Layer 2 tunneling session notifications.
- **license** --Sends licensing notifications as traps or informs.
- **llc2** --Sends Logical Link Control, type 2 (LLC2) notifications.
- **mac-notification** --Sends SNMP MAC notifications.
- **memory** --Sends memory pool and memory buffer pool notifications.
- **module** --Sends SNMP module notifications.
- **module-auto-shutdown** --Sends SNMP module autosutdown MIB notifications.
- **mpls-fast-reroute** --Sends SNMP Multiprotocol Label Switching (MPLS) traffic engineering fast reroute notifications.
- **mpls-ldp** --Sends MPLS Label Distribution Protocol (LDP) notifications indicating status changes in LDP sessions.
- **mpls-traffic-eng** --Sends MPLS traffic engineering notifications, indicating changes in the status of MPLS traffic engineering tunnels.
- **mpls-vpn** --Sends MPLS VPN notifications.
- **msdp** --Sends SNMP Multicast Source Discovery Protocol (MSDP) notifications.
- **mvpn** --Sends multicast VPN notifications.
- **nhrp** --Sends Next Hop Resolution Protocol (NHRP) notifications.
- **ospf** --Sends Open Shortest Path First (OSPF) sham-link notifications.
- **pim** --Sends Protocol Independent Multicast (PIM) notifications.
- **port-security** --Sends SNMP port-security notifications.
- **power-ethernet** --Sends SNMP power Ethernet notifications.
- **public storm-control** --Sends SNMP public storm-control notifications.
- **pw-vc** --Sends SNMP pseudowire virtual circuit (VC) notifications.
- **p2mp-traffic-eng** --Sends SNMP MPLS Point to Multi-Point MPLS-TE notifications.
- **repeater** --Sends standard repeater (hub) notifications.
- **resource-policy** --Sends CISCO-ERM-MIB notifications.
- **rf** --Sends SNMP RF MIB notifications.
- **rogue-ap** --Sends an SNMP 802.11 Rogue AP trap.
- **rsrb** --Sends remote source-route bridging (RSRB) notifications.
- **rsvp** --Sends Resource Reservation Protocol (RSVP) notifications.
- **rtr** --Sends Response Time Reporter (RTR) notifications.
- **sdlc** --Sends Synchronous Data Link Control (SDLC) notifications.

- **sdllc** --Sends SDLC Logical Link Control (SDLLC) notifications.
- **slb** --Sends SNMP server load balancer (SLB) notifications.
- **snmp** --Sends any enabled RFC 1157 SNMP linkUp, linkDown, authenticationFailure, warmStart, and coldStart notifications.




---

**Note** To enable RFC-2233-compliant link up/down notifications, you should use the **snmp server link trap** command.

---

- **sonet** --Sends SNMP SONET notifications.
- **srp** --Sends Spatial Reuse Protocol (SRP) notifications.
- **stp** --Sends SNMP STP MIB notifications.
- **srst** --Sends SNMP Survivable Remote Site Telephony (SRST) traps.
- **stun** --Sends serial tunnel (STUN) notifications.
- **switch-over** --Sends an SNMP 802.11 Standby Switchover trap.
- **syslog** --Sends error message notifications (Cisco Syslog MIB). Use the **logging history level** command to specify the level of messages to be sent.
- **syslog** --Sends error message notifications (Cisco Syslog MIB). Use the **logging history level** command to specify the level of messages to be sent.
- **tty** --Sends Cisco enterprise-specific notifications when a TCP connection closes.
- **udp-port** --Sends the notification host's UDP port number.
- **vlan-mac-limit** --Sends SNMP L2 control VLAN MAC limit notifications.
- **vlancreate** --Sends SNMP VLAN created notifications.
- **vlandelete** --Sends SNMP VLAN deleted notifications.
- **voice** --Sends SNMP voice traps.
- **vrp** --Sends Virtual Router Redundancy Protocol (VRRP) notifications.
- **vsimaster** --Sends Virtual Switch Interface (VSI) Master notifications.
- **vswitch** --Sends SNMP virtual switch notifications.
- **vtp** --Sends SNMP VLAN Trunking Protocol (VTP) notifications.
- **wlan-wep** --Sends an SNMP 802.11 Wireless LAN (WLAN) Wired Equivalent Privacy (WEP) trap.
- **x25** --Sends X.25 event notifications.
- **xgcp** --Sends External Media Gateway Control Protocol (XGCP) traps.

### SNMP-Related Notification-Type Keywords

The *notification-type* argument used in the **snmp-server host** command do not always match the keywords used in the corresponding **snmp-server enable traps** command. For example, the *notification-type* argument applicable to Multiprotocol Label Switching Protocol (MPLS) traffic engineering tunnels is specified as **mpls-traffic-eng** (containing two hyphens and no embedded spaces). The corresponding parameter in the

**snmp-server enable traps** command is specified as **mpls traffic-eng** (containing an embedded space and a hyphen).

This syntax difference is necessary to ensure that the CLI interprets the *notification-type* keyword of the **snmp-server host** command as a unified, single-word construct, which preserves the capability of the **snmp-server host** command to accept multiple *notification-type* keywords in the command line. The **snmp-server enable traps** commands, however, often use two-word constructs to provide hierarchical configuration options and to maintain consistency with the command syntax of related commands. The table below maps some examples of **snmp-server enable traps** commands to the keywords used in the **snmp-server host** command.

**Table 7: snmp-server enable traps Commands and Corresponding Notification Keywords**

snmp-server enable traps Command	snmp-server host Command Keyword
snmp-server enable traps l2tun session	l2tun-session
snmp-server enable traps mpls ldp	mpls-ldp
snmp-server enable traps mpls traffic-eng <sup>2</sup>	mpls-traffic-eng
snmp-server enable traps mpls vpn	mpls-vpn
snmp-server host <i>host-address community-string</i> udp-port <i>port</i> p2mp-traffic-eng	snmp-server enable traps mpls p2mp-traffic-eng [down   up]

<sup>2</sup> See the *Cisco IOS Multiprotocol Label Switching Command Reference* for documentation of this command.

## Examples

If you want to configure a unique SNMP community string for traps but prevent SNMP polling access with this string, the configuration should include an access list. The following example shows how to name a community string comaccess and number an access list 10:

```
Router(config)# snmp-server community comaccess ro 10
Router(config)# snmp-server host 10.0.0.0 comaccess
Router(config)# access-list 10 deny any
```



### Note

The “at” sign (@) is used as a delimiter between the community string and the context in which it is used. For example, specific VLAN information in BRIDGE-MIB may be polled using *community @VLAN-ID* (for example, public@100), where 100 is the VLAN number.

The following example shows how to send RFC 1157 SNMP traps to a specified host named myhost.cisco.com. Other traps are enabled, but only SNMP traps are sent because only **snmp** is specified in the **snmp-server host** command. The community string is defined as comaccess.

```
Router(config)# snmp-server enable traps
Router(config)# snmp-server host myhost.cisco.com comaccess snmp
```

The following example shows how to send the SNMP and Cisco environmental monitor enterprise-specific traps to address 10.0.0.0 using the community string public:

```
Router(config)# snmp-server enable traps snmp
```

```
Router(config)# snmp-server enable traps envmon
Router(config)# snmp-server host 10.0.0.0 public snmp envmon
```

The following example shows how to enable the router to send all traps to the host myhost.cisco.com using the community string public:

```
Router(config)# snmp-server enable traps
Router(config)# snmp-server host myhost.cisco.com public
```

The following example will not send traps to any host. The BGP traps are enabled for all hosts, but only the ISDN traps are enabled to be sent to a host. The community string is defined as public.

```
Router(config)# snmp-server enable traps bgp
Router(config)# snmp-server host myhost.cisco.com public isdn
```

The following example shows how to enable the router to send all inform requests to the host myhost.cisco.com using the community string public:

```
Router(config)# snmp-server enable traps
Router(config)# snmp-server host myhost.cisco.com informs version 2c public
```

The following example shows how to send HSRP MIB informs to the host specified by the name myhost.cisco.com. The community string is defined as public.

```
Router(config)# snmp-server enable traps hsrp
Router(config)# snmp-server host myhost.cisco.com informs version 2c public hsrp
```

The following example shows how to send all SNMP notifications to example.com over the VRF named trap-vrf using the community string public:

```
Router(config)# snmp-server host example.com vrf trap-vrf public
```

The following example shows how to configure an IPv6 SNMP notification server with the IPv6 address 2001:0DB8:0000:ABCD:1 using the community string public:

```
Router(config)# snmp-server host 2001:0DB8:0000:ABCD:1 version 2c public udp-port 2012
```

The following example shows how to specify VRRP as the protocol using the community string public:

```
Router(config)# snmp-server enable traps vrrp
Router(config)# snmp-server host myhost.cisco.com traps version 2c public vrrp
```

The following example shows how to send all Cisco Express Forwarding informs to the notification receiver with the IP address 10.0.1.1 using the community string public:

```
Router(config)# snmp-server enable traps cef
Router(config)# snmp-server host 10.0.1.1 informs version 2c public cef
```

The following example shows how to enable all NHRP traps, and how to send all NHRP traps to the notification receiver with the IP address 10.0.0.0 using the community string public:

```
Router(config)# snmp-server enable traps nhrp
Router(config)# snmp-server host 10.0.0.0 traps version 2c public nhrp
```

The following example shows how to enable all P2MP MPLS-TE SNMP traps, and send them to the notification receiver with the IP address 172.20.2.160 using the community string "comp2mppublic":

```
Router(config)# snmp-server enable traps mpls p2mp-traffic-eng
Router(config)# snmp-server host 172.20.2.160 comp2mppublic udp-port 162 p2mp-traffic-eng
```

## Related Commands

Command	Description
<b>show snmp host</b>	Displays recipient details configured for SNMP notifications.

<b>Command</b>	<b>Description</b>
<b>snmp-server enable peer-trap poor qov</b>	Enables poor quality of voice notifications for applicable calls associated with a specific voice dial peer.
<b>snmp-server enable traps</b>	Enables SNMP notifications (traps and informs).
<b>snmp-server enable traps nhrp</b>	Enables SNMP notifications (traps) for NHRP.
<b>snmp-server informs</b>	Specifies inform request options.
<b>snmp-server link trap</b>	Enables linkUp/linkDown SNMP traps that are compliant with RFC 2233.
<b>snmp-server trap-source</b>	Specifies the interface from which an SNMP trap should originate.
<b>snmp-server trap-timeout</b>	Defines how often to try resending trap messages on the retransmission queue.
<b>test snmp trap storm-control event-rev1</b>	Tests SNMP storm-control traps.

## snmp-server inform

To specify inform request options, use the **snmp-server inform** command in global configuration mode. To return settings to their default values, use the **no** form of this command.

**snmp-server inform** [*pending pending*] [*retries retries*] [*timeout seconds*]

**no snmp-server inform** [*pending pending*] [*retries retries*] [*timeout seconds*]

### Syntax Description

<b>pending</b>	(Optional) Specifies a maximum number of informs waiting for acknowledgment at any one time. When the maximum is reached, older pending informs are discarded.
<i>pending</i>	(Optional) Number of unacknowledged informs to hold. The range is from 1 to 4294967295. The default is 25.
<b>retries</b>	(Optional) Specifies a maximum number of times to resend an inform request.
<i>retries</i>	(Optional) Number of retries. The range is from 1 to 100. The default value is 3.
<b>timeout</b>	(Optional) Specifies a number of seconds to wait for an acknowledgment before resending.
<i>seconds</i>	(Optional) Time in seconds. The range is from 0 to 42949671. The default is 15.

### Command Default

Inform requests are resent three times. Informs are resent after 30 seconds if no response is received. The maximum number of informs waiting for acknowledgment at any one time is 25.

### Command Modes

Global configuration (config)

### Command History

Release	Modification
11.3T	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Release	Modification
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

## Examples

The following example shows how to increase the pending queue size when several informs drop:

```
Router(config)# snmp-server inform pending 50
```

The following example shows how to increase the default timeout when you send informs over slow network links. Because informs will remain in the queue longer than other types of messages, you also may need to increase the pending queue size.

```
snmp-server inform timeout 60 pending 40
```

The following example shows how to decrease the default timeout when you send informs over very fast links:

```
Router(config)# snmp-server inform timeout 5
```

The following example shows how to increase the retry count when you send informs over unreliable links. Because informs will remain in the queue longer than other types of messages, you may need to increase the pending queue size.

```
Router(config)# snmp-server inform retries 10 pending 45
```

## Related Commands

Command	Description
<b>snmp-server enable traps</b>	Enables a router to send SNMP traps and informs.



## snmp-server location

To set the system location string, use the **snmp-server location** command in global configuration mode. To remove the location string, use the **no** form of this command.

**snmp-server location** *text*

**no snmp-server location**

### Syntax Description

<i>text</i>	String that describes the system location information.
-------------	--

### Command Default

No system location string is set.

### Command Modes

Global configuration

### Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Examples

The following example shows how to set a system location string:

```
Router(config)# snmp-server location '{"city": "Raleigh", "zip": "00000", "site": "RTP", "st": "NM", "bu": "TAC", "addr1": "123 TAC Rd"}'
```

### Related Commands

Command	Description
show snmp location	Displays the SNMP system location string.
<b>snmp-server contact</b>	Sets the system contact (sysContact) string.

## snmp-server packetsize

To establish control over the largest Simple Network Management Protocol (SNMP) packet size permitted when the SNMP server is receiving a request or generating a reply, use the **snmp-server packetsize** command in global configuration mode. To restore the default value, use the **no** form of this command.

**snmp-server packetsize** *byte-count*

**no snmp-server packetsize**

### Syntax Description

<i>byte-count</i>	Integer from 484 to 8192. The default is 1500.
-------------------	--

### Command Default

Packet size is not configured.

### Command Modes

Global configuration

### Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Examples

The following example establishes a packet filtering of a maximum size of 1024 bytes:

```
Router(config)# snmp-server packetsize 1024
```

### Related Commands

Command	Description
<b>snmp-server queue-length</b>	Establishes the message queue length for each trap host.

# snmp-server system-shutdown

To use the Simple Network Management Protocol (SNMP) message reload feature, the router configuration must include the **snmp-server system-shutdown** command in global configuration mode. To prevent an SNMP system-shutdown request (from an SNMP manager) from resetting the Cisco agent, use the **no** form of this command.

**snmp-server system-shutdown**

**no snmp-server system-shutdown**

**Syntax Description** This command has no arguments or keywords.

**Command Default** This command is not included in the configuration file.

**Command Modes** Global configuration

Command History	Release	Modification
	10.0	This command was introduced.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
	12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
	Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
	Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

**Examples** The following example enables the SNMP message reload feature:

```
Router(config)# snmp-server system-shutdown
```

## snmp-server tftp-server-list



### Note

This command was replaced with the **snmp-server file-transfer access-group** command in Cisco IOS Release 12.4(12). Use the **snmp-server file-transfer access-group** command in Cisco IOS Release 12.4(12) and in later releases.

To limit the TFTP servers used via Simple Network Management Protocol (SNMP) controlled TFTP operations (saving and loading configuration files) to the servers specified in an access list, use the **snmp-server tftp-server-list** command in global configuration mode. To disable this function, use the **no** form of this command.

**snmp-server tftp-server-list** {*acl-number*|*acl-name*}

**no snmp-server tftp-server-list** {*acl-number*|*acl-name*}

### Syntax Description

<i>acl-number</i>	Integer from 1 to 99 that specifies a standard access control list (standard ACL).
<i>acl-name</i>	String (not to exceed 64 characters) that specifies a standard ACL.

### Command Default

Disabled

### Command Modes

Global configuration

### Command History

Release	Modification
10.2	This command was introduced.
12.3(2)T	Support for standard named access lists was added.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

## Examples

The following example shows how to limit the TFTP servers that can be used for saving and loading configuration files via SNMP to the servers specified in the standard named access list `lmpnop`:

```
Router(config)# snmp-server tftp-server-list lmpnop
```

The following example shows how to limit the TFTP servers that can be used for copying configuration files via SNMP to the servers in access list `44`:

```
Router(config)# snmp-server tftp-server-list 44
```

## snmp-server trap-source



### Note

Effective with Cisco IOS Release 12.2(18)SXB6, the **snmp-server trap-source** command is replaced by the **snmp-server source-interface** command. See the **snmp-server source-interface** command for more information.

To specify the interface (and hence the corresponding IP address) from which a Simple Network Management Protocol (SNMP) trap should originate, use the **snmp-server trap-source** command in global configuration mode. To remove the source designation, use the **no** form of the command.

**snmp-server trap-source** *interface*

**no snmp-server trap-source**

### Syntax Description

*interface*

Interface from which the SNMP trap originates. Includes the interface type and number in platform-specific syntax (for example, *typeslot /port*).

### Command Default

No interface is specified.

### Command Modes

Global configuration (config)

### Command History

Release	Modification
10.0	This command was introduced.
12.2(33)SRA	This command was integrated in to Cisco IOS Release 12.2(33)SRA.
12.2(18)SXB6	This command was replaced by the <b>snmp-server source-interface</b> command in Cisco IOS Release 12.2(18)SXB6.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

An SNMP trap or inform sent from a Cisco SNMP server has a notification address of the interface it went out of at that time. Use this command to monitor notifications from a particular interface.

**Examples**

The following example shows how to set the IP address for Ethernet interface 0 as the source for all SNMP notifications:

```
Router(config)# snmp-server trap-source ethernet 0
```

The following example shows how to set the IP address for the Ethernet interface in slot 2, port 1 as the source for all SNMP notifications:

```
Router(config)# snmp-server trap-source ethernet 2/1
```

**Related Commands**

Command	Description
<b>snmp-server enable traps</b>	Enables a router to send SNMP traps and informs.
<b>snmp-server host</b>	Specifies the recipient of a SNMP notification operation.

## snmp-server user

To configure a new user to a Simple Network Management Protocol (SNMP) group, use the **snmp-server user** command in global configuration mode. To remove a user from an SNMP group, use the **no** form of this command.

```
snmp-server user username group-name [remote host [udp-port port] [vrf vrf-name]] {v1|v2c|v3
[encrypted] [auth {md5|sha} auth-password]} [access [ipv6 nacl] [priv {des|3des|aes {128|192|256} }
privpassword] {acl-number|acl-name}]
```

```
no snmp-server user username group-name [remote host [udp-port port] [vrf vrf-name]] {v1|v2c|v3
[encrypted] [auth {md5|sha} auth-password]} [access [ipv6 nacl] [priv {des|3des|aes {128|192|256} }
privpassword] {acl-number|acl-name}]
```

### Syntax Description

<i>username</i>	Name of the user on the host that connects to the agent.
<i>group-name</i>	Name of the group to which the user belongs.
<b>remote</b>	(Optional) Specifies a remote SNMP entity to which the user belongs, and the hostname or IPv6 address or IPv4 IP address of that entity. If both an IPv6 address and IPv4 IP address are being specified, the IPv6 host must be listed first.
<i>host</i>	(Optional) Name or IP address of the remote SNMP host.
<b>udp-port</b>	(Optional) Specifies the User Datagram Protocol (UDP) port number of the remote host.
<i>port</i>	(Optional) Integer value that identifies the UDP port. The default is 162.
<b>vrf</b>	(Optional) Specifies an instance of a routing table.
<i>vrf-name</i>	(Optional) Name of the Virtual Private Network (VPN) routing and forwarding (VRF) table to use for storing data.
<b>v1</b>	Specifies that SNMPv1 should be used.
<b>v2c</b>	Specifies that SNMPv2c should be used.
<b>v3</b>	Specifies that the SNMPv3 security model should be used. Allows the use of the <b>encrypted</b> keyword or <b>auth</b> keyword or both.



<b>encrypted</b>	(Optional) Specifies whether the password appears in encrypted format.
<b>auth</b>	(Optional) Specifies which authentication level should be used.
<b>md5</b>	(Optional) Specifies the HMAC-MD5-96 authentication level.
<b>sha</b>	(Optional) Specifies the HMAC-SHA-96 authentication level.
<i>auth-password</i>	(Optional) String (not to exceed 64 characters) that enables the agent to receive packets from the host.
<b>access</b>	(Optional) Specifies an Access Control List (ACL) to be associated with this SNMP user.
<b>ipv6</b>	(Optional) Specifies an IPv6 named access list to be associated with this SNMP user.
<i>nacl</i>	(Optional) Name of the ACL. IPv4, IPv6, or both IPv4 and IPv6 access lists may be specified. If both are specified, the IPv6 named access list must appear first in the statement.
<b>priv</b>	(Optional) Specifies the use of the User-based Security Model (USM) for SNMP version 3 for SNMP message level security.
<b>des</b>	(Optional) Specifies the use of the 56-bit Digital Encryption Standard (DES) algorithm for encryption.
<b>3des</b>	(Optional) Specifies the use of the 168-bit 3DES algorithm for encryption.
<b>aes</b>	(Optional) Specifies the use of the Advanced Encryption Standard (AES) algorithm for encryption.
<b>128</b>	(Optional) Specifies the use of a 128-bit AES algorithm for encryption.
<b>192</b>	(Optional) Specifies the use of a 192-bit AES algorithm for encryption.
<b>256</b>	(Optional) Specifies the use of a 256-bit AES algorithm for encryption.
<i>privpassword</i>	(Optional) String (not to exceed 64 characters) that specifies the privacy user password.

<i>acl-number</i>	(Optional) Integer in the range from 1 to 99 that specifies a standard access list of IP addresses.
<i>acl-name</i>	(Optional) String (not to exceed 64 characters) that is the name of a standard access list of IP addresses.

**Command Default**

See the table in the “Usage Guidelines” section for default behaviors for encryption, passwords, and access lists.

**Command Modes**

Global configuration (config)

**Command History**

Release	Modification
12.0(3)T	This command was introduced.
12.3(2)T	Support for named standard access lists was added.
12.0(27)S	The <b>ipv6</b> keyword and <i>naclargument</i> were added to allow for configuration of IPv6 named access lists and IPv6 remote hosts.
12.3(14)T	The <b>ipv6</b> keyword and <i>naclargument</i> were integrated into Cisco IOS Release 12.3(14)T.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.4(11)T	The <b>priv</b> keyword and associated arguments were added to enable the use of the USM for SNMP version 3 for SNMP message level security.
12.2(33)SRB	This command was integrated into Cisco IOS Release 12.2(33)SRB.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.
Cisco IOS XE Release 2.1	This command was introduced on Cisco ASR 1000 Series Aggregation Services Routers.
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

**Usage Guidelines**

To configure a remote user, specify the IP address or port number for the remote SNMP agent of the device where the user resides. Also, before you configure remote users for a particular agent, configure the SNMP engine ID, using the **snmp-server engineID** command with the **remote** keyword. The remote agent’s SNMP

engine ID is needed when computing the authentication and privacy digests from the password. If the remote engine ID is not configured first, the configuration command will fail.

For the *privpassword* and *auth-password* arguments, the minimum length is one character; the recommended length is at least eight characters, and should include both letters and numbers. The recommended maximum length is 64 characters.

The table below describes the default user characteristics for encryption, passwords, and access lists.

**Table 8: snmp-server user Default Descriptions**

Characteristic	Default
Access lists	Access from all IP access lists is permitted.
Encryption	Not present by default. The <b>encrypted</b> keyword is used to specify that the passwords are message digest algorithm 5 (MD5) digests and not text passwords.
Passwords	Assumed to be text strings.
Remote users	All users are assumed to be local to this SNMP engine unless you specify they are remote with the <b>remote</b> keyword.

SNMP passwords are localized using the SNMP engine ID of the authoritative SNMP engine. For informs, the authoritative SNMP agent is the remote agent. You need to configure the remote agent's SNMP engine ID in the SNMP database before you can send proxy requests or informs to it.



**Note**

Changing the engine ID after configuring the SNMP user, does not allow to remove the user. To remove the user, you need to first reconfigure the SNMP user.

### Working with Passwords and Digests

No default values exist for authentication or privacy algorithms when you configure the command. Also, no default passwords exist. The minimum length for a password is one character, although Cisco recommends using at least eight characters for security. The recommended maximum length of a password is 64 characters. If you forget a password, you cannot recover it and will need to reconfigure the user. You can specify either a plain-text password or a localized MD5 digest.

If you have the localized MD5 or Secure Hash Algorithm (SHA) digest, you can specify that string instead of the plain-text password. The digest should be formatted as aa:bb:cc:dd where aa, bb, and cc are hexadecimal values. Also, the digest should be exactly 16 octets long.

### Examples

The following example shows how to add the user abcd to the SNMP server group named public. In this example, no access list is specified for the user, so the standard named access list applied to the group applies to the user.

```
Device(config)# snmp-server user abcd public v2c
```

The following example shows how to add the user abcd to the SNMP server group named public. In this example, access rules from the standard named access list qrst apply to the user.

```
Device(config)# snmp-server user abcd public v2c access qrst
```

In the following example, the plain-text password cisco123 is configured for the user abcd in the SNMP server group named public:

```
Device(config)# snmp-server user abcd public v3 auth md5 cisco123
```

When you enter a **show running-config** command, a line for this user will be displayed. To learn if this user has been added to the configuration, use the **show snmp user** command.



#### Note

The **show running-config** command does not display any of the active SNMP users created in **authPriv** or **authNoPriv** mode, though it does display the users created in **noAuthNoPriv** mode. To display any active SNMPv3 users created in **authPriv**, **authNoPriv**, or **noAuthNoPriv** mode, use the **show snmp user** command.

If you have the localized MD5 or SHA digest, you can specify that string instead of the plain-text password. The digest should be formatted as aa:bb:cc:dd where aa, bb, and cc are hexadecimal values. Also, the digest should be exactly 16 octets long.

In the following example, the MD5 digest string is used instead of the plain-text password:

```
Device(config)# snmp-server user abcd public v3 encrypted auth md5
00:11:22:33:44:55:66:77:88:99:AA:BB:CC:DD:EE:FF
```

In the following example, the user abcd is removed from the SNMP server group named public:

```
Device(config)# no snmp-server user abcd public v2c
```

In the following example, the user abcd from the SNMP server group named public specifies the use of the 168-bit 3DES algorithm for privacy encryption with **secure3des** as the password.

```
Device(config)# snmp-server user abcd public priv v2c 3des secure3des
```

#### Related Commands

Command	Description
<b>show running-config</b>	Displays the contents of the currently running configuration file or the configuration for a specific interface, or map class information.
<b>show snmp user</b>	Displays information on each SNMP username in the group username table.
<b>snmp-server engineID</b>	Displays the identification of the local SNMP engine and all remote engines that have been configured on the device.

## snmp-server view

To create or update a view entry, use the **snmp-server view** command in global configuration mode. To remove the specified Simple Network Management Protocol (SNMP) server view entry, use the **no** form of this command.

**snmp-server view** *view-name oid-tree* {**included**|**excluded**}

**no snmp-server view** *view-name*

### Syntax Description

<i>view-name</i>	Label for the view record that you are updating or creating. The name is used to reference the record.
<i>oid-tree</i>	Object identifier of the ASN.1 subtree to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as system. Replace a single subidentifier with the asterisk (*) wildcard to specify a subtree family; for example 1.3.*.4.
<b>included</b>	Configures the OID (and subtree OIDs) specified in <i>oid-tree</i> argument to be included in the SNMP view.
<b>excluded</b>	Configures the OID (and subtree OIDs) specified in <i>oid-tree</i> argument to be explicitly excluded from the SNMP view.

### Command Default

No view entry exists.

### Command Modes

Global configuration

### Command History

Release	Modification
10.0	This command was introduced.
12.3(4)T	This command was modified to exclude USM, VACM, and Community MIBs from any parent OIDs in a configured view by default.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2SX	This command is supported in the Cisco IOS Release 12.2SX train. Support in a specific 12.2SX release of this train depends on your feature set, platform, and platform hardware.

Release	Modification
Cisco IOS XE Release 3.2SE	This command was implemented in Cisco IOS XE Release 3.2SE.
Cisco IOS XE Release 3.3SE	This command was implemented in Cisco IOS XE Release 3.3SE.

### Usage Guidelines

Other SNMP commands require an SMP view as an argument. You use this command to create a view to be used as arguments for other commands.

Two standard predefined views can be used when a view is required, instead of defining a view. One is *everything*, which indicates that the user can see all objects. The other is *restricted*, which indicates that the user can see three groups: system, snmpStats, and snmpParties. The predefined views are described in RFC 1447.



#### Note

Beginning in Release 12.0(26)S and 12.2(2)T, the USM, VACM, and Community MIBs are excluded from any parent OIDs in a configured view by default. If you wish to include these MIBs in a view, you must now explicitly include them.

The first **snmp-server** command that you enter enables SNMP on your routing device.

### Examples

The following example creates a view that includes all objects in the MIB-II subtree:

```
snmp-server view mib2 mib-2 included
```

The following example creates a view that includes all objects in the MIB-II system group and all objects in the Cisco enterprise MIB:

```
snmp-server view root_view system included
snmp-server view root_view cisco included
```

The following example creates a view that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interfaces group:

```
snmp-server view agon system included
snmp-server view agon system.7 excluded
snmp-server view agon ifEntry.*.1 included
```

In the following example, the USM, VACM, and Community MIBs are explicitly included in the view “test” with all other MIBs under the root parent “internet”:

```
! -- include all MIBs under the parent tree "internet"
snmp-server view test internet included
! -- include snmpUsmMIB
snmp-server view test 1.3.6.1.6.3.15 included
! -- include snmpVacmMIB
snmp-server view test 1.3.6.1.6.3.16 included
! -- exclude snmpCommunityMIB
snmp-server view test 1.3.6.1.6.3.18 excluded
```

**Related Commands**

Command	Description
snmp-server community	Sets up the community access string to permit access to the SNMP protocol.







## startup (test boolean) through write mib-data

---

- [startup \(test boolean\)](#), page 78
- [startup \(test existence\)](#), page 79
- [startup \(test threshold\)](#), page 80
- [test \(event trigger\)](#), page 82
- [type \(test existence\)](#), page 84
- [url \(bulk statistics\)](#), page 86
- [value \(test boolean\)](#), page 88
- [value type](#), page 89
- [wildcard \(expression\)](#), page 91
- [write mib-data](#), page 92

## startup (test boolean)

To specify whether an event can be triggered for the Boolean trigger test, use the **startup** command in event trigger boolean configuration mode. To disable the configured settings, use the **no** form of this command.

**startup**

**no startup**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The startup event is enabled when the Boolean trigger test is enabled.

**Command Modes** Event trigger boolean configuration (config-event-trigger-boolean)

### Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

### Usage Guidelines

The **startup** command triggers an event when the conditions specified for the Boolean trigger test are met.

### Examples

The following example shows how to specify startup for the Boolean trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name EventA
Router(config-event-trigger)# test boolean
Router(config-event-trigger-boolean)# startup
Router(config-event-trigger-boolean)# end
```

### Related Commands

Command	Description
test	Enables a trigger test.

## startup (test existence)

To specify whether an event can be triggered for the existence trigger test, use the **startup** command in event trigger existence configuration mode. To disable the configured settings, use the **no** form of this command.

```
startup {present| absent}
no startup {present| absent}
```

### Syntax Description

<b>present</b>	Triggers the present startup test when the existence trigger conditions are met.
<b>absent</b>	Triggers the absent startup test when the existence trigger conditions are met.

### Command Default

By default, both present and absent startup tests are triggered.

### Command Modes

Event trigger existence configuration (config-event-trigger-existence)

### Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

### Usage Guidelines

The **startup** command triggers an event when the conditions specified for the existence trigger test are met.

### Examples

The following example shows how to specify startup for the existence trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name EventA
Router(config-event-trigger)# test existence
Router(config-event-trigger-existence)# startup
Router(config-event-trigger-existence)# end
```

### Related Commands

Command	Description
<b>test</b>	Enables a trigger test.

## startup (test threshold)

To specify whether an event can be triggered for the threshold trigger test, use the **startup** command in event trigger threshold configuration mode. To disable the configured settings, use the **no** form of this command.

**startup** {rising| falling| rise-or-falling}

**no startup**

### Syntax Description

<b>rising</b>	Specifies the rising threshold value to check against the set value during startup when the trigger type is threshold.
<b>falling</b>	Specifies the falling threshold value to check against the set value during startup when the trigger type is threshold.
<b>rise-or-falling</b>	Specifies the rising or falling threshold value to check against the set value during startup when the trigger type is threshold. This is the default value.

### Command Default

The rising or falling threshold value is checked against the set value during startup when the trigger type is threshold.

### Command Modes

Event trigger threshold configuration (config-event-trigger-threshold)

### Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

### Usage Guidelines

The **startup** command starts an event when conditions for the threshold trigger test are met.

### Examples

The following example shows how to specify startup for the threshold trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name EventA
Router(config-event-trigger)# test threshold
Router(config-event-trigger-threshold)# startup rising
Router(config-event-trigger-threshold)# end
```

**Related Commands**

Command	Description
test	Enables a trigger test.

## test (event trigger)

To specify the type of test to perform during an event trigger, use the **test** command in event trigger configuration mode. To disable the trigger test configuration settings, use the **no** form of this command.

**test** {existence| boolean| threshold}

**no test** {existence| boolean| threshold}

### Syntax Description

<b>existence</b>	Enables the existence trigger test.
<b>boolean</b>	Enables the Boolean trigger test. Boolean test is the default trigger test performed during event triggers.
<b>threshold</b>	Enables the threshold trigger test.

### Command Default

The Boolean trigger test is enabled by default.

### Command Modes

Event trigger configuration (config-event-trigger)

### Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

### Usage Guidelines

The trigger table in the Event MIB has supplementary tables for additional objects that are configured based on the type of test performed for the trigger. For each trigger entry type such as existence, threshold, or Boolean, the corresponding tables (existence, threshold, and Boolean tables) are populated with the information required to perform the test. You can set event triggers based on existence, threshold, and Boolean trigger types.

The existence trigger tests are performed based on the following parameters:

- Absent
- Present
- Changed

The Boolean tests are comparison tests that are performed based on one of the following parameters:

- Unequal
- Equal
- Less
- Less Or Equal
- Greater
- Greater Or Equal

The threshold tests are performed based on the following parameters:

- Rising
- Falling
- Rising or Falling

## Examples

The following example shows how to enable the existence trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name triggerA
Router(config-event-trigger)# test existence
Router(config-event-trigger-existence)#
```

The following example shows how to enable the Boolean trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name EventA
Router(config-event-trigger)# test boolean
Router(config-event-trigger-boolean)#
```

The following example shows how to enable the threshold trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name triggerA
Router(config-event-trigger)# test threshold
Router(config-event-trigger-threshold)#
```

## Related Commands

Command	Description
<b>comparison</b>	Specifies the type of Boolean comparison to be performed.
<b>event owner</b>	Specifies the event owner for an event trigger according to the trigger type and status of the trigger.
<b>object list</b>	Configures a list of objects during an event.
<b>startup</b>	Specifies whether an event can be triggered for the Boolean, existence, or threshold trigger test.
<b>value</b>	Sets a value for the Boolean trigger test.

## type (test existence)

To specify the type of existence trigger test to perform, use the **type** command in event trigger existence configuration mode. To disable the specified trigger test type, use the **no** form of this command.

**type** {present| absent| changed}

**no type** {present| absent| changed}

### Syntax Description

<b>present</b>	Specifies whether the trigger conditions for the existence test are present.
<b>absent</b>	Specifies whether the trigger conditions for the existence test are absent.
<b>changed</b>	Specifies whether the trigger conditions for the existence test are changed.

### Command Default

By default, both present and absent tests are performed.

### Command Modes

Event trigger existence configuration (config-event-trigger-existence)

### Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

### Usage Guidelines

The existence trigger tests are performed based on the following parameters:

- Absent
- Present
- Changed

When the test type is not specified, both present and absent tests are performed.



### Examples

The following example shows how to specify the existence trigger test as present:

```
Router(config)#snmp mib event trigger owner owner1 name triggerA
Router(config-event-trigger)# test existence
Router(config-event-trigger-existence)# type present
Router(config-event-trigger-existence)# end
```

### Related Commands

Command	Description
test	Enables a trigger test.

## url (bulk statistics)

To specify the host to which bulk statistics files should be transferred, use the **url** command in Bulk Statistics Transfer configuration mode. To remove a previously configured destination host, use the **no** form of this command.

**url** {primary| secondary} *url*

**no url** {primary| secondary}

### Syntax Description

<b>primary</b>	Specifies the URL to be used first for bulk statistics transfer attempts.
<b>secondary</b>	Specifies the URL to be used for bulk statistics transfer attempts if the transfer to the primary URL is not successful.
<i>url</i>	<p>Destination URL address for the bulk statistics file transfer. Use FTP, RCP, or TFTP. The Cisco IOS File System (IFS) syntax for these URLs is as follows:</p> <ul style="list-style-type: none"> <li>• <b>ftp:</b> [[[//username[:password]@]location]/directory]/filename</li> <li>• <b>rtp:</b> [[[//username@]location]/directory]/filename</li> <li>• <b>tftp:</b> [[//location]/directory]/filename</li> </ul> <p>The <i>location</i> argument is typically an IP address.</p>

### Command Default

No host is specified.

### Command Modes

Bulk Statistics Transfer configuration (config-bulk-tr)

### Command History

Release	Modification
12.0(24)S	This command was introduced.
12.3(2)T	This command was integrated into Cisco IOS Release 12.3(2)T.
12.2(25)S	This command was integrated into Cisco IOS Release 12.2(25)S.
12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.
12.2(33)SXH	This command was integrated into Cisco IOS Release 12.2(33)SXH.

Release	Modification
12.2(33)SB	This command was integrated into Cisco IOS Release 12.2(33)SB.
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS Release XE 2.1.

### Usage Guidelines

For bulk statistics transfer retry attempts, a single retry consists of an attempt to send first to the primary URL, and then to the secondary URL.

### Examples

In the following example, an FTP server is used as the primary destination for the bulk statistics file. If a transfer to that address fails, an attempt is made to send the file to the TFTP server at 192.168.10.5. No retry command is specified, which means that only one attempt to each destination will be made.

```
Router(config)# snmp mib bulkstat transfer ifMibTesting
Router(config-bulk-tr)# schema carMibTesting1
Router(config-bulk-tr)# schema carMibTesting2
Router(config-bulk-tr)# format bulkBinary
Router(config-bulk-tr)# transfer-interval 60
Router(config-bulk-tr)# buffer-size 10000
Router(config-bulk-tr)# url primary ftp://user2:pswd@192.168.10.5/functionality/
Router(config-bulk-tr)# url secondary tftp://user2@192.168.10.8/tftpboot/
Router(config-bulk-tr)# buffer-size 2500000
Router(config-bulk-tr)# enable
Router(config-bulk-tr)# exit
```

### Related Commands

Command	Description
<b>retry (bulk statistics)</b>	Configures the number of retries that should be attempted for sending bulk statistics files.
<b>snmp mib bulkstat transfer</b>	Names a bulk statistics transfer configuration and enters Bulk Statistics Transfer configuration mode.

## value (test boolean)

To set a value for the Boolean trigger test, use the **value** command in event trigger boolean configuration mode. To disable the configured settings, use the **no** form of this command.

**value** *integer-value*

**no value**

### Syntax Description

<i>integer-value</i>	Numerical value to set for the Boolean test. The default is 0.
----------------------	--

### Command Default

The Boolean trigger test value is set to 0.

### Command Modes

Event trigger boolean configuration (config-event-trigger-boolean)

### Command History

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

### Usage Guidelines

The **value** command specifies the value to be set for the Boolean trigger test.

### Examples

The following example shows how to set a value for the Boolean trigger test:

```
Router(config)# snmp mib event trigger owner owner1 name triggerA
Router(config-event-trigger)# test boolean
Router(config-event-trigger-boolean)# value 10
Router(config-event-trigger-boolean)# end
```

### Related Commands

Command	Description
<b>test</b>	Enables a trigger test.

## value type

To specify the type of bulkstat expression to use during object sampling, use the **value type** command in Bulkstat expression configuration mode. To disable the specified value type, use the **no** form of this command.

**value type** [counter32| unsigned32| timeticks| integer32| ipaddress| octetstring| objectid| counter64]  
**no value type**

### Syntax Description

<b>counter32</b>	(Optional) Specifies a counter32 value. Counter32 specifies a value that represents a count. The value ranges from 0 to 4,29,49,67,295.
<b>unsigned32</b>	(Optional) Specifies an unsigned integer value. Unsigned32 specifies a value that includes only non-negative integers. The value ranges from 0 to 4294967295.
<b>timeticks</b>	(Optional) Specifies a value based on timeticks. Timeticks represents a non-negative integer value that specifies the elapsed time between two events, in units of hundredth of a second.  When objects in the MIB are defined using the subset of Abstract Syntax Notation One (ASN.1), the description of the object type identifies this reference period.
<b>integer32</b>	(Optional) Specifies an integer32 value. The Integer32 represents 32-bit signed integer values for the Simple Network Management Protocol (SNMP). The value range includes both negative and positive numbers.
<b>ipaddress</b>	(Optional) Specifies a value based on the IP address. The IP address is a string of four octets. The IP address value type is generally an IPv4 address. This value is encoded as four bytes in the network byte order.
<b>octetstring</b>	(Optional) Specifies a value based on octetstring. The octetstring specifies octets of binary or textual information. The octet string length ranges from 0 to 65535 octets.
<b>objectid</b>	(Optional) Specifies a value based on the object identifier of an object. Each object type in a MIB is identified by an object identifier value assigned by the administrator. The object identifier identifies the value type that has an assigned object identifier value.
<b>counter64</b>	(Optional) Specifies a counter64 value that represents a count. However, the counter64 value ranges from 0 to 18446744073709551615. This value type is used when a 32-bit counter rollover occurs in less than an hour.

**Command Default** By default, the value type is not configured.

**Command Modes** expression configuration (config-expression)  
Bulkstat data set expression configuration (config-bs-ds-expr)

Release	Modification
12.4(20)T	This command was introduced.
12.2(33)SRE	This command was integrated into Cisco IOS Release 12.2(33)SRE.
12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.
15.3(1)S	This command was integrated into Cisco IOS Release 15.3(1)S.
Cisco IOS Release XE 3.8S	This command was integrated into Cisco IOS Release XE 3.8S.

**Usage Guidelines** The **value type** command specifies a value for expression evaluation.

**Examples** The following example shows how to specify the counter32 value type:

```
Device> enable
Device# configure terminal
Device(config)# snmp mib expression owner owner1 name ExpressionA
Device(config-expression)# value type counter32
```

The following example shows how to specify the counter32 value type for Bulkstat expression data set:

```
Device> enable
Device# configure terminal
Device(config)# bulkstat data interface-util type expression
Device(config-bs-ds-expr)# expression 100*$1+$2
Device(config-bs-ds-expr)# value type counter32
```

#### Related Commands

Command	Description
<b>snmp mib expression owner</b>	Specifies the owner for an expression.
<b>bulkstat data</b>	Configures Bulkstat data set for expression type.

## wildcard (expression)

To specify whether an object used for evaluating an expression is to be wildcarded during an event configuration, use the **wildcard** command in expression configuration mode. To remove the wildcard object identifier, use the **no** form of this command.

**wildcard**

**no wildcard**

**Syntax Description** This command has no arguments or keywords.

**Command Default** This command is enabled by default.

**Command Modes** Expression configuration (config-expression)

Command History	Release	Modification
	12.4(20)T	This command was introduced.
	12.2(50)SY	This command was integrated into Cisco IOS Release 12.2(50)SY.

**Usage Guidelines** The **wildcard** command allows you to apply a single expression to multiple instances of the same MIB object. When you specify this choice and provide a partial object identifier, the application obtains the object values and discovers the instances of the object. By default, the objects are identified based on instances and are not wildcarded.

**Examples** The following example shows how to specify the wildcard object identifier by using the **wildcard** command:

```
Router(config)# snmp mib expression owner owner1 name expression1
Router(config-expression)#object 2
Router(config-expression-object)# wildcard
Router(config-expression-object)# end
```

### Related Commands

Command	Description
<b>object id</b>	Specifies the object identifier of an object associated with an event.
<b>snmp mib expression owner</b>	Specifies the owner of an expression.

# write mib-data

To save MIB data to system memory (NVRAM) for MIB Data Persistence, use the **write mib-data** command in EXEC mode.

## write mib-data

### Syntax Description

This command has no arguments or keywords.

### Command Modes

Privileged EXEC (#)

### Command History

Release	Modification
15.0(1)M	This command was introduced in a release earlier than Cisco IOS Release 15.0(1)M.
12.2(33)SRC	This command was integrated into a release earlier than Cisco IOS Release 12.2(33)SRC.
12.2(33)SXI	This command was integrated into a release earlier than Cisco IOS Release 12.2(33)SXI.
Cisco IOS XE Release 2.1	This command was implemented on the Cisco ASR 1000 Series Aggregation Services Routers.

### Usage Guidelines

The MIB Data Persistence feature allows the SNMP data of a MIB to be persistent across reloads; that is, the values of certain MIB objects are retained even if your networking device reboots.

To determine which MIBs support “MIB Persistence” in your release, use the **snmp mib persist** command in global configuration mode.

Any modified MIB data must be written to NVRAM memory using the **write mib-data** command. If the **write mib-data** command is not used, modified MIB data is not saved automatically, even if MIB Persistence is enabled. Executing the **write mib-data** command saves only the current MIB data; if the MIB object values are changed, you should reenter the **write mib-data** command to ensure that those values are persistent across reboots.

### Examples

The following example shows the enabling of event MIB persistence, circuit MIB persistence, and saving the changes to set object values for these MIBs to NVRAM:

```
Router# configure terminal
Router(config)# snmp mib persist circuit
Router(config)# snmp mib persist event
Router(config)# end
Router# write mib-data
```



**Related Commands**

Command	Description
snmp mib persist	Enables MIB data persistence.

