



IPSec Commands

This module describes the IPSec commands.

For detailed information about the configuration tasks, and examples, see the *System Security Configuration Guide for Cisco ASR 9000 Series Routers* and *System Security Configuration Guide for Cisco 8000 Series Routers*.

- [clear crypto ipsec sa, on page 2](#)
- [interface tunnel-ip \(GRE\), on page 3](#)
- [show crypto ipsec sa, on page 4](#)
- [show crypto ipsec summary, on page 7](#)
- [show crypto ipsec transform-set, on page 9](#)

clear crypto ipsec sa

To delete specific security associations (SAs), or all SAs in the IP Security (IPSec) security associations database (SADB), use the **clear crypto ipsec sa** command.

clear crypto ipsec sa {*sa-id* | **all** | **counters** | {*sa-id* | **all**} | **interface tunnel-ipsec**}

Syntax Description		
<i>sa-id</i>	Identifier for the SA. IPSec supports from 1 to 64,500 sessions.	
all	Deletes all IPSec SAs in the IPSec SADB.	
counters	Clears the counters in the IPSec SADB.	
interface	Clears the interfaces in the IPSec SADB.	
tunnel-ipsec	The range of tunnel-ipsec is <0-4294967295>.	

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines SAs are established to secure data flows in IPSec. Use the **clear crypto ipsec sa** command to delete active IPSec sessions or force IPSec to reestablish new SAs. Usually, the establishment of SAs is negotiated between peers through Internet Key Exchange (IKE) on behalf of IPSec.

Task ID	Task ID	Operations
	crypto	execute

Examples The following example shows how to remove the SA with ID 100 from the SADB:

```
RP/0/RP0RSP0/CPU0:router# clear crypto ipsec sa 100
```

Related Commands	Command	Description
	show crypto ipsec sa, on page 4	Displays the settings used by current SAs.

interface tunnel-ip (GRE)

To configure a tunnel interface for generic routing encapsulation (GRE), use the **interface tunnel-ip** command in global configuration mode. To delete the IP tunnel interface, use the **no** form of this command.

```
interface tunnel-ip number
no interface tunnel-ip number
```

Syntax Description	<i>number</i> Instance number of the interface. The range is from 0 to 65535.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to use the **interface tunnel-ip** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# interface tunnel-ip 50000
RP/0/RSP0/CPU0:router(config-if)#
```

show crypto ipsec sa

To display security association (SA) information based on the rack/slot/module location, use the **show crypto ipsec sa** command.

show crypto ipsec sa [*sa-id* | **peer** *ip-address* | **profile** *profile-name* | **detail** | **count** | **fvr** *fvr-name* | **ivrf** *ivrf-name* | **location** *node-id*]

Syntax Description		
sa-id	(Optional)	Identifier for the SA. The range is from 1 to 64500.
peer <i>ip-address</i>	(Optional)	IP address used on the remote (PC) side. Invalid IP addresses are not accepted.
profile <i>profile-name</i>	(Optional)	Specifies the alphanumeric name for a security profile. The character range is from 1 to 64. Profile names cannot be duplicated.
detail	(Optional)	Provides additional dynamic SA information.
count	(Optional)	Provides SA count.
fvr <i>fvr-name</i>	(Optional)	Specifies that all existing SAs for front door virtual routing and forwarding (FVRF) is the same as the fvr-name.
ivrf <i>ivrf-name</i>	(Optional)	Specifies that all existing SAs for inside virtual routing and forwarding (IVRF) is the same as the ivrf-name.
location <i>node-id</i>	(Optional)	Specifies that the SAs are configured on a specified location.

Command Modes EXEC

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines If no optional argument or keyword is used, all SAs are displayed within a flow. Within a flow, the SAs are listed by protocol (Encapsulating Security Payload [ESP] or Authentication Header [AH]) and direction (inbound or outbound).

The **detail** keyword provides additional information only for SAs that are configured in a software crypto engine. The SAs are configured by using tunnel-ipsec and transport.

Task ID	Task ID	Operations
	crypto	read

Examples

The following sample output is from the **show crypto ipsec sa** command:

```
RP/0/RP0RSP0/CPU0:router# show crypto ipsec sa
```

```

SSA id:          510
Node id:         0/1/0
SA Type:         MANUAL
interface:       service-ipsec22
profile :        p7
local ident (addr/mask/prot/port) : (0.0.0.0/0.0.0.255/512/0)
remote ident (addr/mask/prot/port) : (0.0.0.0/0.0.0.0/512/0)
local crypto endpt: 0.0.0.0, remote crypto endpt: 0.0.0.0, vrf default

#pkts tx          :0                #pkts rx          :0
#bytes tx         :0                #bytes rx         :0
#pkts encrypt     :0                #pkts decrypt    :0
#pkts digest      :0                #pkts verify     :0
#pkts encrpt fail:0                #pkts decrpt fail:0
#pkts digest fail:0                #pkts verify fail:0
#pkts replay fail:0                #pkts rx errors  :0
#pkts tx errors   :0

outbound esp sas:
  spi: 0x322(802)
  transform: esp-3des-md5
  in use settings = Tunnel
  sa agreed lifetime: 3600s, 4194303kb
  sa timing: remaining key lifetime: 3142303931sec/0kb
  sa DPD: disable, mode none, timeout 0s
  sa idle timeout: disable, 0s
  sa anti-replay (HW accel): enable, window 64
inbound esp sas:
  spi: 0x322(802)
  transform: esp-3des-md5
  in use settings = Tunnel
  sa agreed lifetime: 3600s, 4194303kb
  sa timing: remaining key lifetime: 3142303931sec/0kb
  sa DPD: disable, mode none, timeout 0s
  sa idle timeout: disable, 0s
  sa anti-replay (HW accel): enable, window 64

```

This table describes the significant fields shown in the display.

Table 1: show crypto ipsec sa Field Descriptions

Field	Description
SA id	Identifier for the SA.
interface	Identifier for the interface.
profile	String of alphanumeric characters that specify the name of a security profile.
local ident	IP address, mask, protocol, and port of the local peer.
remote ident	IP address, mask, protocol and port of the remote peer.
outbound esp sas	Outbound ESP SAs.
inbound esp sas	Inbound ESP SAs.
transform	The transform being used in the SA.

Field	Description
sa lifetime	The lifetime value used in the SA.

The following sample output is from the **show crypto ipsec sa** command for the **profile** keyword for a profile named **pn1**:

```
RP/0/RP0RSP0/CPU0:router# show crypto ipsec sa profile pn1

SA id: 2
interface: tunnel0
profile: pn1
local ident (addr/mask/prot/port): (172.19.70.92/255.255.255.255/0/0)
remote ident (addr/mask/prot/port): (172.19.72.120/255.255.255.255/0/0)
local crypto endpt: 172.19.70.92, remote crypto endpt: 172.19.72.120
outbound esp sas:
spi: 0x8b0e950f (2332988687)
transform: esp-3des-sha
in use settings = Tunnel
sa lifetime: 3600s, 4194303kb

SA id: 2
interface: tunnel0
profile: pn1
local ident (addr/mask/prot/port): (172.19.72.120/255.255.255.255/0/0)
remote ident (addr/mask/prot/port): (172.19.70.92/255.255.255.255/0/0)
local crypto endpt: 172.19.72.120, remote crypto endpt: 172.19.70.92
inbound esp sas:
spi: 0x2777997c (662149500)
transform: esp-3des-sha
in use settings = Tunnel
sa lifetime: 3600s, 4194303kb
```

The following sample output is from the **show crypto ipsec sa** command for the **peer** keyword:

```
RP/0/RP0RSP0/CPU0:router# show crypto ipsec sa peer 172.19.72.120

SA id: 2
interface: tunnel0
profile: pn1
local ident (addr/mask/prot/port): (172.19.70.92/255.255.255.255/0/0)
remote ident (addr/mask/prot/port): (172.19.72.120/255.255.255.255/0/0)
local crypto endpt: 172.19.70.92, remote crypto endpt: 172.19.72.120
outbound esp sas:
spi: 0x8b0e950f (2332988687)
transform: esp-3des-sha
in use settings = Tunnel
sa lifetime: 3600s, 4194303kb

SA id: 2
interface: tunnel0
profile: pn1
local ident (addr/mask/prot/port): (172.19.72.120/255.255.255.255/0/0)
remote ident (addr/mask/prot/port): (172.19.70.92/255.255.255.255/0/0)
local crypto endpt: 172.19.72.120, remote crypto endpt: 172.19.70.92
inbound esp sas:
spi: 0x2777997c (662149500)
transform: esp-3des-sha
in use settings = Tunnel
sa lifetime: 3600s, 4194303kb
```

show crypto ipsec summary

To display IP Security (IPSec) summary information, use the **show crypto ipsec summary** command.

show crypto ipsec summary

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	crypto	read

Examples

The following sample output is from the **show crypto ipsec summary** command:

```
RP/0/RP0RSP0/CPU0:router# show crypto ipsec summary
# * Attached to a transform indicates a bundle
# Active IPsec Sessions: 1

SA  Interface          Local Peer/Port  Remote Peer/Port  FVRF    Profile  Transform Lifetime
-----
502 tunnel-ipsec100 70.70.70.2/500   60.60.60.2/500   default ipsec1    esp-3des esp
3600/100000000
```

This table describes the significant fields shown in the display.

Table 2: show crypto ipsec summary Field Descriptions

Field	Description
SA	Identifier for the security association.
Node	Identifier for the node.
Local Peer	IP address of the local peer.
Remote Peer	IP address of the remote peer.

Field	Description
FVRF	The front door virtual routing and forwarding (FVRF) of the SA. If the FVRF is global, the output shows f_vrf as an empty field
Mode	Profile mode type.
Profile	Crypto profile in use.
Transform	Transform in use.
Lifetime	Lifetime value, displayed in seconds followed by kilobytes.

show crypto ipsec transform-set

To display the configured transform sets, use the **show crypto ipsec transform-set** command.

```
show crypto ipsec transform-set [transform-set-name]
```

Syntax Description	<i>transform-set-name</i> (Optional) IPSec transform set with the specified value for the <i>transform-set-name</i> argument are displayed.
---------------------------	---

Command Default	No default values. The default behavior is to print all the available transform-sets.
------------------------	---

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	If no transform is specified, all transforms are displayed.
-------------------------	---

Task ID	Task	Operations
	crypto	read

Examples

The following sample output is from the **show crypto ipsec transform-set** command:

```
RP/0/RP0RSP0/CPU0:router# show crypto ipsec transform-set

Transform set combined-des-sha: {esp-des esp-sha-hmac}
Transform set tsfm2: {esp-md5-hmac esp-3des }
      Mode: Transport
Transform set tsfm1: {esp-md5-hmac esp-3des }
      Mode: Tunnel
Transform set ts1: {esp-des }
      Mode: Tunnel
```

```
show crypto ipsec transform-set
```