



## **VPN and Ethernet Services Command Reference for Cisco 8000 Series Routers**

**First Published:** 2021-02-01

**Last Modified:** 2024-09-04

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2021 Cisco Systems, Inc. All rights reserved.



## CONTENTS

---

### PREFACE

#### **Preface** vii

Changes to This Document vii

Communications, Services, and Additional Information vii

---

### CHAPTER 1

#### **EVPN Commands** 1

advertise-mac 2

convergence reroute 3

core-isolation-group 4

ethernet-segment 5

etree rt-leaf 6

evi 7

evpn 8

host mac-address duplicate-detection 9

show bgp l2vpn evpn 11

load-balancing-mode 13

show evpn ethernet-segment 14

show evpn evi 15

show evpn summary 18

---

### CHAPTER 2

#### **L2VPN Commands** 21

bridge-domain 22

bridge group 23

encapsulation dot1ad 24

encapsulation dot1q 25

encapsulation dot1q second-dot1q 26

flood mode ac-ingress-replication 27

interface	28
l2vpn	30
mac withdraw	31
propagate remote-status	32
pw-class encapsulation mpls	33
rewrite ingress tag	34
show l2vpn	36
show l2vpn bridge-domain	37
show l2vpn database	41
show l2vpn forwarding	44
show l2vpn protection main-interface	47
show l2vpn resource	50
show l2vpn trace	51
split-horizon group	53
storm-control	54
vpws-seamless-integration	56

---

**CHAPTER 3 Multiple Spanning Tree Protocol Commands 57**

allow-legacy-bpdu	58
instance (MSTP)	59
interface (MSTP)	60
name (MSTP)	61
portfast	62
show spanning-tree mst	63
spanning-tree mst	65
vlan-id (MSTP)	66

---

**CHAPTER 4 Integrated Routing and Bridging Commands 67**

interface bvi	68
routed interface bvi	70
show interfaces bvi	71

---

**CHAPTER 5 Layer 2 Access List Commands 77**

ethernet-services access-group	78
--------------------------------	----

ethernet-services access-list	79
show access-lists ethernet-services	80
show access-lists ethernet-services usage pfilter	82

---

**CHAPTER 6****VXLAN Commands 83**

host-reachability protocol static	84
hw-module profile cef vxlan ipv6-tnl-scale	85
interface nve	86
member vni	87
overlay-encapsulation	88
peer-ip lookup disable	89
show nve interface	90
show nve vni	91
source-interface loopback	92





## Preface

---

This preface contains these sections:

- [Changes to This Document, on page vii](#)
- [Communications, Services, and Additional Information, on page vii](#)

## Changes to This Document

This table lists the technical changes made to this document since it was first released.

**Table 1: Changes to This Document**

Date	Summary
September 2024	Republished with documentation updates for Release 24.3.1 features.
June 2024	Republished with documentation updates for Release 24.2.11 features.
March 2024	Republished with documentation updates for Release 24.1.1 features.
December 2023	Republished with documentation updates for Release 7.11.1 features.
October 2021	Republished with documentation updates for Release 7.3.2 features.
May 2021	Republished with documentation updates for Release 7.3.15 features.
February 2021	Initial release of this document.

## Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).

- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco DevNet](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

### **Cisco Bug Search Tool**

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.





## EVPN Commands

---

This section describes the commands used to configure Ethernet VPN (EVPN) services for Layer 2 VPNs.

- [advertise-mac](#), on page 2
- [convergence reroute](#), on page 3
- [core-isolation-group](#), on page 4
- [ethernet-segment](#), on page 5
- [etree rt-leaf](#), on page 6
- [evi](#), on page 7
- [evpn](#), on page 8
- [host mac-address duplicate-detection](#), on page 9
- [show bgp l2vpn evpn](#), on page 11
- [load-balancing-mode](#), on page 13
- [show evpn ethernet-segment](#), on page 14
- [show evpn evi](#), on page 15
- [show evpn summary](#), on page 18

## advertise-mac

To advertise local MAC to the peers, use **advertise-mac** command in the EVPN configuration mode. The local MAC is advertised to the peer in control plane using BGP.

### advertise-mac

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EVPN

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

The following example shows how to advertise local MAC.

```
Router(config)# evpn
Router(config-evpn)# interface Bundle-Ether 1
Router(config-evpn-ac)# exit
Router(config-evpn)# evi 2001
Router(config-evpn-instance)# advertise-mac
Router(config-evpn-instance-mac)# commit
```

## convergence reroute

To enable the switchover of a failed primary link from one PE device to another by redirecting the unicast traffic to backup peer , use the **convergence reroute** command in the EVPN interface Ethernet segment configuration mode.

### convergence reroute

<b>Syntax Description</b>	This command has no keywords or arguments.
<b>Command Default</b>	None
<b>Command Modes</b>	EVPN interface Ethernet segment configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.3.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read, write

### Example

This example shows how to redirect the unicast traffic to backup peer.

```
Router(config)# evpn
Router(config-evpn)# interface Bundle-Ether1
Router(config-evpn-ac)# ethernet-segment
Router(config-evpn-ac-es)# identifier type 0 00.00.00.00.00.00.05.01.02
Router(config-evpn-ac-es)# convergence reroute
```

# core-isolation-group

To configure EVPN core isolation group after the core interfaces fail, use the **core-isolation-group** command in the EVPN Timers configuration mode.

**core-isolation-group** *group-id*

<b>Syntax Description</b>	<i>group-id</i> Specifies the core isolation group ID. The range is from 1 to 4294967295.				
<b>Command Default</b>	None.				
<b>Command Modes</b>	EVPN configuration mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.11.1	This command was introduced.
Release	Modification				
Release 7.11.1	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				

## Example

This example shows how to configure the EVPN core isolation group.

```
Router# configure
Router(config-evpn)# interface bundle-Ether 43001
Router(config-evpn-ac)# core-isolation-group 43001
Router(config-evpn-ac)# commit
```

# ethernet-segment

To enter the EVPN interface ethernet segment configuration mode, use the **ethernet-segment** command in the EVPN interface configuration mode. To disable the Ethernet segment configuration, use the **no** form of this command.

```
ethernet-segment [ backbone-source-mac | identifier | load-balancing-mode | service-carving ]
no ethernet-segment [ backbone-source-mac | identifier | load-balancing-mode | service-carving ]
```

Syntax Description	backbone-source-mac	Specifies Backbone Source MAC.
	identifier	Specifies Ethernet Segment Identifier.
	load-balancing-mode	Specifies load balancing mode.
	service-carving	Specifies service carving.

**Command Default** None.

**Command Modes** EVPN interface configuration

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to enter the EVPN interface ethernet segment configuration mode:

```
Router# configure
Router(config)# evpn
Router(config-evpn)# interface bundle-ether 1
Router(config-evpn-ac)# ethernet-segment
Router(config-evpn-ac-es)#
```

## etree rt-leaf

To enable EVPN instance as EVPN E-Tree leaf site using BGP Route Target (RT) import and export policies, use the **etree rt-leaf** command in the EVPN EVI configuration submode.

### etree rt-leaf

**Syntax Description** This command has no keywords or arguments.

**Command Default** None.

**Command Modes** EVI configuration submode

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read, write

### Example

This example shows how to designate EVPN instance as EVPN E-Tree Route-Target leaf site.

```
Router(config)# evpn
Router(config-evpn)# evi 15
Router(config-evpn-instance)# etree
Router(config-evpn-instance-etree)# rt-leaf
```

# evi

To enter the EVPN EVI configuration mode and configure BGP settings for a bridge domain or EVI, use the **evi** command in the EVPN configuration mode.

**evi** *evi-id*

<b>Syntax Description</b>	<i>evi-id</i> Specifies the Ethernet VPN ID to set. The range is from 1 to 65534.				
<b>Command Default</b>	None.				
<b>Command Modes</b>	EVPN configuration mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.11.1	This command was introduced.
Release	Modification				
Release 7.11.1	This command was introduced.				
<b>Usage Guidelines</b>	Use this command to configure static BGP route distinguisher or BGP route target for an EVI.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write
Task ID	Operation				
l2vpn	read, write				

## Example

This example shows how to enter the EVPN EVI configuration mode:

```
Router# configure
Router(config)# evpn
Router(config-evpn)# evi 2
```

## evpn

To enter EVPN configuration mode, use the **evpn** command in the global configuration mode. To return to the global configuration mode, use the **no** form of this command.

```
evpn [ bgp | evi | interface | timers ]
no evpn [ bgp | evi | interface | timers ]
```

Syntax Description	
<b>bgp</b>	Configures BGP.
<b>evi</b>	Configures Ethernet VPN ID (EVI).
<b>interface</b>	Assigns an interface to EVPN.
<b>timers</b>	Configures global EVPN timers.

**Command Default** None.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read, write

### Example

This example shows how to enter the EVPN configuration mode:

```
Router# configure
Router(config)# evpn
Router(config-evpn)#
```



# host mac-address duplicate-detection

To enable duplicate detection of host MAC address, use the **host mac-address duplicate-detection** command in the EVPN configuration mode.

**host mac-address duplicate-detection** [ **freeze-time** *freeze-time* | **move-count** *move-count* | **move-interval** *move-interval* | **retry-count** *retry-count* | **infinity** | **reset-freeze-count-interval** *interval* ] **disable**

Syntax Description	freeze-time <i>freeze-time</i>	move-count <i>move-count</i>	move-interval <i>move-interval</i>	retry-count <i>retry-count</i>	infinity	reset-freeze-count-interval <i>interval</i>	disable
	Length of time to lock the MAC address after it has been detected as duplicate. Default is 30 seconds.	Number of moves to occur within the specified <b>move-interval</b> before freezing the MAC address. Default is 5.	Interval to watch for subsequent MAC moves before freezing the MAC address. Default is 180 seconds.	Number of times to unfreeze an MAC address before freezing it permanently. Default is three times.	Infinite retry count. Prevents freezing of the duplicate MAC address permanently.	Interval after which the count of duplicate detection events is reset. Default is 24 hours. The range is from 1 hour to 48 hours.	Disable duplicate detection of MAC addresses.

**Command Default** None

**Command Modes** EVPN configuration mode

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

**Usage Guidelines** None

Task ID	Task ID	Operation
	l2vpn	read, write

## Example

This example shows how to enable duplicate detection of host MAC address:

```
Router# configure
Router(config)# evpn
Router(config-evpn)# host MAC-address duplicate-detection
Router(config-evpn-host-mac-addr-dup-detection)# move-count 2
Router(config-evpn-host-mac-addr-dup-detection)# freeze-time 10
Router(config-evpn-host-mac-addr-dup-detection)# retry-count 2
Router(config-evpn-host-mac-addr-dup-detection)# commit
```

This example shows how to prevent permanent freezing of duplicate host MAC address:

```
Router# configure
Router(config)# evpn
Router(config-evpn)# host MAC-address duplicate-detection
Router(config-evpn-host-mac-addr-dup-detection)# retry-count infinity
Router(config-evpn-host-mac-addr-dup-detection)# commit
```

This example shows how to reset the interval after which the count of duplicate detection events are permanently frozen.

```
Router# configure
Router(config)# evpn
Router(config-evpn)# host MAC-address duplicate-detection
Router(config-evpn-host-mac-addr-dup-detection)# reset-freeze-count-interval 20
Router(config-evpn-host-mac-addr-dup-detection)# commit
```

## show bgp l2vpn evpn

To display BGP routes associated with EVPN under L2VPN address family, use the **show bgp l2vpn evpn** command in EXEC mode.

```
show bgp l2vpn evpn {bridge-domain bridge-domain-name | rd {all IPv4 address:nn 4-byte
as-number:nn 2-byte as-number:nn}}
```

Syntax	Description
<b>bridge-domain</b> <i>bridge-domain-name</i>	Displays the bridges by the bridge ID. The <i>bridge-domain-name</i> argument is used to name a bridge domain.
<b>rd</b>	Displays routes with specific route distinguisher.
<b>all</b>	Displays specified routes in all RDs.
<i>IPv4 address:nn</i>	Specifies the IPv4 address of the route distinguisher. nn: 16-bit number
<i>4-byte as-number:nn</i>	Specifies 4-byte AS number in asdot (X.Y) format or in asplain format. <ul style="list-style-type: none"> <li>For 4-byte AS number in asdot (X.Y) format, the range is from 1 to 65535. The format is: &lt;1-65535&gt;.&lt;0-65535&gt;:&lt;0-65535&gt;</li> <li>For 4-byte AS number in asplain format, the range is from 65536 to 4294967295. The format is: &lt;65536-4294967295&gt;:</li> </ul> nn: 32-bit number
<i>2-byte as-number:nn</i>	Specifies 2-byte as-number. The range is from 1 to 65535. nn: 32-bit number

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	bgp	read

**Example**

This sample output shows the BGP routes associated with EVPN with bridge-domain filter:

**show bgp l2vpn evpn bridge-domain bd1**

```

Network          Next Hop          Metric LocPrf Weight Path
Route Distinguisher: 192.0.2.1:1 (default for vrf bd1)
*>i[1][0077.0000.0000.0000.0001][0]/120
      198.51.100.1          100      0 i
*>i[1][0077.0000.0000.0000.0001][4294967295]/120
      198.51.100.1          100      0 i
*>i[1][0088.0000.0000.0000.0001][0]/120
      203.0.113.1          100      0 i
* i          209.165.200.225        100      0 i
*>i[1][0088.0000.0000.0000.0001][4294967295]/120
      203.0.113.1          100      0 i
* i          209.165.200.225        100      0 I
* [2][0][48][0001.0000.0001][0]/104
*>          209.165.201.1          0 101 i
*>i[2][0][48][0002.0000.0001][0]/104
      203.0.113.1          100      0 102 i
* i          209.165.200.225        100      0 102 i
*>i[3][0][32][203.0.113.1]/80
      203.0.113.1          100      0 i
*>i[3][0][32][209.165.200.225]/80
      209.165.200.225        100      0 i

```

# load-balancing-mode

To enable the load-balancing mode, use the **load-balancing-mode** command in the EVPN interface configuration mode. To disable the load-balancing mode, use the **no** form of this command.

**load-balancing-mode** { **port-active** | **single-active** | **single-flow-active** }

Syntax Description	port-active	single-active	single-flow-active
	Enables the port-active load-balancing mode	Enables the single-active load-balancing mode.	Enables the single-flow-active load-balancing mode.

**Command Default** None

**Command Modes** EVPN configuration mode

Command History	Release	Modification
	Release 24.2.11	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read, write

## Example

This example shows how to enable the single-active load-balancing mode:

```
Router# configure
Router(config)# evpn
Router(config-evpn)# ethernet-segment
Router(config-evpn-es)# load-balancing-mode single-active
```

This example shows how to enable the single-flow-active load-balancing mode:

```
Router# configure
Router(config)# evpn
Router(config-evpn)# ethernet-segment
Router(config-evpn-es)# load-balancing-mode single-flow-active
```

# show evpn ethernet-segment

To display the EVPN Ethernet segment information, use the **show evpn ethernet-segment** command in the EXEC mode.

**show evpn ethernet-segment** [ **detail** | **esi** | **interface** | **location** | **private** | **standby** | **carving** ]

Syntax Description	Parameter	Description
	<b>detail</b>	Displays detailed information.
	<b>esi</b>	Filters by Ethernet Segment identifier.
	<b>interface</b>	Filters by interface name.
	<b>location</b>	Displays location specific information.
	<b>private</b>	Displays private information.
	<b>standby</b>	Displays standby node specific information.

**Command Default** None.

**Command Modes** EXEC

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read

## Example

This sample output shows the EVPN Ethernet segment detailed information:

```
Router# show evpn ethernet-segment interface HundredGigE 0/0/0/24 detail

Ethernet Segment Id      Interface                Nexthops
-----
N/A                      HundredGigE 0/0/0/24  10.0.0.1
.....
Topology :
Operational : SH
```

# show evpn evi

To display the EVPN E-VPN ID information, use the **show evpn evi** command in the EXEC mode.

```
show evpn evi [ bridge-domain | detail | inclusive-multicast | location | mac | standby | vpn-id ]
```

Syntax Description	Option	Description
	<b>bridge-domain</b>	Displays information for a specified bridge-domain..
	<b>detail</b>	Displays detailed information.
	<b>inclusive-multicast</b>	Displays EVPN Inclusive Multicast information.
	<b>location</b>	Displays location specific information.
	<b>mac</b>	Displays EVI MAC route associated configuration information.
	<b>standby</b>	Displays standby node specific information.
	<b>vpn-id</b>	Displays information for a specified E-VPN Identifier.

**Command Default** None.

**Command Modes** EXEC

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read

## Example

This sample output shows the EVPN EVI information with the VPN-ID and MAC address filter:

```
Router#show evpn evi vpn-id 185 mac 0024.be03.ce01
MAC address      Nexthop                Label  vpn-id
-----
0024.be03.ce01  3.100.100.100         16004  185
                  4.100.100.100         16004  185
ESI port key    : 0x0000
Source          : Remote
Flush Count     : 0
```

This sample output shows the EVPN EVI information with the VPN-ID and inclusive-multicast filter:

```
Router#show evpn evi vpn-id 185 inclusive-multicast service-id 1850312 orig-ip 1.100.100.100
ISID          Originating IP          vpn-id
-----
1850312      1.100.100.100          185
1850312      2.100.100.100          185
1850312      3.100.100.100          185
1850312      4.100.100.100          185
```

This sample output shows the EVPN EVI inclusive-multicast information:

```
Router#show evpn evi inclusive-multicast detail
ISID: 1850312, Originating IP: 1.100.100.100          185
  Nexthop: ::
  Label   : 16005
  Source  : Local
ISID: 1850312, Originating IP: 2.100.100.100          185
  Nexthop: 2.100.100.100
  Label   : 16005
  Source  : Remote
ISID: 1850312, Originating IP: 3.100.100.100          185
  Nexthop: 3.100.100.100
  Label   : 16005
  Source  : Remote
ISID: 1850312, Originating IP: 4.100.100.100          185
  Nexthop: 4.100.100.100
  Label   : 16005
  Source  : Remote
```

This sample output shows the EVPN EVI information with the bridge-domain filter:

```
Router#show evpn evi bridge-domain tb1-core1 detail
EVI          Bridge Domain          Type
-----
145          tb1-core1                  PBB
165          tb1-core2                  PBB
185          tb1-core3                  PBB
65535       ES:GLOBAL                  BD
```

This sample output shows the EVPN EVI detailed information:

```
Router#show evpn evi detail
EVI          Bridge Domain          Type
-----
145          tb1-core1                  PBB
  Unicast Label   : 16000
  Multicast Label : 16001
  RD Config: none
  RD Auto   : (auto) 1.100.100.100:145
  RT Auto   : 100:145
  Route Targets in Use          Type
  -----
  100:145                      Import
  100:145                      Export
165          tb1-core2                  PBB
```



```
Unicast Label : 16002
Multicast Label: 16003
RD Config: none
RD Auto : (auto) 1.100.100.100:165
RT Auto : 100:165
Route Targets in Use          Type
-----
100:165                        Import
100:165                        Export

185          tbl-core3          PBB
Unicast Label : 16004
Multicast Label: 16005
RD Config: none
RD Auto : (auto) 1.100.100.100:185
RT Auto : 100:185
Route Targets in Use          Type
-----
100:185                        Import
100:185                        Export

65535        ES:GLOBAL          BD
Unicast Label : 0
Multicast Label: 0
RD Config: none
RD Auto : (auto) 1.100.100.100:0
RT Auto : none
Route Targets in Use          Type
-----
0100.9e00.0210                Import
0100.be01.ce00                Import
0100.be02.0101                Import
```

## show evpn summary

To display the EVPN summary, use the **show evpn summary** command in the EXEC mode.

**show evpn summary**[location | private | standby]

<b>Syntax Description</b>	<b>location</b> Displays location specific information.				
	<b>private</b> Displays private information.				
	<b>standby</b> Displays standby node specific information.				
<b>Command Default</b>	None.				
<b>Command Modes</b>	EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.11.1	This command was introduced.
Release	Modification				
Release 7.11.1	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read
Task ID	Operation				
l2vpn	read				

### Example

This sample output shows the EVPN summary:

```
Router#show evpn summary
-----
Global Information
-----
Number of EVIs                : 1
Number of Local MAC Routes    : 1
Number of Remote MAC Routes   : 0
Number of Local IMCAST Routes : 0
Number of Remote IMCAST Routes: 0
Number of Internal Labels     : 0
Number of ES Entries          : 0
BGP Router ID                 : ::
BGP ASN                       : Invalid
PBB BSA MAC address           : f866.f214.abd7
Global peering timer          : 45 seconds
Global recovery timer         : 20 seconds
Global programming timer      : 1500 microseconds
Global flushagain timer       : 60 seconds
-----
High Availability Information
```

```
-----  
BGP EOD : N  
Number of Marked MAC Routes : 0  
Number of Swept MAC Routes : 0  
Number of Marked IMCAST Routes: 0  
Number of Swept IMCAST Routes : 0
```

show evpn summary



## L2VPN Commands

---

This section describes the commands used to configure Gigabit Ethernet services for Layer 2 VPNs.

By default, all interfaces are Layer 3 interfaces. You can change the interface to Layer 2 interface using the **l2transport** command.

For detailed information about concepts and configuration, see the *Introduction to Layer 2 Virtual Private Networks* chapter in the L2VPN and Ethernet Services Configuration Guide for Cisco 8000 Series Routers.

- [bridge-domain](#), on page 22
- [bridge group](#), on page 23
- [encapsulation dot1ad](#), on page 24
- [encapsulation dot1q](#), on page 25
- [encapsulation dot1q second-dot1q](#), on page 26
- [flood mode ac-ingress-replication](#), on page 27
- [interface](#), on page 28
- [l2vpn](#), on page 30
- [mac withdraw](#), on page 31
- [propagate remote-status](#), on page 32
- [pw-class encapsulation mpls](#), on page 33
- [rewrite ingress tag](#), on page 34
- [show l2vpn](#), on page 36
- [show l2vpn bridge-domain](#), on page 37
- [show l2vpn database](#), on page 41
- [show l2vpn forwarding](#), on page 44
- [show l2vpn protection main-interface](#), on page 47
- [show l2vpn resource](#), on page 50
- [show l2vpn trace](#), on page 51
- [split-horizon group](#), on page 53
- [storm-control](#) , on page 54
- [vpws-seamless-integration](#), on page 56

# bridge-domain

To establish a bridge domain and to enter L2VPN bridge group bridge domain configuration mode, use the **bridge-domain** command in L2VPN bridge group configuration submenu.

**bridge-domain** *bridge-domain-name*

## Syntax Description

*bridge-domain-name* Name of the bridge domain.

**Note** The maximum number of characters that can be specified in the bridge domain name is 27.

## Command Default

The default value is a single bridge domain.

## Command Modes

L2VPN bridge group configuration

## Command History

Release	Modification
Release 7.2.12	This command was introduced.

## Usage Guidelines

Use the **bridge-domain** command to enter L2VPN bridge group bridge domain configuration mode.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

The following example shows how to configure a bridge domain:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group BG1
Router(config-l2vpn-bg)# bridge-domain BD1
Router(config-l2vpn-bg-bd)#
```

## Related Commands

Command	Description
<a href="#">l2vpn, on page 30</a>	Enters L2VPN configuration mode.
<a href="#">bridge group, on page 23</a>	Creates a bridge group
<a href="#">show l2vpn bridge-domain, on page 37</a>	Display information for the bridge ports such as attachment circuits for the specific bridge domains.

# bridge group

To create a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain, use the **bridge group** command in L2VPN configuration mode. To remove all the bridge domains that are created under this bridge group and to remove all network interfaces that are assigned under this bridge group, use the **no** form of this command.

```
bridge group bridge-group-name
no bridge-group bridge-group-name
```

<b>Syntax Description</b>	<i>bridge-group-name</i> Number of the bridge group to which the interface belongs.
---------------------------	---

<b>Command Default</b>	No bridge group is created.
------------------------	-----------------------------

<b>Command Modes</b>	L2VPN configuration
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.2.12	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>bridge group</b> command to enter L2VPN bridge group configuration mode.
-------------------------	---

<b>Task ID</b>	<b>Task</b>	<b>Operations</b>
	l2vpn	read, write

<b>Examples</b>	The following example shows that bridge group 1 is assigned:
-----------------	--

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group BG1
Router(config-l2vpn-bg)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">l2vpn, on page 30</a>	Enters L2VPN configuration mode.
	<a href="#">bridge-domain, on page 22</a>	Establishes a bridge domain

# encapsulation dot1ad

To define the matching criteria to map 802.1ad frames ingress on an interface to the appropriate service instance, use the **encapsulation dot1ad** command in the interface configuration mode.

**encapsulation dot1ad** *vlan-id*

## Syntax Description

*vlan-id* VLAN ID, can be given as single ID.

## Command Default

No matching criteria are defined.

## Command Modes

Interface configuration

## Command History

Release	Modification
Release 7.3.2	This command was introduced.

## Usage Guidelines

Only one encapsulation statement can be applied to a sub-interface. Encapsulation statements cannot be applied to main interfaces.

A single encapsulation dot1ad statement specifies matching for frames with a single VLAN ID.

## Examples

The following example shows how to map 802.1ad frames ingress on an interface to the appropriate service instance:

```
Router(config-if)# encapsulation dot1ad 10
```

The following example shows how to map 802.1ad frames ingress on an l2transport sub-interface:

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/24.1 l2transport
Router(config-subif)# encapsulation dot1ad 10
```



# encapsulation dot1q

To define the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance, use the **encapsulation dot1q** command in the interface configuration mode.

```
encapsulation dot1q vlan-id
```

## Syntax Description

*vlan-id* VLAN ID, can be given as single ID.

## Command Default

No matching criteria are defined.

## Command Modes

Interface configuration

## Command History

Release	Modification
Release 7.3.2	This command was introduced.

## Usage Guidelines

Only one encapsulation statement can be applied to a sub-interface. Encapsulation statements cannot be applied to main interfaces.

A single encapsulation dot1q statement specifies matching for frames with a single VLAN ID.

## Examples

The following example shows how to map 802.1Q frames ingress on an interface to the appropriate service instance:

```
Router(config-if) # encapsulation dot1q 10
```

The following example shows how to map 802.1Q frames ingress on an l2transport sub-interface:

```
Router# configure  
Router(config)# interface HundredGigE 0/0/0/24.1 l2transport  
Router(config-subif) # encapsulation dot1q 10
```

# encapsulation dot1q second-dot1q

To define the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance, use the **encapsulation dot1q second-dot1q** command in interface configuration mode. To remove the configuration, use the **no** form of this command.

```
encapsulation dot1q vlan-id [ second-dot1q vlan-id ]
```

<b>Syntax Description</b>	<i>vlan-id</i>	Specifies VLAN identifier.
	<b>dot1q</b>	Specifies IEEE 802.1Q VLAN tagged packets.
	<b>second-dot1q</b>	
<b>Command Default</b>	No matching criteria are defined.	
<b>Command Modes</b>	Interface configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.1.1	This command was introduced.

- Usage Guidelines**
- The following restrictions are applicable for this command:
- The outer tag must be unique and the inner tag may be a single VLAN.
  - Only one encapsulation command must be configured per VLAN service instance.
  - Overlapping inner VLAN ranges are not supported.

**Examples**

The following example shows how to map ingress frames to a VLAN service instance:

```
Router#configure
Router(config)#interface TenGigE 0/0/0/1.102 l2transport
Router(config-subif)#encapsulation dot1q 200 second-dot1q 201
Router(config-subif)#commit
Router(config-subif)#exit
Router(config)#exit
```

# flood mode ac-ingress-replication

To add BUM traffic queueing support for attachment circuits in a bridge domain, use the **flood mode ac-ingress-replication** command in the L2VPN bridge group bridge domain configuration mode.

## flood mode ac-ingress-replication

This command has no keywords or arguments.

### Command Default

BUM traffic queueing support is not supported for attachment circuits in a bridge domain.

### Command Modes

L2VPN bridge group bridge domain configuration

### Command History

Release	Modification
Release 7.11.1	This command was introduced.

### Usage Guidelines

BUM traffic queueing support for attachment circuits in a bridge domain is not supported on devices that have multiple NPUs or line cards. It is only supported on single NPU devices.

Perform this task to add BUM traffic queueing support for attachment circuits in a bridge domain

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group 10
Router(config-l2vpn-bg)# bridge-domain 1
Router(config-l2vpn-bg-bd)# flood mode ac-ingress-replication
Router(config-l2vpn-bg-bd)# commit
```

# interface

To create a VLAN interface or subinterface, use the **interface** command in global configuration mode.

```
interface type interface-path-id . subinterface
```

## Syntax Description

<i>type</i>	Type of Ethernet interface on which you want to create a VLAN interface or subinterface. Enter <b>HundredGigabitEthernet</b> .
<i>interface-path-id</i>	Physical interface or virtual interface followed by the interface path ID. Naming notation is <i>interface-path-id</i> .  For more information about the syntax for the router, use the question mark (?) online help function.
<i>subinterface</i>	Physical interface or virtual interface followed by the subinterface path ID. Naming notation is <i>interface-path-id.subinterface</i> . The period in front of the subinterface value is required as part of the notation.  For more information about the syntax for the router, use the question mark (?) online help function.

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
Release 7.2.12	This command was introduced.

## Usage Guidelines

For the *interface-path-id* argument, use the following guidelines:

- If specifying a physical interface, the naming notation is *rack/slot/module/port*. The slash between values is required as part of the notation. An explanation of each component of the naming notation is as follows:
  - *rack*: Chassis number of the rack.
  - *slot*: Physical slot number of the line card.
  - *module*: Module number. A physical layer interface module (PLIM) is always 0.
  - *port*: Physical port number of the interface.
- If specifying an Ethernet bundle interface, the range is from 1 through 65535.

For the *subinterface* argument, the range is from 0 through 4095.

To configure a large number of subinterfaces, we recommend entering all configuration data before you commit the **interface** command.

## Usage Guidelines



**Note** A subinterface does not pass traffic without an assigned VLAN ID.

Task ID	Task ID	Operations
	vlan	read, write

## Examples

This example shows how to configure a VLAN interface on a 100-Gigabit Ethernet interface:

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/24
Router(config-subif)# dot1q vlan 1
Router(config-subif)# ipv4 address 10.0.0.1/8
```

This example shows how to configure a VLAN subinterface on a 100-Gigabit Ethernet interface:

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/24.1
Router(config-subif)# dot1q vlan 1
Router(config-subif)# ipv4 address 10.0.0.1/8
```

To change an interface from Layer 2 to Layer 3 mode and back, you must delete the interface first and then re-configure it in the appropriate mode.

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/24
Router(config-subif)# exit
Router(config)# no interface HundredGigE 0/0/0/24
```

# l2vpn

To enter L2VPN configuration mode, use the **l2vpn** command in the global configuration mode. To return to the default behavior, use the **no** form of this command.

## l2vpn

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Global Configuration mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	l2vpn	read, write

## Examples

The following example shows how to enter L2VPN configuration mode:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)#
```

Related Commands	Command	Description
	<a href="#">show l2vpn, on page 36</a>	Displays L2VPN information

# mac withdraw

To enable MAC address withdrawal for a specified bridge domain, use the **mac withdraw** command in L2VPN configuration mode.

**mac withdraw** [ **disable** | **optimize** | **state-down** ]

Syntax Description	disable	optimize	state-down
	Disables MAC address withdrawal.	Enables optimization of MAC address withdrawal when the bridge port goes down.	Sends MAC address withdrawal message when the bridge port goes down.

**Command Default** None

**Command Modes** L2VPN configuration mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

The following example shows how to disable MAC address withdrawal.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# mac
Router(config-l2vpn-bg-bd-mac)# withdraw disable
```

The following example shows how to configure MAC address withdrawal when the bridge port goes down.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# mac
Router(config-l2vpn-bg-bd-mac)# withdraw state-down
```

The following example shows how to configure optimization of MAC address withdrawal when the bridge port goes down.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg1
Router(config-l2vpn-bg)# bridge-domain bd1
Router(config-l2vpn-bg-bd)# mac
Router(config-l2vpn-bg-bd-mac)# withdraw optimize
```

## propagate remote-status

To propagate Layer 2 transport events, use the **propagate remote-status** command in in the Layer 2 transport configuration. To return to the default behavior, use the **no** form of this command.

### propagate remote-status

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** Layer 2 transport configuration

Command History	Release	Modification
	Release 24.3.1	This command was introduced.

**Usage Guidelines** Link Loss Forwarding (LLF) feature uses this command to propagate link failures to remote endpoints.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example shows how to use the command to propagate Layer 2 transport events and to enable LLF.

```
Router(config)# interface tenGigE 0/0/0/1
Router(config-if)# l2transport
Router(config-if-l2)# propagate remote-status
```



## pw-class encapsulation mpls

To configure MPLS pseudowire encapsulation, use the **pw-class encapsulation mpls** command in L2VPN pseudowire class configuration mode. To undo the configuration, use the **no** form of this command.

```
pw-class class-name encapsulation mpls { control-word | | load-balancing flow-label | both }
pw-class class-name encapsulation mpls { control-word | | load-balancing flow-label |
both }
```

Syntax Description		
	<i>class-name</i>	Encapsulation class name.
	<b>control-word</b>	Disables control word for MPLS encapsulation. Disabled by default.
	<b>load-balancing flow-label both</b>	Sets flow-label based load balancing.

**Command Default** None

**Command Modes** L2VPN pseudowire class configuration

Command History	Release	Modification
	Release 7.3.15	This command was introduced.

### Usage Guidelines



**Note** All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

This example shows how to define MPLS pseudowire encapsulation:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# pw-class path1
Router(config-l2vpn-pwc)# encapsulation mpls
Router(config-l2vpn-pwc-mpls)# control-word
Router(config-l2vpn-pwc-mpls)# load-balancing flow-label both
```

## rewrite ingress tag

To specify the encapsulation adjustment that is to be performed on the frame ingress to the VLAN service instance, use the **rewrite ingress tag** command in the interface configuration mode. Use the following VLAN rewrite configuration to add or modify double dot1q VLAN tags on L2 Ethernet frames. To delete the encapsulation adjustment, use the **no** form of this command.

```
rewrite ingress tag {push {dot1q vlan-id} | pop {2} | translate {1-to-2 {dot1q vlan-id
second-dot1q vlan-id} | 2-to-2 {dot1q vlan-id second-dot1q vlan-id}}} [symmetric]
```

### Syntax Description

<i>vlan-id</i>	Specifies VLAN identifier.
<b>push dot1q</b> <i>vlan-id</i> <b>second-dot1q</b> <i>vlan-id</i>	Pushes the pair of 802.1Q tags with VLAN IDs.
<b>pop</b> { <b>2</b> }	Specifies removal of the pair of 802.1Q tags from the packet.
<b>translate 1-to-2 dot1q</b> <i>vlan-id</i> <b>second-dot1q</b> <i>vlan-id</i>	Replaces the incoming tag defined by the encapsulation command by a pair of 802.1Q tags.
<b>translate 2-to-2 dot1q</b> <i>vlan-id</i> <b>second-dot1q</b> <i>vlan-id</i>	Replaces the pair of tags defined by the encapsulation command by a pair of VLANs defined by this rewrite.
<b>symmetric</b>	(Optional) A rewrite operation is applied on both ingress and egress. The operation on egress is the inverse operation as ingress.  <b>Note</b> Symmetric is the default behavior. Hence, it cannot be disabled.

### Command Default

The Dot1q VLAN tags in the Ethernet frame is not modified on ingress.

### Command Modes

Interface configuration

### Command History

Release	Modification
Release 24.1.1	This command was introduced.

### Usage Guidelines

The **symmetric** keyword is accepted only when a single VLAN is configured in encapsulation.

Define the elements being popped with an encapsulation type before using the **pop** command.

Define the elements being translated with an encapsulation type before using the **rewrite ingress tag translate** command. In the 2-to-1 option, “2” means two tags of a type defined by the **encapsulation** command.

### Examples

The following example shows how to specify the encapsulation adjustment that is to be performed on the frame ingress to the VLAN service instance:

```
Router#configure
Router(config)#interface TenGigE 0/0/0/1.102 l2transport
Router(config-subif)#encapsulation dot1q 200 second-dot1q 201
```

```
Router(config-subif)#rewrite ingress tag pop 2 symmetric
Router(config-subif)#commit
Router(config-subif)#exit
Router(config)#exit
```

# show l2vpn

To display L2VPN information, use the **show l2vpn** command in the EXEC mode.

## show l2vpn

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task	Operation ID
	l2vpn	read

## Example

The following example displays output for the **show l2vpn** command. The output provides an overview of the state of the globally configured features.

```
Router# show l2vpn

Mon Oct 12 14:14:48.869 UTC
HA role      : Active
ISSU role    : Primary
Process FSM  : PrimaryActive
-----
PW-Status: enabled
PW-Grouping: disabled
Logging PW: disabled
Logging BD state changes: disabled
Logging VFI state changes: disabled
Logging NSR state changes: disabled
TCN propagation: disabled
PW OAM transmit time: 30s
```

Related Commands	Command	Description
	<a href="#">l2vpn, on page 30</a>	Enters L2VPN configuration mode.

## show l2vpn bridge-domain

To display information for the bridge ports such as attachment circuits for the specific bridge domains, use the **show l2vpn bridge-domain** command in EXEC Mode.

```
show l2vpn bridge-domain [ autodiscovery bgp | bd-name bridge-domain-name | brief |
detail | group bridge-domain-group-name | hardware | interface type interface-path-id | location
node-id neighbor ip-address | summary | no-statistics | p2mp tunnel-id id | standby ]
```

Syntax	Description
<b>autodiscovery bgp</b>	(Optional) Displays BGP autodiscovery information.
<b>bd-name</b> <i>bridge-domain-name</i>	(Optional) Displays filter information on the <i>bridge-domain-name</i> . The <i>bridge-domain-name</i> argument is used to name a bridge domain.
<b>brief</b>	(Optional) Displays brief information about the bridges.
<b>detail</b>	(Optional) Displays detailed information about the bridges. Also, displays the output for the Layer 2 VPN (L2VPN) to indicate whether or not the MAC withdrawal feature is enabled and the number of MAC withdrawal messages that are sent or received from the AC.
<b>group</b> <i>bridge-domain-group-name</i>	(Optional) Displays filter information on the bridge-domain group name. The <i>bridge-domain-group-name</i> argument is used to name the bridge domain group.
<b>hardware</b>	(Optional) Displays hardware information.
<b>interface</b> <i>type</i> <i>interface-path-id</i>	(Optional) Displays the filter information for the interface on the bridge domain.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>location</b> <i>node-id</i>	(Optional) Displays the location specific information of the node.
<b>neighbor</b> <i>ip-address</i>	(Optional) Displays the bridge domains that contain the ACs to match the filter for the neighbor. The <i>ip-address</i> argument is used to specify IP address of the neighbor.
<b>no-statistics</b>	(Optional) Disables the collection of statistics for the bridge domain.
<b>p2mp</b> <b>tunnel-id</b> <i>id</i>	(Optional) Displays the bridge domain that contain the p2mp enabled bridge domain. The <b>tunnel-id</b> <i>id</i> argument is used too specify the tunnel of the p2mp brigde domain.
<b>summary</b>	(Optional) Displays the summary information for the bridge domain.
<b>standby</b>	(Optional) Displays whether the node is in the standby mode.

## show l2vpn bridge-domain

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.2.12	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>interface</b> keyword to display only the bridge domain that contains the specified interface as an attachment circuit. In the sample output, only the attachment circuit matches the filter that is displayed.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read

**Examples**

This is the sample output for **show l2vpn bridge-domain** command with VLAN parameters configured:

```
Router# show l2vpn bridge-domain bd-name BG1_BD1 detail
Legend: pp = Partially Programmed.
Bridge group: bg1, bridge-domain: bg1_bdl, id: 0, state: up, ShgId: 0, MSTi: 0
  Coupled state: disabled
  MAC learning: enabled
  MAC withdraw: enabled
    MAC withdraw for Access PW: enabled
    MAC withdraw sent on: bridge port up
    MAC withdraw relaying (access to access): disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: disabled
  Bridge MTU: 1500
  MIB cvplsConfigIndex: 1
  Filter MAC addresses:
  P2MP PW: disabled
  Create time: 30/03/2015 22:25:38 (00:26:08 ago)
  No status change since creation
  ACs: 2 (2 up), VFIs: 1, PWs: 0 (0 up), PBBs: 0 (0 up)
  List of ACs:
    AC: BV11, state is up
      Type Routed-Interface
      MTU 1514; XC ID 0x80000001; interworking none
      BVI MAC address:
```

```

    1000.4444.0001
AC: HundredgiabitEthernet0/0/0/0.1, state is up
  Type VLAN; Num Ranges: 1
  Outer Tag: 1
  VLAN ranges: [1001, 1001]
  MTU 1508; XC ID 0x508000a; interworking none
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: bridge-domain policer
  Static MAC addresses:

  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0
  Dynamic ARP inspection drop counters:
    packets: 0, bytes: 0
  IP source guard drop counters:
    packets: 0, bytes: 0
List of VNIs:
  VNI 1, state is up
  XC ID 0x80000014
  Encap type VXLAN
  Overlay nve100, Source 10.0.0.1, Multicast Group 225.1.1.1, UDP Port 4789
  Anycast VTEP 100.1.1.1, Anycast Multicast Group 224.10.10.1
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: bridge-domain policer

List of Access PWs:
List of VFIs:
  VFI bg1_bdl_vfi (up)
  VFI Statistics:
    drops: illegal VLAN 0, illegal length 0

```

Verify the EVPN and VPLS status.

```
Router# show l2vpn bridge-domain
Legend: pp = Partially Programmed.
Bridge group: vplstoevpn, bridge-domain: vplstoevpn, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 2 (1 up), PBBs: 0 (0 up), VNIs: 0 (0 up)
List of EVPNs:
  EVPN, state: up
List of ACs:
  Hu0/0/0/0, state: up, Static MAC addresses: 0, MSTi: 5
List of Access PWs:
List of VFIs:
  VFI vpls (up)
  Neighbor 172.16.0.1 pw-id 12, state: down, Static MAC addresses: 0
  Neighbor 192.168.0.1 pw-id 13, state: up, Static MAC addresses: 0
```

This indicates that VPLS and EVPN L2 bridging for the same VPN instance coexists and EVPN takes precedence over VPLS.

#### Related Commands

Command	Description
<a href="#">l2vpn, on page 30</a>	Enters L2VPN configuration mode.
<a href="#">show l2vpn, on page 36</a>	Displays L2VPN information



# show l2vpn database

To display L2VPN database, use the **show l2vpn database** command in EXEC mode.

```
show l2vpn database {ac | node}
```

<b>Syntax Description</b>	<b>ac</b> Displays L2VPN Attachment Circuit (AC) database				
	<b>node</b> Displays L2VPN node database.				
<b>Command Default</b>	None				
<b>Command Modes</b>	EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.2.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.2.12	This command was introduced.
Release	Modification				
Release 7.2.12	This command was introduced.				
<b>Usage Guidelines</b>	Even when xSTP (extended spanning tree protocol) operates in the PVRST mode, the output of the show or debug commands flag prefix is displayed as MSTP or MSTi, instead of PVRST.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read
Task ID	Operation				
l2vpn	read				

The following example displays output for the **show l2vpn database ac** command:

```
Router# show l2vpn database ac

Mon Oct 12 14:15:47.731 UTC
Bundle-Ether1:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x3
  Signaled capability valid: Yes
  Signaled capability flags: 0x360018
  Configured capability flags: 0x0
  XCID: 0xa0000001
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
  AC defn:
    ac-iframe: Bundle-Ether1
    capabilities: 0x00368079
    extra-capabilities: 0x00000000
    parent-ifh: 0x00000000
    ac-type: 0x04
    interworking: 0x00
  AC info:
    seg-status-flags: 0x00000003
    segment mtu/l2-mtu: 1500/1514
```

## show l2vpn database

```

HundredGigE0/0/0/0.1:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x3
  Signaled capability valid: Yes
  Signaled capability flags: 0x360018
  Configured capability flags: 0x0
  XCID: 0xea
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
  AC defn:
    ac-ifname: HundredGigE0_0_0_0.1
    capabilities: 0x00368079
    extra-capabilities: 0x00000000
    parent-ifh: 0x08000018
    ac-type: 0x15
    interworking: 0x00
  AC info:
    seg-status-flags: 0x00000003
    segment mtu/l2-mtu: 1504/1518

```

The following example displays output for the **show l2vpn database node** command:

```

Router# show l2vpn database node
Mon Oct 12 14:16:30.540 UTC
Node ID: 0x1000 (0/RP0/CPU0)
MA: vlan_ma      inited:1, flags:0x 2, circuits:3744
  AC event trace history [Total events: 4]
  -----
  Time           Event                               Num Rcvd   Num Sent
  ====          =====
  10/12/2015 12:46:00 Process joined                       0           0
  10/12/2015 12:46:00 Process init success                   0           0
  10/12/2015 12:46:00 Replay start rcvd                     0           0
  10/12/2015 12:46:00 Replay end rcvd                       0           0

MA: ether_ma     inited:1, flags:0x 2, circuits:2
  AC event trace history [Total events: 4]
  -----
  Time           Event                               Num Rcvd   Num Sent
  ====          =====
  10/12/2015 12:41:19 Process joined                       0           0
  10/12/2015 12:41:19 Process init success                   0           0
  10/12/2015 12:41:19 Replay start rcvd                     0           0
  10/12/2015 12:41:19 Replay end rcvd                       0           0

MA: atm_ma       inited:0, flags:0x 0, circuits:0
MA: hdlc_ma      inited:0, flags:0x 0, circuits:0
MA: fr_ma        inited:0, flags:0x 0, circuits:0
MA: ppp_ma       inited:0, flags:0x 0, circuits:0
MA: cem_ma       inited:0, flags:0x 0, circuits:0
MA: vif_ma       inited:0, flags:0x 0, circuits:0
MA: pwhe_ma      inited:0, flags:0x 0, circuits:0
MA: nve_mgr      inited:0, flags:0x 0, circuits:0
MA: mstp         inited:0, flags:0x 0, circuits:0
MA: span         inited:0, flags:0x 0, circuits:0
MA: erp          inited:0, flags:0x 0, circuits:0
MA: erp_test     inited:0, flags:0x 0, circuits:0

```

```
MA: mstp_test    initd:0, flags:0x 0, circuits:0
MA: evpn        initd:0, flags:0x 0, circuits:0
```

**Related Commands**

Command	Description
<a href="#">l2vpn, on page 30</a>	Enters L2VPN configuration mode.
<a href="#">show l2vpn, on page 36</a>	Displays L2VPN information

## show l2vpn forwarding

To display forwarding information from the layer2\_fib manager, use the **show l2vpn forwarding** command in EXEC mode.

**show l2vpn forwarding** {**counter** | **debug** | **detail** | **hardware** | **interface** | **location** [*node-id*] | **private**}

Syntax Description		
<b>counter</b>		Displays the cross-connect counters.
<b>debug</b>		Displays debug information.
<b>detail</b>		Displays detailed information from the layer2_fib manager.
<b>hardware</b>		Displays hardware-related layer2_fib manager information.
<b>interface</b>		Displays the match AC subinterface.
<b>location</b> <i>node-id</i>		Displays layer2_fib manager information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>private</b>		Output includes private information.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	l2vpn	read

### Examples

The following sample output is from the **show l2vpn forwarding** command:

```
Router# show l2vpn forwarding location 0/RP0/CPU0
Mon Oct 12 14:19:11.771 UTC
Segment 1                               Segment 2                               State
-----
Hu0/0/0/0.234                           ac Hu0/0/0/26.234                       UP
Hu0/0/0/0.233                           ac Hu0/0/0/26.233                       UP
Hu0/0/0/0.232                           ac Hu0/0/0/26.232                       UP
Hu0/0/0/0.231                           ac Hu0/0/0/26.231                       UP
Hu0/0/0/0.230                           ac Hu0/0/0/26.230                       UP
```

The following sample output is from the **show l2vpn forwarding counter location** command:

```
Router# show l2vpn forwarding counter location 0/RP0/CPU0

Mon Oct 12 14:18:01.194 UTC
Legend: ST = State, DN = Down

Segment 1                               Segment 2                               ST Byte
-----                               -----                               -
Hu0/0/0/0.234                           ac Hu0/0/0/26.234                       UP 15098997504
Hu0/0/0/0.233                           ac Hu0/0/0/26.233                       UP 15098997568
Hu0/0/0/0.232                           ac Hu0/0/0/26.232                       UP 15098997504
Hu0/0/0/0.231                           ac Hu0/0/0/26.231                       UP 15098997568
HU0/0/0/0.230                           ac Hu0/0/0/26.230                       UP 15098997568
```

The following sample output is from the **show l2vpn forwarding summary location** command:

```
Router# show l2vpn forwarding summary location 0/RP0/CPU0
Thu Oct 22 06:14:17.767 UTC
To Resynchronize MAC table from the Network Processors, use the command...
    l2vpn resynchronize forwarding mac-address-table location <r/s/i>

Major version num:721, minor version num:2
Shared memory timestamp:0x19c9b0f580
Global configuration:
Number of forwarding xconnect entries:0
  Up:0  Down:0
  AC-PW(atom):0 AC-PW(iid):0 AC-PW(l2tpv2):0 AC-PW(l2tpv3):0
  AC-PW(l2tpv3-ipv6):0
  AC-AC:0 AC-BP:0 (PWHE AC-BP:0) AC-Unknown:0
  PW-BP:0 PW-Unknown:0
  PBB-BP:0 PBB-Unknown:0
  EVPN-BP:0 EVPN-Unknown:0
  VNI-BP:0 VNI-Unknown:0
  Monitor-Session-PW:0 Monitor-Session-Unknown:0
Number of xconnects down due to:
  AIB:0 L2VPN:0 L3FIB:0 VPDN:0
Number of xconnect updates dropped due to:
  Invalid XID: 0 VPWS PW, 0 VPLS PW, 0 Virtual-AC, 0 PBB,
  0 EVPN
  0 VNI
  0 Global
  Exceeded max allowed: 0 VPLS PW, 0 Bundle-AC
Number of p2p xconnects: 0
Number of bridge-port xconnects: 0
Number of nexthops:0
Number of bridge-domains: 0
  0 with routed interface
  0 with PBB-EVPN enabled
  0 with EVPN enabled
  0 with p2mp enabled
Number of bridge-domain updates dropped: 0
Number of total macs: 0
  0 Static macs
  0 Routed macs
  0 BMAC
  0 Source BMAC
  0 Locally learned macs
  0 Remotely learned macs
Number of total ipmacs: 0
  0 Locally learned ip4macs
  0 Remotely learned ip4macs
```

## show l2vpn forwarding

```

0 Locally learned ip6macs
0 Remotely learned ip6macs
Number of total P2MP Ptree entries: 0
Number of PWHE Main-port entries: 0
Number of EVPN Multicast Replication lists: 0 (0 default, 0 stitching, 0 isid)

```

The following sample output is from the **show l2vpn forwarding detail location** command:

```

Router# show l2vpn forwarding detail location 0/RP0/CPU0

Mon Oct 12 14:18:47.187 UTC
Local interface: HundredGigE 0/0/0/24, Xconnect id: 0x1, Status: up
  Segment 1
    AC, HundredGigE 0/0/0/24, status: Bound
    Statistics:
      packets: received 238878391, sent 313445
      bytes: received 15288217024, sent 20060480
      packets dropped: PLU 0, tail 0
      bytes dropped: PLU 0, tail 0
  Segment 2
    AC, HundredGigE 0/0/0/24, status: Bound

Local interface: HundredGigE 0/0/0/25, Xconnect id: 0x2, Status: up
  Segment 1
    AC, HundredGigE 0/0/0/25, status: Bound
    Statistics:
      packets: received 238878392, sent 313616
      bytes: received 15288217088, sent 20071424
      packets dropped: PLU 0, tail 0
      bytes dropped: PLU 0, tail 0
  Segment 2
    AC, HundredGigE 0/0/0/25, status: Bound

Local interface: HundredGigE 0/0/0/24, Xconnect id: 0x3, Status: up
  Segment 1
    AC, HundredGigE 0/0/0/24, status: Bound
    Statistics:
      packets: received 238878391, sent 313476
      bytes: received 15288217024, sent 20062464
      packets dropped: PLU 0, tail 0
      bytes dropped: PLU 0, tail 0
  Segment 2
    AC, HundredGigE 0/0/0/24, status: Bound

```

## Related Commands

Command	Description
<a href="#">l2vpn, on page 30</a>	Enters L2VPN configuration mode.
<a href="#">show l2vpn, on page 36</a>	Displays L2VPN information
<a href="#">show l2vpn database, on page 41</a>	Displays L2VPN database

# show l2vpn protection main-interface

To display an overview of the main interface or instance operational information, use the **show l2vpn protection main-interface** command in EXEC mode.

```
show l2vpn protection main-interface [ interface name { Interface } ] [ brief | detail | private ]
```

Syntax Description		
	<i>interface name</i>	Interface name of the Ethernet ring G.8032 name.
	<i>interface</i>	The forwarding interface ID in number or in Rack/Slot/Instance/Port format as required.
	<b>brief</b>	Brief information about the G.8032 ethernet ring configuration.
	<b>detail</b>	Information in detail about the G.8032 ethernet ring configuration.
	<b>private</b>	Private information about the G.8032 ethernet ring configuration.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 7.2.12	This command was introduced.
	Release 7.7.1	The command output was enhanced to include protection access gateway subtype indication MST-AG.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read

## Example

This example shows the output from the **show l2vpn protection main-interface** command:

```
RP/0/0/CPU0:router# show l2vpn protection main-interface

Main Interface ID          Subintf Count Protected Blocked
-----
GigabitEthernet0/0/0/0    1                None      No
```

## show l2vpn protection main-interface

```

Instance : 0
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 0
  Sub-interfaces : GigabitEthernet0/0/0/0.4

```

Main Interface ID	Subintf Count	Protected	Blocked
GigabitEthernet0/0/0/1	1	None	No

```

Instance : 0
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 0
  Sub-interfaces : GigabitEthernet0/0/0/0.4

```

```

RP/0/0/CPU0:ios#show l2vpn protection main-interface gigabitEthernet 0/0/0/1
Tue Mar 15 10:54:13.366 EDT

```

Main Interface ID	# of subIntf	Protected	Protect Type
GigabitEthernet0/0/0/1	2	Yes	MST-AG

```

Instance : 0
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 1

```

```

Instance : 1
  State      : BLOCKED
  Sub-Intf # : 1
  Flush #    : 0

```

```

RP/0/0/CPU0:ios#show l2vpn protection main-interface gigabitEthernet 0/0/0/2
Tue Mar 15 10:54:15.044 EDT

```

Main Interface ID	# of subIntf	Protected	Protect Type
GigabitEthernet0/0/0/2	2	Yes	STP

```

Instance : 0
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 0

```

```

Instance : 1
  State      : FORWARDING
  Sub-Intf # : 1
  Flush #    : 0

```

```

RP/0/0/CPU0:router# show l2vpn protection main-interface brief

```

Main Interface ID	Ref Count	Instance	Protected	State
GigabitEthernet0/0/0/0	3	2	No	FORWARDING
GigabitEthernet0/0/0/1	1	1	No	FORWARDING

```

RP/0/RSP0/CPU0:router# show l2vpn protection main-interface detail

```

Main Interface ID	# of subIntf	Protected
GigabitEthernet0/1/0/19	4	No

Main Interface ID	# of subIntf	Protected
-------------------	--------------	-----------



```

GigabitEthernet0/1/0/20      3          No

Main Interface ID           # of subIntf Protected
-----
GigabitEthernet0/1/0/3      2          No

Main Interface ID           # of subIntf Protected
-----
GigabitEthernet0/1/0/30     1          No

Main Interface ID           # of subIntf Protected
-----
GigabitEthernet0/1/0/7      4          No

```

RP/0/0/CPU0:router# show l2vpn protection main-interface private

```

Main Interface ID           Ref Count   Protected   Blocked     If Handle   Registered
-----
GigabitEthernet0/0/0/0     3          None        No          0x20000020 No

```

Instance : 0

```

State      : FORWARDING      Config ID : 0
Sub-Intf # : 0              Ack      # : 0
Bridge D # : 0              N-Ack   # : 0
Flush #    : 0              Rcv     # : 0
Sub-interfaces : GigabitEthernet0/0/0/0.4

```

Instance event trace history [Total events: 1, Max listed: 8]

```

Time          Event                      State          Action
====          =====
01/01/1970 01:00:01 Rcv state IF known      Invalid        134833160
07/02/2010 10:13:03 Update L2FIB            FORWARDING     0
01/01/1970 01:00:25 Rcvd AC MA create + UP I/F ST FORWARDING     0

```

## Related Commands

Command	Description
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

# show l2vpn resource

To display the memory state in the L2VPN process, use the **show l2vpn resource** command in EXEC mode.

**show l2vpn resource**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	l2vpn	read

## Examples

The following example shows a sample output for the **show l2vpn resource** command:

```
Router# show l2vpn resource
Wed Oct 14 11:27:23.447 UTC
Memory: Normal
```

This table describes the significant fields shown in the display.

**Table 2: show l2vpn resource Command Field Descriptions**

Field	Description
Memory	Displays memory status.

Related Commands	Command	Description
	<a href="#">l2vpn</a> , on page 30	Enters L2VPN configuration mode.
	<a href="#">show l2vpn</a> , on page 36	Displays L2VPN information

## show l2vpn trace

To display trace data for L2VPN, use the **show l2vpn trace** command in EXEC mode.

```
show l2vpn trace [checker] |[file filename filepath] |[last entry] |[location node-id]
|[udir path] [reverse] |[stats] |[tailf] |[usec] |[verbose] |[wide]
```

Syntax	Description
<b>checker</b>	Displays trace data for the L2VPN Uberverifier.
<b>file filename filepath</b>	Displays trace data for the specified file.
<b>hexdump</b>	Display traces data in hexadecimal format.
<b>last entry</b>	Display last <n> entries
<b>location node-id</b>	Displays trace data for the specified location.
<b>reverse</b>	Display latest traces first
<b>stats</b>	Display trace statistics
<b>tailf</b>	Display new traces as they are added
<b>unique</b>	Display unique entries with counts
<b>usec</b>	Display usec details with timestamp
<b>udir path</b>	Display a temporary directory to copy traces from remote locations
<b>verbose</b>	Display internal debugging information
<b>wide</b>	Display trace data excluding buffer name, node name, tid
<b>wrapping</b>	Display wrapping entries

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	l2vpn	read

This example displays output for the **show l2vpn trace** command:

```
Router# show l2vpn trace
Mon Oct 12 14:22:09.082 UTC
188 unique entries (2596 possible, 0 filtered)
Oct 12 12:37:44.197 l2vpn/policy 0/RP0/CPU0 1# t4349 POLICY:320: l2vpn_policy_reg_agent
started - route_policy_supported=False, forward_class_supported=False
Oct 12 12:39:21.870 l2vpn/fwd-pd 0/RP0/CPU0 1# t5664 FWD_PD:731:
Oct 12 12:39:21.883 l2vpn/fwd-err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:76: Major version mis-match,
SHM: 0x0 Expected: 0x1
Oct 12 12:39:21.883 l2vpn/fwd-err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:87: Magic number mis-match,
SHM: 0x0 Expected: 0xa7b6c3d8
Oct 12 12:39:21.884 l2vpn/err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:76: Major version mis-match,
SHM: 0x0 Expected: 0x1
Oct 12 12:39:21.884 l2vpn/err 0/RP0/CPU0 1# t5664 FWD_ERR|ERR:87: Magic number mis-match,
SHM: 0x0 Expected: 0xa7b6c3d8
Oct 12 12:39:21.890 l2vpn/fwd-detail 0/RP0/CPU0 1# t5664 FWD_DETAIL:263: PWGROUP Table init
succeeded
Oct 12 12:39:21.890 l2vpn/fwd-detail 0/RP0/CPU0 2# t5664 FWD_DETAIL:416: l2tp session table
rebuilt
Oct 12 12:39:21.903 l2vpn/fwd-common 0/RP0/CPU0 1# t5664 FWD_COMMON:39: L2FIB_OBJ_TRACE:
trace_buf=0x7d48e0
Oct 12 12:39:25.613 l2vpn/issu 0/RP0/CPU0 1# t5664 ISSU:790: ISSU - iMDR init called;
'infra/imdr' detected the 'informational' condition 'the service is not supported in the
node'
Oct 12 12:39:25.613 l2vpn/issu 0/RP0/CPU0 1# t5664 ISSU:430: ISSU - attempt to start
COLLABORATOR wait timer while not in ISSU mode
Oct 12 12:39:25.638 l2vpn/fwd-common 0/RP0/CPU0 1# t5664 FWD_COMMON:4241: show edm thread
initialized
Oct 12 12:39:25.781 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC|ERR:783: Mac aging init
Oct 12 12:39:25.781 l2vpn/fwd-mac 0/RP0/CPU0 2# t5664 FWD_MAC:1954: l2vpn_gsp_cons_init
returned Success
Oct 12 12:39:25.781 l2vpn/err 0/RP0/CPU0 1# t5664 FWD_MAC|ERR:783: Mac aging init
Oct 12 12:39:25.782 l2vpn/fwd-aib 0/RP0/CPU0 4# t5664 FWD_AIB:446: aib connection opened
successfully
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 2# t5664 FWD_MAC:2004: Client successfully
joined gsp group
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC:781: Initializing the txlist
IPC thread
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC:3195: gsp_optimal_msg_size =
31264 (real: True)
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t5664 FWD_MAC:626: Entering mac aging timer
init
Oct 12 12:39:25.783 l2vpn/fwd-mac 0/RP0/CPU0 1# t7519 FWD_MAC:725: Entering event loop for
mac txlist thread
Oct 12 12:39:25.797 l2vpn/fwd-mac 0/RP0/CPU0 1# t4222 FWD_MAC:2221: learning_client_colocated
0, is_client_netio 1
```

## Related Commands

Command	Description
<a href="#">l2vpn, on page 30</a>	Enters L2VPN configuration mode.
<a href="#">show l2vpn, on page 36</a>	Displays L2VPN information
<a href="#">show l2vpn resource, on page 50</a>	Displays the memory state in the L2VPN process.

## split-horizon group

To add an AC to a split horizon group, use the **split-horizon group** command in L2VPN bridge group bridge domain attachment circuit configuration mode.

### **split-horizon group**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	L2VPN bridge group bridge domain attachment circuit configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.11.1	This command was introduced.

**Usage Guidelines** Only one split horizon group exists for ACs per bridge domain. By default, the group does not have any ACs. You can configure individual ACs to become members of the group using the **split-horizon group** configuration command.

You can configure an entire physical interface or EFPs within an interface to become members of the split horizon group.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	Read, write

### Examples

The following example shows the split horizon group configuration:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group bg
Router(config-l2vpn-bg)# bridge-domain bd
Router(config-l2vpn-bg-bd-ac)# interface Ten0/7/0/22/0 <- (split-horizon group 0, default)
Router(config-l2vpn-bg-bd-ac)# interface Ten0/7/0/22/1.1
Router(config-l2vpn-bg-bd-ac)# split-horizon group <- (split-horizon group 2)
Router(config-l2vpn-bg-bd-ac)# neighbor 10.0.0.1 pw-id 1
Router(config-l2vpn-bg-bd-pw)# split-horizon group <- (split-horizon group 2)
Router(config-l2vpn-bg-bd-pw)# vfi vf
Router(config-l2vpn-bg-bd-vfi)# neighbor 172.16.0.1 pw-id 10001 <- (split-horizon group 1, default)
Router(config-l2vpn-bg-bd-vfi-pw)# commit
```

# storm-control

To enable storm control on an access circuit (AC) under a VPLS bridge, use the **storm-control** command in l2vpn bridge group bridge-domain access circuit configuration mode. To disable storm control, use the **no** form of this command.

```
storm-control { broadcast | multicast | unknown-unicast } { pps pps-value | kbps kbps-value }
no storm-control { broadcast | multicast | unknown-unicast } { pps pps-value | kbps kbps-value }
```

## Syntax Description

**broadcast** Configures storm control for broadcast traffic.

**multicast** Configures storm control for multicast traffic.

**unknown-unicast** Configures storm control for unknown unicast traffic.

- Storm control does not apply to bridge protocol data unit (BPDU) packets. All BPDU packets are processed as if traffic storm control is not configured.
- Storm control does not apply to internal communication and control packets, route updates, SNMP management traffic, Telnet sessions, or any other packets addressed to the router.

**pps pps-value** Configures the packets-per-second (pps) storm control threshold for the specified traffic type. Valid values range from 1 to 160000.

**kbps kbps-value** Configures the storm control in kilo bits per second (kbps). The range is from 64 to 1280000.

## Command Default

Storm control is disabled by default.

## Command Modes

l2vpn bridge group bridge-domain access circuit configuration

## Command History

Release	Modification
Release 7.3.2	This command was introduced.

## Usage Guidelines

- Storm control is supported on main ports only.
- Storm control configuration is supported at the bridge-port level, and not at the bridge-domain level.
- PW-level storm control is not supported.
- Storm control is not supported through QoS input policy.
- Although pps is configurable, it is not natively supported. PPS configuration is converted to a kbps value assuming a 256 byte packet size when configuring the hardware policers.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example enables two storm control thresholds on an access circuit:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group BG1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain BD1
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# interface HundredGigE0/0/0/0
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)# storm-control broadcast kbps 4500
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)# commit
```

# vpws-seamless-integration

To enable EVPN-VPWS seamless integration, use the **vpws-seamless-integration** command in L2VPN configuration mode. To disable EVPN-VPWS seamless integration, use the **no** form of this command.

## vpws-seamless-integration

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** L2VPN configuration mode

Command History	Release	Modification
	Release 7.8.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	L2VPN	read, write

## Examples

The following example shows how to enable EVPN-VPWS integration on an edge device for BGP PW.

```
Router# configure
Router(config)# l2vpn xconnect group 1
Router(config-l2vpn-xc)# mp2mp 2
Router(config-l2vpn-xc-mp2mp)# autodiscovery bgp
Router(config-l2vpn-xc-mp2mp-ad)# signaling-protocol bgp
Router(config-l2vpn-xc-mp2mp-ad-sig)# ce-id 3
Router(config-l2vpn-xc-mp2mp-ad-sig-ce)# vpws-seamless-integration
```

The following example shows how to enable EVPN-VPWS integration for TLDP PW.

```
Router# configure
Router(config)# l2vpn xconnect group 1
Router(config-l2vpn-xc)# p2p p1
Router(config-l2vpn-xc-p2p)# interface BE1.1
Router(config-l2vpn-xc-p2p)# neighbor 1.1.1.1 pw-id 1
Router(config-l2vpn-xc-p2p-pw)# exit
Router(config-l2vpn-xc-p2p)# vpws-seamless-integration
```





## Multiple Spanning Tree Protocol Commands

---

This module describes the commands used to configure multiple spanning tree protocol. For detailed information about MSTP concepts, configuration tasks, and examples, see the *L2VPN and Ethernet Services Configuration Guide for Cisco 8000 Series Routers*.

- [allow-legacy-bpdu](#), on page 58
- [instance \(MSTP\)](#), on page 59
- [interface \(MSTP\)](#), on page 60
- [name \(MSTP\)](#), on page 61
- [portfast](#), on page 62
- [show spanning-tree mst](#), on page 63
- [spanning-tree mst](#), on page 65
- [vlan-id \(MSTP\)](#), on page 66

## allow-legacy-bpdu

To enable MSTP to accept legacy TCN notifications and allow it to prompt a flush rather than putting the interface into an error-disabled state, use the **allow-legacy-bpdu** command in the MSTP interface configuration submode.

### allow-legacy-bpdu

**Syntax Description** This command has no keywords or arguments.

**Command Default** allow-legacy-bpdu is disabled.

**Command Modes** MSTP interface configuration

Command History	Release	Modification
	Release 7.1.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	ethernet-services	read, write

### Examples

The following example shows how to enable **allow-legacy-bpdu** command:

```
Router# config
Router(config)# spanning-tree MST test
Router(config-mstp)# allow-legacy-bpdu
```

# instance (MSTP)

To enter the multiple spanning tree instance (MSTI) configuration submode, use the **instance** command in MSTP configuration submode.

**instance** *id*

<b>Syntax Description</b>	<i>id</i> MSTI ID. Range is 0 to 4094.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	MSTP configuration
----------------------	--------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.2.12	This command was introduced.

## Usage Guidelines



**Note** An instance ID of 0 represents the CIST for the region.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	<b>interface</b>	read, write

## Examples

The following example shows how to enter the MSTI configuration submode:

```
Router# configure
Router(config)#spanning-tree mst a
Router(config-mstp)# instance 101
Router(config-mstp-inst)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show spanning-tree mst, on page 63</a>	Displays the multiple spanning tree protocol status information.
	<a href="#">spanning-tree mst, on page 65</a>	Enters the MSTP configuration submode
	<a href="#">vlan-id (MSTP), on page 66</a>	Associates a set of VLAN IDs with the current MSTI.

# interface (MSTP)

To enter the MSTP interface configuration submode, and to enable STP for the specified port, use the **interface** command in MSTP configuration submode.

**interface interface-type interface-path-id**

<b>Syntax Description</b>	<b>interface</b> Interface type. For more information, use the question mark (?) online help function.
	<b>interface-path-id</b> Physical interface.  Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.

**Command Default** None

**Command Modes** MSTP configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.2.12	This command was introduced.

**Usage Guidelines** A given port may only be enabled with one of MSTP, MSTAG, REPAG, PVSTAG or PVRSTAG.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	interface	read, write

## Examples

The following example shows how to enter the MSTP interface configuration submode:

```
Router# configure
Router(config)# spanning-tree mst M0
Router(config-mstp)# interface hundredGigE 0/0/0/1
Router(config-mstp-if)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show spanning-tree mst, on page 63</a>	Displays the multiple spanning tree protocol status information.
	<a href="#">spanning-tree mst, on page 65</a>	Enters the MSTP configuration submode

## name (MSTP)

To set the name of the MSTP region, use the **name** command in MSTP configuration submode.

**name** *name*

### Syntax Description

*name* Specifies the name of the mstp region.

String of a maximum of 32 characters conforming to the definition of SnmpAdminString in RFC 2271.

### Command Default

The MAC address of the switch, formatted as a text string using the hexadecimal representation specified in IEEE Std 802.

### Command Modes

MSTP configuration

### Command History

Release	Modification
Release 7.2.12	This command was introduced.

### Task ID

Task ID	Operations
interface	read, write

### Examples

The following example shows how to set the name of the MSTP region to m1:

```
Router# configure
RP/0/RP0/CPU0:ios(config)#spanning-tree mst M0
Router(config-mstp)# name m1
```

### Related Commands

Command	Description
<a href="#">show spanning-tree mst, on page 63</a>	Displays the multiple spanning tree protocol status information.
<a href="#">spanning-tree mst, on page 65</a>	Enters the MSTP configuration submode

# portfast

To enable Port Fast on the port, and optionally enable BPDU guard, use the **portfast** command in MSTP interface configuration submenu.

**portfast** [**bpduguard**]

**Syntax Description** This command has no keywords or arguments.

**Command Default** PortFast is disabled.

**Command Modes** MSTP interface configuration

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** You must disable and re-enable the port for Port Fast configuration to take effect. Use **shutdown** and **no shutdown** command (in interface configuration mode) to disable and re-enable the port.

This command enables the Port Fast feature (also known as edge port). When this is enabled, MSTP treats the port as an edge port, i.e., it keeps it in forwarding state and does not generate topology changes if the port goes down or comes up. It is not expected to receive MSTP BPDUs on an edge port. BPDU guard is a Cisco extension that causes the interface to be shut down using error-disable if an MSTP BPDU is received. For more information on Port Fast feature, refer to the *Multiple Spanning Tree Protocol* module in the *L2VPN and Ethernet Services Configuration Guide for Cisco 8000 Series Routers*

Task ID	Task ID	Operations
	interface	read, write

## Examples

The following example shows how to enable PortFast and BPDU guard on the port:

```
Router# configure
Router(config)# spanning-tree mst a
Router(config-mstp)# interface HundredGigE0/0/0/2
Router(config-mstp-if)# portfast
Router(config-mstp-if)# portfast bpduguard
```

Related Commands	Command	Description
	<a href="#">interface (MSTP), on page 60</a>	Enters the MSTP interface configuration submenu, and enables STP for the specified port.
	<a href="#">show spanning-tree mst, on page 63</a>	Displays the multiple spanning tree protocol status information.
	<a href="#">spanning-tree mst, on page 65</a>	Enters the MSTP configuration submenu

# show spanning-tree mst

To display the multiple spanning tree protocol status information, use the **show spanning-tree mst** command in EXEC mode.

**show spanning-tree mst** *protocol instance identifier* [**instance** *instance-id*] [**blocked-ports** | **brief**]

Syntax Description	
<i>protocol instance identifier</i>	String of a maximum of 25 characters that identifies the protocol instance.
<b>instance</b> <i>instance-id</i>	Forward interface in rack/slot/instance/port format.
<b>brief</b>	Displays a summary of MST information only.
<b>blocked-ports</b>	Displays MST information for blocked ports only.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Task ID	Task ID	Operations
	interface	read

## Examples

The following example shows the output from the **show spanning-tree mst** command, which produces an overview of the spanning tree protocol state:

```
Router# show spanning-tree mst a instance 0
Operating in Provider Bridge mode
MSTI 0 (CIST):

  VLANs Mapped: 1-100, 500-1000, 1017

  Root ID      Priority    4097
  Address      0004.9b78.0800
  This bridge is the root
  Hello Time   2 sec    Max Age 20 sec    Forward Delay 15 sec

  Bridge ID    Priority    4097    (priority 4096 sys-id-ext 1)
  Address      0004.9b78.0800
  Hello Time   2 sec    Max Age 20 sec    Forward Delay 15 sec

Interface      Port ID          Designated          Port ID
Name           Prio.Nbr Cost   Role State   Cost Bridge ID      Prio.Nbr
```

## show spanning-tree mst

```

-----
HundredGigEthernet0/0/0/1 128.65 20000 DSGN FWD 0 4097 0004.9b78.0800 128.65
HundredGigEthernet0/0/0/2 128.66 20000 DSGN FWD 0 4097 0004.9b78.0800 128.66
...

```

The following example shows the output from the **show spanning-tree mst** command when the **brief** and **blocked-ports** keywords are used:

```

Router# show spanning-tree mst a brief
MSTI 0 (CIST):
  VLAN IDs: 1-100, 500-1000, 1017
  This is the Root Bridge
MSTI 1:
  VLAN IDS: 101-499
  Root Port HundredGigEthernet0/0/0/2 , Root Bridge ID 0002.9b78.0812
...
Router# show spanning-tree mst blocked-ports
MSTI 0 (CIST):

Interface          Port ID          Designated          Port ID
Name               Prio.Nbr Cost   Role State   Cost Bridge ID      Prio.Nbr
-----
HundredGigEthernet0/0/0/4 128.196 200000 ALT BLK 0 4097 0004.9b78.0800 128.195
...

```

## Related Commands

Command	Description
<a href="#">spanning-tree mst, on page 65</a>	Enters the MSTP configuration submenu



# spanning-tree mst

To enter the MSTP configuration submode, use the **spanning-tree mst** command in global configuration mode.

**spanning-tree mst** *protocol instance identifier*

<b>Syntax Description</b>	<i>protocol instance identifier</i> String of a maximum of 25 characters that identifies the protocol instance.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.2.12	This command was introduced.

## Usage Guidelines



**Note** In MSTP configuration, only one protocol instance can be configured at a time.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	interface	read, write

## Examples

The following example shows how to enter the MSTP configuration submode:

```
Router(config)# spanning-tree mst a
Router(config-mst)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">instance (MSTP), on page 59</a>	Enters the multiple spanning tree instance (MSTI) configuration submode.
	<a href="#">interface (MSTP), on page 60</a>	Enters the MSTP interface configuration submode, and enables STP for the specified port.
	<a href="#">show spanning-tree mst, on page 63</a>	Displays the multiple spanning tree protocol status information.

## vlan-id (MSTP)

To associate a set of VLAN IDs with the current MSTI, use the **vlan-id** command in MSTI configuration submode.

```
vlan-id vlan-range [vlan-range] [vlan-range] [vlan-range]
```

<b>Syntax Description</b>	<i>vlan-range</i> List of VLAN ranges in the form a-b, c, d, e-f, g etc.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	MSTI configuration
----------------------	--------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.2.12	This command was introduced.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	interface	read, write

**Examples** The following example shows how to use the vlan-id command:

```
Router(config-mstp-inst)# vlan-id 2-1005
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">instance (MSTP), on page 59</a>	Enters the multiple spanning tree instance (MSTI) configuration submode.
	<a href="#">spanning-tree mst, on page 65</a>	Enters the MSTP configuration submode
	<a href="#">show spanning-tree mst, on page 63</a>	Displays the multiple spanning tree protocol status information.



## Integrated Routing and Bridging Commands

---

This module describes the commands to configure Integrated Routing and Bridging (IRB) on the Cisco 8000 Series Routers.

- [interface bvi](#) , on page 68
- [routed interface bvi](#) , on page 70
- [show interfaces bvi](#), on page 71

# interface bvi

To create a bridge-group virtual interface (BVI), use the **interface bvi** command in Global Configuration mode. To delete the BVI, use the **no** form of this command.

**interface bvi** *identifier*

<b>Syntax Description</b>	<i>identifier</i> Number for the BVI interface from 1 to 4294967295.
---------------------------	--

<b>Command Default</b>	No BVI interface is configured.
------------------------	---------------------------------

<b>Command Modes</b>	Global Configuration mode
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.2.12	This command was introduced.

<b>Usage Guidelines</b>	<p>The BVI is a virtual interface within the router that acts like a normal routed interface. The BVI does not support bridging itself, but acts as a gateway for the corresponding bridge-domain to a routed interface within the router.</p> <p>Aside from supporting a configurable MAC address, a BVI supports only Layer 3 attributes, and has the following characteristics:</p> <ul style="list-style-type: none"> <li>• Uses a MAC address taken from the local chassis MAC address pool, unless overridden at the BVI interface.</li> <li>• Is configured as an interface type using the <b>interface bvi</b> command and uses an IPv4 or IPv6 address that is in the same subnet as the hosts on the segments of the bridged domain. The BVI also supports secondary addresses.</li> <li>• The BVI identifier is independent of the bridge-domain identifier. These identifiers do not need to correlate like they do in Cisco IOS software.</li> <li>• Is associated to a bridge group using the <b>routed interface bvi</b> command.</li> <li>• The following interface commands are supported on a BVI: <ul style="list-style-type: none"> <li>• <b>arp purge-delay</b></li> <li>• <b>arp timeout</b></li> <li>• <b>bandwidth</b> (The default is 10 Gbps and is used as the cost metric for routing protocols for the BVI.)</li> <li>• <b>ipv4</b></li> <li>• <b>ipv6</b></li> <li>• <b>mac-address</b></li> <li>• <b>mtu</b> (The default is 1514 bytes.)</li> <li>• <b>shutdown</b></li> </ul> </li> </ul>
-------------------------	--

- The BVI supports IP helper addressing and secondary IP addressing.

To display bridge group, bridge-domain, interface status, line protocol state, and packet counters for the specified BVI, use the **show l2vpn bridge domain interface bvi** form of the **show l2vpn bridge domain (VPLS)** command. To display the reason that a BVI is down, you can use the **detail** keyword option.

Task ID	Operations
	interface read, write

### Examples

The following example shows how to create a BVI interface and configure its IPv4 address:

```
Router# configure
Router(config)# interface bvi 50
Router(config-if)# ipv4 address 10.10.0.4 255.255.255.0
Router(config-if)# commit
```

Related Commands	Command	Description
	<a href="#">routed interface bvi</a> , on page 70	
	<a href="#">show interfaces bvi</a> , on page 71	

## routed interface bvi

To associate the specified bridge group virtual interface (BVI) as the routed interface for the interfaces assigned to the bridge domain, use the **routed interface bvi** command in L2VPN bridge group bridge domain configuration mode. To remove the BVI as the routed interface for the interfaces assigned to the bridge domain, use the **no** form of this command.

**routed interface bvi** *identifier*

Syntax Description	
	<i>identifier</i> Number for the BVI interface from 1 to 65535.

Command Default	
	No routed interface is configured.

Command Modes	
	L2VPN bridge group bridge domain configuration mode (config-l2vpn-bg-bd)

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines	
	<ul style="list-style-type: none"> <li>• Only one BVI can be configured in any bridge domain.</li> <li>• The same BVI can not be configured in multiple bridge domains.</li> </ul>

Task ID	Task ID	Operation
	l2vpn	read, write

The following example shows association of a BVI interface numbered “50” on the bridge domain named “IRB”:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group 10
Router(config-l2vpn-bg)# bridge-domain IRB
Router(config-l2vpn-bg-bd)# routed interface bvi 50
Router(config-l2vpn-bg-bd-bvi)# commit
```

Related Commands	Command	Description
	<a href="#">interface bvi</a> , on page 68	
	<a href="#">show interfaces bvi</a> , on page 71	

# show interfaces bvi

To display interface status, line protocol state, and packet counters for the specified BVI, use the **show interfaces bvi** command in XR EXEC mode.

**show interfaces bvi** *identifier* [ **accounting** | **brief** | **description** | **detail** | **location** *location* ]

Syntax Description		
	<i>identifier</i>	Number for the BVI interface from 1 to 4294967295.
	<b>accounting</b>	(Optional) Displays the number of packets of each protocol type that have been sent through the interface.
	<b>brief</b>	(Optional) Displays summary information about the interface.
	<b>description</b>	(Optional) Displays summary status information and the description for the interface.
	<b>detail</b>	(Optional) Displays detailed information about the interface. This is the default.
	<b>location</b> <i>location</i>	(Optional) Displays information the interface on the specified node. The <i>location</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** Detailed information about the BVI interface is displayed.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	interface	read

The following example shows sample output for the **show interfaces bvi** command:

```
Router# show interfaces bvi 50
Mon Oct 19 07:22:55.233 UTC
BVI50 is down, line protocol is down
  Interface state transitions: 0
  Hardware is Bridge-Group Virtual Interface, address is
  Internet address is 10.10.0.4/24
  MTU 1514 bytes, BW 10000000 Kbit (Max: 10000000 Kbit)
    reliability 255/255, txload 0/255, rxload 0/255
  Encapsulation ARPA, loopback not set,
  ARP type ARPA, ARP timeout 04:00:00
  Last input never, output never
  Last clearing of "show interface" counters never
  5 minute input rate 0 bits/sec, 0 packets/sec
```

```

5 minute output rate 0 bits/sec, 0 packets/sec
 0 packets input, 0 bytes, 0 total input drops
 0 drops for unrecognized upper-level protocol
Received 0 broadcast packets, 0 multicast packets
 0 packets output, 0 bytes, 0 total output drops
Output 0 broadcast packets, 0 multicast packets

```

Table 3: show interfaces bvi Field Descriptions

Field	Description
BVIx is	Displays the state of the specified BVI interface, where <i>x</i> is the number of the interface. The possible values are: administratively down, down, or up.
line protocol is	Displays the state of the line protocol for the BVI interface. The possible values are: administratively down, down, or up.  <b>Note</b> The line protocol state is not the same as the protocol state displayed in the <b>show ip interfaces</b> command, because it is the state of Layer 2 (media) rather than Layer 3 (IP protocol).
Interface state transitions:	Displays the number of times the interface has changed states.
Hardware is	Displays Bridge-Group Virtual Interface for a BVI.
address is	Layer 2 MAC address of the BVI.
Description:	Displays the description of the interface when configured.
Internet address is <i>n.n.n.n/n</i>	Layer 3 IP address of the BVI in dotted decimal format.
MTU	Displays the maximum transmission unit (MTU) for the interface. The MTU is the maximum packet size that can be transmitted over the interface.  1514 is the default.
BW <i>x</i> Kbit	Displays the current bandwidth of the interface in kilobits per second.
Max:	Displays the maximum bandwidth available on the interface in kilobits per second.
reliability	Displays the proportion of packets that are not dropped and do not have errors.  <b>Note</b> The reliability is shown as a fraction of 255.



Field	Description
txload	Indicates the traffic flowing out of the interface as a proportion of the bandwidth. <b>Note</b> The txload is shown as a fraction of 255.
rxload	Indicates the traffic flowing into the interface as a proportion of the bandwidth. <b>Note</b> The rxload is shown as a fraction of 255.
Encapsulation	Layer 2 encapsulation on the interface.
loopback	Always displays “not set” for a BVI because loopbacks are not supported.
ARP type	Address Resolution Protocol (ARP) type used on the interface.
ARP timeout	ARP timeout in the format hours:mins:secs. This value is configurable using the <b>arp timeout</b> command.
Last input	Number of hours, minutes, and seconds since the last packet was successfully received by an interface and processed locally on the router. Useful for knowing when a dead interface failed.
output	Number of hours, minutes, and seconds since the last packet was successfully transmitted by the interface. Useful for knowing when a dead interface failed.
Last clearing of “show interface” counters	Time since the counters in this command were last cleared using the <b>clear counters</b> Exec command in hours:mins:secs.

Field	Description
5 minute input rate	<p>Average number of bits and packets received per second in the last 5 minutes. If the interface is not in promiscuous mode, it senses network traffic that it sends and receives (rather than all network traffic).</p> <p><b>Note</b> The 5-minute period referenced in the command output is a load interval that is configurable under the interface. The default value is 5 minutes.</p> <p><b>Note</b> The 5-minute input should be used only as an approximation of traffic per second during a given 5-minute period. This rate is exponentially weighted average with a time constant of 5 minutes. A period of four time constants must pass before the average will be within two percent of the instantaneous rate of a uniform stream of traffic over that period.</p>
5 minute output rate	<p>Average number of bits and packets transmitted per second in the last 5 minutes. If the interface is not in promiscuous mode, it senses network traffic that it sends and receives (rather than all network traffic).</p> <p><b>Note</b> The 5-minute period referenced in the command output is a load interval that is configurable under the interface. The default value is 5 minutes.</p> <p><b>Note</b> The 5-minute output should be used only as an approximation of traffic per second during a given 5-minute period. This rate is exponentially weighted average with a time constant of 5 minutes. A period of four time constants must pass before the average will be within two percent of the instantaneous rate of a uniform stream of traffic over that period.</p>
packets input	Number of packets received on the interface that were successfully delivered to higher layers.
bytes	Number of bytes received on the interface.
total input drops	Total number of valid packets that were dropped after they were received. This includes packets that were dropped due to configured quality of service (QoS) or access control list (ACL) policies. This does not include drops due to unknown Layer 3 protocol.

Field	Description
drops for unrecognized upper-level protocol	Total number of packets that could not be delivered because the necessary protocol was not configured on the interface.
Received <i>x</i> broadcast packets	Total number of Layer 2 broadcast packets received on the interface. This is a subset of the total input packet count.
multicast packets	Total number of Layer 2 multicast packets received on the interface. This is a subset of the total input packet count.
packets output	Number of packets sent from the interface.
bytes	Total number of bytes successfully sent from the interface.
total output drops	Number of packets that were dropped before being transmitted.
Output <i>x</i> broadcast packets	Number of Layer 2 broadcast packets transmitted on the interface. This is a subset of the total output packet count.
multicast packets	Total number of Layer 2 multicast packets received on the interface. This is a subset of the total output packet count.

**Related Commands**

Command	Description
<a href="#">interface bvi</a> , on page 68	

show interfaces bvi



## Layer 2 Access List Commands

---

This section describes the commands used to configure Layer 2 access list.

For detailed information about concepts and configuration, see the *Configure Layer 2 Access Control Lists* chapter in the *L2VPN and Ethernet Services Configuration Guide for Cisco 8000 Series Routers*.

- [ethernet-services access-group, on page 78](#)
- [ethernet-services access-list, on page 79](#)
- [show access-lists ethernet-services, on page 80](#)
- [show access-lists ethernet-services usage pfilter , on page 82](#)

# ethernet-services access-group

To control access to an interface, use the **ethernet-service access-group** command in interface configuration mode.

**ethernet-services access-group** *access-list-name* **ingress**

Syntax Description	
<i>access-list-name</i>	Name of an Ethernet services access list as specified by the <b>ethernet-service access-list</b> command.
<b>ingress</b>	Filters on inbound packets.

**Command Default** The interface does not have an Ethernet services access list applied to it.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.5.3	This command was introduced.

**Usage Guidelines** The **ethernet-services access-group** command to control access to an interface. To remove the specified access group, use the **no** form of the command. Use the *access-list-name* argument to specify a particular Ethernet services access list. Use the **ingress** keyword to filter on inbound packets.

If the list permits the addresses, the software continues to process the packet. If the access list denies the address, the software discards the packet.

If the specified access list does not exist, all packets are passed.

By default, the unique or per-interface ACL statistics are disabled.

Task ID	Task ID	Operations
	acl	read, write

## Examples

The following example shows how to apply filters on inbound packets from an interface.

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/24
Router(config-if)# l2transport
Router(config-if)# ethernet-services access-group es_acl_1 ingress
Router(config-if)# commit
```

# ethernet-services access-list

To define an Ethernet services (Layer 2) access list by name, use the **ethernet-services access-list** command in global configuration mode.

**ethernet-services access-list** *access-list-name*

<b>Syntax Description</b>	<i>access-list-name</i> Name of the Ethernet services access list. The name cannot contain a spaces or quotation marks, but can include numbers.
---------------------------	--

<b>Command Default</b>	No Ethernet services access list is defined.
------------------------	--

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.5.3	This command was introduced.

<b>Usage Guidelines</b>	The <b>ethernet-services access-list</b> command places the router in access list configuration mode, in which the denied or permitted access conditions must be defined.
-------------------------	---

Layer 2 access control lists are supported only for the field's L2 source and destination address, EtherType, Outer VLAN ID, Inner VLAN ID, Class of Service (COS), and VLAN DEI.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	acl	read, write

## Examples

The following example shows how to configure ethernet-services access-list:

```
Router# configure
Router(config)# ethernet-services access-list es_acl_1
Router(config-es-acl)# 10 deny 00ff.eedd.0010 ff00.0000.00ff 0000.0100.0001 0000.0000.ffff
Router(config-es-acl)# 20 permit host 000a.000b.000c host 00aa.ab99.1122 cos 1 dei
Router(config-es-acl)# 30 deny host 000a.000b.000c host 00aa.dc11.ba99 cos 7 dei
Router(config-es-acl)# commit
Router(config)# interface HundredGigE 0/0/0/24
Router(config-if)# l2transport
Router(config-if)# ethernet-services access-group es_acl_1 ingress
Router(config-if)# commit
```

## show access-lists ethernet-services

To display the contents of current Ethernet services access lists, use the **show access-lists ethernet-services** command in EXEC mode.

```
show access-lists ethernet-services access-list-name [ hardware ] ingress [ detail ] [ location { location | all } ]
```

### Syntax Description

<i>access-list-name</i>	Name of a specific Ethernet services access list. The name cannot contain a spaces or quotation marks, but can include numbers.
<b>hardware</b>	(Optional) Display Ethernet services access list entries in hardware including the match count for a specific ACL in a particular direction across the line card.
<b>ingress</b>	Filters on inbound packets.
<b>detail</b>	(Optional) Display TCAM entries.
<b>location</b>	(Optional) Display information for a specific node number.
<i>location</i>	Fully qualified location specification.
<b>all</b>	Displays packet filtering usage for all interface cards.

### Command Default

The contents of all Ethernet services access lists are displayed.

### Command Modes

EXEC mode

### Command History

Release	Modification
Release 7.5.3	This command was introduced.

### Task ID

Task ID	Operations
acl	read, write

### Examples

The following example shows sample output for the **show access-lists ethernet-services** command:

```
Router# show access-lists ethernet-services es_acl_1 hardware ingress location 0/0/CPU0
Thu Nov  3 22:02:27.222 UTC
ethernet-services access-list es_acl_1
 10 deny any host fcd7.844c.7486 cos 3    (65334 matches)
 20 deny any host fcd7.844c.7486
 30 permit any any
```

```
Router# show access-lists ethernet-services es_acl_1 hardware ingress detail location
0/0/CPU0
```



```
Thu Nov 3 22:01:18.620 UTC
es_acl_1 Details:
Sequence Number: 10
Number of DPA Entries: 1
ACL ID: 1
ACE Action: DENY
ACE Logging: DISABLED
Hit Packet Count: 0
Source MAC: 0000:0000:0000
  Source MAC Mask: 0000:0000:0000
Destination MAC: FCD7:844C:7486
  Destination MAC Mask: FFFF:FFFF:FFFF
COS: 0x03
  Entry Index: 0x0
  DPA Handle: 0x89BF60E8
```

```
es_acl_1 Details:
Sequence Number: 20
Number of DPA Entries: 1
ACL ID: 1
ACE Action: DENY
ACE Logging: DISABLED
Hit Packet Count: 0
Source MAC: 0000:0000:0000
  Source MAC Mask: 0000:0000:0000
Destination MAC: FCD7:844C:7486
  Destination MAC Mask: FFFF:FFFF:FFFF
  Entry Index: 0x0
  DPA Handle: 0x89BF62E8
```

```
es_acl_1 Details:
Sequence Number: 30
Number of DPA Entries: 1
ACL ID: 1
ACE Action: PERMIT
ACE Logging: DISABLED
Source MAC: 0000:0000:0000
  Source MAC Mask: 0000:0000:0000
Destination MAC: 0000:0000:0000
  Destination MAC Mask: 0000:0000:0000
  Entry Index: 0x0
  DPA Handle: 0x89BF64E8
```

```
es_acl_1 Details:
Sequence Number: IMPLICIT DENY
Number of DPA Entries: 1
ACL ID: 1
ACE Action: DENY
ACE Logging: DISABLED
Hit Packet Count: 0
Source MAC: 0000:0000:0000
  Source MAC Mask: 0000:0000:0000
Destination MAC: 0000:0000:0000
  Destination MAC Mask: 0000:0000:0000
  Entry Index: 0x0
  DPA Handle: 0x89BF66E8
```

## show access-lists ethernet-services usage pfilter

To identify the modes and interfaces on which a particular access-list is applied, use the **show access-lists ethernet-services usage pfilter** command in EXEC mode. Information displayed includes the application of all or specific access-lists, the interfaces on which they have been applied and the direction in which they are applied.

**show access-lists ethernet-services** *access-list-name* **usage pfilter location** { *location* | **all** }

### Syntax Description

<i>access-list-name</i>	Name of a specific Ethernet services access list. The name cannot contain a spaces or quotation marks, but can include numbers.
<b>usage</b>	Displays the usage of the Ethernet services access list on a given interface card
<b>pfilter</b>	Displays the packet filtering usage for the specified interface card.
<b>location</b>	Interface card on which the access list information is needed.
<i>location</i>	Fully qualified location specification.
<b>all</b>	Displays packet filtering usage for all interface cards.

### Command Modes

EXEC mode

### Command History

Release	Modification
Release 7.5.3	This command was introduced.

### Usage Guidelines

None

### Task ID

Task ID	Operations
acl	read, write

### Examples

The following example shows how to display packet filter usage at a specific location:

```
Router# show access-lists ethernet-services es_acl_1 usage pfilter location 0/0/CPU0
Interface : HundredGigE 0/0/0/24
  Input ACL : es_acl_1
  Output ACL : N/A
```



## VXLAN Commands

---

This section describes the commands used to configure VXLAN.

- [host-reachability protocol static](#), on page 84
- [hw-module profile cef vxlan ipv6-tnl-scale](#) , on page 85
- [interface nve](#), on page 86
- [member vni](#), on page 87
- [overlay-encapsulation](#), on page 88
- [peer-ip lookup disable](#), on page 89
- [show nve interface](#), on page 90
- [show nve vni](#), on page 91
- [source-interface loopback](#), on page 92

## host-reachability protocol static

To configure the static control protocol for VXLAN tunnel endpoint reachability, use the **host-reachability protocol static** command in NVE interface configuration mode.

This command has no keywords or arguments.

<b>Command Default</b>	None	
<b>Command Modes</b>	NVE interface configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.2.11	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	interface	read, write
	tunnel	read, write

### Example

The following example shows control protocol configuration for VXLAN tunnel endpoint reachability.

```
Router(config)# interface nve1
Router(config-if)# member vni 2
Router(config-nve-vni)# vrf vrf1
Router(config-nve-vni)# host-reachability protocol protocol static
Router(config-nve-vni)# commit
```

## hw-module profile cef vxlan ipv6-tnl-scale

To increase the VXLAN static routes, use the **hw-module profile cef vxlan ipv6-tnl-scale** command in the XR Config mode.

This command has no keywords or arguments.

<b>Command Default</b>	None	
<b>Command Modes</b>	XR Config	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	VXLAN supports up to 160000 static routes by default. However, you can increase the scale value up to one million VXLAN static routes for IPv6 tunnel remote nexthop using the <b>hw-module profile cef vxlan ipv6-tnl-scale</b> command.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read, write

### Example

The following example shows how to increase the scale value of VXLAN static routes up to one million:

```
Router# configuration
Router(config)# hw-module profile cef vxlan ipv6-tnl-scale
Router(config)# commit
```

## interface nve

To create a network virtualization endpoint (NVE) interface and enter the NVE interface configuration mode, use the **interface nve** command in XR Config mode. To remove the NVE interface, use the **no** form of this command.

```
interface nve nve-id
```

<b>Syntax Description</b>	<i>nve-id</i> The NVE interface ID. It can take values from 1 to 65535.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	XR Config
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.2.11	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	interface	read, write

### Example

The following example shows how to create an NVE interface and enter the NVE interface configuration mode.

```
Router(config)# interface nve 1
Router(config-if)#
```

## member vni

To map a VXLAN to a network virtualization endpoint (NVE) interface, use the **member vni** command in the XR Config mode. To remove the VXLAN from the bridge domain, use the **no** form of this command.

**member vni** *number*

### Syntax Description

<b>vni</b>	The member virtual network identifier (VNI).
<b>number</b>	The ID of the VXLAN to be mapped to the NVE. The valid values are from 1 to 16777215.

### Command Default

None

### Command Modes

Bridge-domain configuration

### Command History

Release	Modification
Release 24.2.11	This command was introduced.

### Usage Guidelines

No specific guidelines impact the use of this command.

### Task ID

Task ID	Operation
interface	read, write
tunnel	read, write

### Example

The following example shows the VXLAN with VNI "2" associated with the NVE "1".

```
Router(config)# interface nve 1
Router(config-if)# member vni 2
```

# overlay-encapsulation

To define the encapsulation type for Network Virtualization Endpoint (NVE) interface, use the **overlay-encapsulation** command in NVE interface configuration mode.

**overlay-encapsulation vxlan**

**Syntax Description**      **vxlan** Sets VXLAN as an overlay encapsulation type for NVE interface.

**Command Default**      VXLAN

**Command Modes**      NVE interface configuration

Command History	Release	Modification
	Release 24.2.11	This command was introduced.

**Usage Guidelines**      No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	interface	read, write
	tunnel	read, write

**Example**

The following example shows an NVE interface configured for VXLAN encapsulation.

```
Router# configure
Router(config)# interface nve1
Router(config-if)# overlay-encapsulation vxlan
Router(config-nve-encap-vxlan)# commit
```



# peer-ip lookup disable

To disable lookup of peer IP address to accept packets from unknown peers, use the **peer-ip lookup disable** command in NVE interface configuration mode.

## **peer-ip lookup disable**

This command has no keywords or arguments.

### Command Default

None

### Command Modes

NVE interface configuration

### Command History

Release	Modification
Release 24.2.11	This command was introduced.

### Usage Guidelines

No specific guidelines impact the use of this command.

### Task ID

Task ID	Operation
interface	read, write
tunnel	read, write

### Example

The following example shows how to disable lookup of peer-ip to accept packets from unknown peers.

```
Router# configure
Router(config)# interface nve1
Router(config-if)# overlay-encapsulation vxlan
Router(config-nve-encap-vxlan)# peer-ip lookup disable
Router(config-nve-encap-vxlan)# commit
```

# show nve interface

To display the network virtualization endpoint (NVE) interface information, use the **show nve interface** command in XR EXEC mode.

```
show nve interface [ detail | nve nve-id ]
```

<b>Syntax Description</b>	<b>detail</b>	Displays detailed information about NVE interfaces.
	<b>nve nve-id</b>	Displays information only about the specified NVE interface.
<b>Command Default</b>	None	
<b>Command Modes</b>	XR EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	interface	read

## Example

This is the sample output of the **show interface nve** command anycast gateway parameters.

```
Router# show interface nve100 detail
Interface: nve100 State: Up Encapsulation: VxLAN
  Source Interface: Loopback1 (primary: 10.0.0.1)
  Source Interface State: Up
  NVE Flags: 0x1, Admin State: Up, Interface Handle 0xba0
  UDP Port: 4789
  Anycast Source Interface: Loopback100 (primary: 100.1.1.1)
```

## show nve vni

To display list of all VNIs that are associated with various NVE interfaces and the associated multicast IP address that is used for multi-destination frames, use the **show nve vni** command in XR EXEC mode.

```
show nve vni [ vni_number | detail | interface nve nve-id ]
```

Syntax Description		
<i>vni_number</i>		Displays output for the specific VNI.
<b>detail</b>		Displays more detailed output.
<b>interface nve</b> <i>nve-id</i>		Displays details for the specific NVE interface.

**Command Default** None

**Command Modes** XR EXEC

Command History	Release	Modification
	Release 24.2.11	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	tunnel	read

### Example

The following shows an example output of this show command:

```
Router# show nve vni
Interface VNI          MCAST      VNI State   Mode
nve3     1002          0.0.0.0    Up          L3 Control (Static)
nve1     17001         0.0.0.0    Up          L3 Control (Static)
nve2     17002         0.0.0.0    Up          L3 Control (Static)
nve3     17003         0.0.0.0    Up          L3 Control (Static)
```

# source-interface loopback

To specify a loopback interface whose IP address should be set as the IP address for the NVE interface, use the **source-interface loopback** command.

**source-interface loopback** *interface-id*

<b>Syntax Description</b>	<b>loopback</b>	Specifies a loopback interface as providing IP address for the NVE interface.
	<i>interface-id</i>	Specifies the loopback interface ID. It can take values from 0 to 65535.

**Command Default** None

**Command Modes** NVE interface configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.2.11	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	tunnel	read, write
	interface	read, write

## Example

The following example shows how to configure the IP address of an NVE interface as the IP address of a loopback interface.

```
Router(config)# interface nve 1
Router(config-if)# source-interface loopback 1
```