



Configuring Modular QoS Congestion Avoidance

Congestion avoidance techniques monitor traffic flow in an effort to anticipate and avoid congestion at common network bottlenecks. Avoidance techniques are implemented before congestion occurs as compared with congestion management techniques that control congestion after it has occurred.

Congestion avoidance is achieved through packet dropping. Cisco IOS XR software supports these quality of service (QoS) congestion avoidance techniques that drop packets:

- Random early detection (RED)
- Weighted random early detection (WRED)
- Tail drop

The module describes the concepts and tasks related to these congestion avoidance techniques.

Line Card, SIP, and SPA Support

Feature	ASR 9000 Ethernet Line Cards	SIP 700 for the ASR 9000
Random Early Detection	yes	yes
Weighted Random Early Detection	yes	yes
Tail Drop	yes	yes

Feature History for Configuring Modular QoS Congestion Avoidance on Cisco ASR 9000 Series Routers

Release	Modification
Release 3.7.2	The Congestion Avoidance feature was introduced on ASR 9000 Ethernet Line Cards. The Random Early Detection, Weighted Random Early Detection, and Tail Drop features were introduced on ASR 9000 Ethernet Line Cards.
Release 3.9.0	The Random Early Detection, Weighted Random Early Detection, and Tail Drop features were supported on the SIP 700 for the ASR 9000.

- [Prerequisites for Configuring Modular QoS Congestion Avoidance, on page 2](#)
- [Information About Configuring Modular QoS Congestion Avoidance, on page 2](#)

- [Additional References, on page 15](#)

Prerequisites for Configuring Modular QoS Congestion Avoidance

This prerequisite is required for configuring QoS congestion avoidance on your network:

You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Information About Configuring Modular QoS Congestion Avoidance

Random Early Detection and TCP

The Random Early Detection (RED) congestion avoidance technique takes advantage of the congestion control mechanism of TCP. By randomly dropping packets prior to periods of high congestion, RED tells the packet source to decrease its transmission rate. Assuming the packet source is using TCP, it decreases its transmission rate until all packets reach their destination, indicating that the congestion is cleared. You can use RED as a way to cause TCP to slow transmission of packets. TCP not only pauses, but it also restarts quickly and adapts its transmission rate to the rate that the network can support.

RED distributes losses in time and maintains normally low queue depth while absorbing traffic bursts. When enabled on an interface, RED begins dropping packets when congestion occurs at a rate you select during configuration.

Queue-limit for WRED

Queue-limit is used to fine-tune the number of buffers available for each queue. It can only be used on a queuing class. Default queue limit is 100 ms of the service rate for the given queue. The service rate is the sum of minimum guaranteed bandwidth and bandwidth remaining assigned to a given class either implicitly or explicitly.

The queue-limit is rounded up to the nearest power of 2, and depending on the line cards on your system, the queue-limit values vary. To check the current queue-limit for class-default, use the **show qos interface** command.

Because WRED needs a queue to operate on, the class that WRED is applied on must have either a bandwidth statement or a parent policy with a shaper if WRED is applied only on a class default queue.

Examples

The following policy configuration does not use the queue limit because the policy is flat and doesn't have a designated queue on which it operates.

```
policy-map incorrect-flat
class class-default
  random-detect dscp 16 250 packets 500 packets
```

```
queue-limit 158000 kbytes
```

The following policy configuration can use the queue limit because it uses a parent policy map with the `shape average` command.

```
policy-map parent
class class-default
shape average 100 mbps
service-policy child

policy-map child
class class-default
  random-detect dscp 16 250 packets 500 packets
  queue-limit 158000 kbytes
```

The following policy configuration can use the queue limit because it provides a flat policy with a shaped queue through the `bandwidth` command for the `class-default`.

```
policy-map correct-flat
class class-default
  bandwidth 100 mbps
  random-detect dscp 16 250 packets 500 packets
  queue-limit 158000 kbytes
```

Tail Drop and the FIFO Queue

Tail drop is a congestion avoidance technique that drops packets when an output queue is full until congestion is eliminated. Tail drop treats all traffic flow equally and does not differentiate between classes of service. It manages the packets that are unclassified, placed into a first-in, first-out (FIFO) queue, and forwarded at a rate determined by the available underlying link bandwidth.

See the “Default Traffic Class” section of the “Configuring Modular Quality of Service Packet Classification and Marking on Cisco ASR 9000 Series Routers”.

Configuring Random Early Detection

This configuration task is similar to that used for WRED except that the `random-detect precedence` command is not configured and the `random-detect` command with the `default` keyword must be used to enable RED.

Restrictions

If you configure the `random-detect default` command on any class including `class-default`, you must configure one of the following commands:

- `shape average`
- `bandwidth`
- `bandwidth remaining`

SUMMARY STEPS

1. `configure`
2. `policy-map policy-map-name`
3. `class class-name`

4. **random-detect** {*cos value* | **default** | **discard-class** *value* | **dscp** *value* | **exp** *value* | **precedence** *value* | *min-threshold* [*units*] *max-threshold* [*units*] }
5. **bandwidth** {*bandwidth* [*units*] | **percent** *value*} or **bandwidth remaining** [**percent** *value* | **ratio** *ratio-value*]
6. **shape average** {**percent** *percentage* | *value* [*units*]}
7. **exit**
8. **exit**
9. **interface** *type interface-path-id*
10. **service-policy** {**input** | **output**} *policy-map*
11. Use the **commit** or **end** command.

DETAILED STEPS

Procedure

	Command or Action	Purpose
Step 1	configure Example: RP/0/RSP0/CPU0:router# configure	Enters global configuration mode.
Step 2	policy-map <i>policy-map-name</i> Example: RP/0/RSP0/CPU0:router(config)# policy-map policy1	Creates or modifies a policy map that can be attached to one or more interfaces to specify a service policy and enters the policy map configuration mode.
Step 3	class <i>class-name</i> Example: RP/0/RSP0/CPU0:router(config-pmap)# class class1	Specifies the name of the class whose policy you want to create or change and enters the policy map class configuration mode.
Step 4	random-detect { <i>cos value</i> default discard-class <i>value</i> dscp <i>value</i> exp <i>value</i> precedence <i>value</i> <i>min-threshold</i> [<i>units</i>] <i>max-threshold</i> [<i>units</i>] } Example: RP/0/RSP0/CPU0:router(config-pmap-c)# random-detect default	Enables RED with default minimum and maximum thresholds.
Step 5	bandwidth { <i>bandwidth</i> [<i>units</i>] percent <i>value</i> } or bandwidth remaining [percent <i>value</i> ratio <i>ratio-value</i>] Example: RP/0/RSP0/CPU0:router(config-pmap-c)# bandwidth percent 30 or	(Optional) Specifies the bandwidth allocated for a class belonging to a policy map. or (Optional) Specifies how to allocate leftover bandwidth to various classes.

	Command or Action	Purpose
	RP/0/RSP0/CPU0:router(config-pmap-c)# bandwidth remaining percent 20	
Step 6	shape average {percent <i>percentage</i> value [<i>units</i>]} Example: RP/0/RSP0/CPU0:router(config-pmap-c)# shape average percent 50	(Optional) Shapes traffic to the specified bit rate or a percentage of the available bandwidth.
Step 7	exit Example: RP/0/RSP0/CPU0:router(config-pmap-c)# exit	Returns the router to policy map configuration mode.
Step 8	exit Example: RP/0/RSP0/CPU0:router(config-pmap)# exit	Returns the router to global configuration mode.
Step 9	interface type interface-path-id Example: RP/0/RSP0/CPU0:router(config)# interface TenGigE 0/2/0/0	Enters the configuration mode and configures an interface.
Step 10	service-policy {input output} policy-map Example: RP/0/RSP0/CPU0:router(config-if)# service-policy output policy1	Attaches a policy map to an input or output interface to be used as the service policy for that interface. In this example, the traffic policy evaluates all traffic leaving that interface.
Step 11	Use the commit or end command.	commit —Saves the configuration changes, and remains within the configuration session. end —Prompts user to take one of these actions: <ul style="list-style-type: none"> • Yes — Saves configuration changes and exits the configuration session. • No —Exits the configuration session without committing the configuration changes. • Cancel —Remains in the configuration mode, without committing the configuration changes.

Configuring Weighted Random Early Detection

WRED drops packets selectively based on any specified criteria, such as CoS, DSCP, EXP, discard-class, or precedence. WRED uses these matching criteria to determine how to treat different types of traffic.

Configure WRED using the **random-detect** command and different CoS, DSCP, EXP, and discard-class values. The value can be range or a list of values that are valid for that field. You can also use minimum and maximum queue thresholds to determine the dropping point.

When a packet arrives, the following actions occur:

- If the queue size is less than the minimum queue threshold, the arriving packet is queued.
- If the queue size is between the minimum queue threshold for that type of traffic and the maximum threshold for the interface, the packet is either dropped or queued, depending on the packet drop probability for that type of traffic.
- If the queue size is greater than the maximum threshold, the packet is dropped.

Restrictions

- On systems with Cisco ASR 9000 High-Density 100GE Ethernet line cards and fifth-generation line cards, ensure that you configure the minimum and maximum threshold values that are greater than the default minimum and maximum threshold values. If you apply a policy that has lesser than default values to a bundle that has both these line cards, the **show policy-map interface** command displays a mismatch in statistics bag size.
- When configuring the **random-detect dscp** command, you must configure one of the following commands: **shape average**, **bandwidth**, and **bandwidth remaining**.



Note The Cisco ASR 9000 Series ATM SPA supports only time-based WRED thresholds. Therefore, if you try to configure the WRED threshold using the **random-detect default** command with bytes or packet as the threshold units, the "Unsupported WRED unit on ATM interface" error occurs.

- Only two minimum and maximum thresholds (each with different match criteria) can be configured per class.

SUMMARY STEPS

1. **configure**
2. **policy-map** *policy-name*
3. **class** *class-name*
4. **random-detect dscp** *dscp-value min-threshold [units] max-threshold [units]*
5. **bandwidth** {*bandwidth [units]* | **percent** *value*} or **bandwidth remaining** {**percent** *value* | **ratio** *ratio-value*}
6. **bandwidth** {*bandwidth [units]* | **percent** *value*}
7. **bandwidth remaining** **percent** *value*
8. **shape average** {**percent** *percentage* | *value [units]*}
9. **queue-limit** *value [units]*
10. **exit**
11. **interface** *type interface-path-id*
12. **service-policy** {**input** | **output**} *policy-map*
13. Use the **commit** or **end** command.

DETAILED STEPS

Procedure

	Command or Action	Purpose
Step 1	configure Example: RP/0/RSP0/CPU0:router# configure	Enters global configuration mode.
Step 2	policy-map <i>policy-name</i> Example: RP/0/RSP0/CPU0:router(config)# policy-map policy1	Creates or modifies a policy map that can be attached to one or more interfaces to specify a service policy and enters the policy map configuration mode.
Step 3	class <i>class-name</i> Example: RP/0/RSP0/CPU0:router(config-pmap)# class class1	Specifies the name of the class whose policy you want to create or change and enters the policy map class configuration mode.
Step 4	random-detect dscp <i>dscp-value</i> <i>min-threshold</i> [<i>units</i>] <i>max-threshold</i> [<i>units</i>] Example: RP/0/RSP0/CPU0:router(config-pmap-c)# random-detect dscp af11 1000000 bytes 2000000 bytes	Modifies the minimum and maximum packet thresholds for the DSCP value. <ul style="list-style-type: none"> • Enables WRED. • <i>dscp-value</i>—Number from 0 to 63 that sets the DSCP value. Reserved keywords can be specified instead of numeric values. • <i>min-threshold</i>—Minimum threshold in the specified units. When the average queue length reaches the minimum threshold, WRED randomly drops some packets with the specified DSCP value. • <i>max-threshold</i>—Maximum threshold in the specified units. When the average queue length exceeds the maximum threshold, WRED drops all packets with the specified DSCP value. • <i>units</i>—Units of the threshold value. This can be bytes, gbytes, kbytes, mbytes, ms (milliseconds), packets, or us (microseconds). The default is packets. • This example shows that for packets with DSCP AF11, the WRED minimum threshold is 1,000,000 bytes and maximum threshold is 2,000,000 bytes.
Step 5	bandwidth {<i>bandwidth</i> [<i>units</i>] percent <i>value</i>} or bandwidth remaining [percent <i>value</i> ratio <i>ratio-value</i>] Example: 	(Optional) Specifies the bandwidth allocated for a class belonging to a policy map. or

	Command or Action	Purpose
	<pre>RP/0/RSP0/CPU0:router(config-pmap-c)# bandwidth percent 30</pre> <p>or</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# bandwidth remaining percent 20</pre>	(Optional) Specifies how to allocate leftover bandwidth to various classes.
Step 6	<p>bandwidth {<i>bandwidth [units]</i> percent value}</p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# bandwidth percent 30</pre>	(Optional) Specifies the bandwidth allocated for a class belonging to a policy map. This example guarantees 30 percent of the interface bandwidth to class class1.
Step 7	<p>bandwidth remaining percent value</p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# bandwidth remaining percent 20</pre>	(Optional) Specifies how to allocate leftover bandwidth to various classes. <ul style="list-style-type: none"> • The remaining bandwidth of 70 percent is shared by all configured classes. • In this example, class class1 receives 20 percent of the 70 percent.
Step 8	<p>shape average {percent percentage <i>value [units]</i>}</p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# shape average percent 50</pre>	(Optional) Shapes traffic to the specified bit rate or a percentage of the available bandwidth.
Step 9	<p>queue-limit value [units]</p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# queue-limit 50 ms</pre>	(Optional) Changes queue-limit to fine-tune the amount of buffers available for each queue. The default queue-limit is 100 ms of the service rate for a non-priority class and 10ms of the service rate for a priority class. <p>Note Even though this command is optional, it is recommended that you use it to fine-tune the queue limit, instead of relying on your system default settings. If the queue limit is too large, the buffer consumption goes up, resulting in delays. On the other hand, too small a queue limit may result in extra drops while allowing for faster rate adaption.</p>
Step 10	<p>exit</p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap)# exit</pre>	Returns the router to global configuration mode.
Step 11	<p>interface type interface-path-id</p> <p>Example:</p>	Enters the configuration mode and configures an interface.

	Command or Action	Purpose
	RP/0/RSP0/CPU0:router(config)# interface gigabitethernet 0/2/0/0	
Step 12	<p>service-policy {input output} <i>policy-map</i></p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-if)# service-policy output policy1</pre>	<p>Attaches a policy map to an input or output interface to be used as the service policy for that interface.</p> <ul style="list-style-type: none"> • In this example, the traffic policy evaluates all traffic leaving that interface. • Ingress policies are not valid; the bandwidth and bandwidth remaining commands cannot be applied to ingress policies.
Step 13	Use the commit or end command.	<p>commit —Saves the configuration changes and remains within the configuration session.</p> <p>end —Prompts user to take one of these actions:</p> <ul style="list-style-type: none"> • Yes — Saves configuration changes and exits the configuration session. • No —Exits the configuration session without committing the configuration changes. • Cancel —Remains in the configuration session, without committing the configuration changes.

Configuring Tail Drop

Packets satisfying the match criteria for a class accumulate in the queue reserved for the class until they are serviced. The **queue-limit** command is used to define the maximum threshold for a class. When the maximum threshold is reached, enqueued packets to the class queue result in tail drop (packet drop).

The **queue-limit** value uses the guaranteed service rate (GSR) of the queue as the reference value for the **queue_bandwidth**. If the class has bandwidth percent associated with it, the **queue-limit** is set to a proportion of the bandwidth reserved for that class.

If the GSR for a queue is zero, use the following to compute the default **queue-limit**:

- 1 percent of the interface bandwidth for queues in a nonhierarchical policy.
- 1 percent of parent maximum reference rate for hierarchical policy.

The parent maximum reference rate is the minimum of parent shape, policer maximum rate, and the interface bandwidth.



Note The default **queue-limit** is set to bytes of 100 ms of queue bandwidth. The following formula is used to calculate the default queue limit (in bytes): $bytes = (100\text{ ms} / 1000\text{ ms}) * queue_bandwidth\text{ kbps}) / 8$

Restrictions

- When configuring the **queue-limit** command in a class, you must configure one of the following commands: **priority**, **shape average**, **bandwidth**, or **bandwidth remaining**, except for the default class.

SUMMARY STEPS

1. **configure**
2. **policy-map** *policy-name*
3. **class** *class-name*
4. **queue-limit** *value* [*units*]
5. **priority** [*level* *priority-level*]
6. **police rate** *percent* *percentage*
7. **class** *class-name*
8. **bandwidth** {*bandwidth* [*units*] | **percent** *value*}
9. **bandwidth remaining** *percent* *value*
10. **exit**
11. **exit**
12. **interface** *type* *interface-path-id*
13. **service-policy** {**input** | **output**} *policy-map*
14. Use the **commit** or **end** command.

DETAILED STEPS

Procedure

	Command or Action	Purpose
Step 1	configure Example: RP/0/RSP0/CPU0:router# configure	Enters global configuration mode.
Step 2	policy-map <i>policy-name</i> Example: RP/0/RSP0/CPU0:router(config)# policy-map policy1	Creates or modifies a policy map that can be attached to one or more interfaces to specify a service policy and also enters the policy map configuration mode.
Step 3	class <i>class-name</i> Example: RP/0/RSP0/CPU0:router(config-pmap)# class class1	Specifies the name of the class whose policy you want to create or change and enters the policy map class configuration mode.
Step 4	queue-limit <i>value</i> [<i>units</i>] Example: RP/0/RSP0/CPU0:router(config-pmap-c)# queue-limit 1000000 bytes	Specifies or modifies the maximum the queue can hold for a class policy configured in a policy map. The default value of the <i>units</i> argument is packets . In this example, when the queue limit reaches 1,000,000 bytes, enqueued packets to the class queue are dropped.

	Command or Action	Purpose
Step 5	<p>priority [<i>level priority-level</i>]</p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# priority level 1</pre>	Specifies priority to a class of traffic belonging to a policy map.
Step 6	<p>police rate percent <i>percentage</i></p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# police rate percent 30</pre>	Configures traffic policing.
Step 7	<p>class <i>class-name</i></p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap)# class class2</pre>	Specifies the name of the class whose policy you want to create or change. In this example, class2 is configured.
Step 8	<p>bandwidth {<i>bandwidth [units]</i> percent <i>value</i>}</p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# bandwidth percent 30</pre>	(Optional) Specifies the bandwidth allocated for a class belonging to a policy map. This example guarantees 30 percent of the interface bandwidth to class class2.
Step 9	<p>bandwidth remaining percent <i>value</i></p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# bandwidth remaining percent 20</pre>	(Optional) Specifies how to allocate leftover bandwidth to various classes. This example allocates 20 percent of the leftover interface bandwidth to class class2.
Step 10	<p>exit</p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap-c)# exit</pre>	Returns the router to policy map configuration mode.
Step 11	<p>exit</p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config-pmap)# exit</pre>	Returns the router to global configuration mode.
Step 12	<p>interface <i>type interface-path-id</i></p> <p>Example:</p> <pre>RP/0/RSP0/CPU0:router(config)# interface POS 0/2/0/0</pre>	Enters the configuration mode and configures an interface.
Step 13	<p>service-policy {input output} <i>policy-map</i></p> <p>Example:</p>	Attaches a policy map to an input or output interface to be used as the service policy for that interface. In this example, the traffic policy evaluates all traffic leaving that interface.

	Command or Action	Purpose
	RP/0/RSP0/CPU0:router(config-if)# service-policy output policy1	
Step 14	Use the commit or end command.	<p>commit —Saves the configuration changes and remains within the configuration session.</p> <p>end —Prompts user to take one of these actions:</p> <ul style="list-style-type: none"> • Yes — Saves configuration changes and exits the configuration session. • No —Exits the configuration session without committing the configuration changes. • Cancel —Remains in the configuration session, without committing the configuration changes.

Low Queue Limit and WRED Values for Low Access Speeds

Table 1: Feature History Table

Feature Name	Release Information	Feature Description
Low Queue Limit and WRED Values for Low Access Speeds	Release 7.11.1	<p>You can now design your infrastructure for low access speeds, allowing your customers to use low-speed Layer 3 VPN services. Your customers can thus deliver these low-speed services to their end-customers, who can use them to connect their branch offices, home-workers, or any other business scenario requiring low-speed services. To achieve these services, we have enabled the configuration of lower minimum values for queue limit and WRED on the fourth and fifth generations of the ASR 9000 Series High Density Ethernet line cards. You can configure lower queue limit values only for 1 Gbps, 10 Gbps, and 400 Gbps interfaces and lower WRED values for 1 Gbps and 10 Gbps interfaces.</p> <p>There's no action required for you to enable this functionality, and there are no changes to command options.</p>

Previously, the minimum value for both queue limit and Weighted Random Early Detection (WRED) was 100 KB. These values meant that when you deployed lower-capacity devices in your networks for low access speeds, you couldn't configure any value lower than 100 KB for queue limit and WRED. If you did, the hardware would round off that value to 100 KB.

From Release 7.11.1, you can configure lower values for queue limit (using the [queue-limit](#) command) and WRED (using the [random-detect](#) command) to effectively deploy and operate lower-capacity devices in

your network for lower access speeds. These new values also apply to 1 Gbps and 10 Gbps interfaces when they're part of a bundle interface, while other interfaces that are part of the bundle will continue to have the earlier minimum values. For 400 Gbps interfaces, the new queue limit value is 400 KB, which also applies when they're part of a bundle interface.

The table displays the queue limit and WRED values for different interfaces before and from Release 7.11.1.

Table 2: Queue Limit and WRED Values

Interface Speed	Minimum Queue Limit Value Before Release 7.11.1	Minimum Queue Limit Value After Release 7.11.1	Minimum WRED Value Before Release 7.11.1	Minimum WRED Value After Release 7.11.1
1 Gbps	100 KB	10 KB	100 KB	5 KB
10 Gbps	100 KB	10 KB	100 KB	5 KB
400 Gbps	100 KB	400 KB	100 KB	100 KB (no change)
All other interfaces	100 KB	100 KB (no change)	100 KB	100 KB (no change)

Low Queue Limit and WRED Values for Low Access Speeds: Guidelines and Limitations

- The minimum queue limit value is only modified for 1 Gbps, 10 Gbps, and 400 Gbps interfaces, and the minimum WRED is only modified for 1 Gbps and 10 Gbps interfaces.
- This feature is supported on the fourth and fifth generations of the ASR 9000 Series High Density Ethernet line cards.
- This feature isn't supported on the third generation of the ASR 9000 Series High Density Ethernet line cards.
- These new minimum queue limit and WRED values apply to 1 Gbps and 10 Gbps interfaces when they're part of a bundle interface, while other interfaces that are part of the bundle will continue to have the earlier minimum values. For 400 Gbps interfaces, you can configure a WRED value, which also applies when they're part of a bundle interface.

Configure and View Low Queue Limit and WRED Values for Low Access Speeds

Low Queue Limit Values

Let's say you configure a queue limit of 10 KB for a policy map named **test-qlimit** and class map **match-vlan1**, which you attach to a 10 Gbps interface.

```
Router(config)#policy-map test-qlimit
Router(config-pmap)#class match-vlan1
Router(config-pmap-c)#queue-limit 10 kbytes
Router(config-pmap-c)#priority level 3
Router(config-pmap)#commit
Router(config)#int tenGigE 0/0/0/3/3
Router(config-if)#service-policy output test-qlimit
Router(config-if)#commit
```

Run the **show qos interface** command to view the lower queue limit value that you configured for class map **match-vlan1**.

```

Router#show qos interface tenGigE 0/0/0/3/3 output location 0/0/0/3/3
Interface: TenGigE0_0_0_3_3 output
Bandwidth configured: 10000000 kbps Bandwidth programed: 10000000 kbps
ANCP user configured: 0 kbps ANCP programed in HW: 0 kbps
Port Shaper programed in HW: 0 kbps
Policy: test-q-limit Total number of classes: 2
-----
Level: 0 Policy: test-q-limit Class: match-vlan1
QueueID: 0x9032 (Priority 3)
Queue Limit: 10 kbytes (10 kbytes) Abs-Index: 0 Template: 0 Curve: 0
-----
Level: 0 Policy: test-qlimit Class: class-default
QueueID: 0x9037 (Priority Normal)
Queue Limit: 1250 kbytes Abs-Index: 0 Template: 0 Curve: 0
WFQ Profile: 0/0 Committed Weight: 0 Excess Weight: 1
Bandwidth: 0 kbps, BW sum for Level 0: 0 kbps, Excess Ratio: 1
WFQ HW CIR Token refill: 0 Saturation num: 0 Excess wt: 0

```

Low WRED Values

Let's say you configure the minimum and maximum values for random-detect (WRED) value as 5 KB for policy map **test-wred** and class map **match-vlan1**.



Note Per the new functionality, any WRED value you configure below 5 KB gets rounded to 5 KB. Also, you can configure these values in units other than KBs (such as packets or ms), but the router hardware converts them to KB and rounds off the value to 5 KB if the converted value in KB is less than 5 KB.

```

Router(config)#policy-map test-wred
Router(config-pmap)#class match-vlan1
Router(config-pmap-c)#queue-limit 10 kbytes
Router(config-pmap-c)#bandwidth percent 10
Router(config-pmap-c)#random-detect dscp 30 5 kbytes 5 kbytes
Router(config-pmap-c)#commit

Router(config)#int tenGigE 0/0/0/3/3
Router(config-if)#service-policy output test-wred
Router(config-if)#commit

```

Run the **show qos interface** command to view the lower WRED value (**random-detect**) that you configured for class map **match-vlan1**.

```

Router#sh qos interface tenGigE 0/0/0/3/3 output location 0/0/0/3/3
Interface: TenGigE0_0_0_3_3 output
Bandwidth configured: 10000000 kbps Bandwidth programed: 10000000 kbps
ANCP user configured: 0 kbps ANCP programed in HW: 0 kbps
Port Shaper programed in HW: 0 kbps
Policy: test-wred Total number of classes: 2
-----
Level: 0 Policy: test-wred Class: match-vlan1
QueueID: 0x9032 (Priority Normal)
Queue Limit: 10 kbytes (10 kbytes) Abs-Index: 0 Template: 0 Curve: 0
WFQ Profile: 0/0 Committed Weight: 1000000 Excess Weight: 1
Bandwidth: 1000000 kbps, BW sum for Level 0: 1000000 kbps, Excess Ratio: 1
WFQ HW CIR Token refill: 0 Saturation num: 0 Excess wt: 655
WRED Type: DSCP and EXP based Curves: 2
Default RED Curve Profile: 0/0/0 Thresholds Min : 10 (10) kbytes Max: 10 (10) kbytes
Hardware Output: 5000000a00000000
segment_size = 10 (0xa)

```

```

wred_index                =                0 (0x0)
min_threshold              =                10 (0xa)
first_segment              =                0 (0x0)
max_minus_min_threshold    =                0 (0x0)
WRED Curve: 1 Profile: 0/0/0 Thresholds Min : 5 (5) kbytes Max: 5 (5) kbytes
  Match: 30
Hardware Output: 50000005000000000
segment_size               =                10 (0xa)
wred_index                 =                0 (0x0)
min_threshold              =                5 (0x5)
first_segment              =                0 (0x0)
max_minus_min_threshold    =                0 (0x0)
-----
Level: 0 Policy: test-wred Class: class-default
QueueID: 0x9033 (Priority Normal)
Queue Limit: 1250 kbytes Abs-Index: 0 Template: 0 Curve: 0
WFQ Profile: 0/0 Committed Weight: 0 Excess Weight: 1
Bandwidth: 0 kbps, BW sum for Level 0: 1000000 kbps, Excess Ratio: 1
WFQ HW CIR Token refill: 0 Saturation num: 0 Excess wt: 16

```

Additional References

These sections provide references related to implementing QoS congestion avoidance.

Related Documents

Related Topic	Document Title
Initial system bootup and configuration	<i>Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide</i>
QoS commands	<i>Cisco ASR 9000 Series Aggregation Services Router Module Configuration Reference</i>
User groups and task IDs	“Configuring AAA Services on Cisco ASR 9000 Series Routers” of <i>Cisco ASR 9000 Series Aggregation Services Router Security Configuration Guide</i>

Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

MIBs

MIBs	MIBs Link
—	To locate and download MIBs using Cisco IOS XR software, Cisco MIB Locator found at the following URL and choose a under the Cisco Access Products menu: http://cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml

RFCs

RFCs	Title
No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature.	—

Technical Assistance

Description	Link
The Cisco Technical Support website contains thousands of pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content.	http://www.cisco.com/cisco/web/support/index.html