



MPLS Transport Profile Commands

This module describes the commands used to configure Transport Profile (MPLS-TP) in a Multiprotocol Label Switching (MPLS) network.

MPLS Transport Profile supported by IETF enables the migration of transport networks to a packet-based network that efficiently scale to support packet services in a simple and cost effective way. MPLS transport profile enables you to create tunnels that provide the transport network service layer over which IP and MPLS traffic traverse.

For detailed information about MPLS concepts, configuration tasks, and examples, see *Cisco ASR 9000 Series Aggregation Services Router MPLS Configuration Guide*.

- [fault-oam-refresh, on page 2](#)
- [link-id, on page 3](#)
- [lockout \(MPLS LSP\), on page 4](#)
- [node-id, on page 5](#)
- [alarm \(MPLS\), on page 6](#)
- [bfd \(MPLS\), on page 7](#)
- [bandwidth \(MPLS\), on page 8](#)
- [description, on page 9](#)
- [destination \(MPLS\), on page 10](#)
- [fast-protect, on page 11](#)
- [mid, on page 12](#)
- [protect LSP, on page 13](#)
- [working LSP, on page 14](#)
- [forward LSP, on page 15](#)
- [reverse LSP, on page 17](#)

fault-oam-refresh

To configure a refresh interval globally for all MPLS-TP LSPs, use the **fault-oam-refresh** command in MPLS-TP configuration mode. To return to the default behavior, use the **no** form of this command.

fault-oam-refresh interval seconds

Syntax Description	interval seconds Configures the interval value, in seconds, that gets refreshed for all MPLS-TP LSPs. Range is 1 to 20 seconds. The default is 20 seconds.				
Command Default	The default interval is 20 seconds.				
Command Modes	MPLS-TP configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.2.0	This command was introduced.
Release	Modification				
4.2.0	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>MPLS-TE</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	MPLS-TE	read, write
Task ID	Operation				
MPLS-TE	read, write				

The following example shows how to configure the global refresh interval :

```
RP/0/RP0RSP0/CPU0:router:hostname# config
RP/0/RP0RSP0/CPU0:router:hostname(config)# mpls traffic-eng
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te)# tp
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-tp)# fault-oam-refresh 10
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-tp)# commit
```

The following example shows how to configure the OAM refresh interval for a LSP :

```
RP/0/RP0RSP0/CPU0:router:hostname# config
RP/0/RP0RSP0/CPU0:router:hostname(config)# interface tunnel-tp 10
RP/0/RP0RSP0/CPU0:router:hostname(config-if)# static-lsp
RP/0/RP0RSP0/CPU0:router:hostname(config-if-slsp)# fault-oam-refresh 10
RP/0/RP0RSP0/CPU0:router:hostname(config-if-slsp-prot)# commit
```

link-id

To define an ID for an interface or next-hop address that carries MPLS-TP LSPs, use the **link-id** command in interface configuration mode. To remove the ID, use the **no** form of this command.

link-id value next-hop [IPv4address]

Syntax Description	<i>value</i> Value number that identifies the link ID. Range is 1 to 65535. <i>IPv4 address</i> Configures the IPv4 address for the MPLS-TP link ID.				
Command Default	No default behavior or values				
Command Modes	Interface configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.2.0	This command was introduced.
Release	Modification				
4.2.0	This command was introduced.				

Usage Guidelines



Note You can define MPLS-TP link ID only once. If you attempt to use the same MPLS-TP link ID with different interface or next-hop-address, the configuration gets rejected.

Task ID	Task ID	Operation
MPLS-TE	read, write	

The following example shows how to define an ID for the GigabitEthernet interface 0/2/1/1:

```
RP/0/RP0RSP0/CPU0:router:hostname# config
RP/0/RP0RSP0/CPU0:router:hostname(config)# mpls traffic-eng
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te)# interface Gige0/2/1/1
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-if)# link-id 22 next-hop 192.4.1.0
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-if)# commit
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-if)# no link-id 22
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-if)# exit
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-if)# exit
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te)# interface Gige0/2/1/3
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-if)# link-id 22 next-hop 192.4.1.0
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-if)# commit
```

lockout (MPLS LSP)

To enable lockout on a LSP, use the **lockout** command in LSP interface configuration mode. To disable lockout, use the **no** form of this command.

lockout

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values

Command Modes LSP interface configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	MPLS-TE	read, write

The following example shows how to enable lock on the working LSP:

```
RP/0/RP0RSP0/CPU0:router:hostname# config
RP/0/RP0RSP0/CPU0:router:hostname(config)# interface tunnel-tp 1
RP/0/RP0RSP0/CPU0:router:hostname(config-if)# working-lsp
RP/0/RP0RSP0/CPU0:router:hostname(config-if-slsp-work)# lockout
RP/0/RP0RSP0/CPU0:router:hostname(config-if-slsp-work)# commit
RP/0/RP0RSP0/CPU0:router:hostname(config-if-slsp-work)# no lockout
RP/0/RP0RSP0/CPU0:router:hostname(config-if-slsp-work)# commit
```

The following example shows how to enable lock on the protecting LSP:

```
RP/0/RP0RSP0/CPU0:router:hostname# config
RP/0/RP0RSP0/CPU0:router:hostname(config)# interface tunnel-tp 1
RP/0/RP0RSP0/CPU0:router:hostname(config-if)# protect-lsp
RP/0/RP0RSP0/CPU0:router:hostname(config-if-slsp-work)# lockout
RP/0/RP0RSP0/CPU0:router:hostname(config-if-slsp-work)# commit
```

node-id

To assign a node ID for each node, use the **Node-ID** command in MPLS-TP configuration mode. To remove the ID, use the **no** form of this command.

node-id address

Syntax Description	<i>address</i> Configures the IPv4 address for the MPLS-TP node ID.				
Command Default	No default behavior or values				
Command Modes	MPLS transport profile configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.2.0	This command was introduced.
Release	Modification				
4.2.0	This command was introduced.				
Usage Guidelines	The node ID is a 32-bit number represented in IPv4 address format, and can be optionally assigned to each node.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>MPLS-TE</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	MPLS-TE	read, write
Task ID	Operation				
MPLS-TE	read, write				

The following example shows how to define a node ID for the node:

```
RP/0/RP0RSP0/CPU0:router:hostname# config
RP/0/RP0RSP0/CPU0:router:hostname(config)# mpls traffic-eng
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te)# tp
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-tp)# node-id 10.1.1.1
RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-tp)# commit
```

alarm (MPLS)

To enable alarm, use the **alarm** command in MPLS-TP configuration mode. To disable alarm, use the **no** form of this command.

alarm {soak-time time | suppression disable}

Syntax Description	soak-time time Defines the time interval in seconds. Range is 0 to 10. suppression Suppresses the alarm that is configured. disable Disables the configured alarm.				
Command Default	None				
Command Modes	MPLS Transport Profile configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification				
Release 4.2.0	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>mpls-te</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	mpls-te	read, write
Task ID	Operation				
mpls-te	read, write				

This example shows how to disable alarm configured in MPLS-TP configuration mode:

```
conf
  mpls traffic-eng
    tp alarm
      suppression disable
```

bfd (MPLS)

To specify the minimum control packet interval for BFD sessions for the corresponding BFD configuration scope, use the **bfd** command in the MPLS-TP configuration mode. To return the router to the default setting, use the **no** form of this command.

```
bfd {min-interval {value | standby value} | multiplier {value | standby value}}
```

Syntax Description	min-interval <i>time</i> Specifies the rate, in seconds, at which BFD control packets are sent BFD peers. Range is 15 to 5000. standby <i>time</i> Specifies the minimum interval, in seconds, for a standby LSP. Range is 15 to 5000. multiplier <i>value</i> Specifies the number of consecutive BFD control packets that must be missed from a BFD peer before BFD declares that the peer is unavailable. Range is 2 to 10. standby <i>value</i> Specifies the multiplier for a standby LSP. Range is from 2 to 10.
---------------------------	---

Command Default The default value of minimum interval is 50 seconds.

The default value of multiplier is 3.

Command Modes MPLS Transport profile configuration

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
MPLS-TE	read, write	

Examples This example shows how to configure BFD parameters on a working LSP:

```
interface tunnel-tpl
  bfd
    min-interval 30 standby 300
    multiplier 3 standby 5
  !
!
```

bandwidth (MPLS)

To configure MPLS-TP bandwidth, use the **bandwidth** command in MPLS-TP configuration mode. To remove the configured bandwidth from the MPLS-TP mode, use the **no** form of this command.

bandwidth *kbps*

Syntax Description	<i>kbps</i> Number of kilobits per second set aside for the MPLS-TP tunnel. Range is 0 to 4294967295.
---------------------------	---

Command Default	The default bandwidth is 0.
------------------------	-----------------------------

Command Modes	MPLS Transport profile configuration
----------------------	--------------------------------------

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	MPLS-TE	read, write

Examples	This example shows how to configure bandwidth on a MPLS-TP tunnel:
-----------------	--

```
mpls traffic-eng
  tp mid midpt1
  tunnel-name tunnel-tpl1
    lsp-id 20
    fwd-lsp
    source 10.0.0.1 10 tunnel-id 20 bandwidth 500
    in-label 2000 out-label 2000 out-tp-link 1
  exit
  rev-lsp
  source 172.16.0.1 20 tunnel-id 30 bandwidth 500
  in-label 2000 out-label 3000 out-tp-link 1
exit
```

description

To give a descriptive name to a MPLS-TP tunnel, use the **description** command at MPLS-TP interface configuration mode.

description *line*

Syntax Description	<i>line</i> Describes the MPLS-TP tunnel.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	MPLS Transport Profile Interface configuration
----------------------	--

Command History	Release	Modification
	4.2.0	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	MPLS-TE	read, write

Examples	This example shows how to describe the MPLS-TP tunnel:
-----------------	--

```
interface tunnel-tpl1
description PE1_PE2
source 10.0.0.1
```

destination (MPLS)

To specify destination at a destination end point, use the **destination** command in MPLS-TP interface configuration mode.

destination node id global-id id tunnel-id id

Syntax Description	<p>node id Specifies node ID at a destination. It is a 32-bit number represented in IPv4 address format.</p> <p>Note The destination node ID do not have to be a routable IPv4 address.</p>				
	global-id id Specifies global ID at a destination end point. It is a 32-bit number.				
	tunnel-id id Specifies tunnel ID at the destination end point.				
Command Default	None				
Command Modes	MPLS Transport Profile Interface configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 4.2.0</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification				
Release 4.2.0	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operations</th></tr> </thead> <tbody> <tr> <td>MPLS-TE</td><td>read, write</td></tr> </tbody> </table>	Task ID	Operations	MPLS-TE	read, write
Task ID	Operations				
MPLS-TE	read, write				

Examples

This example shows how to configure various options at the destination end point:

```
interface tunnel-tp 2
  tunnel-name tunnell1
  source 10.1.1.1
  destination 2.2.2.2
  bandwidth 500
```

fast-protect

To enable MPLS-TP LSP wrapping, use the **fast-protect** command in MPLS-TP mode. To remove MPLS-TP LSP wrapping, use the **no** form of this command.

fast-protect

Syntax Description	This command has no keywords or arguments.	
Command Default	No default behavior or values.	
Command Modes	MPLS-TP configuration.	
Command History	Release	Modification
	Release 4.3.1	This command was introduced.
Usage Guidelines	To verify if MPLS-TP LSP wrapping is enabled, use the show run mpls traffic-eng tp mid command and check for fast-protect .	
Task ID	Task ID	Operations
	mpls-te	read, write
Examples	The following example shows how to enable LSP wrapping:	
<pre>RP/0/RP0RSP0/CPU0:router:hostname# configure RP/0/RP0RSP0/CPU0:router:hostname(config)#mpls traffic-eng tp mid midpt1 RP/0/RP0RSP0/CPU0:router:hostname(config-mpls-te-tp-mid)#fast-protect</pre>		
Related Commands	Command	Description
	mpls traffic-eng	
	show mpls forwarding	

mid

To specify the mid-point identifier for the MPLS-TP tunnel, use the **mid** command in MPLS-TP configuration mode.

mid name

Syntax Description	<i>name</i> Specifies the name of the mid-point identifier.	
Command Default	None	
Command Modes	MPLS Transport Profile configuration	
Command History	Release	Modification
	Release 4.2.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	MPLS-TE	read, write

Examples This example shows how to configure the mid point with various parameters:

```
mid tun_PE1_PE2_1_7_Protect
  lsp-number 1
  source 10.0.0.1 tunnel-id 1
  destination 172.16.0.1 tunnel-id 2
```

protect LSP

To configure the working LSP on a MPLS-TP tunnel, use the **protect-lsp** command in MPLS-TP interface configuration mode.

protect-lsp {in-label | lockout | lsp-number | out-label}

Syntax Description	in-label Specifies the incoming MPLS label.
	lockout Locks out the protecting LSP.
	lsp-number Specifies the LSP identifier.
	out-label Specifies the outgoing MPLS label.

Command Default	None
------------------------	------

Command Modes	MPLS Transport Profile Interface configuration
----------------------	--

Command History	Release	Modification
	4.2.0	This command was introduced.

Task ID	Task ID	Operations
	MPLS-TE	read, write

Examples	This example shows how to configure protecting LSP on a MPLS-TP tunnel:
-----------------	---

```
interface tunnel-tpl1
  description Router_1
  source 10.0.0.1
  destination 172.16.0.1
  working-lsp
    in-label 2000
    out-label 2000 out-link 1
  !
  protect-lsp
    in-label 3000
    out-label 3000 out-link 2
  !
!
```

working LSP

To configure the working LSP on a MPLS-TP tunnel, use the **working-lsp** command in MPLS-TP interface configuration mode.

working-lsp {in-label | lockout | lsp-number | out-label}

Syntax Description	in-label Specifies the incoming MPLS label. lockout Locks out the working LSP. lsp-number Specifies the LSP identifier. out-label Specifies the outgoing MPLS label.				
Command Default	None				
Command Modes	MPLS Transport Profile Interface configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>4.2.0</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	4.2.0	This command was introduced.
Release	Modification				
4.2.0	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operations</th></tr> </thead> <tbody> <tr> <td>MPLS-TE</td><td>read, write</td></tr> </tbody> </table>	Task ID	Operations	MPLS-TE	read, write
Task ID	Operations				
MPLS-TE	read, write				

Examples This example shows how to configure working LSP on a MPLS-TP tunnel:

```
interface tunnel-tp1
description Router_1
source 10.0.0.1
destination 172.16.0.1
  working-lsp
    in-label 2000
    out-label 2000 out-link 1
!
!
```

forward LSP

To configure LSP in forward direction, use the **forward-lsp** command in MPLS transport profile midpoint configuration mode.

forward-lsp bandwidth value in-label value out-label value out-tp-link value

Syntax Description	bandwidth <i>value</i>	Defines the bandwidth in kbps. The range is 0 to 4294967295.				
	in-label <i>value</i>	Defines the incoming local MPLS label.				
	out-label <i>value</i>	Defines the outgoing local MPLS label.				
	out-tp-link <i>value</i>	Defines the TP link ID of outgoing link.				
Command Default	None					
Command Modes	MPLS Transport Profile midpoint configuration					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>		Release	Modification	4.2.0	This command was introduced.
Release	Modification					
4.2.0	This command was introduced.					
Usage Guidelines	No specific guidelines impact the use of this command.					
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>MPLS-TP</td> <td>read, write</td> </tr> </tbody> </table>		Task ID	Operations	MPLS-TP	read, write
Task ID	Operations					
MPLS-TP	read, write					

Examples This sample shows an output from the **forward-lsp** command:

```
mpls traffic-eng
!
tp
mid work
lsp-number 0
source 10.0.0.1 tunnel-id 1
destination 4.4.4.4 tunnel-id 1
forward-lsp
in-label 2001 out-label 4001 out-link 3
!
reverse-lsp
in-label 2002 out-label 1001 out-link 1
!
mid protect
lsp-number 1
source 10.0.0.1 tunnel-id 1
```

forward LSP

```
destination 4.4.4.4 tunnel-id 1
forward-lsp
  in-label 2003 out-label 4002 out-link 4
!
reverse-lsp
  in-label 2004 out-label 1002 out-link 2
!
!
!
```

reverse LSP

To configure LSP in reverse direction, use the **reverse-lsp** command in MPLS transport profile midpoint configuration mode.

reverse-lsp bandwidth value in-label value out-label value out-tp-link value

Syntax Description	bandwidth value	Defines the bandwidth in kbps.				
	in-label value	Defines the incoming local MPLS label.				
	out-label value	Defines the outgoing local MPLS label.				
	out-tp-link value	Defines the TP link ID of outgoing link.				
Command Default	None					
Command Modes	MPLS Transport Profile midpoint configuration					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.2.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>		Release	Modification	4.2.0	This command was introduced.
Release	Modification					
4.2.0	This command was introduced.					
Usage Guidelines	No specific guidelines impact the use of this command.					
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>mpls-tp</td> <td>read, write</td> </tr> </tbody> </table>		Task ID	Operations	mpls-tp	read, write
Task ID	Operations					
mpls-tp	read, write					

Examples This sample shows an output from the **reverse-lsp** command:

```
mpls traffic-eng
!
tp
mid work
lsp-number 0
source 10.0.0.1 tunnel-id 1
destination 4.4.4.4 tunnel-id 1
forward-lsp
in-label 2001 out-label 4001 out-link 3
!
reverse-lsp
in-label 2002 out-label 1001 out-link 1
!
mid protect
lsp-number 1
source 10.0.0.1 tunnel-id 1
```

reverse LSP

```
destination 4.4.4.4 tunnel-id 1
forward-lsp
  in-label 2003 out-label 4002 out-link 4
!
reverse-lsp
  in-label 2004 out-label 1002 out-link 2
!
!
!
```