



Cisco Catalyst Wireless Gateway Software Configuration Guide

First Published: 2022-09-29

Last Modified: 2023-11-10

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2022 –2023 Cisco Systems, Inc. All rights reserved.



CONTENTS

Full Cisco Trademarks with Software License ?

CHAPTER 1

Manage Cisco Catalyst Wireless Gateways Using Cisco SD-WAN Manager	1
Manage Cisco Catalyst Wireless Gateways Using Cisco SD-WAN Manager	2
Information About Managing Cisco Catalyst Wireless Gateways	3
Benefits of Managing a Cisco Catalyst Wireless Gateway Using Cisco SD-WAN Manager	4
Information About IPv6 Support	4
Supported Cisco Catalyst Wireless Gateways	4
Prerequisites for Managing Cisco Catalyst Wireless Gateways	4
Restrictions for Managing Cisco Catalyst Wireless Gateways	5
Use Cases for Managing Cisco Catalyst Wireless Gateways	6
Configure Cisco Catalyst Wireless Gateway Devices Using a Workflow in Cisco SD-WAN Manager	6
Configure Cisco Catalyst Wireless Gateways Using Configuration Groups in Cisco SD-WAN Manager	19
Edit a Configuration Group	22
Add Devices to a Configuration Group	23
Add Devices to a Configuration Group Manually	23
Add Devices to a Configuration Group Using Rules	24
Deploy the Configuration Group to Devices	25
Verify the Configuration of Cisco Catalyst Wireless Gateways	25
Monitor Cisco Catalyst Wireless Gateways	25

CHAPTER 2

System Logs	27
System Logs	27
Information About System Logs	27
Prerequisites for Saving System Logs	28

Restrictions for Saving System Logs 28
Configure a Device to Save System Logs 28

CHAPTER 3

Prioritization of Corporate Traffic (QoS) 33
Prioritization of Corporate Traffic (QoS) 33
Information About the Prioritization of Corporate Traffic (QoS) 33
Configure Prioritization of Corporate Traffic (QoS) 33

APPENDIX A

Additional References 35
Additional References 35



CHAPTER 1

Manage Cisco Catalyst Wireless Gateways Using Cisco SD-WAN Manager



Note To achieve simplification and consistency, the Cisco SD-WAN solution has been rebranded as Cisco Catalyst SD-WAN. In addition, from Cisco IOS XE SD-WAN Release 17.12.1a and Cisco Catalyst SD-WAN Release 20.12.1, the following component changes are applicable: **Cisco vManage** to **Cisco Catalyst SD-WAN Manager**, **Cisco vAnalytics** to **Cisco Catalyst SD-WAN Analytics**, **Cisco vBond** to **Cisco Catalyst SD-WAN Validator**, and **Cisco vSmart** to **Cisco Catalyst SD-WAN Controller**. See the latest Release Notes for a comprehensive list of all the component brand name changes. While we transition to the new names, some inconsistencies might be present in the documentation set because of a phased approach to the user interface updates of the software product.

- [Manage Cisco Catalyst Wireless Gateways Using Cisco SD-WAN Manager, on page 2](#)
- [Information About Managing Cisco Catalyst Wireless Gateways, on page 3](#)
- [Supported Cisco Catalyst Wireless Gateways, on page 4](#)
- [Prerequisites for Managing Cisco Catalyst Wireless Gateways, on page 4](#)
- [Restrictions for Managing Cisco Catalyst Wireless Gateways, on page 5](#)
- [Use Cases for Managing Cisco Catalyst Wireless Gateways, on page 6](#)
- [Configure Cisco Catalyst Wireless Gateway Devices Using a Workflow in Cisco SD-WAN Manager, on page 6](#)
- [Configure Cisco Catalyst Wireless Gateways Using Configuration Groups in Cisco SD-WAN Manager, on page 19](#)
- [Verify the Configuration of Cisco Catalyst Wireless Gateways, on page 25](#)
- [Monitor Cisco Catalyst Wireless Gateways, on page 25](#)

Manage Cisco Catalyst Wireless Gateways Using Cisco SD-WAN Manager

Table 1: Feature History

Feature Name	Release Information	Description
Manage Cisco Catalyst Wireless Gateways Using Cisco SD-WAN Manager	Cisco vManage: Cisco vManage Release 20.9.1.1 Device: Cisco IOS CG Release 17.9.1a	You can use Cisco SD-WAN Manager to configure Cisco Catalyst Wireless Gateways. Cisco SD-WAN Manager provides a step-by-step workflow for creating a configuration that you can apply to one or more devices. This configuration is stored as a configuration group. After you create a configuration group, you can perform a variety of tasks, including editing the configuration group, associating devices with it, and deploying the configuration group to its associated devices.
Support for Cisco Catalyst SD-WAN Remote Access VPN	Cisco Catalyst SD-WAN Control Components Release 20.11.1 Cisco IOS CG Release 17.11.1	Cisco Catalyst Wireless Gateways support VPN connectivity with Cisco Catalyst SD-WAN Remote Access servers. From this release, the default configuration of VPN connectivity is for a Cisco Catalyst SD-WAN Remote Access headend, but a Static Settings option is available for configuring devices using Cisco IOS CG Releases 17.9.x or 17.10.x.
Tunnel Redundancy	Cisco vManage Release 20.11.1 Cisco IOS CG Release 17.11.1	You can configure a secondary remote access server IP address or fully qualified domain name (FQDN), as a failover option in case the primary remote access server becomes unavailable.
Support for Additional Cipher Suites	Cisco vManage Release 20.11.1 Cisco IOS CG Release 17.11.1	You can configure the specific cipher suite to use for VPN encryption, if required by the VPN service. This is considered an advanced option and is available through the configuration group that you create for configuring Cisco Catalyst Wireless Gateways.
Support for Corporate Wired LAN	Cisco vManage Release 20.11.1 Cisco IOS CG Release 17.11.1	You can connect a corporate device, such as a corporate laptop, to a wired Ethernet connection on the Cisco Catalyst Wireless Gateway.
IPv6 Support	Cisco Catalyst SD-WAN Manager Release 20.12.1 Cisco IOS CG Release 17.12.1	Added support for IPv4 and IPv6 addressing through wired Ethernet or cellular internet connectivity.

Information About Managing Cisco Catalyst Wireless Gateways

Cisco Catalyst Wireless Gateways extend the enterprise network to remote workers. Connectivity is as follows:

- The Cisco Catalyst Wireless Gateway CG113-W6 accesses the internet using a wired WAN connection at a remote site.
- The Cisco Catalyst Wireless Gateway CG113-4GW6 accesses the internet using a wired WAN connection at a remote site or using a cellular link. The device supports two SIM cards: one active, and one on standby. If the wired WAN connection fails, the device fails over to the cellular link to ensure internet connectivity.

If more than one connection is available, the Cisco Catalyst Wireless Gateway CG113-4GW6 applies the following connection priority:

1. Ethernet WAN connection
2. Cellular connection using the SIM slot configured as primary
3. Cellular connection using the SIM slot configured as secondary



Note The device has a single cellular connection. Only one SIM can be active at a given time. You can configure which of the two SIM slots serves as primary and which serves as secondary (failover). See the information about cellular settings in [Configure Cisco Catalyst Wireless Gateway Devices Using a Workflow in Cisco SD-WAN Manager, on page 6](#) for details.

Cisco Catalyst Wireless Gateways provide numerous advantages to the remote worker, including the following:

- Hardware-based stable connectivity to an enterprise VPN
- Optimized network performance with Wi-Fi 6
- Cellular network connectivity, in supporting models, providing a cellular internet connection (with one active and one standby SIM) for uninterrupted internet connectivity
- Separate service set identifiers (SSIDs) for connecting work and personal devices

Managing Cisco Catalyst Wireless Gateways

Use Cisco SD-WAN Manager to configure and manage Cisco Catalyst Wireless Gateways. Cisco SD-WAN Manager provides a convenient workflow for configuring Wi-Fi, cellular, VPN, and other functionality. Cisco SD-WAN Manager also provides methods for monitoring device performance.

Secure Communication with Devices through a vmanage-admin Account

Cisco SD-WAN Manager communicates with devices, such as Cisco Catalyst Wireless Gateway, using a secure channel—either a datagram transport layer security (DTLS) tunnel or transport layer security (TLS) tunnel. Within this secure channel, it communicates with the devices or controllers using the NETCONF protocol, within an SSH session. It uses an internal-use-only passwordless "vmanage-admin" user account on the device or controller. The vmanage-admin account is created during the initial device setup. Cisco SD-WAN Manager uses this secure channel for monitoring, configuring, and managing devices.

As noted, the vmanage-admin user accounts do not have any password associated with them, so Cisco SD-WAN Manager uses a passwordless procedure to log in to the account. To accomplish this, Cisco SD-WAN Manager generates an asymmetric encryption public-private key pair. During deployment of a device, Cisco SD-WAN Manager copies the public key that it has generated to the device. It sends the public key using a proprietary protocol, within a secure channel—a DTLS or TLS tunnel.

The activity that Cisco SD-WAN Manager performs using the vmanage-admin account appears in syslog messages and in the output of certain show commands. The syslog messages are logged with the same level of detail as activities performed through any other user account. The level of syslog detail depends on the syslog configuration of the device.

Cisco SD-WAN Manager requires the vmanage-admin account on devices in order to monitor, configure, and manage the devices. Removing, disabling, or altering this account on a device would prevent Cisco SD-WAN Manager from performing these activities, and is not supported.

Benefits of Managing a Cisco Catalyst Wireless Gateway Using Cisco SD-WAN Manager

- Streamlined workflow for device configuration.
- The Cisco Catalyst Wireless Gateways appear in Cisco SD-WAN Manager together with all of the devices in the Cisco Catalyst SD-WAN overlay, enabling you to view device status for Cisco Catalyst Wireless Gateways as with other devices in the network.
- You can download software updates for Cisco Catalyst Wireless Gateways (from the [Cisco Software Download](#) site), add them to the Cisco SD-WAN Manager software repository, and update the devices using the same method as for other devices managed by Cisco SD-WAN Manager.

Information About IPv6 Support

Minimum software releases: Cisco Catalyst SD-WAN Manager Release 20.12.1, Cisco IOS CG Release 17.12.1

Cisco Catalyst Wireless Gateways support IPv6 addressing through wired WAN Ethernet or cellular internet connectivity. When you configure IPv6 support, the device requests an IPv6 prefix from the internet gateway (wired or cellular). The device uses the IPv6 prefix to provide IPv6 addresses to clients connected to the device.

Supported Cisco Catalyst Wireless Gateways

- Cisco Catalyst Wireless Gateway CG113-W6 (Cisco CG113-W6)
- Cisco Catalyst Wireless Gateway CG113-4GW6 (Cisco CG113-4GW6)

Prerequisites for Managing Cisco Catalyst Wireless Gateways

- Onboarding: Cisco Catalyst Wireless Gateways use the Plug and Play onboarding method, which requires a Cisco Smart Account.

- For devices in a Smart Account to appear in the device list in Cisco SD-WAN Manager, synchronize Cisco SD-WAN Manager with the Smart Account.
- After the Plug and Play onboarding steps add the Cisco Catalyst Wireless Gateways to the device list in Cisco SD-WAN Manager, use the Quick Connect workflow to provide the devices with connectivity to Cisco SD-WAN Manager. For information about the [Quick Connect Workflow](#), see the *Cisco Catalyst SD-WAN Getting Started Guide*.
- Configuring cellular connectivity for Cisco Catalyst Wireless Gateways requires the connection details provided by the cellular service(s), such as the access point name (APN), and so on. For the device to use the configuration, the device requires an active SIM.

Restrictions for Managing Cisco Catalyst Wireless Gateways

Table 2: Restrictions

Restriction	Description
No local configuration	All configuration of a Cisco Catalyst Wireless Gateway is managed centrally using Cisco SD-WAN Manager. The remote user does not perform any configuration functions for the device.
Wired connection for corporate VPN	You can configure an SSID for Wi-Fi connectivity to a corporate VPN. However, it is not possible to configure one of the LAN interfaces on the device to provide a wired connection for corporate VPN.
Maximum number of Wi-Fi clients	Maximum number of Wi-Fi clients that can connect to the device: 125
Static virtual tunnel interface (SVTI)	Static virtual tunnel interface (SVTI) VPN solutions are not supported.

Table 3: Supported VPN Solutions

Releases	Supported VPN Solutions	Configuration Requirements
Cisco SD-WAN Manager: Cisco vManage Release 20.9.x Cisco vManage Release 20.10.x Cisco Catalyst Wireless Gateway: Cisco IOS Release CG 17.9.x Cisco IOS Release CG 17.10.x	FlexVPN	<ul style="list-style-type: none"> • Local private subnet • Remote private subnets
Cisco SD-WAN Manager: Cisco vManage Release 20.11.1 or later Cisco Catalyst Wireless Gateway: Cisco IOS CG Release 17.11.1 or later	Cisco Catalyst SD-WAN Remote Access (SD-WAN RA) FlexVPN	Use the dynamic option instead of configuring static subnets.

Use Cases for Managing Cisco Catalyst Wireless Gateways

An organization with a large number of remote workers provides a Cisco Catalyst Wireless Gateway device to each remote worker. Optionally, the organization may purchase a cellular data plan for each device to provide a cellular network backup for internet connectivity.

The organization purchases the devices using the Cisco Commerce portal. When the devices are shipped, they appear in the organization's Cisco Smart Account. The network administrator synchronizes Cisco SD-WAN Manager with the Cisco Smart Account so that the purchased devices appear in the Cisco SD-WAN Manager device list.



Note The Quick Connect workflow available in Cisco SD-WAN Manager automatically synchronizes Cisco SD-WAN Manager with the Cisco Smart Account. For information about the [Quick Connect Workflow](#), see the *Cisco Catalyst SD-WAN Getting Started Guide*.

Using Cisco SD-WAN Manager, the network administrator configures connectivity for each device, which may include connectivity to the organization's VPN, Wi-Fi, cellular, and other configuration details. The network administrator can create different configurations to apply to different Cisco Catalyst Wireless Gateway devices.

After the network administrator applies a configuration to Cisco Catalyst Wireless Gateway devices, Cisco SD-WAN Manager periodically checks whether the specified devices are reachable. When the devices are reachable, Cisco SD-WAN Manager applies the configuration to them.

After receiving a Cisco Catalyst Wireless Gateway, a remote worker connects it to home internet. The remote worker does not perform any configuration directly on the device, as all configuration tasks are handled by the network administrator.

The remote worker uses the SSID designated for corporate use to connect work devices, such as a work laptop. Using a non-corporate SSID, the remote worker can also use the Cisco Catalyst Wireless Gateway as an access point for non-corporate personal internet connectivity.

Configure Cisco Catalyst Wireless Gateway Devices Using a Workflow in Cisco SD-WAN Manager

Before You Begin

Cisco SD-WAN Manager workflows are a streamlined method of creating a configuration, with step-by-step instructions. This procedure uses the following workflows to create a configuration group for Cisco Catalyst Wireless Gateways, and to apply the configuration group to devices:

- Configure Teleworker Devices workflow

This workflow is required. It creates a configuration group, and enables you to configure settings for ethernet, cellular connectivity, VPN, Wi-Fi, DHCP, and so on.

- Add Devices to Configuration Group workflow

This workflow is optional.

- Deploy Configuration Group workflow

This workflow is optional.

After using the workflow to create a configuration group, you can edit, copy, or delete the resulting configuration group. For information, see [Configure Cisco Catalyst Wireless Gateways Using Configuration Groups in Cisco SD-WAN Manager, on page 19](#).

In addition, the Configure Teleworker Devices workflow does not address a few types of advanced configuration, such as advanced Wi-Fi radio settings and security policy. Configuring these requires editing the configuration group.

Configure Cisco Catalyst Wireless Gateways Using a Workflow

1. From the Cisco SD-WAN Manager menu, choose **Workflows > Workflow Library**.
2. Do one of the following:
 - To create a new configuration, click **Configure Teleworker Devices**. A workflow page opens, showing the steps included in the workflow.
 - To return to an incomplete configuration that you saved earlier, click a workflow in the **In Progress** list.
3. Click **Let's Do It** to begin (or resume) the **Configure Teleworker** configuration workflow.
4. On the **Process Overview** page, click **Next** to begin.



Note On the workflow pages that follow, you can click **Exit** at any time. Cisco SD-WAN Manager saves the steps that you have configured as an in-progress workflow, and you can return to the workflow later.

5. On the workflow pages that follow, enter the following information.

Table 4: Workflow Page: Give Your Teleworker Configuration Group a Name

Settings	Configuration Details
Name and description	Name and description of the configuration group. After you create a configuration group, you can apply it to one or more devices.

Table 5: Workflow Page: Configure WAN Connectivity

Settings	Configuration Details
Username and password	The username for logging in to the console by SSH terminal, using Cisco SD-WAN Manager, is preset to admin . Set a password.

Settings	Configuration Details
Ethernet settings	<p>If you need to change from the default ethernet settings, configure the settings for the three interfaces on the Cisco Catalyst Wireless Gateway.</p> <ul style="list-style-type: none"> • GigabitEthernet 0/0: In Port Type, choose WAN or LAN port type, and the IP assignment type. <ul style="list-style-type: none"> • WAN option: <ul style="list-style-type: none"> • In the IPv4 Assignment field, choose Dynamic or Static IP assignment. If you choose Static, then configure the static IP address, subnet mask, and gateway IP address. • (Optional) (Minimum software releases: Cisco Catalyst SD-WAN Manager Release 20.12.1, Cisco IOS CG Release 17.12.1) In the IPv6 Assignment field, you can choose None to not support IPv6 addressing, or choose AutoConfig-SLAC to automatically support IPv4 addressing, IPv6 addressing, or both, according to what the internet provider supports. • LAN option: <p>Choose to enable or disable the Admin State option, which determines whether the port is active.</p> • GigabitEthernet 0/1: The port type is fixed as LAN. Use the Admin State option to enable or disable the port. • GigabitEthernet 0/2: The port type is fixed as LAN. Use the Admin State option to enable or disable the port.

Settings	Configuration Details
Cellular settings	<p data-bbox="724 291 1463 321">Primary SIM Slot: Choose SIM 0 or SIM 1 as the primary SIM slot.</p> <p data-bbox="724 338 1523 399">If you have installed only one SIM, then choose the slot in which you installed the SIM.</p> <p data-bbox="724 428 997 457">Template Configuration</p> <p data-bbox="724 474 1523 535">For the primary SIM slot, and optionally for the standby SIM slot, configure the following:</p> <ul data-bbox="760 554 1523 1318" style="list-style-type: none"> <li data-bbox="760 554 1523 646">• Carrier Name: Enter a name for the cellular carrier, and choose a carrier profile and data profile (data service details) using the two options that follow. <li data-bbox="760 667 1523 856">• Attach Profile: Click the drop-down list and select an existing profile, or click Create Profile to create a new carrier profile. For each carrier, you can create up to 16 carrier profiles, providing a profile ID number in the range 1 to 16. Creating a profile requires entering information that you receive from your cellular service provider, including the information in the following fields: <ul data-bbox="808 877 1523 1318" style="list-style-type: none"> <li data-bbox="808 877 1029 907">• Access point name <li data-bbox="808 928 1523 989">• Packet data network type: Choose IPv4 for a cellular service that supports only IPv4 addressing. (Minimum software releases: Cisco Catalyst SD-WAN Manager Release 20.12.1, Cisco IOS CG Release 17.12.1) You can choose IPv6 for a cellular service that supports only IPv6 addressing or IPv4v6 for a cellular service that supports IPv4 and IPv6 addressing. <li data-bbox="808 1184 1073 1213">• Authentication method <li data-bbox="808 1234 943 1264">• User name <li data-bbox="808 1285 1008 1314">• Profile password <p data-bbox="776 1352 1338 1381">After you enter the profile details, click Add Profile.</p> <ul data-bbox="760 1402 1523 1562" style="list-style-type: none"> <li data-bbox="760 1402 1523 1562">• Data Profile: Configure the service data plan similarly to the Create Profile option described above. Click the drop-down list and select an existing profile, or click Create Profile to create a new profile. You can create up to 16 carrier profiles, providing a profile ID number in the range 1 to 16. <p data-bbox="776 1583 1523 1675">Note Some carriers require you to configure the attach profile and the data profile identically. Other carriers use different parameters for the two. Check with your carrier for details.</p> <p data-bbox="776 1709 1523 1801">Note You can create 16 profiles for the Attach Profile and 16 for the Data Profile. These are two separate sets of profiles.</p>

Table 6: Workflow Page: Configure VPN, Wi-Fi and DHCP Settings, Cisco vManage Release 20.11.1 and Cisco Catalyst SD-WAN Manager Release 20.12.1 and Later

Settings	Configuration Details
Note	This table applies only to Cisco vManage Release 20.11.1 and to Cisco Catalyst SD-WAN Manager Release 20.12.1 and later releases. If you are using Cisco vManage Releases 20.9.x and 20.10.x, see the table that follows this one.

Settings	Configuration Details
VPN and corporate Wi-Fi settings	<p data-bbox="724 289 922 321">Before You Begin</p> <ul style="list-style-type: none"> <li data-bbox="760 338 1013 369">• Hardware VPN client: <p data-bbox="776 386 1523 541">You can connect the Cisco Catalyst Wireless Gateway to your organization's VPN server as a hardware VPN client. A remote worker using the wireless gateway to connect to an organization does not require a software-based VPN client. To configure this connection, use the VPN details provided by the organization.</p> <li data-bbox="760 564 1101 596">• Supported terminating routers: <p data-bbox="776 613 1495 705">For information about supported terminating routers for VPN connections, see Restrictions for Managing Cisco Catalyst Wireless Gateways, on page 5.</p> <li data-bbox="760 728 932 760">• VPN headend: <p data-bbox="776 777 1523 1024">By default, the VPN configuration options shown on this page configure a device to connect to a Cisco SD-WAN Remote Access headend or other VPN headend. In this case, you do not configure a DNS server, remote private subnets, or the local private subnet. The Cisco SD-WAN Remote Access headend, or other VPN headend, manages these for each client. The remote access headend pushes the DNS server, remote private subnets, and local private subnet information to clients when they connect, as defined by policy on the remote access headend device.</p> <li data-bbox="760 1050 1029 1081">• Dynamic VPN settings: <p data-bbox="776 1098 1523 1253">If you create a configuration group that uses dynamic VPN settings and apply the group to a Cisco Catalyst Wireless Gateway using a release of Cisco IOS CG earlier than Release 17.11.1, Cisco SD-WAN Manager will successfully apply the configuration group to the device, but the VPN tunnel will not be established.</p> <li data-bbox="760 1276 932 1308">• Static settings: <p data-bbox="776 1325 1523 1417">If you are configuring a Cisco Catalyst Wireless Gateway using software earlier than Cisco IOS CG Release 17.11.1, use the Static Settings option described below.</p>

Settings	Configuration Details
	<ul style="list-style-type: none"> • Do not configure Virtual Private Network (VPN) and Corporate Wi-Fi settings: If you do not want to configure VPN settings, check this check box. • Description: Enter a description for the remote access VPN configuration. • Local Interface drop-down list: Choose one of the following: <ul style="list-style-type: none"> • GigabitEthernet0/0 (if using Ethernet as the primary mode of connecting to the internet) • Cellular1/0 (if using a cellular connection as the primary mode of connecting to the internet) • Primary Remote Public IP/FQDN: Consult with your organization's network administrator for the correct value, based on what is configured on the VPN headend device. • Pre-Shared Secret: Consult with your organization's network administrator for the correct value, based on what is configured on the VPN headend device.

Settings	Configuration Details
	<p>Redundancy Settings: Check this check box to specify a secondary IP address for the VPN headend. The device uses this address if the primary tunnel becomes unavailable. The following fields appear:</p> <ul style="list-style-type: none"> • Secondary Remote Public IP/FQDN: Consult with your organization's network administrator for the correct value, based on what is configured on the VPN headend. • DPD Interval: If the VPN tunnel fails, the dead peer detection (DPD) interval provides a factor for calculating the number of seconds to wait before attempting to reconnect. Range: 10 to 300 seconds • DPD Retries: Specifies the number of times the device attempts to reconnect. Range: 1 to 10 <p>The device uses the DPD interval and DPD retries values to determine how many times, and at what time intervals, it attempts to reconnect to the primary VPN headend. During its attempts to reconnect to the VPN headend, the device waits increasingly long intervals before trying to reconnect. If the device cannot reconnect, it fails over to the secondary IP address and attempts to connect to the remote access headend at that address.</p> <p>Simply put, the device attempts $DPD_Retries + 1$ times, with increasing intervals beginning at $DPD_interval$ seconds. More specifically, each subsequent interval (seconds) grows as follows:</p> $interval_n = DPD_interval * interval_factor$ <p>where $interval_factor$ grows from 1 for $n=1$, 1.8 for $n=2$, 3.24 for $n=3$, ... until it reaches the maximum of 357 for $n=10$.</p> <p>For example, if the $DPD_interval$ is 4 seconds, then the intervals begin with 4 seconds, then 7, 13, 23, and 42 seconds, and so on.</p> <p>Static Settings: Check this check box if you are configuring a Cisco Catalyst Wireless Gateway using Cisco IOS CG Release 17.9.x or 17.10.x. The following fields appear:</p> <ul style="list-style-type: none"> • DNS Address: Enter the address of the corporate DNS server. • Remote Private Subnets Configuration: Enter one or more remote private subnets in classless inter-domain routing (CIDR) format, separated by commas. This enables access to services and applications within the subnets at the remote site. Example: 192.168.0.0/16, 192.0.2.0/24 • Local Private Subnet: The local private subnet must be unique for each device to which you apply this configuration. To accommodate this, the field is prepopulated by the local-private-subnet variable. A later page in the workflow (Add and Review Device Configuration) enables you to configure the local private subnet for each individual device.

Settings	Configuration Details
	<p>Enable Corporate Wi-Fi: Check this check box to configure a Wi-Fi network to connect devices to your organization's network—for example, for your corporate laptop.</p> <ul style="list-style-type: none"> • SSID: The default service set identifier (SSID) is Cisco-Teleworker, but you can enter a different SSID. • WLAN Security: Choose the security method, such as Wi-Fi protected access 2 Enterprise (WPA2-Enterprise), which is the default, or WPA2 pre-shared key (WPA2-PSK). <p>If you choose WPA2-Enterprise security, the AAA Radius Server fields (Name, Port, IP Address, and Secret) appear. For information about what to enter in the RADIUS server fields, consult with your organization's network administrator.</p> <ul style="list-style-type: none"> • Broadcast SSID: Enable (default) or disable. <p>Enable Corporate LAN: Check this check box to configure a RADIUS server for wired corporate LAN, using the GigabitEthernet0/1 port, which is the middle port on the device. The AAA Radius Server fields (Name, Port, IP Address, and Secret) appear. For information about what to enter in the RADIUS server fields, consult with your organization's network administrator.</p> <p>The same RADIUS server configuration is used for corporate LAN and for the WPA2-Enterprise security option described in the WLAN Security section for corporate Wi-Fi, in this documentation.</p> <p>Note On devices that you connect to the corporate LAN, enable 802.1x authentication.</p>
Home Wi-Fi settings	<p>SSID 1 segment: Configure the Wi-Fi settings according to the needs of the remote worker using the device.</p> <ul style="list-style-type: none"> • SSID: The default service set identifier (SSID) is Cisco-Teleworker, but you can enter a different SSID. • WLAN Security: Choose the security method, such as Wi-Fi protected access 2 with pre-shared key (WPA2-PSK). • WLAN QoS Setting: You can use the default Best Effort option, or choose an option from the drop-down list to prioritize a specific type of traffic, such as video or voice traffic. • Broadcast SSID: Enable or disable. • WPA PSK Key: For SSID 1, this field is not configurable. Enter the WPA PSK Key in a later step, on the Add and Review Device Configuration page. If you add more SSIDs, as described below, this field is configurable for SSIDs 2, 3, and so on. <p>You can click the plus icon near the SSID 1 segment to add additional SSID's, with a maximum of four SSID's for home Wi-Fi.</p>

Settings	Configuration Details
Dynamic Host Configuration Protocol (DHCP) settings	<p>To configure DHCP, uncheck the Do not configure Dynamic Host Configuration Protocol (DHCP) settings check box.</p> <p>DHCP Pool area: You can configure the device as a DHCP server to provide IP addresses to devices that connect to the Cisco Catalyst Wireless Gateway. This requires configuring a DHCP pool and lease time.</p> <p>DNS Settings area: You can configure the device to use the default Domain Name System (DNS) server or you can specify a custom DNS server.</p> <p>NTP Settings area: You can configure the device to use the default Network Time Protocol (NTP) server or you can specify a custom NTP server.</p>

Table 7: Workflow Page: Configure VPN, Wi-Fi and DHCP Settings, Cisco vManage Releases 20.9.x and 20.10.x

Settings	Configuration Details
Note	This table applies only to Cisco SD-WAN Manager Releases 20.9.x and 20.10.x. If you are using Cisco vManage Release 20.11.1 or later releases, see the table that precedes this one.

Settings	Configuration Details
VPN and corporate Wi-Fi settings	<p data-bbox="683 289 883 321">Before You Begin</p> <p data-bbox="683 338 1479 428">For information about supported terminating routers for VPN connections, see Restrictions for Managing Cisco Catalyst Wireless Gateways, on page 5.</p> <p data-bbox="683 457 930 489">Site-to-Site VPN area:</p> <p data-bbox="683 506 1479 569">If you do not want to configure these settings, check the Do not configure Virtual Private Network (VPN) and Corporate Wi-Fi settings check box.</p> <p data-bbox="683 585 1479 711">You can connect the Cisco Catalyst Wireless Gateway to your organization's VPN headend as a hardware VPN client. A remote worker using the device to connect to an organization does not require a software-based VPN client. To configure this, use the VPN details provided by the organization.</p> <ul data-bbox="721 728 1479 1759" style="list-style-type: none"> <li data-bbox="721 728 1333 760">• Name: This field is preconfigured. No input is required. <li data-bbox="721 779 1479 869">• Pre-Shared Secret: Consult with your organization's network administrator for the correct value, based on what is configured on the VPN headend server. <li data-bbox="721 888 1479 978">• Remote Public IP: Consult with your organization's network administrator for the correct value, based on what is configured on the VPN headend server. <li data-bbox="721 997 1398 1029">• DNS Address: Enter the address of the corporate DNS server. <li data-bbox="721 1050 1479 1255">• Local Interface: Enter one of the following: <ul style="list-style-type: none"> <li data-bbox="773 1108 1458 1171">• GigabitEthernet0/0 (if using Ethernet as the primary mode of connecting to the internet) <li data-bbox="773 1190 1468 1253">• Cellular1/0 (if using a cellular connection as the primary mode of connecting to the internet) <li data-bbox="721 1291 1479 1444">• Local Private Subnet: This field is not configurable. The local private subnet must be unique for each device to which you apply this configuration. A later page in the workflow (Add and Review Device Configuration) enables you to configure the local private subnet for each device individually. <li data-bbox="721 1470 1479 1759">• Remote Private Subnets Configuration: Do one or both of the following: <ul style="list-style-type: none"> <li data-bbox="773 1549 1468 1640">• Click the drop-down list and choose one or more remote private subnets. This enables access to services and applications within the subnets at the remote site. <li data-bbox="773 1659 1468 1759">• To add a new subnet to the list, click Add New Remote Private Subnets and enter the subnet in classless inter-domain routing (CIDR) format. <p data-bbox="789 1776 1057 1808">Example: 192.168.0.1/24</p>

Settings	Configuration Details
	<p>Enable Corporate Wi-Fi check box: Check this check box to configure a Wi-Fi network to use to connect devices to your organization's network—for example, for your corporate laptop.</p> <ul style="list-style-type: none"> • SSID: The default service set identifier (SSID) is Cisco-Teleworker, but you can enter a different SSID. • WLAN Security: Choose the security method, such as Wi-Fi protected access 2 Enterprise (WPA2-Enterprise), which is the default, or WPA2 pre-shared key (WPA2-PSK). • Broadcast SSID: Enable (default) or disable. <p>The WLAN Security option is configured to WPA2-Enterprise. For information about what to enter in the RADIUS server fields (Port, Host IP Address, and Secret), consult with your organization's network administrator.</p>
Home Wi-Fi settings	<p>SSID 1 segment: Configure the Wi-Fi settings according to the needs of the remote worker using the device.</p> <ul style="list-style-type: none"> • SSID: The default service set identifier (SSID) is Cisco-Teleworker, but you can enter a different SSID. • WLAN Security: Choose the security method, such as Wi-Fi protected access 2 with pre-shared key (WPA2-PSK). • WLAN QoS Setting: You can use the default Best Effort option, or choose an option from the drop-down list to prioritize a specific type of traffic, such as video or voice traffic. • Broadcast SSID: Enable or disable. • WPA PSK Key: For SSID 1, this field is not configurable. Enter the WPA PSK Key in a later step, on the Add and Review Device Configuration page. If you add more SSIDs, as described below, this field is configurable for SSIDs 2, 3, and so on. <p>You can click the plus icon near the SSID 1 segment to add additional SSIDs, with a maximum of four SSID's for home Wi-Fi.</p>
Dynamic Host Configuration Protocol (DHCP) settings	<p>To configure DHCP, uncheck the Do not configure Dynamic Host Configuration Protocol (DHCP) settings check box.</p> <p>DHCP Pool area: You can configure the device as a DHCP server to provide IP addresses to devices that connect to the Cisco Catalyst Wireless Gateway. This requires configuring a DHCP pool and lease time.</p> <p>DNS Settings area: You can configure the device to use the default Domain Name System (DNS) server or you can specify a custom DNS server.</p> <p>NTP Settings area: You can configure the device to use the default Network Time Protocol (NTP) server or you can specify a custom NTP server.</p>

6. After configuring the details described in the preceding tables, the workflow presents a summary of the configuration. You can view and edit the configuration as needed.
7. Click **Create Configuration Group**.
The result is a new configuration group, with the name you provided and the settings that you configured in the workflow.
8. You can click **Associate Devices** to associate the new configuration group with specific devices, or you can click **No, I Will Do It Later** to skip this step and not associate any devices until later. For information about associating devices, see [Add Devices to a Configuration Group Manually, on page 23](#).



Note If there are devices listed in your Smart Account that are not in the device list in Cisco SD-WAN Manager, synchronize Cisco SD-WAN Manager with the Smart Account. From the Cisco SD-WAN Manager menu, choose **Configure > Devices** and click **Sync Smart Account**.

The Quick Connect workflow available in Cisco SD-WAN Manager automatically synchronizes Cisco SD-WAN Manager with the Cisco Smart Account. For information about the [Quick Connect Workflow](#), see the *Cisco Catalyst SD-WAN Getting Started Guide*.

9. If you chose to associate devices, the **Add Devices to Configuration Group** workflow begins.
 - a. On the **Process Overview** page, click **Next**.
 - b. On the **Choose Devices** page, choose one or more devices to associate with the configuration group, and click **Next**.
A **Summary** page shows the devices that you have chosen to associate with the configuration group.
 - c. On the **Summary** page, click **Save**.
10. You can click **Provision Devices** to push the configuration group to the associated devices, or you can click **No, I will Do It Later** to skip this step.
11. If you chose to provision devices, the **Deploy Configuration Group** workflow begins.
 - a. On the **Process Overview** page, click **Next**.
 - b. The **Select Devices to Deploy** page shows the associated devices. Choose the devices that you want to push the configuration group to, and click **Next**.
 - c. The **Add and Review Device Configuration** page shows a list of the devices that you selected in a previous step, to which you are applying the configuration. Click a device to show its device-specific information. Some fields are prepopulated with information assigned to the device during onboarding, using the Quick Connect workflow. See [Prerequisites for Managing Cisco Catalyst Wireless Gateways, on page 4](#).
 - **Site Id**: The site ID assigned to the device during onboarding.
 - **System IP**: An IP address assigned to the device during onboarding, for communication with Cisco SD-WAN Manager. The address must be unique for each device. Example: 10.0.0.1
 - **Rollback Timer (sec)**: When you apply a new configuration to the device, a process running on the device monitors whether the new configuration is applied successfully. If the new configuration fails, then after the configured number of seconds, the device reverts to its previous configuration. The default is 300 seconds.

- **Host Name:** A host name assigned to the device during onboarding, for communication with Cisco SD-WAN Manager.
- **home-wifi-psk-key:** Enter a device-specific Wi-Fi PSK key for connecting to Wi-Fi. This key is used for SSID 1, for home (non-corporate) Wi-Fi.
- **local-private-subnet:** Local IP subnet for the device, for communication with the VPN server. This must be unique among all devices with the same site ID, and enables the VPN terminating point to distinguish among each client device. Example: 192.168.0.1/24

Optionally, you can click **Export** to download a CSV file with a row for each of the devices on this page, and a column for each field on this page. In the CSV file, enter the information described above for each device. After entering the information and saving the file, click **Import** and upload the CSV file. The workflow applies the information from the CSV file to the devices in the list.

- d. Click **Next** to display a summary of the configuration.

You can click **Preview CLI** and select a specific device to display the device's current configuration and the differences as compared with the configuration created in this workflow. These differences show how the device configuration will change when you deploy the new configuration.

- e. To deploy the configuration to the selected devices, click **Deploy**. During the deployment, you can click **View Deployment Status of Tasks** to view the current status.

If a device is currently not reachable, Cisco SD-WAN Manager applies the configuration when the device becomes reachable.

Configure Cisco Catalyst Wireless Gateways Using Configuration Groups in Cisco SD-WAN Manager

After using the Cisco SD-WAN Manager workflow to create a configuration group for Cisco Catalyst Wireless Gateways, you can perform operations such as the following:

- Edit the configuration group.
- Configure features that are not available through the Cisco SD-WAN Manager workflow.
- Associate devices with the configuration group.
- Deploy the configuration group to associated devices.

For information about using configuration groups, see the *Cisco Catalyst SD-WAN Configuration Groups, Cisco IOS XE Release 17.x*.

Configure Additional Features

The Teleworker workflow in Cisco SD-WAN Manager creates a configuration group for Cisco Catalyst Wireless Gateways, and provides most configuration options. Other features require editing the configuration group, as follows:

1. From the Cisco SD-WAN Manager menu, choose **Configuration > Configuration Groups**.



Note In Cisco SD-WAN Manager releases earlier than Cisco Catalyst SD-WAN Manager Release 20.12.1, choose **Configuration > Templates** and click **Configuration Groups**.

- For configuration groups that apply to Cisco Catalyst Wireless Gateways, the **Device Solution** column shows **mobility**. Adjacent to a **mobility** configuration group, click ... and choose **Edit**.

Feature	How to Configure
VPN connections	<p>Minimum releases: Cisco vManage Release 20.11.1, Cisco IOS CG Release 17.11.1 (on the device)</p> <ol style="list-style-type: none"> Open a mobility configuration group. Open the Global Profile. If the configuration group has a vpn feature defined, click ... in the adjacent to the feature and choose Edit Feature. If the configuration group does not have a vpn feature defined, do the following: <ol style="list-style-type: none"> Click Add Global Profile Feature. From the drop-down menu, choose VPN. Click Add Remote Access IPSEC VPN. Configure the fields as described for VPN and corporate Wi-Fi settings in Configure Cisco Catalyst Wireless Gateway Devices Using a Workflow in Cisco SD-WAN Manager, on page 6. In the IPsec Policies area, configure internet key exchange (IKE) parameters for the VPN connection, including IKE phase 1 and IKE phase 2. For information about which parameters to use, consult with your organization's network administrator. The Supported IPsec Parameters table below shows the supported IPsec parameters. <p>If you configure VPN using the Teleworker workflow, the configuration includes the default IKE Phase 1 values shown in the Supported IPsec Parameters table.</p>

Feature	How to Configure
Multiple RADIUS servers	<p>Minimum releases: Cisco vManage Release 20.11.1, Cisco IOS CG Release 17.11.1 (on the device)</p> <p>You can define and name one or more RADIUS server configurations. When you enable and configure the corporate LAN option, Cisco SD-WAN Manager prompts you for RADIUS server information and provides a drop-down list enabling you to choose one of the configurations that you have defined here.</p> <p>Note When you define RADIUS configurations, you can use them only within the same configuration group. They are not available globally in other configuration groups.</p> <ol style="list-style-type: none"> 1. Open a mobility configuration group. 2. Open the Global Profile. 3. If the configuration group has the aaaservers feature defined, click ... in the adjacent to the feature and choose Edit Feature. 4. If the configuration group does not have a aaaservers feature defined, do the following: <ol style="list-style-type: none"> a. Click Add Global Profile Feature. b. From the drop-down menu, choose AAA Server. 5. Click the plus (+) icon to add a new RADIUS server configuration. Enter a name for the RADIUS server configuration, and configure the fields as described for VPN and corporate Wi-Fi settings in Configure Cisco Catalyst Wireless Gateway Devices Using a Workflow in Cisco SD-WAN Manager, on page 6. 6. Click Save.

Supported IPsec Parameters

The following table shows the IPsec parameters supported for configuring a VPN connection.

Table 8: Supported IPsec Parameters

Component	IKE Phase 1	IKE Phase 2
Encryption and Hashing	AES 128 CBC SHA1 (default) AES 256 CBC SHA1 AES 128 CBC SHA256 AES 256 CBC SHA256 AES 128 GCM AES 256 GCM	AES 128 SHA1 (default) AES 128 CBC SHA1 AES 128 CBC SHA256 AES 128 GCM AES 256 CBC SHA1 AES 256 CBC SHA256 AES 256 GCM Note Consult with you network administrator before choosing SHA1 or GCM cipher options.
Diffie-Hellman Group	14 (default) 15 16 19 20 21	Not applicable
Rekey Timer (seconds)	Range: 300 to 1209600 Default: 7200	Range: 300 to 1209600 Default: 7200
Authentication	Pre-shared key	Not applicable
Total Child Security Associations (SA) Supported	Not applicable	1

Edit a Configuration Group

1. From the Cisco SD-WAN Manager menu, choose **Configuration > Templates > Configuration Groups**.
2. Click ... adjacent to the configuration group name and choose **Edit**.



Note Configuration groups for Cisco Catalyst Wireless Gateways are labeled **mobility** in the **Device Solution** column.

3. To edit an existing parcel, which contains the configuration of a feature, such as VPN settings, click ... adjacent to the parcel and choose **Edit Parcel**.



Note Some parcels available on this page include options that cannot be configured in the workflow for creating a configuration group for Cisco Catalyst Wireless Gateways. For example, you can configure port address translation (PAT) in the Network Protocol parcel, and you can configure advanced radio settings in the Wifi parcel.

4. To add a new parcel to configure a feature that has not already been added to the configuration group, do the following:
 - a. Click **Add Global Profile Parcel**.
 - b. Click the drop-down list and choose one of the options, which include the following:
 - **Cellular**: Cellular settings
 - **Network Protocol**: DHCP, DNS, NTP, and PAT settings
 - **VPN**: VPN settings
 - **Security Policy**: Security policy actions and rules

If the configuration group already includes one of these parcels, then it does not appear in the drop-down list. For example, if you configured cellular settings when creating the configuration group, then the **Cellular** option does not appear in the list.

- c. Configure the settings for the parcel, and click **Save**.

Add Devices to a Configuration Group

After creating a configuration group, you can add devices to the group either manually or by using rules to add devices automatically.

Add Devices to a Configuration Group Manually

1. From the Cisco SD-WAN Manager menu, choose **Configuration > Templates > Configuration Groups**.
2. Click ... adjacent to the configuration group name and choose **Edit**.



Note Configuration groups for Cisco Catalyst Wireless Gateways are labeled **mobility** in the **Device Solution** column.

3. Click **Associated Devices**, and then click **Add Devices**.
The **Add Devices to Configuration Group** workflow starts.
4. Follow the instructions provided in the workflow.

For information about this workflow, see [Configure Cisco Catalyst Wireless Gateway Devices Using a Workflow in Cisco SD-WAN Manager](#), on page 6.

Add Devices to a Configuration Group Using Rules

Before You Begin

Ensure that you have added tags to devices. For more information about tagging, see [Device Tagging](#) in the *Cisco Catalyst SD-WAN Systems and Interfaces Configuration Guide, Cisco IOS XE Release 17.x*.

Add Devices to a Configuration Group

1. From the Cisco SD-WAN Manager menu, choose **Configuration > Templates > Configuration Groups**.
2. Click ... adjacent to the configuration group name and choose **Edit**.



Note Configuration groups for Cisco Catalyst Wireless Gateways are labeled **mobility** in the **Device Solution** column.

3. Click **Associated Devices**, and then click **Add and Edit Rules**.

The **Automated Rules** sidebar is displayed.

4. In the **Rules** section, choose values for the following options:
 - **Device Attribute:** Choose **Tags**.
 - **Condition:** Choose one of the following operators: **Equal**, **Contains**, **Not contain**, **Not equal**.
 - **Select Value:** Select a tag from the list of available tags.



Note If a device matches a tag rule, the device is added to the configuration group. If you edit the tag rule by changing any of the specified values, the device is removed from the group.

5. Click **Apply**.

A list displays the devices that will be added to the configuration group or removed from the group based on the rule.

6. Click **Confirm** to apply the changes.



Note

- You cannot create a new rule if it conflicts with an existing rule.
- You cannot add a tag to a device if it is already attached to a device template.
- If you have attached a template to a device, and the task is in progress, you can add a tag to the device. However, you cannot apply a rule to add this device to a configuration group using the same tag. To do this, you must either detach the device from the template or use a different tag.

Deploy the Configuration Group to Devices

1. From the Cisco SD-WAN Manager menu, choose **Configuration > Templates > Configuration Groups**.
2. Click ... adjacent to the configuration group name and choose **Edit**.



Note Configuration groups for Cisco Catalyst Wireless Gateways are labeled **mobility** in the **Device Solution** column.

3. Click **Associated Devices**.
4. Choose one or more devices, and then click **Deploy**.
The **Deploy Configuration Group** workflow starts.
5. Follow the instructions provided in the workflow.

For information about this workflow, see [Configure Cisco Catalyst Wireless Gateway Devices Using a Workflow in Cisco SD-WAN Manager, on page 6](#).

Verify the Configuration of Cisco Catalyst Wireless Gateways

1. From the Cisco SD-WAN Manager menu, choose **Configuration > Devices**.
2. Adjacent to a device, click ... and choose **Running Configuration** to display the device configuration.



Note The configuration for Cisco Catalyst Wireless Gateways may include the **config-template-name** command where other devices would use the **config-group-name** command.

Monitor Cisco Catalyst Wireless Gateways

1. From the Cisco SD-WAN Manager menu, choose **Monitor > Devices**.
2. The device list shows a summary of device reachability, CPU load, memory usage, and other device status information. For additional details of device status, click a Cisco Catalyst Wireless Gateway in the list.



CHAPTER 2

System Logs



Note To achieve simplification and consistency, the Cisco SD-WAN solution has been rebranded as Cisco Catalyst SD-WAN. In addition, from Cisco IOS XE SD-WAN Release 17.12.1a and Cisco Catalyst SD-WAN Release 20.12.1, the following component changes are applicable: **Cisco vManage** to **Cisco Catalyst SD-WAN Manager**, **Cisco vAnalytics** to **Cisco Catalyst SD-WAN Analytics**, **Cisco vBond** to **Cisco Catalyst SD-WAN Validator**, and **Cisco vSmart** to **Cisco Catalyst SD-WAN Controller**. See the latest Release Notes for a comprehensive list of all the component brand name changes. While we transition to the new names, some inconsistencies might be present in the documentation set because of a phased approach to the user interface updates of the software product.

- [System Logs](#), on page 27
- [Information About System Logs](#), on page 27
- [Prerequisites for Saving System Logs](#), on page 28
- [Restrictions for Saving System Logs](#), on page 28
- [Configure a Device to Save System Logs](#), on page 28

System Logs

Table 9: Feature History

Feature Name	Release Information	Description
System Log Support	Cisco Catalyst SD-WAN Manager Release 20.12.1 Cisco IOS CG Release 17.12.1	Added support for saving system log files locally and on remote servers. System log information is useful for monitoring or troubleshooting Cisco Catalyst Wireless Gateways.

Information About System Logs

Minimum software releases: Cisco Catalyst SD-WAN Manager Release 20.12.1, Cisco IOS CG Release 17.12.1

Cisco Catalyst Wireless Gateways generate system log messages that provide information about system activities. To save and access log message files, you can do the following:

- Configure how much space to allocate in a device's system storage to store log files.
- Configure a rotation value, which determines how many log files to save locally.
- Configure devices to store their log message files on a remote server.

Administrators can access the local or remotely stored log messages to monitor Cisco Catalyst Wireless Gateway devices or to troubleshoot device issues.

Prerequisites for Saving System Logs

Prerequisite	Description
Remote server requires Linux	For the remote server that saves system log files, use a Linux-based server.
Remote server requires a syslog package	To support system logs, install the syslog-ng-core Linux package on the remote server.

Restrictions for Saving System Logs

Restriction	Description
Remote server down	If you configure a Cisco Catalyst Wireless Gateway device to save system log files to a remote server, the device is unable to check whether the remote server is active or down. If the device attempts to save a system log file to a server and the server is down, the log information may be lost.

Configure a Device to Save System Logs

Before You Begin

This procedure requires a configuration group that applies to Cisco Catalyst Wireless Gateways. On the **Configuration Groups** page in Cisco SD-WAN Manager, configuration groups for Cisco Catalyst Wireless Gateways show **mobility** in the **Device Solution** field.

Configure a Device to Save System Logs

1. From the Cisco SD-WAN Manager menu, choose **Configuration > Configuration Groups**.
2. Click ... adjacent to a configuration group for a Cisco Catalyst Wireless Gateway (marked **mobility**) and choose **Edit**.
3. Click **Global Profile** to show the configured features of the Global Profile.

4. If Logging does not already appear as a configured feature, click **Add Global Profile Feature**, and choose **Logging**. If a Logging feature has already been added, click ... adjacent to the Logging feature and choose **Edit Feature**.
5. For the Logging feature, configure the following fields:

Field	Description
Name	Name of the Logging feature configuration.
Description	(Optional) Description of the Logging feature configuration.
Max File Size (in Megabytes)	<p>Maximum file size for each log file that a Cisco Catalyst Wireless Gateway device stores locally. After reaching the maximum size, the device creates a new log file, with a numerically sequenced filename.</p> <p>The device stores the first log file locally with the filename, "messages". After it reaches the maximum file size, it creates new log files using the following filename format:</p> <pre>messages.number</pre> <p>Default: 10</p> <p>Range: 1 through 20</p> <p>Examples:</p> <pre>messages messages.1 messages.2</pre>
Rotations	<p>Maximum number of log files to store locally.</p> <p>After the maximum number of log files is stored, the next log file that the device saves overwrites the oldest log file.</p> <p>For example, if you configure 3 rotations, the device first saves a log file called messages. When the messages file reaches the maximum file size, the device creates a file called messages.1 to continue saving log messages. When messages.1 reaches its maximum size, the device creates a new message file called messages.2. When messages.2 reaches its maximum size and the device needs to create a new file, the device deletes the original messages file (which is the oldest) and begins writing a file called messages.3.</p> <p>Default: 10</p> <p>Range: 1 through 10</p>

Field	Description
<p>Add Server (in the Server area)</p>	<p>(Optional) Configure up to four servers on which to save log message files remotely.</p> <p>When you click Add Server, the Add Server pop-up window appears. The fields in the pop-up window are described below.</p> <p>The log message file size is limited only by the file system of the server, and is not determined by the Max File Size field described above.</p> <p>Devices save the log message file using the hostname of the device itself in the server's /var/log directory, in the following format:</p> <pre>hostname.log</pre> <p>Example (for a Cisco Catalyst Wireless Gateway device with hostname cwg100):</p> <pre>/var/log/cwg100.log</pre>
<p>Hostname/IP Address (in the Add Server pop-up window)</p>	<p>Hostname or IP address of the server.</p>
<p>Priority (in the Add Server pop-up window)</p>	<p>Filter the type of log messages saved using one of the following priority options, listed from lowest to highest priority.</p> <p>Each priority option configures the device to save log messages of that priority and all higher priorities. For example, information is the lowest priority of message, so choosing information includes information log messages and all other log messages too.</p> <p>Choosing error excludes information, notice, and warn log messages, but includes error messages and all other log messages of higher priority (critical, alert, and emergency).</p> <p>From lowest to highest priority, the options are the following:</p> <ul style="list-style-type: none"> • information • notice • warn • error • critical • alert • emergency

Field	Description
Source IP (in the Add Server pop-up window)	<p>Choose one of the following:</p> <ul style="list-style-type: none">• System IP: (Default) For system log messages that include the system IP address of the Cisco Catalyst Wireless Gateway device, the log message uses the default system IP address of the device. The system IP address is the unique address that you assign to the device when onboarding to Cisco SD-WAN Manager. We recommend using this option.• Device Specific IP: For system log messages that include the device-specific IP address of the Cisco Catalyst Wireless Gateway device, the log message uses a manually configured custom IP address of the device. The device-specific IP is a unique IP address manually configured for each device. <p>The workflow is as follows:</p> <ol style="list-style-type: none">a. Choose the Device Specific IP option.b. When you apply the configuration group to one or more Cisco Catalyst Wireless Gateway devices, Cisco SD-WAN Manager prompts you for a device-specific IP address for each device. Each device creates a loopback interface using the device-specific IP address that you have entered. This address then appears in system log messages for the device.



CHAPTER 3

Prioritization of Corporate Traffic (QoS)

- [Prioritization of Corporate Traffic \(QoS\)](#), on page 33
- [Information About the Prioritization of Corporate Traffic \(QoS\)](#), on page 33
- [Configure Prioritization of Corporate Traffic \(QoS\)](#), on page 33

Prioritization of Corporate Traffic (QoS)

Table 10: Feature History

Feature Name	Release Information	Description
Prioritization of Corporate Traffic (QoS)	Cisco Catalyst SD-WAN Manager Release 20.13.1 Cisco IOS CG Release 17.13.1	Added support for allocating bandwidth to be used strictly for corporate traffic.

Information About the Prioritization of Corporate Traffic (QoS)

You can allocate a specific bandwidth on the GigabitEthernet0/0 or cellular interfaces to be used only for corporate traffic. In a setting where the Cisco Catalyst Wireless Gateway handles both corporate and non-corporate traffic, such as when you are using the device in a home setting, this can help to ensure a desired quality of service for corporate traffic.

Configure Prioritization of Corporate Traffic (QoS)

Before You Begin

Create a configuration group for Cisco Catalyst Wireless Gateways. For information, see [Configure Cisco Catalyst Wireless Gateways Using Configuration Groups in Cisco SD-WAN Manager](#), on page 19.

Configure Prioritization of Corporate Traffic (QoS)

1. From the Cisco SD-WAN Manager menu, choose **Configuration > Configuration Groups**.
2. Click ... adjacent to a configuration group for a Cisco Catalyst Wireless Gateway (marked **mobility**) and choose **Edit**.
3. In the **Global Profile** section, click **Add Global Profile Feature**.
4. From the drop-down list, choose **QoS**.
5. Configure the following fields:

Table 11: Basic Settings

Parameter Name	Description
Enable QoS	Enable the QoS feature.
GigabitEthernet0/0 QoS Config	
Rate	Enter the bandwidth (Mbps) to allocate on the GigabitEthernet0/0 interface for corporate traffic. If the entered value exceeds the bandwidth of the interface, then the full bandwidth of the interface is allocated for corporate traffic.
Cellular 1 QoS Config	
Rate	Enter the bandwidth (Mbps) to allocate on the cellular interface for corporate traffic. If the entered value exceeds the bandwidth of the interface, then the full bandwidth of the interface is allocated for corporate traffic.

6. Click **Save**.



APPENDIX **A**

Additional References

- [Additional References](#), on page 35

Additional References

Reference	Description
Release Notes for Cisco Catalyst Wireless Gateways	Description of new features in each release, and lists of any open or resolved caveats in each release.
Hardware Installation Guide for Cisco Catalyst Wireless Gateways	Detailed information about each Cisco Catalyst Wireless Gateway model, and installation instructions.
Regulatory Compliance and Safety Information – Cisco Catalyst Wireless Gateways	Regulatory compliance and safety information.

