

Starting a Router Terminal Session

This chapter describes how to start a terminal session with the IR8140H using the console port. The console port is found in the CPU module.

Start a terminal session with the router when you are at the router installation location and want to administer the router with a direct connection using the CLI software.

These topics are discussed:

- Before You Begin, on page 1
- About the Console Port, on page 1
- Connecting to the Console Port with Microsoft Windows, on page 3
- Connecting to the Console Port with Mac OS X, on page 3
- Connecting to the Console Port with Linux, on page 4


Before You Begin

Before you start a terminal session with the router, you must connect a PC or PC terminal to the router console port.

About the Console Port

The console port is found in the CPU module, as shown in the following figure.

Figure 1: CPU Module with Console Port



1	M42 plug	2	Console port

To access the console port, open the M42 plug.

The console port is an asynchronous serial port that allows you to connect to the device for initial configuration through a standard RS-232 port with an RJ-45 connector. Any device connected to this port must be capable of asynchronous transmission.



Caution

The console port does not support cable glands. When a cable is connected to this port, the router's interior is exposed to environmental elements, which can damage the port and the router's interior. This port should be exposed only during terminal sessions, when a cable is connected to the port. This port should never be left unattended when in use.

The console port is an asynchronous serial port that allows you to connect to the device for initial configuration through a standard RS-232 port with an RJ-45 connector. Any device connected to this port must be capable of asynchronous transmission.

Console Port Settings

Configure the following parameters for the console port:

Parameter	Console Port Setting	Description
Baud	9600	Specifies the transmission speed for the connection.
Data bits	8	Specifies the number of bits in an 8-bit byte that is used for data.
Parity	None	Specifies the odd or even parity for error detection.

Parameter	Console Port Setting	Description	
Stop bits	1	Specifies the number of stop bits for an asynchronous line.	

Using the Ctrl-C Command

The router console port is located in the router's exterior and can be accessed by removing the seal over the console port (see Figure 1: CPU Module with Console Port, on page 2).

On many Cisco routers, you can enter **Ctrl-C** to interrupt the router startup process and then delete or change the admin password, or view or delete the router configuration.

To prevent unauthorized access to the router configurations and passwords, the **Ctrl-C** command is disabled on the router while it is booting up and loading the system software.

Connecting to the Console Port with Microsoft Windows

To connect to the router console port using Microsoft Windows:

- Start a terminal emulator application, such as Windows HyperTerminal (included with some versions of the Windows operating system) or PuTTY.
- **Step 2** Configure the terminal emulation software with the parameters described in About the Console Port, on page 1.
- **Step 3** Connect to the router.

Connecting to the Console Port with Mac OS X

To connect a Mac OS X system USB port to the console using the built-in OS X Terminal utility:

- **Step 1** Use the Finder application, and go to **Applications > Utilities > Terminal**.
- **Step 2** Connect the OS X USB port to the router.
- **Step 3** Enter the following commands to find the OS X USB port number:

Step 4 Connect to the USB port with the following command, followed by the router USB port speed:

```
macbook:user$ screen /dev/tty.usbmodem1a21 9600
```

To disconnect the OS X USB console from the Terminal window, press Ctrl+A followed by Ctrl+\.

Connecting to the Console Port with Linux

To connect a Linux system USB port to the console using the built-in Linux Terminal utility:

- **Step 1** Open the Linux Terminal window.
- **Step 2** Connect the Linux USB port to the router.
- **Step 3** Enter the following commands to find the Linux USB port number:

```
root@usb-suse# cd /dev
root@usb-suse /dev# ls -ltr *ACM*
crw-r--r- 1 root root 188, 0 Jan 14 18:02 ttyACM0
root@usb-suse /dev#
```

Step 4 Connect to the USB port with the following command followed by the router USB port speed:

```
root@usb-suse /dev# screen /dev/ttyACMO 9600
```

To disconnect the Linux USB console from the Terminal window, press Ctrl+A followed by:, and then enter quit.