



## Controllers STSn Command Reference

---

This chapter describes the commands to configure the STSn controller.

- [controller \(sts\), on page 2](#)
- [overhead j1, on page 3](#)
- [pm \(sts\), on page 4](#)
- [show controllers \(sts\), on page 5](#)
- [threshold, on page 7](#)

## controller (sts)

To configure an STSn controller, use the **controller** command in the config mode. To delete an STSn controller, use the **no** form of this command.

**controller stsn** *R/S/I/P*

**no controller stsn** *R/S/I/P*

<b>Syntax Description</b>	<b>stsn</b> Configures an STSn controller. The range of n is from 48c to 192c.
	<i>R/S/I/P</i> Displays the Rack/Slot/Instance/Port of the controller.

<b>Command Default</b>	None send : (2) expected : (2) receive : (2)
------------------------	---

<b>Command Modes</b>	Config mode
----------------------	-------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.4	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sonet-sdh	write

### Example

This example shows how to access the interface instance of an sts48c controller on port1:

```
RP/0/RP0:hostname(config)# controller stsn-48c 0/0/0/1
```

# overhead j1

To configure overhead value of an STSn controller, use the **overhead j1** command in the config mode. To delete the overhead value of an STSn controller, use the **no** form of this command.

**overhead j1** {**send** | **expected**} [**16Bytes** | **64Bytes**] *value*

**no overhead j1** {**expected**}

Syntax Description	
<b>send</b>	Configures the transmitted trace identifier of the STSn controller.
<b>expected</b>	Configures the expected trace identifier of the STSn controller.
<b>16Bytes</b>	Configures the 16 bytes path trace for the STSn controller.
<b>64Bytes</b>	Configures the 64 bytes path trace for the STSn controller.
<i>value</i>	Enters the ASCII text for the STSn controller.

**Command Default** 2 stands 64 byte mode

**Command Modes** Config mode

Command History	Release	Modification
	Release 5.2.4	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	sonet-sdh	write

## Example

This example shows how to configure the overhead j1 value of the STS48c controller:

```
RP/0/RP0:hostname(config)# controller sts-48c 0/0/0/1
RP/0/RP0:hostname(config-sts48c)# overhead j1 expected 64Bytes abxc
```

# pm (sts)

To configure the pm parameters of an STSn controller, use the **pm** command in the config mode. To delete the pm parameters of an STSn controller, use the **no** form of this command.

**pm** [**15-min** | **24-hour**] {**sts**} [**report status** | **threshold value**]

**no pm** [**15-min** | **24-hour**] {**sts**} [**report status** | **threshold value**]

Syntax Description		
<b>15 min</b>	Configures the 15 minute time interval for the PM parameters.	
<b>24-hour</b>	Configures the 24 hour time interval for the PM parameters.	
<b>sts</b>	Displays the name of the layer.	
<b>report</b>	Configures the TCA reporting status of the controller.	
<i>status</i>	Configures the reporting status of the controller.	
<b>threshold</b>	Configures threshold on the controller.	
<i>value</i>	Configures the threshold value of the controller.	

**Command Default** Enable

**Command Modes** Config mode

Command History	Release	Modification
	Release 5.2.4	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	sonet-sdh	write

The following example shows how to specify the 15 min PM interval for the STS controller and set threshold value for the layer:

```
RP/0/RP0:hostname(config)# controller sts-48c 0/0/0/1
RP/0/RP0:hostname(config-sts48c)# pm 15-min sts threshold cv-p 30
```

# show controllers (sts)

To display all the details of an STSn controller, use the **show controllers** command in the exec mode.

**show controllers stsn** *R/S/I/P*

Syntax Description	stsn	Displays the name of the STSn controller.
	<i>R/S/I/P</i>	Displays the Rack/Slot/Instance/Port of the controller.

**Command Modes** Exec mode

Command History	Release	Modification
	Release 5.2.4	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	sonet-sdh	read

## Example

This example shows how to display the details of an STS48c controller:

```
RP/0/RP0:hostname # show controllers sts48c 0/0/0/1
```

```

Primary State: Down
Sec Admin State: Normal
Derived State: In Service
PATH
  FEBE      = 0          BIP(B3) = 0
  NEWPTR    = 0          PSE      = 0          NSE    = 0
Detected Alarms:      None
Mask for Detected->Asserted:      None
Detected Alerts: None
Mask for Detected->Reported: None
Payload Scrambling: Disabled
C2 State: Stable   C2_rx = 0x0 (0)   C2_tx = 0x0 (0) / Scrambling Derived
B3 = 10e-6
Overhead J1
Transmit          : (2)
Received          : (2)
Expected         : (2)
    
```

```
performace_monitoring enabled
```



---

**Note** Run *do show controller stsn R/S/I/P* when command is executed in config mode.

---

# threshold

To configure threshold for B3 bit error rate (BER) threshold crossing alert (TCA) on an STSn controller, use the **threshold** command in the config mode. To delete the threshold for B3 BER TCA from an STSn controller, use the **no** form of this command.

**threshold** [**b3-tca** *value*]

**no threshold** [**b3-tca** *value*]

<b>Syntax Description</b>	<b>b3-tca</b> Configures the B3 BER threshold for the TCA on the STSn controller.
	<i>value</i> Configures the BER value. The valid range of BER is from 3 to 9. The default value is 6.

**Command Default** None

**Command Modes** Config mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.4	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	sonet-sdh	write

## Example

This example shows how to configure the threshold for B3 BER TCA on the STS48c controller:

```
RP/0/RP0:hostname(config)# controller sts-48c 0/0/0/1
RP/0/RP0:hostname(config-sts48c)# threshold b3-tca 7
```

■ threshold