

Determinazione del numero di serie dei componenti dello switch Catalyst

Sommario

[Introduzione](#)

[Prerequisiti](#)

[Requisiti](#)

[Componenti usati](#)

[Convenzioni](#)

[Premesse](#)

[Catalyst 6500](#)

[Catalyst 4500](#)

[Catalyst 4500 Supervisor Engine II+/III/IV](#)

[Catalyst 3750](#)

[Catalyst 3560](#)

[Catalyst 3550](#)

[Catalyst 2950/2970/2940](#)

[Catalyst 2900XL/3500XL](#)

[Catalyst 2948GL3/4908G-L3/4980G-L3](#)

[Catalyst 9000](#)

[Informazioni correlate](#)

Introduzione

In questo documento viene descritto come determinare i numeri di serie di vari componenti sostituibili sugli switch Cisco Catalyst.

Prerequisiti

Requisiti

Nessun requisito specifico previsto per questo documento.

Componenti usati

Le informazioni fornite in questo documento si basano sulle seguenti versioni software e hardware:

- Vari switch Catalyst
- Varie versioni del software

Le informazioni discusse in questo documento fanno riferimento a dispositivi usati in uno specifico ambiente di emulazione. Su tutti i dispositivi menzionati nel documento la configurazione è stata ripristinata ai valori predefiniti. Se la rete è operativa, valutare attentamente eventuali conseguenze derivanti dall'uso dei comandi.

Convenzioni

Per ulteriori informazioni sulle convenzioni usate, consultare il documento [Cisco sulle convenzioni nei suggerimenti tecnici](#).

Premesse

I numeri di serie sono necessari per creare un database dei componenti della rete. Quando si crea una richiesta di assistenza con il [supporto tecnico Cisco](#), è necessario avere a portata di mano il numero di serie dei dispositivi interessati. Questo requisito si applica in particolare quando è necessario un componente sostitutivo o un'autorizzazione per la restituzione del materiale (RMA).

Non è possibile modificare il numero di serie degli switch Cisco Catalyst. A scopo di gestione, è possibile configurare gli switch Cisco Catalyst con software Cisco IOS® in modo che restituiscano una stringa personalizzata. Per creare una stringa personalizzata, usare il comando `snmp-server chassis-id` in modalità di configurazione globale.



Nota: per informazioni specifiche sui comandi show, vedere [Comandi show](#).

Catalyst 6500

Per determinare il numero di serie dello chassis e di altri componenti, usare il comando `show idprom:`

```
<#root>
```

```
6506#
```

```
show idprom ?
```

```
all          selects all FRU-types
backplane    specify backplane
clock        specify clock <number>
earl         specify earl <slot>
fan-tray     specify fan-tray <number>
interface    interface name
module       specify module <slot>
power-supply specify power-supply <number>
rp           specify RP (MSFC) <slot>
supervisor   specify supervisor <slot>
vtt          specify VTT <number>
```

Per ottenere il numero di serie dello chassis, usare il comando `show idprom backplane:`

<#root>

6506#

show idprom backplane

IDPROM for backplane #0
(FRU is 'Catalyst 6500 6-slot backplane')
OEM String = 'Cisco Systems'

Product Number = 'WS-C6506'

Serial Number = 'TBA03270652'

Manufacturing Assembly Number = '73-3436-01'
Manufacturing Assembly Revision = 'A0'
Hardware Revision = 1.0
Current supplied (+) or consumed (-) = -A

Per ottenere il numero di serie del modulo, usare il comando show idprom module slot<slot number>. In alternativa, è possibile usare il comando show module:

<#root>

6506#

show module

Mod	Ports	Card Type	Model
1	2	Catalyst 6000 supervisor 2 (Active)	WS-X6K-S2U-MSFC2

SAD055006NE

3	0	2 port adapter FlexWAN	WS-X6182-2PA
---	---	------------------------	--------------

SAD04350EEU

4	48	SFM-capable 48-port 10/100 Mbps RJ45	WS-X6548-RJ-45
---	----	--------------------------------------	----------------


SAD055108C2

Mod	MAC addresses	Hw	Fw	Sw	Status
1	0001.6415.a602 to 0001.6415.a603	3.2	6.1(3)	7.5(0.6)HUB6	Ok
3	0001.6413.c86b to 0001.6413.c8aa	1.5	12.1(13)E1	12.1(13)E1	Ok
4	0001.63d3.e77a to 0001.63d3.e7a9	4.0	6.3(1)	7.5(0.6)HUB6	Ok

Mod	Sub-Module	Model	Serial	Hw	Status
1	Policy Feature Card 2	WS-F6K-PFC2	SAD055004VA	3.0	Ok
1	Cat6k MSFC 2 daughterboard	WS-F6K-MSFC2	SAD055006VF	2.0	Ok

Mod Online Diag Status

1 Pass
3 Not Supported
4 Pass

 Nota: utilizzare il comando `show diagbus` per determinare il numero di serie degli adattatori di porte sul modulo Flex WAN.

Catalyst 4500

Catalyst 4500 Supervisor Engine II+/III/IV

Per determinare il numero di serie dello chassis e di altri componenti, usare il comando `show idprom`:

```
<#root>
```

```
Switch#
```

```
show idprom ?
```

```
all          show all non-interface IDPROMs  
chassis     show IDPROM for chassis  
fan-tray    show IDPROM for system fan tray  
interface   show contents of gbic connected to this interface  
module      show IDPROM for module  
power-supply show IDPROM for power supply  
supervisor  show IDPROM for supervisor
```

Per ottenere il numero di serie dello chassis, usare il comando `show idprom chassis`:

```
<#root>
```

```
Switch#
```

```
show idprom chassis
```

```
Chassis Idprom :
```

```
Common Block Signature = 0xABAB  
Common Block Version = 1  
Common Block Length = 144  
Common Block Checksum = 4081  
Idprom Size = 256  
Block Count = 2  
FRU Major Type = 0x4001  
FRU Minor Type = 37  
OEM String = Cisco Systems, Inc.  
Product Number = WS-C4506
```

Serial Number = FOX0627A001
Part Number = 73-8107-04
Part Revision = 01
Manufacturing Deviation String = 0
Hardware Revision = 0.4
Manufacturing Bits = 0x0000
Engineering Bits = 0x0000
Snmp OID = 0.0.0.0.0.0.0.0
Power Consumption = 0
RMA Failure Code = 0 0 0 0
Chassis Block Signature = 0x4001
Chassis Block Version = 1
Chassis Block Length = 22
Chassis Block Checksum = 628
Feature Bits = 0x0000000000000000
MAC Base = 000a.4172.df40
MAC Count = 64

Per ottenere il numero di serie dell'alimentatore, usare il comando `show idprom power-supply {1} | 2}` comando:

<#root>

Switch#

`show idprom power-supply 1`

Power Supply 1 Idprom :
Common Block Signature = 0xABAB
Common Block Version = 1
Common Block Length = 144
Common Block Checksum = 5857
Idprom Size = 256
Block Count = 2
FRU Major Type = 0x4501
FRU Minor Type = 1
OEM String = Cisco Systems, Inc.

Product Number = PWR-C4K-1400AC

Serial Number = ABC06260005

Part Number = 34-1846-01
Part Revision = 45
Manufacturing Deviation String =
Hardware Revision = 1.0
Manufacturing Bits = 0x0000
Engineering Bits = 0x0000
Snmp OID = 22616.22616.22616.22616.22616.22616.22616.22616
Power Consumption = 1400
RMA Failure Code = 0 0 0 0
Power Supply Block Signature = 0x4501
PowerSupply Block Version = 1
PowerSupply Block Length = 20
PowerSupply Block Checksum = 293
Feature Bits = 0x0000000000000000
Current @ 110V = 17

```
Current @ 220V = 9
StackMIB OID = 22616
```

Per ottenere il numero di serie del modulo, usare il comando `show idprom module slot<slot number>`. In alternativa, è possibile utilizzare il comando `show module`:

```
<#root>
```

```
Switch#
```

```
show module
```

Mod	Ports	Card Type	Model	Serial No.
1	2	1000BaseX (GBIC) Supervisor(active)	WS-X4014	

```
JAB054109H1
```

3	48	10/100BaseTX (RJ45)	WS-X4148	
---	----	---------------------	----------	--

```
JAB025202M6
```

4	6	1000BaseX (GBIC)	WS-X4306	
---	---	------------------	----------	--

```
JAB023403BG
```

M	MAC addresses	Hw	Fw	Sw	Status
1	000a.4172.df40 to 000a.4172.df41	0.5	12.1(12r)EW	12.1(13)EW(0.34)	Ok
3	0050.730b.2340 to 0050.730b.236f	1.0			Ok
4	0010.7bfa.7ca4 to 0010.7bfa.7ca9	2.0			Ok

Catalyst 3750

Utilizzare il comando `show version` per determinare il numero di serie dello chassis e il tipo di modello dello switch, come mostrato nell'esempio. L'output contiene tutte le informazioni sui membri dello stack di switch, sullo chassis e sul numero di serie:

```
<#root>
```

```
3750#
```

```
show version
```

```
Cisco Internetwork Operating System Software
Cisco IOS (tm) C3750 Software (C3750-I5-M), Version 12.1(14)EA1, RELEASE SOFTWARE (fc1)
Copyright (c) 1986-2003 by cisco Systems, Inc.
Compiled Tue 22-Jul-03 13:17 by antonino
Image text-base: 0x00003000, data-base: 0x008F0CF8
```

ROM: Bootstrap program is C3750 boot loader
BOOTLDR: C3750 Boot Loader (C3750-HB00T-M) Version 12.1(11r)AX, RELEASE SOFTWARE (fc1)

3750RJ uptime is 1 hour, 29 minutes
System returned to ROM by power-on
System image file is "flash:c3750-i5-mz.121.14-EA1/c3750-i5-mz.121.14-EA1.bin"

cisco WS-C3750-24TS (PowerPC405) processor (revision A0) with 120822K/10240K bytes of memory.

Processor board ID CAT0726R0ZU

Last reset from power-on

Bridging software.

2 Virtual Ethernet/IEEE 802.3 interface(s)

48 FastEthernet/IEEE 802.3 interface(s)

16 Gigabit Ethernet/IEEE 802.3 interface(s)

The password-recovery mechanism is enabled.

512K bytes of flash-simulated non-volatile configuration memory.

Base ethernet MAC Address : 00:0D:29:B4:18:00

Motherboard assembly number : 73-7055-06

Power supply part number : 341-0034-01

Motherboard serial number : CAT0726043V

Power supply serial number : PHI0708009K

Model revision number : A0

Motherboard revision number : A0

Model number : WS-C3750-24TS-E

System serial number : CAT0726R0ZU

Switch Ports Model SW Version SW Image

```
-----  
* 1 26 WS-C3750-24TS 12.1(14)EA1 C3750-I5-M  
2 26 WS-C3750-24TS 12.1(14)EA1 C3750-I5-M  
3 12 WS-C3750G-12S 12.1(14)EA1 C3750-I5-M
```

Switch 02

```
-----  
Switch Uptime : 1 hour, 29 minutes  
Base ethernet MAC Address : 00:0D:29:B4:3F:00  
Motherboard assembly number : 73-7055-06  
Power supply part number : 341-0034-01  
Motherboard serial number : CAT07260438  
Power supply serial number : PHI0708008X  
Model revision number : A0  
Motherboard revision number : A0
```

Model number : WS-C3750-24TS-E

System serial number : CAT0726R10A

Switch 03

```
-----  
Switch Uptime : 1 hour, 29 minutes  
Base ethernet MAC Address : 00:0D:BD:6A:3E:00  
Motherboard assembly number : 73-8307-06
```

Power supply part number : 341-0048-01
Motherboard serial number : CAT073205S2
Power supply serial number : DTH0731055Z
Model revision number : A0
Motherboard revision number : A0

Model number : WS-C3750G-12S-E

System serial number : CAT0732R0M4

Top assembly part number : 800-23419-01
Top assembly revision number : A0

Configuration register is 0xF

3750#

Catalyst 3560

Per determinare il numero di serie dello chassis e il tipo di modello dello switch, usare il comando show version:

```
<#root>
```

```
3560#
```

```
show version
```

```
Cisco Internetwork Operating System Software  
Cisco IOS (tm) C3560 Software (C3560-I5-M), Version 12.1(19)EA1c, RELEASE SOFTWARE (fc2)  
Copyright (c) 1986-2004 by cisco Systems, Inc.  
Compiled Tue 03-Feb-04 05:56 by yenanh  
Image text-base: 0x00003000, data-base: 0x0091D404
```

```
ROM: Bootstrap program is C3560 boot loader  
BOOTLDR: C3560 Boot Loader (C3560-HB00T-M) Version 12.1(19r)EA1b, RELEASE SOFTWARE (fc2)
```

```
3-8-03-CATS3560 uptime is 8 weeks, 4 days, 18 hours, 16 minutes  
System returned to ROM by power-on  
System image file is "flash:c3560-i5-mz.121-19.EA1c.bin"
```

```
cisco WS-C3560-24PS (PowerPC405) processor (revision D0) with 118776K/12288K bytes of memory.
```

```
Processor board ID CSG0802P0G4
```

```
Last reset from power-on
```

```
Bridging software.
```

```
1 Virtual Ethernet/IEEE 802.3 interface(s)
```

```
24 FastEthernet/IEEE 802.3 interface(s)
```

```
2 Gigabit Ethernet/IEEE 802.3 interface(s)
```

```
The password-recovery mechanism is enabled.
```

```
512K bytes of flash-simulated non-volatile configuration memory.
```

```
Base ethernet MAC Address : 00:0E:39:E9:32:80
```

```
Motherboard assembly number : 73-9299-01
```

```
Power supply part number : 341-0029-03
```

```
Motherboard serial number : CAT075108EK
```

```
Power supply serial number : LIT074900K3
```

```
Model revision number : D0
```

```
Motherboard revision number : C0
```


Model number : WS-C3560-24PS-E
System serial number : CSG0802P0G4

Top Assembly Part Number : 800-24814-01
Top Assembly Revision Number : D0
Version ID : N/A
Hardware Board Revision Number : 0x08

Catalyst 3550

Per determinare il numero di serie dello chassis e il tipo di modello dello switch, usare il comando show version:

```
<#root>
```

```
Cat3550#
```

```
show version
```

```
Cisco Internetwork Operating System Software  
Cisco IOS (tm) C3550 Software (C3550-I5Q3L2-M), Version 12.1(12c)EA1, RELEASE SOFTWARE (fc1)  
Copyright (c) 1986-2002 by cisco Systems, Inc.  
Compiled Mon 25-Nov-02 00:07 by antonino  
Image text-base: 0x00003000, data-base: 0x0075FE48
```

```
ROM: Bootstrap program is C3550 boot loader
```

```
Cat3550 uptime is 4 days, 2 hours, 57 minutes  
System returned to ROM by power-on  
System image file is "flash:c3550-i5q3l2-mz.121-12c.EA1.bin"
```

```
cisco WS-C3550-48 (PowerPC) processor (revision G0) with 65526K/8192K bytes of memory.  
Processor board ID CHK0642W02B  
Last reset from warm-reset  
Bridging software.  
Running Layer2/3 Switching Image
```

```
Ethernet-controller 1 has 12 Fast Ethernet/IEEE 802.3 interfaces
```

```
Ethernet-controller 2 has 12 Fast Ethernet/IEEE 802.3 interfaces
```

```
Ethernet-controller 3 has 12 Fast Ethernet/IEEE 802.3 interfaces
```

```
Ethernet-controller 4 has 12 Fast Ethernet/IEEE 802.3 interfaces
```

```
Ethernet-controller 5 has 1 Gigabit Ethernet/IEEE 802.3 interface
```

```
Ethernet-controller 6 has 1 Gigabit Ethernet/IEEE 802.3 interface
```

```
48 FastEthernet/IEEE 802.3 interface(s)  
2 Gigabit Ethernet/IEEE 802.3 interface(s)
```

```
The password-recovery mechanism is enabled.  
384K bytes of flash-simulated non-volatile configuration memory.  
Base ethernet MAC Address: 00:0B:46:8A:2F:80  
Motherboard assembly number: 73-5701-07  
Power supply part number: 34-0967-01
```

Motherboard serial number: CAT0641027L
Power supply serial number: DCA06392BU2
Model revision number: G0
Motherboard revision number: A0

Model number: WS-C3550-48-SMI

System serial number: CHK0642W02B

Configuration register is 0x10F

Catalyst 2950/2970/2940

Per determinare il numero di serie dello chassis e il tipo di modello dello switch, usare il `show version` comando:

```
<#root>
```

```
Cat2950#
```

```
show version
```

```
Cisco Internetwork Operating System Software  
Cisco IOS (tm) C2950 Software (C2950-I6Q4L2-M), Version 12.1(12c)EA1, RELEASE SOFTWARE (fc1)  
Copyright (c) 1986-2002 by cisco Systems, Inc.  
Compiled Sun 24-Nov-02 23:31 by antonino  
Image text-base: 0x80010000, data-base: 0x80562000
```

```
ROM: Bootstrap program is CALHOUN boot loader
```

```
Cat2950 uptime is 4 days, 2 hours, 52 minutes  
System returned to ROM by power-on  
System image file is "flash:c2950-i6q4l2-mz.121-12c.EA1.bin"
```

```
cisco WS-C2950G-48-EI (RC32300) processor (revision C0) with 21002K bytes of memory.  
Processor board ID FHK0624W0HS  
Last reset from system-reset  
Running Enhanced Image  
48 FastEthernet/IEEE 802.3 interface(s)  
2 Gigabit Ethernet/IEEE 802.3 interface(s)
```

```
32K bytes of flash-simulated non-volatile configuration memory.  
Base ethernet MAC Address: 00:09:E8:89:4A:40  
Motherboard assembly number: 73-7409-08  
Power supply part number: 34-0965-01  
Motherboard serial number: FOC06230ERQ  
Power supply serial number: DAB062143BP  
Model revision number: C0  
Motherboard revision number: B0
```

```
Model number: WS-C2950G-48-EI
```

```
System serial number: FHK0624W0HS
```

```
Configuration register is 0xF
```

Catalyst 2900XL/3500XL

Per determinare il numero di serie dello chassis e il tipo di modello dello switch, usare il `show version` comando:

```
<#root>
```

```
Switch#
```

```
show version
```

```
Cisco Internetwork Operating System Software
Cisco IOS (tm) C3500XL Software (C3500XL-C3H2S-M), Version 12.0(5.2)XU, MAINTENANCE
INTERIM SOFTWARE
Copyright (c) 1986-2000 by cisco Systems, Inc.
Compiled Mon 17-Jul-00 18:29 by ayounes
Image text-base: 0x00003000, data-base: 0x00301F3C
```

```
ROM: Bootstrap program is C3500XL boot loader
```

```
Switch uptime is 4 days, 3 hours, 4 minutes
System returned to ROM by power-on
System image file is "flash:c3500XL-c3h2s-mz-120.5.2-XU.bin"
```

```
Cisco WS-C3548-XL (PowerPC403) processor (revision 0x01) with 16384K/1024K bytes
of memory. Processor board ID FOC0616X0RG, with hardware revision 0x00
Last reset from power-on
```

```
Processor is running Enterprise Edition Software
Cluster command switch capable
Cluster member switch capable
48 FastEthernet/IEEE 802.3 interface(s)
2 Gigabit Ethernet/IEEE 802.3 interface(s)
```

```
32K bytes of flash-simulated non-volatile configuration memory.
Base ethernet MAC Address: 00:09:7C:8E:78:80
Motherboard assembly number: 73-3903-09
Power supply part number: 34-0971-02
Motherboard serial number: FOC06160L07
Power supply serial number: APQ061200VZ
Model revision number: M0
Motherboard revision number: A0
```

```
Model number: WS-C3548-XL-EN
```

```
System serial number: FOC0616X0RG
```

```
Configuration register is 0xF
```

Catalyst 2948GL3/4908G-L3/4980G-L3

Per determinare il numero di serie dello chassis, usare il `show hardware` comando:

```
<#root>
```

2948g-13#

show hardware

Model: Cat-2948G-L3 Date: 17:49:42 UTC Tue Mar 18 2003

XPIF FPGA File: xpif_fpga_0_72b_CClk.rbt
XPIF FPGA Date: Wed Dec 8 17:05:42 1999

Slot 0/0:

Chip 0	Reset Count: 0	Chip 1	Reset Count: 0
Chip 2	Reset Count: 0	Chip 3	Reset Count: 0
Chip 4	Reset Count: 0	Chip 5	Reset Count: 0
Chip 6	Reset Count: 0	Chip 7	Reset Count: 0
Chip 8	Reset Count: 0	Chip 9	Reset Count: 0
Chip 10	Reset Count: 0	Chip 11	Reset Count: 0

EPIF Version : 0 CAM size: 32 KB

Ucode Version : 1.0

Ucode Image : EPIF_UCODE_RUNTIME

Port Phy Setup

Port1 :DONE	Port2 :DONE	Port3 :DONE	Port4 :DONE
Port5 :DONE	Port6 :DONE	Port7 :DONE	Port8 :DONE
Port9 :DONE	Port10:DONE	Port11:DONE	Port12:DONE
Port13:DONE	Port14:DONE	Port15:DONE	Port16:DONE
Port17:DONE	Port18:DONE	Port19:DONE	Port20:DONE
Port21:DONE	Port22:DONE	Port23:DONE	Port24:DONE
Port25:DONE	Port26:DONE	Port27:DONE	Port28:DONE
Port29:DONE	Port30:DONE	Port31:DONE	Port32:DONE
Port33:DONE	Port34:DONE	Port35:DONE	Port36:DONE
Port37:DONE	Port38:DONE	Port39:DONE	Port40:DONE
Port41:DONE	Port42:DONE	Port43:DONE	Port44:DONE
Port45:DONE	Port46:DONE	Port47:DONE	Port48:DONE

Slot 0/1:

XPIF Version : 0 CAM size: 128 KB

Ucode Version : 1.0

Ucode Image : XPIF_UCODE_RUNTIME

Port Phy Setup

Port49:DONE	Port50:DONE
-------------	-------------

IDPROM Contents :

FRU Type : 0x0.0x0

OEM String : Cisco_Systems

Product Number : WS-C2948G-L3

Serial Number : FOX05330ADH

Mfg. Assembly No. : 73-4083-07

Mfg. Assembly Ver. : A0

Hardware Version : 1.7

FPGA Version : 0

SNMP IOD : 9.5.1.3.1.1.2.275

RMA Code : 0

Feature Bits : 0x00000000

MAC Address Base : 00:07:85:07:DC:00

Total MAC Adrs. : 1024

Catalyst 9000

Per determinare il numero di serie dello chassis, usare il comando show version. In alternativa, è possibile utilizzare il comando show module per visualizzare un output più piccolo:

```
<#root>
```

```
C9300#
```

```
show version
```

```
Cisco IOS XE Software, Version 17.06.04  
Cisco IOS Software [Bengaluru], Catalyst L3 Switch Software (CAT9K_IOSXE), Version 17.6.4, RELEASE SOFTWARE  
Technical Support: http://www.cisco.com/techsupport  
Copyright (c) 1986-2022 by Cisco Systems, Inc.  
Compiled Sun 14-Aug-22 08:58 by mcpre
```

```
Cisco IOS-XE software, Copyright (c) 2005-2022 by cisco Systems, Inc.  
All rights reserved. Certain components of Cisco IOS-XE software are  
licensed under the GNU General Public License ("GPL") Version 2.0. The  
software code licensed under GPL Version 2.0 is free software that comes  
with ABSOLUTELY NO WARRANTY. You can redistribute and/or modify such  
GPL code under the terms of GPL Version 2.0. For more details, see the  
documentation or "License Notice" file accompanying the IOS-XE software,  
or the applicable URL provided on the flyer accompanying the IOS-XE  
software.
```

```
ROM: IOS-XE ROMMON
```

```
BOOTLDR: System Bootstrap, Version 17.8.1r[FC2], RELEASE SOFTWARE (P)
```

```
C9300 uptime is 1 week, 2 days, 17 hours, 51 minutes  
Uptime for this control processor is 1 week, 2 days, 17 hours, 54 minutes  
System returned to ROM by Reload Command at 07:14:20 jst Wed Aug 2 2023  
System restarted at 07:29:56 jst Wed Aug 2 2023  
System image file is "flash:packages.conf"  
Last reload reason: Reload Command
```

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

Technology Package License Information:

```

-----
Technology-package           Technology-package
Current                       Type                       Next reboot
-----
network-advantage           Smart License             network-advantage
dna-advantage                Subscription Smart License dna-advantage
AIR License Level: AIR DNA Advantage
Next reload AIR license Level: AIR DNA Advantage

```

Smart Licensing Status: Registration Not Applicable/Not Applicable

cisco C9300-24UX (X86) processor with 1317097K/6147K bytes of memory.
 Processor board ID FJC2325E0HB
 5 Virtual Ethernet interfaces
 8 Gigabit Ethernet interfaces
 64 Ten Gigabit Ethernet interfaces
 4 TwentyFive Gigabit Ethernet interfaces
 4 Forty Gigabit Ethernet interfaces
 2048K bytes of non-volatile configuration memory.
 8388608K bytes of physical memory.
 1638400K bytes of Crash Files at crashinfo:.
 11264000K bytes of Flash at flash:.

```

Base Ethernet MAC Address      : c4:c6:03:9a:bd:80
Motherboard Assembly Number    : 73-18276-03
Motherboard Serial Number      : FJZ23210BTF
Model Revision Number          : D0
Motherboard Revision Number    : B0

```

Model Number : C9300-24UX

System Serial Number : FJC2325E0HB

CLEI Code Number :

Switch	Ports	Model	SW Version	SW Image	Mode
*	1 41	C9300-24UX	17.06.04	CAT9K_IOSXE	INSTALL

C9300#

show module

Switch	Ports	Model	Serial No.	MAC address	Hw Ver.	Sw Ver.
1	41					

C9300-24UX

FJC2325E0HB

```

c4c6.039a.bd80 V02          17.06.04

```

Informazioni correlate

- [Comandi show](#)
- [Supporto tecnico Cisco e download](#)

Informazioni su questa traduzione

Cisco ha tradotto questo documento utilizzando una combinazione di tecnologie automatiche e umane per offrire ai nostri utenti in tutto il mondo contenuti di supporto nella propria lingua. Si noti che anche la migliore traduzione automatica non sarà mai accurata come quella fornita da un traduttore professionista. Cisco Systems, Inc. non si assume alcuna responsabilità per l'accuratezza di queste traduzioni e consiglia di consultare sempre il documento originale in inglese (disponibile al link fornito).