



Preface

This guide provides instructions for unpacking the Cisco Network Convergence System (NCS) 4016 chassis and its components, moving the chassis to its permanent location, and mounting the chassis in a rack.

- [Audience, on page i](#)
- [Conventions, on page i](#)
- [Related Documentation, on page ii](#)
- [Changes to This Document, on page iii](#)
- [Obtaining Documentation and Submitting a Service Request, on page iii](#)

Audience

This document is intended for those who unpack the Cisco NCS 4016 chassis and Cisco installation partners who are responsible for moving and securing the Cisco NCS 4016 chassis. No additional knowledge of routing or the Cisco IOS XR software is assumed.

Conventions

This document uses the following conventions:

Convention	Indication
bold font	Commands and keywords and user-entered text appear in bold font .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[]	Elements in square brackets are optional.
{x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Convention	Indication
courier font	Terminal sessions and information the system displays appear in courier font.
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



Note Means *reader take note* . Notes contain helpful suggestions or references to material not covered in the manual.



Tip Means *the following information will help you solve a problem* . The tips information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.



Timesaver Means *the described action saves time* . You can save time by performing the action described in the paragraph.



Caution Means *reader be careful* . In this situation, you might perform an action that could result in equipment damage or loss of data.



Danger IMPORTANT SAFETY INSTRUCTION This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device. SAVE THESE INSTRUCTIONS



Danger Statements using this symbol are provided for additional information and to comply with regulatory and customer requirements.

Related Documentation

For complete planning and installation information, see the following documents:

- Cisco Network Convergence System 4000 Series Hardware Installation Guide

- Regulatory Compliance and Safety Information for the Cisco Network Convergence System 4000 Series Chassis

Changes to This Document

Table 1: [Changes to This Document](#) , on page iii lists the technical changes made to this document since it was first created.

Table 1: Changes to This Document

Date	Change Summary
May 2015	Initial release of this document.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at: <http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html> .

Subscribe to *What's New in Cisco Product Documentation* , which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.

