

# Release Notes for Cisco 5400 Enterprise Network Compute System, BIOS Release ENCS54\_2.13

First Published: 2021-02-04

## About the Cisco 5400 Enterprise Network Compute System

The Cisco 5400 Enterprise Network Compute System (ENCS) combines routing, switching, storage, processing, and a host of other computing and networking activities into a compact one Rack Unit (RU) box. This high-performance unit achieves this goal by providing the infrastructure to deploy virtualized network functions while at the same time acting as a server that addresses processing, workload, and storage challenges.

### What's New


- **PXE Boot Mode:** PXE Boot Mode is a new configuration option in the BIOS **Advanced** option list in CIMC, which can be configured like any other BIOS configuration option in the list. PXE boot mode allows you to configure PXE boot for legacy mode, UEFI mode, or disable it when not in use. Starting from NFVIS 4.5, BIOS 2.13 and CIMC 3.2.12.1, PXE boot is disabled by default.

## Resolved and Open Bugs in BIOS Release ENCS54\_2.13


### About the Cisco Bug Search Tool

Use the [Cisco Bug Search Tool](#) to access open and resolved bugs for a release.

The tool allows you to search for a specific bug ID, or for all bugs specific to a product and a release.



You can filter the search results by last modified date, bug status (open, resolved), severity, rating, and support cases.



### Open Bugs for BIOS Release ENCS54\_2.13

None.

### Resolved Bugs for BIOS Release ENCS54\_2.13

Caveat ID Number	Description
<a href="#">CSCvp71899</a>	Redundant backplane interfaces showing up in boot order
<a href="#">CSCvp73540</a>	Enhance displaying GE ports in BIOS for PXE boot
<a href="#">CSCvu69513</a>	UEFI PXE boot: GE0, GE1 NIC's are not Detected in UCS-E M3 server module.
<a href="#">CSCvv87924</a>	BIOS password unable to be cleared
<a href="#">CSCvw07421</a>	Evaluation of csx for Intel 2020.2 IPU

## Related Documentation

- [API Reference for Cisco Enterprise Network Function Virtualization Infrastructure Software](#)
- [Cisco Enterprise Network Function Virtualization Infrastructure Software Command Reference](#)
- [https://www.cisco.com/c/en/us/td/docs/routers/nfvis/release\\_notes/3-10-1/cisco-enterprise-nfvis-release-notes-3-10-1.html](https://www.cisco.com/c/en/us/td/docs/routers/nfvis/release_notes/3-10-1/cisco-enterprise-nfvis-release-notes-3-10-1.html)
- [Cisco 5400 Enterprise Network Compute System Hardware Installation Guide](#)
- [Cisco 5400 Enterprise Network Compute System Data Sheet](#)
- [Getting Started Guide for Cisco UCS E-Series Servers and the Cisco UCS E-Series Network Compute Engine](#)
- [Cisco UCS C220 M4 Server Installation and Service Guide](#)
- [Configuration Guide for Cisco Network Plug and Play on Cisco APIC-EM](#)

## Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).

- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

### **Cisco Bug Search Tool**

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.

