



# Cisco UCS Director Release Notes, Release 6.8

---

**First Published:** 2021-03-17

**Last Modified:** 2024-06-27

## Cisco UCS Director Release Notes

### Cisco UCS Director

Cisco UCS Director delivers unified, highly secure management for supported compute, network, storage, and virtualization platforms and for the industry's leading converged infrastructure solutions, which are based on the Cisco Unified Computing System (Cisco UCS) and Cisco Nexus platforms. Cisco UCS Director extends the unification of computing and network layers through Cisco UCS to provide data center administrators with comprehensive visibility and management capabilities for compute, network, storage, and virtualization. For more information, see [Cisco UCS Director on Cisco.com](#).

### Revision History

Release	Date	Description
6.8	March 17, 2021	Created for Release 6.8.

Release	Date	Description
6.8(1.0)	September 29, 2021	<p>Updated to include information on Release 6.8(1.0). See the following sections:</p> <ul style="list-style-type: none"> <li>• <a href="#">Supported Migration Paths to Cisco UCS Director, Release 6.8(1.0)</a>, on page 11</li> <li>• <a href="#">Supported Upgrade Paths to Cisco UCS Director, Release 6.8(1.0)</a>, on page 11</li> <li>• <a href="#">Supported Migration Paths for Bare Metal Agent Release 6.8(1.0)</a>, on page 12</li> <li>• <a href="#">Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(1.0)</a>, on page 12</li> <li>• <a href="#">New and Changed Features in Release 6.8(1.0)</a>, on page 22</li> <li>• <a href="#">Open Bugs in Release 6.8(1.0)</a>, on page 26</li> <li>• <a href="#">Resolved Bugs in Release 6.8(1.0)</a>, on page 28</li> </ul>
6.8(2.0)	December 22, 2021	<p>Updated to include information on Release 6.8(2.0). See the following sections:</p> <ul style="list-style-type: none"> <li>• <a href="#">Supported Upgrade Paths to Cisco UCS Director, Release 6.8(2.0)</a>, on page 12</li> <li>• <a href="#">Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(2.0)</a>, on page 13</li> <li>• <a href="#">New and Changed Features in Release 6.8(2.0)</a>, on page 23</li> <li>• <a href="#">Open Bugs in Release 6.8(2.0)</a>, on page 27</li> <li>• <a href="#">Resolved Bugs in Release 6.8(2.0)</a>, on page 29</li> </ul>

Release	Date	Description
6.8(3.0)	March 14, 2022	<p>Updated to include information on Release 6.8(3.0). See the following sections:</p> <ul style="list-style-type: none"><li>• <a href="#">Supported Upgrade Paths to Cisco UCS Director, Release 6.8(3.0), on page 13</a></li><li>• <a href="#">Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(3.0), on page 13</a></li><li>• <a href="#">New and Changed Features in Release 6.8(3.0), on page 23</a></li><li>• <a href="#">Open Bugs in Release 6.8(3.0), on page 27</a></li><li>• <a href="#">Resolved Bugs in Release 6.8(3.0), on page 29</a></li></ul>
6.8(4.0)	July 15, 2022	<p>Updated to include information on Release 6.8(4.0). See the following sections:</p> <ul style="list-style-type: none"><li>• <a href="#">Supported Upgrade Paths to Cisco UCS Director, Release 6.8(4.0), on page 13</a></li><li>• <a href="#">Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(4.0), on page 14</a></li><li>• <a href="#">New and Changed Features in Release 6.8(4.0), on page 24</a></li><li>• <a href="#">Open Bugs in Release 6.8(4.0), on page 27</a></li><li>• <a href="#">Resolved Bugs in Release 6.8(4.0), on page 29</a></li></ul>

Release	Date	Description
6.8(5.0)	December 2, 2022	<p>Updated to include information on Release 6.8(5.0). See the following sections:</p> <ul style="list-style-type: none"> <li>• <a href="#">Supported Upgrade Paths to Cisco UCS Director, Release 6.8(5.0), on page 14</a></li> <li>• <a href="#">Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(5.0), on page 15</a></li> <li>• <a href="#">New and Changed Features in Release 6.8(5.0), on page 24</a></li> <li>• <a href="#">Open Bugs in Release 6.8(5.0), on page 27</a></li> <li>• <a href="#">Resolved Bugs in Release 6.8(5.0), on page 29</a></li> </ul>
6.8(6.0)	April 10, 2023	<p>Updated to include information on Release 6.8(6.0). See the following sections:</p> <ul style="list-style-type: none"> <li>• <a href="#">Supported Upgrade Paths to Cisco UCS Director, Release 6.8(6.0), on page 15</a></li> <li>• <a href="#">Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(6.0), on page 15</a></li> <li>• <a href="#">New and Changed Features in Release 6.8(6.0), on page 25</a></li> <li>• <a href="#">Open Bugs in Release 6.8(6.0), on page 27</a></li> <li>• <a href="#">Resolved Bugs in Release 6.8(6.0), on page 30</a></li> </ul>

Release	Date	Description
6.8(7.0)	July 4, 2023	<p>Updated to include information on Release 6.8(7.0). See the following sections:</p> <ul style="list-style-type: none"><li>• <a href="#">Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(7.0)</a>, on page 16</li><li>• <a href="#">Supported Upgrade Paths to Cisco UCS Director, Release 6.8(7.0)</a>, on page 16</li><li>• <a href="#">New and Changed Features in Release 6.8(7.0)</a>, on page 25</li><li>• <a href="#">Open Bugs in Release 6.8(7.0)</a>, on page 27</li><li>• <a href="#">Resolved Bugs in Release 6.8(7.0)</a>, on page 30</li></ul>
6.8(8.0)	October 13, 2023	<p>Updated to include information on Release 6.8(8.0). See the following sections:</p> <ul style="list-style-type: none"><li>• <a href="#">Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(8.0)</a>, on page 17</li><li>• <a href="#">Supported Upgrade Paths to Cisco UCS Director, Release 6.8(8.0)</a>, on page 17</li><li>• <a href="#">New and Changed Features in Release 6.8(8.0)</a>, on page 25</li><li>• <a href="#">Open Bugs in Release 6.8(8.0)</a>, on page 27</li><li>• <a href="#">Resolved Bugs in Release 6.8(8.0)</a>, on page 30</li></ul>

Release	Date	Description
6.8(9.0)	June 27, 2024	<p>Updated to include information on Release 6.8(9.0). See the following sections:</p> <ul style="list-style-type: none"> <li>• <a href="#">Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(9.0)</a>, on page 18</li> <li>• <a href="#">Supported Upgrade Paths to Cisco UCS Director, Release 6.8(9.0)</a>, on page 18</li> <li>• <a href="#">New and Changed Features in Release 6.8(9.0)</a>, on page 26</li> <li>• <a href="#">Open Bugs in Release 6.8(9.0)</a>, on page 28</li> <li>• <a href="#">Resolved Bugs in Release 6.8(9.0)</a>, on page 30</li> </ul>

## System Requirements

The system requirements for this release are available in the [Cisco UCS Director installation and upgrade guides](#) for the following:

- VMware vSphere
- Microsoft Hyper-V

### Supported Browser Versions

Cisco UCS Director supports the following browsers:

- Microsoft Edge version 120.x.x.x or higher
- Firefox version 120.x or higher
- Safari 17.x or higher
- Google Chrome version 120.x.x.x or higher

## Minimum System Requirements for a Single-Node Setup

The following tables detail the minimum resource requirements for a single-node setup of . Cisco recommends a single-node setup for installations of up to 5000 VMs.

For optimal performance, the entire memory and CPU allocations specified in the table below should be reserved. Failure to follow these specifications could affect performance. For example, 4 vCPU cores with 3000 MHz and 16G of memory must be reserved for the VM.

The minimum memory required for the **inframgr** service is automatically set during deployment. To enable the **inframgr** service to use more than the minimum required memory, edit the `inframgr.env` file available in the following location:

```
/opt/infra/bin/
```

In this file, update the MEMORY\_MAX parameter to the value you want. To activate the changes, restart the **inframgr** service.

The default memory settings are MEMORY\_MIN=8192m and MEMORY\_MAX=8192m.

For information about minimum system requirements for a multi-node setup, see the [Cisco UCS Director Multi-Node Installation and Configuration Guide](#).

**Table 1: Minimum system requirements for a single-node installation (up to 5,000 VMs)**

Element	Minimum Supported Requirement
vCPU	4
Allocated Memory	16 GB
Reserved Memory	16 GB
Disk Space	100 GB
Disk Write I/O Bandwidth	4 MBps
Disk Read I/O Bandwidth	4 MBps
Memory Allocated for <b>inframgr</b>	8 GB

Restart the database and all services after making these changes to the `/etc/my.cnf`.

## Minimum System Requirements for a Multi-Node Setup

### System Requirements for the Primary Node

Number of VMs	vCPU Allocation	Memory Allocation (GB)	Memory Reservation (GB)	Disk Size (GB)	Inframgr Memory Allocation (GB)
1 - 5000	4	16	16	100	8
5001 - 10000	4	22	22	100	12
10001 - 15000	4	28	28	100	12
15001 - 20000	4	34	34	100	16
20001 - 25000	8	40	40	100	16
25001 - 30000	8	46	46	100	24
30001 - 35000	8	52	52	100	24
35001 - 40000	8	58	58	100	28
40001 - 45000	8	64	64	100	28
45001 - 50000	8	64	64	100	32

You can configure the Inframgr memory allocation in the `/opt/infra/bin/inframgr.env` file.

## System Requirements for the Database Node

Number of VMs	vCPU Allocation	Memory Allocation (GB)	Memory Reservation (GB)	Disk Read I/O Bandwidth (MBps)	Disk Write I/O Bandwidth (MBps)	Disk Size (GB)	Database InnoDB Buffer Pool (GB)
1 - 5000	4	12	12	4	4	100	8
5001 - 10000	4	16	16	6	6	100	12
10001 - 15000	4	28	28	8	8	100	24
15001 - 20000	4	40	40	10	10	200	36
20001 - 25000	8	52	52	12	12	200	48
25001 - 30000	8	64	64	14	14	200	60
30001 - 35000	8	76	76	16	16	300	72
35001 - 40000	16	90	90	18	18	600	84
40001 - 45000	16	90	90	20	20	600	84
45001 - 50000	16	90	90	22	22	600	84

You can configure the Database InnoDB Buffer Pool parameter in the `/etc/my.cnf` file.



**Note** To determine the currently configured disk read I/O bandwidth and disk write I/O bandwidth, use the **Collect Diagnostics** option from the Cisco UCS Director Shell Admin menu.

## Database Parameters

VMs	Thread Cache Size	Maximum Connections	innodb lock wait timeout	Query Cache Size (MB)	Maximum Connection Errors	Connection Timeout	innodb read I/O Threads	innodb write I/O Threads
1 - 5000	1000	1000	100	128	10000	20	64	64



VMs	Thread Cache Size	Maximum Connections	innodb lock wait timeout	Query Cache Size (MB)	Maximum Connection Errors	Connection Timeout	innodb read I/O Threads	innodb write I/O Threads
5001 - 10000	1000	1000	100	128	10000	20	64	64
10001 - 15000	1000	1000	100	128	10000	20	64	64
15001 - 20000	1000	1000	100	128	10000	20	64	64
20001 - 25000	2000	2000	100	128	10000	20	64	64
25001 - 30000	2000	2000	100	128	10000	20	64	64
30001 - 35000	4000	2000	100	128	10000	20	64	64
35001 - 40000	4000	4000	100	128	10000	20	64	64
40001 - 45000	4000	4000	100	128	10000	20	64	64
45001 - 50000	4000	4000	100	128	10000	20	64	64

Configure these parameters in the `/etc/my.cnf` file.

## Installation and Upgrade Notes

Cisco UCS Director uses a standard virtual machine that is delivered in OVA format for VMware, and in VHD format for Microsoft Hyper-V. It can be hosted on VMware vSphere or vCenter, or on Microsoft Hyper-V Manager. For installation instructions, see the appropriate [Cisco UCS Director installation guide](#).

### Installation and Upgrade Notes for Cisco UCS Director, Release 6.8

Cisco UCS Director Release 6.8 uses a new version of CentOS operating system and My SQL version. The previous releases of Cisco UCS Director use CentOS version 6.x, which has now reached End of Life. To continue to receive support for security issues and patches, upgrade to Cisco UCS Director 6.8 and Cisco UCS Director Bare Metal Agent 6.8.



**Note** Cisco UCS Director OVA and VHD zip files are created using zip 3.x in Cisco UCS Director, Release 6.8. For Linux systems, you can extract the zip files with unzip 6.x or higher or with the latest version of the 7-Zip archiving tool. For Windows systems, you can extract the zip files with the native Extract All in Windows Explorer for Windows 10 and Windows Server 2012 or with the latest versions of archiving tools such as 7-Zip or WinRAR.

### Installation and Upgrade Notes for Cisco UCS Director Release 6.8(1.0)

Cisco UCS Director Release 6.8(1.0) uses a new version of CentOS operating system, MariaDB, and OpenJDK. To continue to receive support for security issues and patches, upgrade to Cisco UCS Director 6.8(1.0) and Cisco UCS Director Bare Metal Agent 6.8(1.0).




---

**Note** Cisco UCS Director OVA and VHD zip files are created using zip 3.x in Cisco UCS Director, Release 6.8(1.0). For Linux systems, you can extract the zip files with unzip 6.x or higher or with the latest version of the 7-Zip archiving tool. For Windows systems, you can extract the zip files with the native Extract All in Windows Explorer for Windows 10 and Windows Server 2012 or with the latest versions of archiving tools such as 7-Zip or WinRAR.

---

### Installing Cisco UCS Director Powershell Agent

Installing a newer version of the PowerShell Agent requires that you uninstall the older version first. To remove the older version of PowerShell Agent, stop the Cisco PSA Service first and then uninstall the agent. For instructions on installing, see [Cisco UCS Director PowerShell Agent Installation and Configuration Guide, Release 6.8](#).

## Supported Migration Paths to Cisco UCS Director, Release 6.8

The following are the supported migration paths for Cisco UCS Director, Release 6.8.

See the [Cisco UCS Director Upgrade Guide](#) for detailed steps on how to migrate to Release 6.8 from your current release.




---

**Important** You must upgrade to Cisco UCS Director, Release 6.7(4.x) before migrating to Cisco UCS Director, Release 6.8. For more information about upgrading to Cisco UCS Director, Release 6.7(4.x), see the *Supported Upgrade Paths to Cisco UCS Director, Release 6.7* section documented in the [Cisco UCS Director Release Notes, Release 6.7](#).

---

The following are the supported migrated paths for the Cisco UCS Director Release 6.8:

- From Release 6.7(4.0) to Release 6.8
- From Release 6.7(4.1) to Release 6.8
- From Release 6.7(4.2) to Release 6.8
- From Release 6.7(4.3) to Release 6.8




---

**Note** Before migrating from Release 6.7(4.x) to Release 6.8, in progress service requests (SRs) must be in completed state (no in progress service requests) because you cannot complete the service requests after migrating to Release 6.8.

---

## Supported Migration Paths for Bare Metal Agent Release 6.8

The following are the supported migration paths for the Bare Metal Agent Release 6.8:



---

**Important** You must upgrade to Bare Metal Agent Patch, Release 6.7(4.x) before migrating to Bare Metal Agent, Release 6.8. For more information, see the *Supported Upgrade Paths for Bare Metal Agent Patch, Release 6.7(4.x)* section documented in the [Cisco UCS Director Release Notes, Release 6.7](#).

---

- From Release 6.7(4.0) to Release 6.8
- From Release 6.7(4.2) to Release 6.8

## Supported Migration Paths to Cisco UCS Director, Release 6.8(1.0)

The following are the supported migration paths for Cisco UCS Director, Release 6.8(1.0).

See the [Cisco UCS Director Upgrade Guide](#) for detailed steps on how to migrate to Release 6.8(1.0) from your current release.



---

**Important** You must upgrade to Cisco UCS Director, Release 6.7(4.x) before migrating to Cisco UCS Director, Release 6.8(1.0). For more information about upgrading to Cisco UCS Director, Release 6.7(4.x), see the *Supported Upgrade Paths to Cisco UCS Director, Release 6.7* section documented in the [Cisco UCS Director Release Notes, Release 6.7](#).

---



---

**Important** Cisco UCS Director Release 6.7, Release 6.7(1.0), Release 6.7(2.0), Release 6.7(3.0), and Release 6.7(4.0) are no longer available for download. We recommend that you upgrade immediately to Cisco UCS Director Release 6.8(1.0). For more information, contact the Cisco Support Team.

---

The following are the supported migrated paths for the Cisco UCS Director Release 6.8(1.0):

- From Release 6.7(4.0) to Release 6.8(1.0)
- From Release 6.7(4.1) to Release 6.8(1.0)
- From Release 6.7(4.2) to Release 6.8(1.0)
- From Release 6.7(4.3) to Release 6.8(1.0)



---

**Note** Before migrating from Release 6.7(4.x) to Release 6.8(1.0), in progress service requests (SRs) must be in completed state (no in progress service requests) because you cannot complete the service requests after migrating to Release 6.8(1.0).

---

## Supported Upgrade Paths to Cisco UCS Director, Release 6.8(1.0)

The following are the supported upgrade paths for Cisco UCS Director, Release 6.8(1.0).

See the [Cisco UCS Director Upgrade Guide](#) for detailed steps on how to migrate to Release 6.8 from your current release.

### Upgrade Paths from Release 6.8

- From Release 6.8 to Release 6.8(1.0)

### Upgrading from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(1.0). You must first upgrade to Release 6.7(3.0) and Release 6.7(4.0) and then migrate to Release 6.8(1.0).

- From Release 6.5(0.4) to Release 6.7(3.0) to Release 6.7(4.0)
- From Release 6.6(2.0) to Release 6.7(3.0) to Release 6.7(4.0)
- From Release 6.7(3.0) to Release 6.7(4.0)



#### Important

Cisco UCS Director Release 6.7, Release 6.7(1.0), Release 6.7(2.0), Release 6.7(3.0), and Release 6.7(4.0) are no longer available for download. We recommend that you upgrade immediately to Cisco UCS Director Release 6.8(1.0). For more information, contact the Cisco Support Team.

### Supported Migration Paths for Bare Metal Agent Release 6.8(1.0)

The following are the supported migration paths for the Bare Metal Agent Release 6.8(1.0):

- From Release 6.7(4.0) to Release 6.8(1.0)
- From Release 6.7(4.2) to Release 6.8(1.0)

### Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(1.0)

The following are the supported upgrade paths for the Bare Metal Agent Patch Release 6.8(1.0):

- From Release 6.8 to Patch Release 6.8(1.0)

### Supported Upgrade Paths to Cisco UCS Director, Release 6.8(2.0)

The following are the supported upgrade paths for Cisco UCS Director, Release 6.8(2.0).

See the [Cisco UCS Director Upgrade Guide](#) for detailed steps on how to migrate to Release 6.8 from your current release.



#### Note

Cisco UCS Director Release 6.8(2.0) includes fixes for security vulnerabilities reported in releases 6.7(4.1), 6.7(4.2), 6.7(4.3), 6.8, and 6.8(1.0). For information on the security vulnerabilities reported in releases 6.7(4.1), 6.7(4.2), 6.7(4.3), 6.8, and 6.8(1.0), see the security advisories for CVE-2021-44228 and CVE-2021-45046 available at this link:

<https://tools.cisco.com/security/center/publicationListing.x>

### Upgrade Paths from Release 6.8(x.x)

- From Release 6.8(1.0) to Release 6.8(2.0)
- From Release 6.8 to Release 6.8(1.0) to Release 6.8(2.0)

### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(2.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x) and then upgrade to Release 6.8(2.0).

### Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(2.0)

The following are the supported upgrade paths for the Bare Metal Agent Patch Release 6.8(2.0):

- From Release 6.8(1.0) to Patch Release 6.8(2.0)
- From Release 6.8 to Patch Release 6.8(1.0) to Patch Release 6.8(2.0)

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(2.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x) and then upgrade to Release 6.8(2.0).

### Supported Upgrade Paths to Cisco UCS Director, Release 6.8(3.0)

The following are the supported upgrade paths for Cisco UCS Director, Release 6.8(3.0).

See the [Cisco UCS Director Upgrade Guide](#) for detailed steps on how to migrate to Release 6.8 from your current release.

#### Upgrade Paths from Release 6.8(x.x)

- From Release 6.8(2.0) to Release 6.8(3.0)
- From Release 6.8(1.0) to Release 6.8(3.0)
- From Release 6.8 to Release 6.8(1.0) to Release 6.8(3.0)

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(3.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x) and then upgrade to Release 6.8(3.0).

### Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(3.0)

The following are the supported upgrade paths for the Bare Metal Agent Patch Release 6.8(3.0):

- From Release 6.8(2.0) to Release 6.8(3.0)
- From Release 6.8(1.0) to Patch Release 6.8(3.0)
- From Release 6.8 to Release 6.8(1.0) to Release 6.8(3.0)

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(3.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x) and then upgrade to Release 6.8(3.0).

### Supported Upgrade Paths to Cisco UCS Director, Release 6.8(4.0)

The following are the supported upgrade paths for Cisco UCS Director, Release 6.8(4.0).

See the [Cisco UCS Director Upgrade Guide](#) for detailed steps on how to migrate to Release 6.8 from your current release.

#### Upgrade Paths from Release 6.8(x.x)

- From Release 6.8(1.0) to Release 6.8(4.0)
- From Release 6.8(2.0) to Release 6.8(4.0)
- From Release 6.8(3.0) to Release 6.8(4.0)




---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(4.0).

---

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(4.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(4.0).

### Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(4.0)

The following are the supported upgrade paths for the Bare Metal Agent Patch Release 6.8(4.0):

- From Release 6.8(1.0) to Release 6.8(4.0)
- From Release 6.8(2.0) to Release 6.8(4.0)
- From Release 6.8(3.0) to Release 6.8(4.0)




---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(4.0).

---

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(4.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(4.0).

### Supported Upgrade Paths to Cisco UCS Director, Release 6.8(5.0)

The following are the supported upgrade paths for Cisco UCS Director, Release 6.8(5.0).

See the [Cisco UCS Director Upgrade Guide](#) for detailed steps on how to migrate to Release 6.8 from your current release.

#### Upgrade Paths from Release 6.8(x.x)

- From Release 6.8(1.0) to Release 6.8(5.0)
- From Release 6.8(2.0) to Release 6.8(5.0)
- From Release 6.8(3.0) to Release 6.8(5.0)
- From Release 6.8(4.0) to Release 6.8(5.0)




---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(5.0).

---

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(5.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(5.0).

### Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(5.0)

The following are the supported upgrade paths for the Bare Metal Agent Patch Release 6.8(5.0):

- From Release 6.8(1.0) to Release 6.8(5.0)
- From Release 6.8(2.0) to Release 6.8(5.0)
- From Release 6.8(3.0) to Release 6.8(5.0)
- From Release 6.8(4.0) to Release 6.8(5.0)



---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(5.0).

---

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(5.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(5.0).

### Supported Upgrade Paths to Cisco UCS Director, Release 6.8(6.0)

The following are the supported upgrade paths for Cisco UCS Director, Release 6.8(6.0).

See the [Cisco UCS Director Upgrade Guide](#) for detailed steps on how to migrate to Release 6.8 from your current release.

#### Upgrade Paths from Release 6.8(x.x)

- From Release 6.8(1.0) to Release 6.8(6.0)
- From Release 6.8(2.0) to Release 6.8(6.0)
- From Release 6.8(3.0) to Release 6.8(6.0)
- From Release 6.8(4.0) to Release 6.8(6.0)
- From Release 6.8(5.0) to Release 6.8(6.0)



---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(6.0).

---

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(6.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(6.0).

### Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(6.0)

The following are the supported upgrade paths for the Bare Metal Agent Patch Release 6.8(6.0):

- From Release 6.8(1.0) to Release 6.8(6.0)

- From Release 6.8(2.0) to Release 6.8(6.0)
- From Release 6.8(3.0) to Release 6.8(6.0)
- From Release 6.8(4.0) to Release 6.8(6.0)
- From Release 6.8(5.0) to Release 6.8(6.0)




---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(6.0).

---

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(6.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(6.0).

### Supported Upgrade Paths to Cisco UCS Director, Release 6.8(7.0)

The following are the supported upgrade paths for Cisco UCS Director, Release 6.8(7.0).

See the [Cisco UCS Director Upgrade Guide](#) for detailed steps on how to migrate to Release 6.8 from your current release.

#### Upgrade Paths from Release 6.8(x.x)

- From Release 6.8(1.0) to Release 6.8(7.0)
- From Release 6.8(2.0) to Release 6.8(7.0)
- From Release 6.8(3.0) to Release 6.8(7.0)
- From Release 6.8(4.0) to Release 6.8(7.0)
- From Release 6.8(5.0) to Release 6.8(7.0)
- From Release 6.8(6.0) to Release 6.8(7.0)




---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(7.0).

---

#### Migration from Versions Prior to Release 6.8

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(7.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(7.0).

### Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(7.0)

The following are the supported upgrade paths for the Bare Metal Agent Patch Release 6.8(7.0):

- From Release 6.8(1.0) to Release 6.8(7.0)
- From Release 6.8(2.0) to Release 6.8(7.0)
- From Release 6.8(3.0) to Release 6.8(7.0)
- From Release 6.8(4.0) to Release 6.8(7.0)



- From Release 6.8(5.0) to Release 6.8(7.0)
- From Release 6.8(6.0) to Release 6.8(7.0)



---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(7.0).

---

#### **Migration from Versions Prior to Release 6.8**

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(7.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(7.0).

### **Supported Upgrade Paths to Cisco UCS Director, Release 6.8(8.0)**

The following are the supported upgrade paths for Cisco UCS Director, Release 6.8(8.0).

See the [Cisco UCS Director Upgrade Guide, Release 6.8](#) for detailed steps on how to migrate to Release 6.8 from your current release.

#### **Upgrade Paths from Release 6.8(x.x)**

- From Release 6.8(1.0) to Release 6.8(8.0)
- From Release 6.8(2.0) to Release 6.8(8.0)
- From Release 6.8(3.0) to Release 6.8(8.0)
- From Release 6.8(4.0) to Release 6.8(8.0)
- From Release 6.8(5.0) to Release 6.8(8.0)
- From Release 6.8(6.0) to Release 6.8(8.0)
- From Release 6.8(7.0) to Release 6.8(8.0)



---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(8.0).

---

#### **Migration from Versions Prior to Release 6.8**

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(8.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(8.0).

---

### **Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(8.0)**

The following are the supported upgrade paths for the Bare Metal Agent Patch Release 6.8(8.0):

- From Release 6.8(1.0) to Release 6.8(8.0)
- From Release 6.8(2.0) to Release 6.8(8.0)
- From Release 6.8(3.0) to Release 6.8(8.0)
- From Release 6.8(4.0) to Release 6.8(8.0)
- From Release 6.8(5.0) to Release 6.8(8.0)

- From Release 6.8(6.0) to Release 6.8(8.0)
- From Release 6.8(7.0) to Release 6.8(8.0)




---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(8.0).

#### **Migration from Versions Prior to Release 6.8**

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(8.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(8.0).

---

### **Supported Upgrade Paths to Cisco UCS Director, Release 6.8(9.0)**

The following are the supported upgrade paths for Cisco UCS Director, Release 6.8(9.0).

See the [Cisco UCS Director Upgrade Guide, Release 6.8](#) for detailed steps on how to migrate to Release 6.8 from your current release.

#### **Upgrade Paths from Release 6.8(x.x)**

- From Release 6.8(1.0) to Release 6.8(9.0)
- From Release 6.8(2.0) to Release 6.8(9.0)
- From Release 6.8(3.0) to Release 6.8(9.0)
- From Release 6.8(4.0) to Release 6.8(9.0)
- From Release 6.8(5.0) to Release 6.8(9.0)
- From Release 6.8(6.0) to Release 6.8(9.0)
- From Release 6.8(7.0) to Release 6.8(9.0)
- From Release 6.8(8.0) to Release 6.8(9.0)




---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(9.0).

#### **Migration from Versions Prior to Release 6.8**

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(9.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(9.0).

---

### **Supported Upgrade Paths for Bare Metal Agent Patch Release 6.8(9.0)**

The following are the supported upgrade paths for the Bare Metal Agent Patch Release 6.8(9.0):

- From Release 6.8(1.0) to Release 6.8(9.0)
- From Release 6.8(2.0) to Release 6.8(9.0)
- From Release 6.8(3.0) to Release 6.8(9.0)
- From Release 6.8(4.0) to Release 6.8(9.0)

- From Release 6.8(5.0) to Release 6.8(9.0)
- From Release 6.8(6.0) to Release 6.8(9.0)
- From Release 6.8(7.0) to Release 6.8(9.0)
- From Release 6.8(8.0) to Release 6.8(9.0)



---

**Note** If you have installed version 6.8, upgrade to Release 6.8(1.0), and then upgrade to Release 6.8(9.0).

#### **Migration from Versions Prior to Release 6.8**

If you have a version prior to Release 6.8 installed, you cannot upgrade directly to Release 6.8(9.0). You must first migrate to Release 6.8(1.0) from Release 6.7(4.x), and then upgrade to Release 6.8(9.0).

---

## New and Changed Features

This section provides an overview of the significant new and changed features in this release. This section does not provide an exhaustive list of all enhancements included in this release.



---

**Note** For information about the physical and virtual devices and software supported by Cisco UCS Director in this release, see the [Compatibility Matrix for this release](#).

---

## New and Changed Features in Release 6.8

### **Data Migration**

In this release, you must migrate the data from Cisco UCS Director Release 6.7.4.x to Cisco UCS Director Release 6.8.



---

**Note** The `dhcpd.conf` file of Bare Metal Agent (version 6.7.4.X) appliance is copied into the migrated Bare Metal Agent (version 6.8.0.0) appliance in the `/etc/dhcp` path.

---

Before you add a Bare Metal Agent account, do the following:

- Ensure to use the same Samba password of the legacy BMA (version 6.7.4.x) in the Samba Password and Confirm Samba Password fields in the migrated BMA (version 6.8.0.0), if the Samba Service for Windows PXE check box is enabled.
- Log into Bare Metal Agent VM using SSH client and update WinPE.wim with eth1 IP address details of the migrated BMA (version 6.8.0.0), if the legacy BMA (version 6.7.4.x) and migrated BMA (version 6.8.0.0) are deployed with different PXE IP addresses.
- Log into Cisco UCS Manager and update the service profile with PXE VLAN details of the migrated BMA (version 6.8.0.0), reset the server, and then resubmit the service request in Cisco UCS Director appliance, if the legacy BMA (version 6.7.4.x) and migrated BMA (version 6.8.X.X) are deployed with

different PXEVLAN ID or a failed service request is available in the migrated Cisco UCS Director appliance (version 6.8.x.x).

Documented in the [Cisco UCS Director Multi-Node Installation and Configuration Guide, Release 6.8](#) and [Cisco UCS Director Bare Metal Agent Installation and Configuration Guide, Release 6.8](#).

### Enhancement to Setting up Non-Secure Connection to the Cisco UCS Director User Interface

In this release of Cisco UCS Director, the user interface is enhanced to setup the non-secure mode. By default, user interface launches in the secure mode. To bypass the secure mode, login to the Shell Admin and enable the **Enable/Disable HTTP** shelladmin option.

Documented in the [Cisco UCS Director Administration Guide, Release 6.8](#) and [Cisco UCS Director Shell Guide, Release 6.8](#).

### Intersight Driven Backup and Restore

Effective with Cisco UCS Director 6.8, MySQL is upgraded to a higher version. Therefore, older Intersight-driven backups belonging to UCS Director Release 6.7(4.x) cannot be restored in Cisco UCS Director, Release 6.8. You must migrate the data to a 6.8 server. See the [Cisco UCS Director Upgrade Guide, Release 6.8](#) for detailed steps on how to migrate to Release 6.8.

### Support for Creating Trigger Template

In this release of Cisco UCS Director, you can create trigger templates using user interface.

Documented in the [Cisco UCS Director Orchestration Guide, Release 6.8](#).

### Support for Locking/Unlocking the Service Requests

In this release of Cisco UCS Director, you can lock a service request to prevent archiving of the service request. You can use the **Lock/Unlock** option to lock or unlock one or more service requests.

Documented in the [Cisco UCS Director Orchestration Guide, Release 6.8](#).

### Enhancement to Bulk Archival of Service Requests

In this release of Cisco UCS Director, the **Bulk Archive** option has been enhanced to archive large number of service requests at a time. You can archive service requests based on the Status with Range or Date with Range.

To archive multiple service requests simultaneously, on the Service Request page, click the **Bulk Archive** option. On the Bulk Archive page, select the required option from the **Bulk Archive** drop-down list.

Documented in the [Cisco UCS Director Administration Guide, Release 6.8](#).

### Enhancements to the Enhanced SSH Command Task

Starting with this release, the **Enhanced SSH Command** task has been enhanced to support Key based authentication in addition to the existing Username/Password authentication. The Key based authentication includes the following information:

- Enable Key Based Authentication
- Authentication Key Generation Type
- Passphrase

Documented in the [Cisco UCS Director Troubleshooting Guide](#).

### **Support for New Versions of Cisco IMC**

This release introduces support for Cisco IMC version 4.1.2a and 4.1.3b. In addition to new features, these software versions include support for new BIOS tokens. All the newly introduced BIOS tokens are now displayed in the Cisco IMC Supervisor user interface while creating a BIOS policy. For information on the BIOS tokens introduced in the Cisco IMC releases, see the CLI and GUI configuration guides available at: <https://www.cisco.com/c/en/us/support/servers-unified-computing/ucs-c-series-integrated-management-controller/products-installation-and-configuration-guides-list.html>

### **Enhancements to Precision Boot Order Policy**

In this release of Cisco UCS Director, Precision Boot Order policy is enhanced to support HTTP boot device type that provides better performance over TFTP-based PXE methods for installing the OS. HTTP boot device type can also be used to run EFI executable from remote HTTP server for diagnostics or configuration.

### **Enhancements to RAID Policy**

In this release of Cisco UCS Director, RAID policy is enhanced to include an option to specify the virtual drive strip size. M2 RAID controller supports only 32K and 64K. Other RAID controllers support 64k, 128k, 256k, 612k, and 1024k.

### **Deprecated Privacy Type in SNMP Policy**

In this release of Cisco UCS Director, SNMP policy with privacy type (encryption method) DES is deprecated. SNMP policy supports only AES. For the existing SNMP policies with privacy type as DES, you should configure the privacy type as AES.

### **Introduction of New REST APIs**

Following are the APIs introduced in this release:

- AssociatedHardwareProfilesbyServer
- AssociatedServersByPolicyName
- userAPILockServiceRequest
- userAPIGetServiceRequestLockStatus

### **Task to Add Comments to Service Request**

This release introduces a task to Add Comments to the Service Request.

Task takes two inputs:

- Service Request Id
- Comments

The input provided to comment will be assigned to the Service Request selected as other input.



---

**Note** It is recommended not to comment a service request which is in progress.

---

### User Outputs

This release introduces added information in the Service Request Page, Workflow Status Tab, where the user outputs of the workflows and the values are displayed.

### LDAP Integration

The supported versions of `ldap.ssl.socket.protocols` for Cisco UCS Director, Release 6.8 are TLSv1.2 and TLSv1.3.

Documented in the [Cisco UCS Director Administration Guide, Release 6.7](#) and [Cisco UCS Director Compatibility Matrix, Release 6.8](#).

## New and Changed Features in Release 6.8(1.0)

### Data Migration

In this release, you must migrate the data from Cisco UCS Director Release 6.7.4.x to Cisco UCS Director Release 6.8(1.0).



---

**Note** The `dhcpd.conf` file of Bare Metal Agent (version 6.7.4.X) appliance is copied into the migrated Bare Metal Agent (version 6.8.1.0) appliance in the `/etc/dhcp` path.

---

Before you add a Bare Metal Agent account, do the following:

- Ensure to use the same Samba password of the legacy BMA (version 6.7.4.x) in the Samba Password and Confirm Samba Password fields in the migrated BMA (version 6.8.1.0), if the Samba Service for Windows PXE check box is enabled.
- Log into Bare Metal Agent VM using SSH client and update `WinPE.wim` with eth1 IP address details of the migrated BMA (version 6.8.1.0), if the legacy BMA (version 6.7.4.x) and migrated BMA (version 6.8.1.0) are deployed with different PXE IP addresses.
- Log into Cisco UCS Manager and update the service profile with PXE VLAN details of the migrated BMA (version 6.8.1.0), reset the server, and then resubmit the service request in Cisco UCS Director appliance, if the legacy BMA (version 6.7.4.x) and migrated BMA (version 6.8.X.X) are deployed with different PXEVLAN ID or a failed service request is available in the migrated Cisco UCS Director appliance (version 6.8.x.x).

Documented in the [Cisco UCS Director Multi-Node Installation and Configuration Guide, Release 6.8](#) and [Cisco UCS Director Bare Metal Agent Installation and Configuration Guide, Release 6.8](#).

### Using MariaDB

Starting with Release 6.8(1.0), Cisco UCS Director uses MariaDB open source database.

### **Auto Export and Import of Global Variables**

In this release of Cisco UCS Director, the export and import of the Global variables are supported in workflows. If the global variable is available in the importing appliance, the global variable will not be imported.

Documented in the [Cisco UCS Director Orchestration Guide, Release 6.8](#).

### **Security Enhancement in Import/Export Workflows**

In this release of Cisco UCS Director, the security of import and export workflows is enhanced.

Documented in the [Cisco UCS Director Orchestration Guide, Release 6.8](#).

### **Enhancements to Working with Custom Tasks**

Effective with Cisco UCS Director 6.8(1.0), you can download custom task code from files in a GitHub repository. Cisco UCS Director supports BitBucket (Git hosting service).

Documented in the [Cisco UCS Director Custom Task Getting Started Guide, Release 6.8](#).

### **Enhancements to Precision Boot Order Policy**

Starting with this release, you can specify LUN and sub-type for a SD card boot in the Precision Boot Order policy. Also, you can specify the MAC address and IP Type for a PXE boot in the Precision Boot Order policy. The existing slot types are refreshed to accommodate the latest additions in Precision Boot Order policy.

### **Enhancement to Configure Rack Server Task**

Starting with this release, the **Configure Rack Server** task is enhanced to support dynamic MAC address in the PXE Boot option of the Precision Boot Order policy.

## **New and Changed Features in Release 6.8(2.0)**

Cisco UCS Director Release 6.8(2.0) includes fixes for security vulnerabilities reported in releases 6.7(4.1), 6.7(4.2), 6.7(4.3), 6.8, and 6.8(1.0). For information on the security vulnerabilities reported in releases 6.7(4.1), 6.7(4.2), 6.7(4.3), 6.8, and 6.8(1.0), see the security advisories for CVE-2021-44228 and CVE-2021-45046 available at this link:

<https://tools.cisco.com/security/center/publicationListing.x>

## **New and Changed Features in Release 6.8(3.0)**

### **Support for Managing System Tasks**

In this release of Cisco UCS Director, you can modify the schedule for multiple VMware and UCSM accounts system tasks. Also, you can enable and disable system tasks for multiple VMware and UCSM accounts.

Documented in the [Cisco UCS Director Administration Guide, Release 6.8](#).

### **Support for Searching Workflows**

In this release of Cisco UCS Director, you can search the workflows by tasks, activities, inputs, outputs, and global variables.

Documented in the [Cisco UCS Director Orchestration Guide, Release 6.8](#).

**Enhancement to Export Service Request Log**

In this release of Cisco UCS Director, you can download the service request log in your local system.

Documented in the [Cisco UCS Director Orchestration Guide, Release 6.8](#).

**Enhancement to CSA Tool**

In this release of Cisco UCS Director, the CSA tool automatically takes the database password from the Cisco UCS Director appliance.

Documented in the [Cisco UCS Director Upgrade Guide, Release 6.8](#).

**New and Changed Features in Release 6.8(4.0)****Support for deleting unused user-created files**

In this release of Cisco UCS Director, you can delete unused user-created files using the **Clean Up User Created Files** system task.

Documented in the [Cisco UCS Director Administration Guide, Release 6.8](#).

**Introduction of new tasks for reserving and releasing IP addresses in Static IP Pool Policy**

This release introduces the following workflow tasks to enable reservation and release of virtual IP addresses for dynamic NICs.

- VMware-Reserve IP Address In Static IP Pool Policy  
In **Task Inputs**, you can select the Static IP Pool and configure the IP addresses that you want to reserve.
- VMware-Release IP Address In Static IP Pool Policy  
In **Task Inputs**, you can select the Static IP Pool and release the reserved IP addresses.

**Support for adding Annotations to ACI 5.X workflows**

In this release, you can use Annotations, instead of Tags in ACI 5.X workflows. Tags are deprecated for Cisco APIC Release 5.2(1) and above.

Documented in the [Cisco UCS Director APIC Management Guide, Release 6.8](#).

**Support for configuring IP Name**

Starting with this release, you can configure IP Name while adding a Subnet to APIC External Network.

Documented in the [Cisco UCS Director APIC Management Guide, Release 6.8](#).

**New and Changed Features in Release 6.8(5.0)****Support for making password reset mandatory for new users**

In this release of Cisco UCS Director, you can choose to make password reset mandatory for new users at first login.

Documented in the [Cisco UCS Director Administration Guide, Release 6.8](#).



**Introduced New library tasks to archive and purge Service requests in bulk**

This release introduces the following library tasks to archive and purge Service requests in bulk.

- Archive Service Requests
- Delete Service Requests

**VMware - Get Free IP Address from Static IP Pool Policy**

This release introduces the library task which helps to get free IP from the static IP Pool.

**New and Changed Features in Release 6.8(6.0)**

Cisco UCS Director Release 6.8(6.0) includes fixes for security vulnerabilities reported in releases 6.8(5.0).

**Enhancement to support overlap feature in reserve IP and release IP workflow tasks**

In this release of Cisco UCS Director, the reserve IP and release IP workflow tasks have been enhanced to support overlap feature to enable IP reservations and release IP reservations across MSPs and organizations.

**New and Changed Features in Release 6.8(7.0)**

Cisco UCS Director Release 6.8(7.0) includes fixes for security vulnerabilities reported in releases 6.8(6.0).

**Deprecated Support for Payment Gateway**

In this release of Cisco UCS Director, due to the Apache Axis vulnerability the payment gateway configuration is deprecated. You will not be able to make a payment or update payment information using Cisco UCS Director.

**Enhanced User Interface to Display Build Number for vCenter and Host Nodes**

In this release for Cisco UCS Director, the user interface has been enhanced to display the build number of vCenter and Host Nodes along with the version number.

**Support for new OS versions for Cisco UCS Director Bare Metal Agent**

In this release for Cisco UCS Director, support for new OS versions has been enabled for Cisco UCS Director Bare Metal Agent. For more information, see [Cisco UCS Director Compatibility Matrix, Release 6.8](#).

**New and Changed Features in Release 6.8(8.0)**

Cisco UCS Director Release 6.8(8.0) includes fixes for security vulnerabilities reported in releases 6.8(7.0)

**Enhancement During Resubmit of a Service Request**

In release 6.8(8.0) of Cisco UCS Director, we have provided a new option to reset the loop execution count during resubmit of a service request.

**Cisco UCS Director and Bare Metal Agent Support UCSX-Series Servers with New OS Versions**

In release 6.8(8.0), Cisco UCS Director and Bare Metal Agent support UCSX Series Servers. For more information, see [Cisco UCS Director Compatibility Matrix, Release 6.8](#).

## New and Changed Features in Release 6.8(9.0)

### Support for Downloading Rack server Firmware Images to Local Cisco UCS Director System

Starting with Cisco UCS Director Release 6.8(9.0), offline configuration of Cisco credentials under **Cisco.com User** configuration page for software downloads from Cisco is discontinued.

For enhanced security, you should activate your device first using **Activate Device** action under **Images- Local** page in order to download Standalone Rack server firmware from Cisco.com.




---

**Note** For enhanced security, device activation done once stays active for an hour, allowing secure downloads. After one hour, you have to re-activate your device with the **Activate Device** action to download software from Cisco.com .

---

## Open and Resolved Bugs

The open and resolved bugs for this release are accessible through the [Cisco Bug Search Tool](#). This web-based tool provides you with access to the Cisco bug tracking system, which maintains information about bugs and vulnerabilities in this product and other Cisco hardware and software products.




---

**Note** You must have a Cisco.com account to log in and access the Cisco Bug Search Tool. If you do not have one, you can [register for an account](#).

---

For more information about the Cisco Bug Search Tool, see the [Bug Search Tool Help & FAQ](#).

## Open Bugs in Release 6.8

You can find detailed information about all open bugs in Release 6.8 through the [open bug search for Release 6.8](#). This search uses the following parameters:

Field	Parameter
<b>Product</b> drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
<b>Releases</b> drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(0.0).
<b>Filter</b>	Choose <b>Open</b> from the Status drop-down list.

## Open Bugs in Release 6.8(1.0)

You can find detailed information about all open bugs in Release 6.8(1.0) through the [open bug search for Release 6.8\(1.0\)](#). This search uses the following parameters:

Field	Parameter
<b>Product</b> drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.

Field	Parameter
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(1.0).
Filter	Choose <b>Open</b> from the Status drop-down list.

## Open Bugs in Release 6.8(2.0)

There are no open bugs in this release.

## Open Bugs in Release 6.8(3.0)

There are no open bugs in this release.

## Open Bugs in Release 6.8(4.0)

There are no open bugs in this release.

## Open Bugs in Release 6.8(5.0)

There are no open bugs in this release.

## Open Bugs in Release 6.8(6.0)

There are no open bugs in this release.

## Open Bugs in Release 6.8(7.0)

You can find detailed information about all open bugs in Release 6.8(7.0) through the [open bug search for Release 6.8\(7.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(7.0).
Filter	Choose <b>Open</b> from the Status drop-down list.

## Open Bugs in Release 6.8(8.0)

You can find detailed information about all open bugs in Release 6.8(8.0) through the [open bug search for Release 6.8\(8.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.

Field	Parameter
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(8.0).
Filter	Choose <b>Open</b> from the Status drop-down list.

## Open Bugs in Release 6.8(9.0)

You can find detailed information about all open bugs in Release 6.8(9.0) through the [open bug search for Release 6.8\(9.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(9.0).
Filter	Choose <b>Open</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8

You can find detailed information about all resolved bugs in Release 6.8 through the [resolved bug search query for Release 6.8](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(0.0).
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8(1.0)

You can find detailed information about all resolved bugs in Release 6.8 through the [resolved bug search query for Release 6.8\(1.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(1.0).
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8(2.0)

You can find detailed information about all resolved bugs in Release 6.8 through the [resolved bug search query for Release 6.8\(2.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(2.0).
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8(3.0)

You can find detailed information about all resolved bugs in Release 6.8 through the [resolved bug search query for Release 6.8\(3.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(3.0).
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8(4.0)

You can find detailed information about all resolved bugs in Release 6.8 through the [resolved bug search query for Release 6.8\(4.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(4.0).
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8(5.0)

You can find detailed information about all resolved bugs in Release 6.8 through the [resolved bug search query for Release 6.8\(5.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(5.0).

Field	Parameter
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8(6.0)

You can find detailed information about all resolved bugs in Release 6.8 through the [resolved bug search query for Release 6.8\(6.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(6.0).
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8(7.0)

You can find detailed information about all resolved bugs in Release 6.8 through the [resolved bug search query for Release 6.8\(7.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(7.0).
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8(8.0)

You can find detailed information about all resolved bugs in Release 6.8(8.0) through the [resolved bug search query for Release 6.8\(8.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(8.0).
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Resolved Bugs in Release 6.8(9.0)

You can find detailed information about all resolved bugs in Release 6.8(9.0) through the [resolved bug search query for Release 6.8\(9.0\)](#). This search uses the following parameters:

Field	Parameter
Product drop-down list	Choose <b>Series/Model</b> and enter Cisco UCS Director.
Releases drop-down list	Choose <b>Affecting or Fixed in these Releases</b> and enter 6.8(9.0).
Filter	Choose <b>Fixed</b> from the Status drop-down list.

## Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

### Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.

