



Configure and Verify Roaming Parameters

- [Packet Retries Limitation, on page 1](#)
- [Configure Maximum Retry Limit for Packet Retransmissions using CLI, on page 1](#)
- [Verify Maximum Retry Limit for Packet Retransmissions using CLI, on page 1](#)

Packet Retries Limitation

Starting from UIW Release 17.15.1, you can set the limit for the packet retransmissions of unicast packets. This includes both aggregate and non-aggregate packets.



Note The maximum retry limit for packet retransmission is 32.

Configure Maximum Retry Limit for Packet Retransmissions using CLI

Procedure

Step 1 Device#configure dot11Radio <N> packet retries <retry-count>
Step 2 Device#write
Step 3 Device#reload

Verify Maximum Retry Limit for Packet Retransmissions using CLI

```
Device#show dot11Radio 1 config
```

```
.
```

```
.  
.  
DFS region: Q  
DFS radar role: auto  
Radar detected: 0  
Indoor deployment: disable  
Rx-SOP Threshold: 0 dBm(AUTO)  
Max packet retries: 32
```