

# Bepaal het serienummer van Catalyst Switch-componenten

## Inhoud

[Inleiding](#)

[Voorwaarden](#)

[Vereisten](#)

[Gebruikte componenten](#)

[Conventies](#)

[Achtergrondinformatie](#)

[Cisco IOS-systeemsoftware](#)

[Catalyst 5500/5000](#)

[Catalyst 4500/4000](#)

[Catalyst 4000 Supervisor Engine I, 403/2948G/2980G](#)

[Catalyst 4500/4000 met Supervisor Engine 2](#)

[Catalyst 4500/4000 Supervisor Engine II+/III/IV](#)

[Catalyst 3750](#)

[Catalyst 3560](#)

[Catalyst 3550](#)

[Catalyst 2950/2970/2940](#)

[Catalyst 2900XL/3500XL](#)

[Catalyst 2948GL3/4908G-L3/4980G-L3 switch](#)

[Catalyst 8510/8540](#)

[Gerelateerde informatie](#)

## Inleiding

Dit document beschrijft hoe de serienummers van verschillende vervangbare onderdelen op Cisco Catalyst switches moeten worden bepaald.

## Voorwaarden

### Vereisten

Er zijn geen specifieke vereisten van toepassing op dit document.

### Gebruikte componenten

De informatie in dit document is gebaseerd op de volgende software- en hardware-versies:

- Verschillende Catalyst switches
- Verschillende softwareversies

De informatie in dit document is gebaseerd op de apparaten in een specifieke laboratoriumomgeving. Alle apparaten die in dit document worden beschreven, hadden een opgeschoonde (standaard)configuratie. Als uw netwerk live is, moet u zorgen dat u de potentiële impact van elke opdracht begrijpt.

## Conventies

Raadpleeg [Cisco Technical Tips](#) Conventies voor meer informatie over documentconventies.

## Achtergrondinformatie

De serienummers zijn nodig om een database te maken van de onderdelen in het netwerk. Wanneer u een serviceaanvraag maakt [met Cisco Technical Support](#), moet u het serienummer van de getroffen apparaten bij de hand hebben. Deze eis geldt in het bijzonder wanneer u een vervangend onderdeel of een RMA (return materials authorisatie) nodig hebt.

Het serienummer van Cisco Catalyst switches kan niet worden gewijzigd. Voor beheersdoeleinden, kunt u de switches van Cisco Catalyst vormen die de software van Cisco IOS® in werking stellen om een douanekoord terug te keren. Om een aangepaste tekenreeks te maken, geeft u **de opdracht chassis-id van de nmp-server** in globale configuratiemodus uit.

Opmerking: Zie [Opdrachten tonen](#) voor meer informatie over [opdrachten tonen](#).

## Cisco IOS-systeemsoftware

Om het serienummer van het chassis en andere onderdelen te bepalen, geeft u de opdracht **diprom** uit:

```
6506#show idprom ?
all                selects all FRU-types
backplane          specify backplane
clock              specify clock <number>
earl               specify earl <slot>
fan-tray           specify fan-tray <number>
interface          interface name
module            specify module <slot>
power-supply       specify power-supply <number>
rp                 specify RP (MSFC) <slot>
supervisor         specify supervisor <slot>
vtt                specify VTT <number>
```

Om het serienummer van het chassis te verkrijgen, geeft u **de opdracht dprom backplane** uit:

```
6506#show idprom backplane
IDPROM for backplane #0
(FRU is 'Catalyst 6500 6-slot backplane')
OEM String = 'Cisco Systems'
Product Number = 'WS-C6506'
Serial Number = 'TBA03270652'
Manufacturing Assembly Number = '73-3436-01'
Manufacturing Assembly Revision = 'A0'
Hardware Revision = 1.0
```

Current supplied (+) or consumed (-) = -A

Om het serienummer van de module te verkrijgen, geef **thhow idprom moduleslot #**commando uit. U kunt ook **de opdracht** modulus opgeven:

```
6506#show module
```

| Mod | Ports | Card Type                            | Model            | Serial No.         |
|-----|-------|--------------------------------------|------------------|--------------------|
| 1   | 2     | Catalyst 6000 supervisor 2 (Active)  | WS-X6K-S2U-MSFC2 | <b>SAD055006NE</b> |
| 3   | 0     | 2 port adapter FlexWAN               | WS-X6182-2PA     | <b>SAD04350EEU</b> |
| 4   | 48    | SFM-capable 48-port 10/100 Mbps RJ45 | WS-X6548-RJ-45   | <b>SAD055108C2</b> |

| Mod | MAC addresses                    | Hw  | Fw         | Sw           | Status |
|-----|----------------------------------|-----|------------|--------------|--------|
| 1   | 0001.6415.a602 to 0001.6415.a603 | 3.2 | 6.1(3)     | 7.5(0.6)HUB6 | Ok     |
| 3   | 0001.6413.c86b to 0001.6413.c8aa | 1.5 | 12.1(13)E1 | 12.1(13)E1   | Ok     |
| 4   | 0001.63d3.e77a to 0001.63d3.e7a9 | 4.0 | 6.3(1)     | 7.5(0.6)HUB6 | Ok     |

| Mod | Sub-Module                 | Model        | Serial      | Hw  | Status |
|-----|----------------------------|--------------|-------------|-----|--------|
| 1   | Policy Feature Card 2      | WS-F6K-PFC2  | SAD055004VA | 3.0 | Ok     |
| 1   | Cat6k MSFC 2 daughterboard | WS-F6K-MSFC2 | SAD055006VF | 2.0 | Ok     |

```
Mod Online Diag Status
```

```
-----  
1 Pass  
3 Not Supported  
4 Pass
```

**Opmerking:** Gebruik de opdracht **show diagbus** om het serienummer van poortadapters op de Flex WAN-module te bepalen.

## Catalyst 5500/5000

Gebruik **de opdracht hoe versie** is om het serienummer van de verschillende hardwarecomponenten te bepalen.

**Opmerking:** Gebruik de opdracht **show diag** op de Route Switch Module (RSM) met veelzijdige interfaceprocessor (VIP) (WS-X5304=) om het serienummer van poortadapters te vinden.

## Catalyst 4500/4000

### Catalyst 4000 Supervisor Engine I, 403/2948G/2980G

Catalyst 4000 met Supervisor Engine I chassisserienummer op Catalyst 4003, 2948G en 2980G is niet leesbaar via een CLI-opdracht. Het serienummer dat in de opdrachtoutput van de **showversie** in het voorbeeld in deze sectie wordt weergegeven, is het serienummer van de Supervisor Engine. Het feitelijke serienummer staat op een sticker aan de buitenkant van het chassis.

```
CAT4003(enable) show version
```

```
WS-C4003 Software, Version NmpSW: 7.1(1a)
```

```
Copyright (c) 1995-2002 by Cisco Systems, Inc.
```

NMP S/W compiled on Feb 8 2002, 17:17:54  
GSP S/W compiled on Feb 08 2002, 17:30:19

System Bootstrap Version: 5.5(5)

Hardware Version: 2.2 Model: WS-C4003 **Serial #: JAE053002JD**

| Mod | Port | Model          | Serial #           | Versions                                  |
|-----|------|----------------|--------------------|---|
| 1   | 0    | WS-X4012       | <b>JAE053002JD</b> | Hw : 2.2<br>Gsp: 7.1(1.0)<br>Nmp: 7.1(1a) |
| 2   | 34   | WS-X4232-GB-RJ | JAE053101RQ        | Hw : 2.3                                  |

| Module | DRAM   |        |        | FLASH  |       |       | NVRAM |      |      |
|--------|--------|--------|--------|--------|-------|-------|-------|------|------|
|        | Total  | Used   | Free   | Total  | Used  | Free  | Total | Used | Free |
| 1      | 65536K | 34119K | 31417K | 12288K | 8832K | 3456K | 480K  | 263K | 217K |

Uptime is 20 days, 6 hours, 5 minutes

## Catalyst 4500/4000 met Supervisor Engine 2

Op Catalyst 4500/4000 Supervisor 2 is het serienummer van het chassis beschikbaar via CLI in versies 5.5(10), 6.3(2) en latere versies. In eerdere versies toont **de** opdracht **hoe** versie het serienummer van de Supervisor Engine in plaats van het serienummer van het chassis. Controleer de externe sticker op het chassis om het serienummer van het chassis in deze eerdere versies te verkrijgen.

## Catalyst 4500/4000 Supervisor Engine II+/III/IV

Om het serienummer van het chassis en andere onderdelen te bepalen, gebruikt u **de** opdracht **Demonstratie**:

```
Switch#show idprom ?
  all          show all non-interface IDPROMs
  chassis     show IDPROM for chassis
  fan-tray    show IDPROM for system fan tray
  interface   show contents of gbic connected to this interface
  module      show IDPROM for module
  power-supply show IDPROM for power supply
  supervisor  show IDPROM for supervisor
```

Om het serienummer van het chassis te verkrijgen, gebruikt u de opdracht **chassis show idprom**:

```
Switch#show idprom chassis
Chassis Idprom :
Common Block Signature = 0xABAB
Common Block Version = 1
Common Block Length = 144
Common Block Checksum = 4081
Idprom Size = 256
Block Count = 2
FRU Major Type = 0x4001
FRU Minor Type = 37
OEM String = Cisco Systems, Inc.
Product Number = WS-C4506
Serial Number = FOX0627A001
Part Number = 73-8107-04
```

Part Revision = 01  
Manufacturing Deviation String = 0  
Hardware Revision = 0.4  
Manufacturing Bits = 0x0000  
Engineering Bits = 0x0000  
Snmp OID = 0.0.0.0.0.0.0.0  
Power Consumption = 0  
RMA Failure Code = 0 0 0 0  
Chassis Block Signature = 0x4001  
Chassis Block Version = 1  
Chassis Block Length = 22  
Chassis Block Checksum = 628  
Feature Bits = 0x0000000000000000  
MAC Base = 000a.4172.df40  
MAC Count = 64

Om het serienummer van de machtslevering te verkrijgen gebruik `thhow idprom macht-levering {1}`  
| 2}opdracht:

Switch#**show idprom power-supply 1**

Power Supply 1 Idprom :  
Common Block Signature = 0xABAB  
Common Block Version = 1  
Common Block Length = 144  
Common Block Checksum = 5857  
Idprom Size = 256  
Block Count = 2  
FRU Major Type = 0x4501  
FRU Minor Type = 1  
OEM String = Cisco Systems, Inc.  
**Product Number = PWR-C4K-1400AC**  
**Serial Number = ABC06260005**  
Part Number = 34-1846-01  
Part Revision = 45  
Manufacturing Deviation String =  
Hardware Revision = 1.0  
Manufacturing Bits = 0x0000  
Engineering Bits = 0x0000  
Snmp OID = 22616.22616.22616.22616.22616.22616.22616.22616  
Power Consumption = 1400  
RMA Failure Code = 0 0 0 0  
Power Supply Block Signature = 0x4501  
PowerSupply Block Version = 1  
PowerSupply Block Length = 20  
PowerSupply Block Checksum = 293  
Feature Bits = 0x0000000000000000  
Current @ 110V = 17  
Current @ 220V = 9  
StackMIB OID = 22616

Om het serienummer van de module te verkrijgen, gebruikt u de opdracht `dprom moduleslot #`. U kunt ook de opdracht modulaire **methode** gebruiken:

Switch#**show module**

| Mod | Ports | Card Type                           | Model    | Serial No.         |
|-----|-------|-------------------------------------|----------|--------------------|
| 1   | 2     | 1000BaseX (GBIC) Supervisor(active) | WS-X4014 | <b>JAB054109H1</b> |
| 3   | 48    | 10/100BaseTX (RJ45)                 | WS-X4148 | <b>JAB025202M6</b> |
| 4   | 6     | 1000BaseX (GBIC)                    | WS-X4306 | <b>JAB023403BG</b> |

| M MAC addresses                    | Hw  | Fw          | Sw               | Status |
|------------------------------------|-----|-------------|------------------|--------|
| 1 000a.4172.df40 to 000a.4172.df41 | 0.5 | 12.1(12r)EW | 12.1(13)EW(0.34) | Ok     |
| 3 0050.730b.2340 to 0050.730b.236f | 1.0 |             |                  | Ok     |
| 4 0010.7bfa.7ca4 to 0010.7bfa.7ca9 | 2.0 |             |                  | Ok     |

## Catalyst 3750

Gebruik de opdracht **show version** is om het serienummer van het chassis en het modeltype switch te bepalen, zoals in het voorbeeld hier wordt getoond. U vindt alle chassisonderdelen, switch- en serienummer informatie in de uitvoer:

### 3750#show version

```
Cisco Internetwork Operating System Software
IOS (tm) C3750 Software (C3750-I5-M), Version 12.1(14)EA1, RELEASE SOFTWARE (fc1
)
Copyright (c) 1986-2003 by cisco Systems, Inc.
Compiled Tue 22-Jul-03 13:17 by antonino
Image text-base: 0x00003000, data-base: 0x008F0CF8
```

```
ROM: Bootstrap program is C3750 boot loader
BOOTLDR: C3750 Boot Loader (C3750-HBOOT-M) Version 12.1(11r)AX, RELEASE SOFTWARE
(fc1)
```

```
3750RJ uptime is 1 hour, 29 minutes
System returned to ROM by power-on
System image file is "flash:c3750-i5-mz.121.14-EA1/c3750-i5-mz.121.14-EA1.bin"
```

```
cisco WS-C3750-24TS (PowerPC405) processor (revision A0) with 120822K/10240K byt
es of memory.
Processor board ID CAT0726R0ZU
Last reset from power-on
Bridging software.
2 Virtual Ethernet/IEEE 802.3 interface(s)
48 FastEthernet/IEEE 802.3 interface(s)
16 Gigabit Ethernet/IEEE 802.3 interface(s)
The password-recovery mechanism is enabled.
```

```
512K bytes of flash-simulated non-volatile configuration memory.
Base ethernet MAC Address : 00:0D:29:B4:18:00
Motherboard assembly number : 73-7055-06
Power supply part number : 341-0034-01
Motherboard serial number : CAT0726043V
Power supply serial number : PHI0708009K
Model revision number : A0
Motherboard revision number : A0
Model number : WS-C3750-24TS-E
System serial number : CAT0726R0ZU
```

### Switch Ports Model SW Version SW Image

```
-----
* 1 26 WS-C3750-24TS 12.1(14)EA1 C3750-I5-M
2 26 WS-C3750-24TS 12.1(14)EA1 C3750-I5-M
3 12 WS-C3750G-12S 12.1(14)EA1 C3750-I5-M
```

### Switch 02

```
-----
Switch Uptime : 1 hour, 29 minutes
Base ethernet MAC Address : 00:0D:29:B4:3F:00
Motherboard assembly number : 73-7055-06
Power supply part number : 341-0034-01
```

Motherboard serial number : CAT07260438  
Power supply serial number : PHI0708008X  
Model revision number : A0  
Motherboard revision number : A0  
**Model number : WS-C3750-24TS-E**  
**System serial number : CAT0726R10A**

### Switch 03

-----  
Switch Uptime : 1 hour, 29 minutes  
Base ethernet MAC Address : 00:0D:BD:6A:3E:00  
Motherboard assembly number : 73-8307-06  
Power supply part number : 341-0048-01  
Motherboard serial number : CAT073205S2  
Power supply serial number : DTH0731055Z  
Model revision number : A0  
Motherboard revision number : A0  
**Model number : WS-C3750G-12S-E**  
**System serial number : CAT0732R0M4**  
Top assembly part number : 800-23419-01  
Top assembly revision number : A0

Configuration register is 0xF

3750#

## Catalyst 3560

Om het serienummer en het modeltype van de switch te bepalen, gebruikt u de opdracht **getoond**:

3560#**show version**

Cisco Internetwork Operating System Software  
IOS (tm) C3560 Software (C3560-I5-M), Version 12.1(19)EA1c, RELEASE SOFTWARE (fc  
2)  
Copyright (c) 1986-2004 by cisco Systems, Inc.  
Compiled Tue 03-Feb-04 05:56 by yenanh  
Image text-base: 0x00003000, data-base: 0x0091D404

ROM: Bootstrap program is C3560 boot loader  
BOOTLDR: C3560 Boot Loader (C3560-HBOOT-M) Version 12.1(19r)EA1b, RELEASE SOFTWA  
RE (fc2)

3-8-03-CATS3560 uptime is 8 weeks, 4 days, 18 hours, 16 minutes  
System returned to ROM by power-on  
System image file is "flash:c3560-i5-mz.121-19.EA1c.bin"

cisco WS-C3560-24PS (PowerPC405) processor (revision D0) with 118776K/12288K byt  
es of memory.

Processor board ID CSG0802P0G4

Last reset from power-on

Bridging software.

1 Virtual Ethernet/IEEE 802.3 interface(s)  
24 FastEthernet/IEEE 802.3 interface(s)  
2 Gigabit Ethernet/IEEE 802.3 interface(s)  
The password-recovery mechanism is enabled.

512K bytes of flash-simulated non-volatile configuration memory.

Base ethernet MAC Address : 00:0E:39:E9:32:80  
Motherboard assembly number : 73-9299-01  
Power supply part number : 341-0029-03  
Motherboard serial number : CAT075108EK

Power supply serial number : LIT074900K3  
Model revision number : D0  
Motherboard revision number : C0  
**Model number : WS-C3560-24PS-E**  
**System serial number : CSG0802P0G4**  
Top Assembly Part Number : 800-24814-01  
Top Assembly Revision Number : D0  
Version ID : N/A  
Hardware Board Revision Number : 0x08

## Catalyst 3550

Om het chassisserienummer en het modeltype van de switch te bepalen, gebruikt u **de opdracht getoond**:

```
Cat3550#show version
Cisco Internetwork Operating System Software
IOS (tm) C3550 Software (C3550-I5Q3L2-M), Version 12.1(12c)EA1, RELEASE SOFTWARE (fc1)
Copyright (c) 1986-2002 by cisco Systems, Inc.
Compiled Mon 25-Nov-02 00:07 by antonino
Image text-base: 0x00003000, data-base: 0x0075FE48

ROM: Bootstrap program is C3550 boot loader

Cat3550 uptime is 4 days, 2 hours, 57 minutes
System returned to ROM by power-on
System image file is "flash:c3550-i5q3l2-mz.121-12c.EA1.bin"

cisco WS-C3550-48 (PowerPC) processor (revision G0) with 65526K/8192K bytes of memory.
Processor board ID CHK0642W02B
Last reset from warm-reset
Bridging software.
Running Layer2/3 Switching Image

Ethernet-controller 1 has 12 Fast Ethernet/IEEE 802.3 interfaces

Ethernet-controller 2 has 12 Fast Ethernet/IEEE 802.3 interfaces

Ethernet-controller 3 has 12 Fast Ethernet/IEEE 802.3 interfaces

Ethernet-controller 4 has 12 Fast Ethernet/IEEE 802.3 interfaces

Ethernet-controller 5 has 1 Gigabit Ethernet/IEEE 802.3 interface

Ethernet-controller 6 has 1 Gigabit Ethernet/IEEE 802.3 interface

48 FastEthernet/IEEE 802.3 interface(s)
2 Gigabit Ethernet/IEEE 802.3 interface(s)

The password-recovery mechanism is enabled.
384K bytes of flash-simulated non-volatile configuration memory.
Base ethernet MAC Address: 00:0B:46:8A:2F:80
Motherboard assembly number: 73-5701-07
Power supply part number: 34-0967-01
Motherboard serial number: CAT0641027L
Power supply serial number: DCA06392BU2
Model revision number: G0
Motherboard revision number: A0
Model number: WS-C3550-48-SMI
System serial number: CHK0642W02B
Configuration register is 0x10F
```



# Catalyst 2950/2970/2940

Om het chassisserienummer en het modeltype van de switch te bepalen, gebruikt u de opdracht **show version**:

```
Cat2950#show version
Cisco Internetwork Operating System Software
IOS (tm) C2950 Software (C2950-I6Q4L2-M), Version 12.1(12c)EA1, RELEASE SOFTWARE (fc1)
Copyright (c) 1986-2002 by cisco Systems, Inc.
Compiled Sun 24-Nov-02 23:31 by antonino
Image text-base: 0x80010000, data-base: 0x80562000
```

ROM: Bootstrap program is CALHOUN boot loader

```
Cat2950 uptime is 4 days, 2 hours, 52 minutes
System returned to ROM by power-on
System image file is "flash:c2950-i6q4l2-mz.121-12c.EA1.bin"
```

```
cisco WS-C2950G-48-EI (RC32300) processor (revision C0) with 21002K bytes of memory.
Processor board ID FHK0624W0HS
Last reset from system-reset
Running Enhanced Image
48 FastEthernet/IEEE 802.3 interface(s)
2 Gigabit Ethernet/IEEE 802.3 interface(s)
```

32K bytes of flash-simulated non-volatile configuration memory.

Base ethernet MAC Address: 00:09:E8:89:4A:40

Motherboard assembly number: 73-7409-08

Power supply part number: 34-0965-01

Motherboard serial number: FOC06230ERQ

Power supply serial number: DAB062143BP

Model revision number: C0

Motherboard revision number: B0

**Model number: WS-C2950G-48-EI**

**System serial number: FHK0624W0HS**

Configuration register is 0xF

# Catalyst 2900XL/3500XL

Om het chassisserienummer en het modeltype van de switch te bepalen, gebruikt u de opdracht **show version**:

```
Switch#show version
Cisco Internetwork Operating System Software
IOS (tm) C3500XL Software (C3500XL-C3H2S-M), Version 12.0(5.2)XU, MAINTENANCE
INTERIM SOFTWARE
Copyright (c) 1986-2000 by cisco Systems, Inc.
Compiled Mon 17-Jul-00 18:29 by ayounes
Image text-base: 0x00003000, data-base: 0x00301F3C
```

ROM: Bootstrap program is C3500XL boot loader

```
Switch uptime is 4 days, 3 hours, 4 minutes
System returned to ROM by power-on
System image file is "flash:c3500XL-c3h2s-mz-120.5.2-XU.bin"
```

```
Cisco WS-C3548-XL (PowerPC403) processor (revision 0x01) with 16384K/1024K bytes
of memory. Processor board ID FOC0616X0RG, with hardware revision 0x00
```

Last reset from power-on

Processor is running Enterprise Edition Software  
Cluster command switch capable  
Cluster member switch capable  
48 FastEthernet/IEEE 802.3 interface(s)  
2 Gigabit Ethernet/IEEE 802.3 interface(s)

32K bytes of flash-simulated non-volatile configuration memory.  
Base ethernet MAC Address: 00:09:7C:8E:78:80  
Motherboard assembly number: 73-3903-09  
Power supply part number: 34-0971-02  
Motherboard serial number: FOC06160L07  
Power supply serial number: APQ061200VZ  
Model revision number: M0  
Motherboard revision number: A0  
**Model number: WS-C3548-XL-EN**  
**System serial number: FOC0616X0RG**  
Configuration register is 0xF

## Catalyst 2948GL3/4908G-L3/4980G-L3 switch

Om het serienummer van het chassis te bepalen, gebruikt u de opdracht **hardware tonen**:

```
2948g-l3#show hardware
```

```
Model: Cat-2948G-L3 Date: 17:49:42 UTC Tue Mar 18 2003
```

```
XPIF FPGA File:      xpif_fpga_0_72b_CClk.rbt  
XPIF FPGA Date:     Wed Dec  8 17:05:42 1999
```

```
Slot 0/0:
```

```
Chip 0 Reset Count: 0      Chip 1 Reset Count: 0  
Chip 2 Reset Count: 0      Chip 3 Reset Count: 0  
Chip 4 Reset Count: 0      Chip 5 Reset Count: 0  
Chip 6 Reset Count: 0      Chip 7 Reset Count: 0  
Chip 8 Reset Count: 0      Chip 9 Reset Count: 0  
Chip 10 Reset Count: 0     Chip 11 Reset Count: 0
```

```
EPIF Version      : 0          CAM size: 32 KB
```

```
Ucode Version     : 1.0
```

```
Ucode Image       : EPIF_UCODE_RUNTIME
```

```
Port Phy Setup
```

```
Port1 :DONE      Port2 :DONE      Port3 :DONE      Port4 :DONE  
Port5 :DONE      Port6 :DONE      Port7 :DONE      Port8 :DONE  
Port9 :DONE      Port10:DONE     Port11:DONE     Port12:DONE  
Port13:DONE     Port14:DONE     Port15:DONE     Port16:DONE  
Port17:DONE     Port18:DONE     Port19:DONE     Port20:DONE  
Port21:DONE     Port22:DONE     Port23:DONE     Port24:DONE  
Port25:DONE     Port26:DONE     Port27:DONE     Port28:DONE  
Port29:DONE     Port30:DONE     Port31:DONE     Port32:DONE  
Port33:DONE     Port34:DONE     Port35:DONE     Port36:DONE  
Port37:DONE     Port38:DONE     Port39:DONE     Port40:DONE  
Port41:DONE     Port42:DONE     Port43:DONE     Port44:DONE  
Port45:DONE     Port46:DONE     Port47:DONE     Port48:DONE
```

```
Slot 0/1:
```

```
XPIF Version      : 0          CAM size: 128 KB
```

```
Ucode Version     : 1.0
```

```
Ucode Image       : XPIF_UCODE_RUNTIME
```

```
Port Phy Setup
```

```
Port49:DONE      Port50:DONE
```

```

IDPROM Contents      :
FRU Type             : 0x0.0x0
OEM String           : Cisco_Systems
Product Number    : WS-C2948G-L3
Serial Number     : FOX05330ADH
Mfg. Assembly No.   : 73-4083-07
Mfg. Assembly Ver.  : A0
Hardware Version     : 1.7
FPGA Version         : 0
SNMP IOD             : 9.5.1.3.1.1.2.275
RMA Code             : 0
Feature Bits         : 0x00000000
MAC Address Base     : 00:07:85:07:DC:00
Total MAC Addrs.    : 1024

```

## Catalyst 8510/8540

Om het serienummer van het chassis te bepalen, gebruikt u **de hardwarecomdracht van de rekenmachine**. Zoek naar het backplaneserial nummer:

```
8510#show hardware
```

```
C8510 named 8510, Date: 03:56:23 UTC Wed Jan 12 2000
```

| Slot | Ctrlr-Type  | Part No.   | Rev | Ser No   | Mfg Date  | RMA No. | Hw Vrs | Tst | EEP |
|------|-------------|------------|-----|----------|-----------|---------|--------|-----|-----|
| 4/*  | Route Proc  | 73-3775-04 | A0  | 0322249G | Oct 01 99 | 0       | 5.7    |     |     |
| 5/*  | Switch Card | 73-3327-07 | B0  | 031111F4 | Mar 14 99 | 0       | 7.2    |     |     |
| 7/*  | Switch Card | 73-3327-07 | B0  | 03151G44 | May 22 99 | 0       | 7.2    |     |     |

```
DS1201 Backplane EEPROM:
```

| Model        | Ver. | Serial          | MAC-Address  | MAC-Size | RMA | RMA-Number | MFG-Date    |
|--------------|------|-----------------|--------------|----------|-----|------------|-------------|
| <b>C8510</b> | 2    | <b>68011735</b> | 0010073D2600 | 1024     | 0   | 0          | Jun 02 1998 |

```
Power Supply:
```

| Slot | Part No.   | Rev  | Serial No.  | RMA No.     | Hw Vrs | Power Consumption |
|------|------------|------|-------------|-------------|--------|-------------------|
| 0    | 34-0829-02 | A000 | APQ0237002Q | 00-00-00-00 | 1.0    | 2746 cA           |

## Gerelateerde informatie

- [Opdrachten weergeven](#)
- [Technische ondersteuning en documentatie – Cisco Systems](#)

## Over deze vertaling

Cisco heeft dit document vertaald via een combinatie van machine- en menselijke technologie om onze gebruikers wereldwijd ondersteuningscontent te bieden in hun eigen taal. Houd er rekening mee dat zelfs de beste machinevertaling niet net zo nauwkeurig is als die van een professionele vertaler. Cisco Systems, Inc. is niet aansprakelijk voor de nauwkeurigheid van deze vertalingen en raadt aan altijd het oorspronkelijke Engelstalige document ([link](#)) te raadplegen.